

BLACK SCREEN (NO IMAGE APPEARS ON NAVIGATION AND AUDIO SCREEN)

INSPECTION PROCEDURE

1 CHECK DISPLAY SETTING

(a) Check that the display is not in "Screen OFF" mode.

OK: The display setting is not in "Screen OFF" mode.

NG

CHANGE SCREEN TO "SCREEN ON" MODE

OK

2 CHECK IMAGE QUALITY SETTING

(a) Check if screen color quality can be set.

OK: Screen color quality can be set.

OK

PRESS PANEL SWITCH "DISPLAY" AND SET SCREEN COLOR QUALITY TO NORMAL

NG

3 CHECK CABIN

(a) Check if condensation is likely to occur, or the temperature is high or low (extremely cold) in the cabin.

HINT:

This problem occurs when the cabin is humid and the temperature rapidly changes. This condition may produce condensation, resulting in a short circuit.

OK: The above conditions are not observed.

NG

SET CABIN TEMPERATURE TO APPROPRIATE DEGREES (20 TO 30°C) (68 TO 86°F)

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-1094)