


DTC	P0500/42	VEHICLE SPEED SENSOR MALFUNCTION
-----	----------	----------------------------------


CIRCUIT DESCRIPTION

The vehicle speed sensor outputs a 4-pulse signal for every revolution of the rotor shaft, which is rotated by the transmission output shaft via the driven gear. After this signal is converted into a more precise rectangular waveform by the waveform shaping circuit inside the combination meter, it is then transmitted to the Engine ECU. The Engine ECU determines the vehicle speed based on the frequency of these pulse signals.



DTC No.	DTC Detecting Condition	Trouble Area
P0500/42	No vehicle speed sensor signal to ECM under following condition: (2 trip detection logic) (a) Vehicle is being driven (b) Clutch or brake slips or gear is broken (2-trip detection logic)	<ul style="list-style-type: none"><li>• Combination meter</li><li>• Open or short in vehicle speed sensor circuit</li><li>• Vehicle speed sensor</li><li>• ECM</li></ul>

WIRING DIAGRAM



\*1:LHD  
\*2:RHD

## INSPECTION PROCEDURE

### HINT:

Read freeze frame data using the hand-held tester, as freeze frame data records the engine conditions when the malfunction is detected. When troubleshooting, it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.

### When using hand-held tester:

#### 1 CHECK OPERATION OF SPEED METER

- (a) Drive the vehicle and check if the operation of the speedometer in the combination meter is normal.

### HINT:


The vehicle speed sensor is operating normally if the speedometer display is normal.

NG

CHECK SPEED METER CIRCUIT


OK

#### 2 INSPECT ECM(CHECK VOLTAGE)



- (a) Shift the lever to the neutral position.
- (b) Jack up the vehicle.
- (c) Turn the ignition switch ON.
- (d) Measure the voltage between terminal SPD of the ECM connector and E2 of the ECM connector with turning the wheel slowly.

**Voltage: Generated intermittently**



NG

REPAIR OR REPLACE WIRE HARNESS OR CONNECTOR

OK

#### CHECK AND REPLACE ECM

## When not using hand-held tester:

### 1 CHECK OPERATION OF SPEED METER

(a) Drive the vehicle and check if the operation of the speedometer in the combination meter is normal.

HINT:


The vehicle speed sensor is operating normally if the speedometer display is normal.

NG

CHECK SPEED METER CIRCUIT

OK

### 2 INSPECT ECM



(a) Check continuity between the terminals SPD and E2 of the ECM connector.


**Resistance: No continuity**

NG

REPAIR OR REPLACE WIRE HARNESS OR CONNECTOR

OK

### 3 INSPECT ECM(CHECK VOLTAGE)



(a) Turn the ignition switch ON.  
(b) Measure the voltage between terminals SPD of the ECM E6 connector and E2 of the ECM connector.

**Voltage: 0 - 5 V**

NG

CHECK AND REPLACE ECM

OK

CHECK WIRE HARNESS OR CONNECTOR