


DTC	C1210 / 36	Zero Point Calibration of Yaw Rate Sensor Undone
------------	-------------------	---

CIRCUIT DESCRIPTION


DTC No.	DTC Detecting Condition	Trouble Area
C1210 / 36	When either the condition 1. or 2. is detected: 1. After battery terminal was connected, ECU terminal IG1 is turned ON for the first time. Within 15 sec. the shift lever is moved to any position except P range. 2. When the yaw rate sensor zero point recorded in ECU is deleted.	<ul style="list-style-type: none"> • Yaw rate sensor • Yaw rate sensor circuit • PNP switch circuit (P range)

WIRING DIAGRAM



INSPECTION PROCEDURE

- | | |
|---|---|
| 1 | Perform zero point calibration of yaw rate sensor (See page DI-224). |
|---|---|



- | | |
|---|----------------------|
| 2 | Is DTC still output? |
|---|----------------------|


Check DTC on page [DI-224](#) .

NO

No problem.

YES

- | | |
|---|--|
| 3 | Check output value of yaw rate sensor. |
|---|--|



In case of using the hand-held tester:

PREPARATION:

- (a) Remove the 2 bolts and the yaw rate sensor with the connector still connected.
- (b) Connect the hand-held tester to DLC3.
- (c) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (d) Select the DATALIST mode on the hand-held tester.

CHECK:

Check that the yaw rate sensor value of the yaw rate sensor displayed on the hand-held tester is changing: Place the yaw rate sensor vertically to the ground and turn the sensor pivoted on its center.


OK:

Yaw rate value must be changing.

(Reference)

When the yaw rate sensor is stationary:

Output value: ± 4 deg/s



In case of not using the hand-held tester:

PREPARATION:

- (a) Remove the consol box, then the yaw rate sensor with the connector still connected.
- (b) Turn the ignition switch ON.

CHECK:

Measure voltage between terminals YAW2 (1) - GYAW (3), and terminals YD (4) - GYAW (3) of the yaw rate sensor.

OK:

Terminals 1 and 3 (YAW - GYAW)	About 2.42 - 2.58 V
Terminals 4and 3 (YD - GYAW)	About 4.5 - 5.3 V

NG

Replace yaw rate sensor.

OK

4

Check for open and short circuit in harness and connector between yaw rate sensor and skid control ECU (See page [IN-28](#)).

NG

Repair or replace harness or connector.

OK

Check and replace skid control ECU.