



## REPLACEMENT

### 1. REPLACE COMPANION FLANGE DUST DEFLECTOR, IF NECESSARY

- (a) Using SST and a press, remove the dust deflector.  
SST 09950-00020




- (b) Using SST and a press, install a new dust deflector.  
SST 09636-20010




### 2. REPLACE INTERMEDIATE SHAFT NO. 2, IF NECESSARY


- (a) w/ A.D.D.:  
Remove the clutch hub.  
(1) Using a snap ring expander, remove the snap ring.  
(2) Remove the clutch hub from the intermediate shaft No. 2.




- (b) Remove the oil seal.  
Using SST, remove the oil seal from the differential tube.  
SST 09308-00010  
(c) Remove the intermediate shaft No. 2  
(1) Using needle nose pliers, remove the snap ring.  
(2) Remove the shaft from the differential tube.




- (d) Remove the intermediate shaft No. 2 bearing.  
(1) Using a snap ring expander, remove the snap ring.  
(2) Using SST, a brass bar and press, remove the bearing.  
SST 09950-00020



- (e) Install a new intermediate shaft No.2 bearing.
- (1) Using SST and a press, install a new bearing.  
SST 09309-37010
  - (2) Using a snap ring expander, install the snap ring.
- (f) Install the intermediate shaft No.2
- (1) Install the shaft into the differential tube.
  - (2) Using needle nose pliers, install the snap ring.



- (g) Install a new oil seal.
- (1) Using SST, install a new oil seal.  
SST 09223-15020  
**Oil seal drive in depth: 5.5 mm (0.217 in.)**
  - (2) Coat the oil seal lip with MP grease.



- (h) w/ A.D.D.:  
Install the clutch hub.
- (1) Install the clutch hub to the intermediate shaft No.2.
  - (2) Using snap ring pliers, install the snap ring.