



## INSPECTION

### INSPECT BALL JOINT FOR ROTATION CONDITION

- (a) As shown, flip the ball joint stud back and forth 5 times, before installing the nut.
- (b) Using a torque wrench, turn the stud continuously one turn each 2 - 4 seconds and take the torque reading on the 5th turn.

#### Turning torque:

**0.05 - 2.0 N·m (0.5 - 20 kgf·cm, 0.4 - 17 in.-lbf)**