



INSPECTION

INSPECT BALL JOINT FOR ROTATION CONDITION

- As shown, flip the ball joint stud back and forth 5 times, before installing the nut.
- Using a torque wrench, turn the nut continuously one turn each 2 - 4 seconds and take the torque reading on the 5th turn.

Turning torque:

0.7 - 4.4 N·m (7 - 45 kgf·cm, 6 - 39 in.-lbf)