









SYSTEM OUTLINE

The engine control system utilize a microcomputer and maintains overall control of the engine, transmission, etc. An outline of engine control is given here.

1. INPUT SIGNAL

(1) Engine coolant temp. signal system

The engine coolant temp. sensor detects the engine coolant temp. and has a built-in thermistor with a resistance which varies according to the engine coolant temp. The engine coolant temp. is input as a control signal to TERMINAL THW of the engine control module.

(2) Heated oxygen sensor signal system

The oxygen density in the exhaust emissions is detected and input as a control signal to TERMINAL OXB2 of the engine control module. To maintain stable detection performance by the heated oxygen sensor, the heated oxygen sensors are warmed. The heater is also controlled by the engine control module (HT2B).

(3) RPM signal system

Camshaft position and crankshaft position are detected by the camshaft position sensor and crankshaft position sensor, camshaft position is input as a control signal to TERMINAL G2 of the engine control module, and engine RPM is input to TERMINAL NE+.

(4) Throttle signal system

The throttle position sensor detects the throttle valve opening angle, which is input as a control signal to TERMINALS VTA and VTA2 of the engine control module.

(5) Vehicle speed signal system

The vehicle speed sensor, detects the vehicle speed and input to ABS speed sensor of the VSC ECU, from VSC ECU to TERMINAL SP1 of the engine control module, via combination meter.

(6) A/C SW signal system

The operating voltage of the A/C magnetic clutch is detected and input as a control signal to TERMINAL AC1 of the engine control module.

(7) Battery signal system

Voltage is constantly applied to TERMINAL BATT of the engine control module. When the ignition SW is turned to on, voltage for engine control module operation is applied via the EFI relay to TERMINAL +B of the engine control module.

(8) Intake air volume signal system

Intake air volume is detected by the mass air flow meter and a signal is input into TERMINAL VG of the engine control module as a control signal.

(9) Stop light SW signal system

The stop light SW is used to detect whether or not the vehicle is braking and the information is input as a control signal to TERMINAL STP of the engine control module.

(10) Starter signal system

To confirm that the engine is cranking, the voltage applied to the starter motor during cranking is detected and is input as a control signal to TERMINAL STA of the engine control module.

(11) Engine knock signal system

Engine knocking is detected by the knock sensor no. 1 and no. 2 and the signals are input to TERMINALS KNK1 and KNK2 of the engine control module.

(12) 4WD signal system (4WD)

Whether or not the vehicle is operating in 4WD mode is determined, and a control signal is input to TERMINAL 4WD of the engine control module.

(13) Intake air temp. signal circuit

The intake air temp. sensor is installed in the mass air flow meter and detects the intake air temp., which is input as a control signal into TERMINAL THA of the engine control module.

(14) Air fuel ratio signal system

The air fuel ratio is detected and input as a control signal into TERMINAL AF1+ of the engine control module.

2. CONTROL SYSTEM

* SFI system

The SFI system monitors the engine conditions through the signals each sensor inputs to the engine control module. Based on this data and the program memorized in the engine control module, the most appropriate fuel injection timing is detected and current is output to TERMINALS #10, #20, #30, #40, #50 AND #60 of the engine control module, causing the injectors to operate (to inject fuel). It is this system which, through the work of the engine control module, finely controls fuel injection in response to driving conditions.

* ESA system

The ESA system monitors the engine conditions using the signals input to the engine control module from each sensor. Based on this data and the program memorized in the engine control module, the most appropriate ignition timing is decided and current is output to TERMINALS IGT1, IGT2 and IGT3 of the engine control module. This output controls the igniter to produce the most appropriate ignition timing for the driving conditions.

* Heated oxygen sensor heater control system

The heated oxygen sensor heater control system turns the heater to on when the intake air volume is low (Temp. of exhaust emissions is low). And warms up the heated oxygen sensors to improve detection performance of the sensors. The engine control module evaluates the signals from each sensor current is output to TERMINAL HT2B and controls the heater.

3. DIAGNOSIS SYSTEM

With the diagnosis system, when there is a malfunction in the ECU signal system, the malfunctioning system is recorded in the memory. The malfunctioning system can then be found by reading the display (Code) of the malfunction indicator lamp.

4. FAIL- SAFE SYSTEM

When a malfunction occurs in any system, if there is a possibility of engine being caused by continued control based on the signals from that system, the fail-safe system either controls the system by using data (Standard values) recorded in the engine control module memory or else stops the engine.

SERVICE HINTS

EFI RELAY

5-3 : Closed with ignition SW at **ON** or **ST** position

C6 CIRCUIT OPENING RELAY

5-3 : Closed with starter running or ignition SW at **ON** position

I6, I7, I8, I9, I10, I11 INJECTOR

1-2 : **13.4- 14.2** Ω

E3 ENGINE COOLANT TEMP. SENSOR

1-2 : **10- 20** k Ω (**-20** °C, **-4** °F)

4- 7 k Ω (**0** °C, **32** °F)

2- 3 k Ω (**20** °C, **68** °F)

0.9- 1.3 k Ω (**40** °C, **104** °F)

0.4- 0.7 k Ω (**60** °C, **140** °F)

0.2- 0.4 k Ω (**80** °C, **176** °F)

E9 (A), E10 (B), E11 (C), E12 (D), E14 (E) ENGINE CONTROL MODULE

Voltage at engine control module wiring connectors

+B-E1 : **9- 14** volts (Ignition SW on)

BATT-E1 : **9- 14** volts (Always)

VC-E2 : **4.5- 5.5** volts (Ignition SW on)

VTA-E2 : Approx. **0.6** volts (Ignition SW on and throttle valve fully closed)

Approx. **4** volts (ignition SW on and throttle valve fully open)

STA-E1 : **6** volts or more (Ignition SW at **ST** position)

W-E1 : **9- 14** volts (No trouble and engine running)

THW-E1 : **0.2- 1.0** volts (Ignition SW on and coolant temp. **80** °C, **176** °F)

SP1-E1 : Pulse generation with vehicle moving

STP-E1 : **7.5- 14** volts (Stop light SW on)

IGT1, IGT2, IGT3-E1 : Pulse generation (Cranking or idling)

#10, #20, #30, #40, #50, #60-E1 : **9- 14** volts (Ignition SW on)

RESISTANCE AT ECU WIRING CONNECTOR

(Disconnect wiring connector)

THW-E2 : **0.2- 0.4** k Ω (Coolant temp. **80** °C, **176** °F)

NE+-E2 : **140- 180** Ω

: PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page
A12	A	30	H4		28	J8	B	31
A27		28	I2		29	J9		31
A30	B	30	I3		29	K2		29
A38		28	I4		29	K3		29
C1		28	I5		29	M1		29
C2		28	I6		29	P1		29
C6		30	I7		29	P22		29
C29		30	I8		29	S4		31
D1		28	I9		29	T2		29
D7		30	I10		29	T6		31
E3		28	I11		29	T7		29
E9	A	31	I14		31	V1		33
E10	B	31	J1	A	29	V7		29
E11	C	31	J2	B	29	V8		33
E12	D	31	J4		31	V13		29
E14	E	31	J6		31	V19		31
F10		32	J7	A	31			

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	22	Engine Room R/B (Engine Compartment Left)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	24	Cowl Wire and Driver Side J/B (Lower Finish Panel)
1I	24	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
1J	24	Cowl Wire and Driver Side J/B (Lower Finish Panel)
3C	26	Cowl Wire and Center J/B (Near the Steering Column Tube)
3E		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB1	36	Sensor Wire and Engine Wire (Front Side of Cylinder Head Cover Right)
EC1	36	Engine Wire and Water Temp. Sensor Wire (Front Side of Cylinder Head Cover Right)
IE1	38	Cowl Wire and Floor No.2 Wire (Left Kick Panel)
IE3		
IG1	38	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
II1	40	Engine Wire and Cowl Wire (On the Glove Box)
II4		
BN2	42	Frame Wire and Floor No.2 Wire (Under the Left Side of Rear Seat Cushion)
BZ1	42	Frame Wire and Frame No.2 Wire (Upper the Rear Axle Housing Left)

: GROUND POINTS

Code	See Page	Ground Points Location
EB	36	Front Left Fender
EC	36	Intake Manifold Left
IE	38	Cowl Side Panel LH
IF	38	Cowl Side Panel RH
BH	42	Left Quarter Panel Inner

ENGINE CONTROL



: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	36	Engine Wire	I12	40	Cowl Wire
E4	36	Sensor Wire	I20	40	Engine Wire

