


DTC	C1231/31	MALFUNCTION IN STEERING ANGLE SENSOR CIRCUIT
------------	-----------------	---

CIRCUIT DESCRIPTION

The skid control ECU inputs the steering sensor signal through the CAN communication. When a malfunction occurs in the communication line with the steering sensor, DTC U0126/63 (malfunction in communication with steering angle sensor) is output.

DTC No.	DTC Detecting Condition	Trouble Area
C1231/31	<ul style="list-style-type: none">Steering angle sensor malfunction signal is received when data transmission is valid (internal malfunction is detected at sensor self-check).A signal of +B open in steering angle sensor is received when communication with sensor is valid.	<ul style="list-style-type: none">Steering angle sensorSkid control ECU

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

- When U0126 is output together with C1231/31, inspect and repair the trouble areas indicated by U0126/63 first.
- When the speed sensor or the yaw rate (deceleration) sensor has trouble, DTCs for the steering angle sensor may be output even when the steering angle sensor is normal. When DTCs for the speed sensor or yaw rate sensor are output together with other DTCs for the steering angle sensor, inspect and repair the speed sensor and yaw rate (deceleration) sensor first, and then inspect and repair the steering angle sensor.

1 CHECK HARNESS AND CONNECTOR(MOMENTARY INTERRUPTION)

- (a) Using the hand-held tester, check for any momentary interruption in the wire harness and connectors between the skid control ECU and steering angle sensor (see page 05-954).

Item	Measurement Item / Range (Display)	Normal Condition
STEERING SEN	Steering sensor open detection	NORMAL : Normal condition

OK:

There are no momentary interruptions.

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

2 READ VALUE OF HAND-HELD TESTER

- (a) Connect the hand-held tester to the DLC3.
 (b) Turn the power switch ON (READY).
 (c) Select the DATA LIST mode on the hand-held tester.

Item	Measurement Item / Range (Display)	Normal Condition
STEERING ANG	Steering sensor/ Min.: -1152 deg, Max.: 1150.875 deg	Left turn: Increase Right turn: Decrease

- (d) Check that the steering angle sensor value of the steering angle sensor observed in the hand-held tester changes when the steering wheel is moved.

OK:

Steering angle value should change.

NG

Go to step 3

OK


REPLACE SKID CONTROL ECU ASSY (SEE PAGE 32-68)

NOTICE:

When replacing the skid control ECU assy, perform initialization of linear solenoid valve and calibration (see page 05-956).

3 CHECK TERMINAL VOLTAGE(STEERING ANGLE SENSOR CONNECTOR)

Steering Angle Sensor
(harness side connector)



- (a) Remove the steering wheel and the column lower cover.
- (b) Disconnect the steering angle sensor connector.
- (c) Turn the power switch ON (READY).
- (d) Measure the voltage according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
S13-1 (IG) - S13-2 (ESS)	10 to 14 V

- (e) Measure the voltage according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
S13-3 (BAT) - S13-2 (ESS)	10 to 14 V

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE STEERING ANGLE SENSOR (SEE PAGE 32-71)