

<b>DTC</b>	<b>P0351</b>	<b>IGNITION COIL "A" PRIMARY/SECONDARY CIRCUIT</b>
------------	--------------	--

<b>DTC</b>	<b>P0352</b>	<b>IGNITION COIL "B" PRIMARY/SECONDARY CIRCUIT</b>
------------	--------------	--

<b>DTC</b>	<b>P0353</b>	<b>IGNITION COIL "C" PRIMARY/SECONDARY CIRCUIT</b>
------------	--------------	--

<b>DTC</b>	<b>P0354</b>	<b>IGNITION COIL "D" PRIMARY/SECONDARY CIRCUIT</b>
------------	--------------	--

## CIRCUIT DESCRIPTION


### HINT:

- These DTCs indicate malfunction related to the primary circuit.
- If DTC P0351 is displayed, check the ignition coil No.1 (#1) circuit.
- If DTC P0352 is displayed, check the ignition coil No.1 (#2) circuit.
- If DTC P0353 is displayed, check the ignition coil No.1 (#3) circuit.
- If DTC P0354 is displayed, check the ignition coil No.1 (#4) circuit.


A Direct Ignition System (DIS) is used on this vehicle.

The DIS is a 1-cylinder ignition system which ignites one cylinder with one ignition coil. In the 1-cylinder ignition system, the one spark plug is connected to the end of the secondary winding. High voltage generated in the secondary winding is applied directly to the spark plug. The spark of the spark plug passes from the center electrode to the ground electrode.

The ECM determines the ignition timing and outputs the ignition (IGT) signals for each cylinder. Using the IGT signal, the ECM turns ON and OFF the power transistor inside the igniter and this switches ON and OFF the current to the primary coil. When the current flow to the primary coil is cut off, high-voltage is generated in the secondary coil and this voltage is applied to the spark plugs to spark inside the cylinders. As the ECM cuts the current to the primary coil, the igniter sends back the ignition confirmation (IGF) signal to the ECM.




DTC No.	DTC Detection Condition	Trouble Area
P0351 P0352 P0353 P0354	No IGF signal to ECM while engine is running	<ul style="list-style-type: none"><li>• Ignition system</li><li>• Open or short in IGF or IGT circuit from ignition coil with igniter to ECM (ignition coil circuit 1 through 4)</li><li>• Ignition coil with igniter (ignition coil circuit 1 through 4)</li><li>• ECM</li></ul>



Reference: Inspection using an oscilloscope.  
HINT:  
The correct waveform is as shown on the left.

Item	Contents
Terminal	CH1: IGT1, IGT2, IGT3, IGT4 - E1 CH2: IGF - E1
Equipment Setting	2 V/Division, 20 ms/Division
Condition	While the engine is cranking or idling

## MONITOR DESCRIPTION



If the ECM does not receive the ignition confirmation (IGF) signal after sending the ignition (IGT) signal, the ECM interprets this as a fault in the igniter and sets a DTC.

## MONITOR STRATEGY

Related DTCs	P0351: Ignition coil with igniter circuit (#1) malfunction P0352: Ignition coil with igniter circuit (#2) malfunction P0353: Ignition coil with igniter circuit (#3) malfunction P0354: Ignition coil with igniter circuit (#4) malfunction
Required sensors/components	Igniter
Frequency of operation	Continuous
Duration	0.256 second
MIL operation	Immediately
Sequence of operation	None

## TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not present	See page <a href="#">05-20</a>
Engine speed	1,500 rpm or less
Either of the following conditions is met:	(a) or (b)
(a) Following conditions are met:	1 & 2
1. Engine speed	500 rpm or less
2. Battery voltage	6 V or more
(b) Following conditions are met:	1 & 2
1. Engine speed	More than 500 rpm
2. Battery voltage	10 V or more

## TYPICAL MALFUNCTION THRESHOLDS


Ignition signal fail count*	More than 2 times
-----------------------------	-------------------

\*: Counted when the IGF signal is not returned to the ECM despite sending the IGT signal.

## COMPONENT OPERATING RANGE

Number of IGF signals	Equals the number of IGT signals
-----------------------	----------------------------------

## WIRING DIAGRAM



Y

A94238



## INSPECTION PROCEDURE

### HINT:

Read freeze frame data using the hand-held tester or the OBD II scan tool. Freeze frame data records the engine condition when malfunction is detected. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, if the air-fuel ratio was lean or rich, and other data from the time the malfunction occurred.

### 1 CHECK SPARK PLUG AND SPARK OF MISFIRING CYLINDER (See page 18-3)


OK: Spark occurs.

NG

Go to step 4

OK

### 2 CHECK HARNESS AND CONNECTOR(IGNITION COIL NO.1 - ECM (IGF SIGNAL TERMINAL))



- Disconnect the I1, I2, I3 or I4 ignition coil and igniter connector.
- Disconnect the E4 ECM connector.
- Check the resistance between the wire harness side connectors.

#### Standard (Check for open):

Tester Connection	Specified Condition
IGF (I1-2) - IGF (E4-23)	Below 1 $\Omega$
IGF (I2-2) - IGF (E4-23)	Below 1 $\Omega$
IGF (I3-2) - IGF (E4-23)	Below 1 $\Omega$
IGF (I4-2) - IGF (E4-23)	Below 1 $\Omega$

#### Standard (Check for short):


Tester Connection	Specified Condition
IGF (I1-2) or IGF (E4-23) - Body ground	10 k $\Omega$ or higher
IGF (I2-2) or IGF (E4-23) - Body ground	10 k $\Omega$ or higher
IGF (I3-2) or IGF (E4-23) - Body ground	10 k $\Omega$ or higher
IGF (I4-2) or IGF (E4-23) - Body ground	10 k $\Omega$ or higher

- Reconnect the ignition coil and igniter connector.
- Reconnect the ECM connector.


NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK



### 3 INSPECT ECM(IGF VOLTAGE)



- Disconnect the I1, I2, I3 or I4 ignition coil and igniter connector.
- Turn the power switch ON (IG).
- Measure the voltage between the specified terminals of the E4 and E5 ECM connectors.

#### Standard:

Tester Connection	Specified Condition
IGF (E4-23) - E1 (E5-28)	4.5 to 5.5 V

- Reconnect the ignition coil and igniter connector.


**NG**

**REPLACE ECM (See page 10-24 )**

**OK**

### REPLACE IGNITION COIL NO.1

### 4 CHECK HARNESS AND CONNECTOR(IGNITION COIL NO.1 - ECM (IGT SIGNAL TERMINAL))



- Disconnect the I1, I2, I3 or I4 ignition coil and igniter connector.
- Disconnect the E4 ECM connector.
- Check the resistance between the wire harness side connectors.

#### Standard (Check for open):

Tester Connection	Specified Condition
IGT (I1-3) - IGT1 (E4-8)	Below 1 $\Omega$
IGT (I2-3) - IGT2 (E4-9)	Below 1 $\Omega$
IGT (I3-3) - IGT3 (E4-10)	Below 1 $\Omega$
IGT (I4-3) - IGT4 (E4-11)	Below 1 $\Omega$

#### Standard (Check for short):


Tester Connection	Specified Condition
IGT (I1-3) or IGT1 (E4-8) - Body ground	10 k $\Omega$ or higher
IGT (I2-3) or IGT2 (E4-9) - Body ground	10 k $\Omega$ or higher
IGT (I3-3) or IGT3 (E4-10) - Body ground	10 k $\Omega$ or higher
IGT (I4-3) or IGT4 (E4-11) - Body ground	10 k $\Omega$ or higher


- Reconnect the ignition coil and igniter connector.
- Reconnect the ECM connector.

**NG**

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**




**5 INSPECT ECM(IGT1, IGT2, IGT3 OR IGT4 VOLTAGE)**

- (a) Measure the voltage between the applicable terminals of the E4 and E5 ECM connectors when the engine is cranked.

**Standard:**

Tester Connection	Specified Condition
IGT1 (E4-8) - E1 (E5-28)	Between 0.1 V and 4.5 V
IGT2 (E4-9) - E1 (E5-28)	Between 0.1 V and 4.5 V
IGT3 (E4-10) - E1 (E5-28)	Between 0.1 V and 4.5 V
IGT4 (E4-11) - E1 (E5-28)	Between 0.1 V and 4.5 V

**NG****REPLACE ECM (See page 10-24 )****OK****6 INSPECT ECM(IGT1, IGT2, IGT3 OR IGT4 VOLTAGE)**

- (a) Disconnect the I1, I2, I3 or I4 ignition coil and igniter connector.
- (b) Measure the voltage between the applicable terminals of the E4 and E5 ECM connectors when the engine is cranked.

**Standard:**

Tester Connection	Specified Condition
IGT1 (E4-8) - E1 (E5-28)	4.5 V or more
IGT2 (E4-9) - E1 (E5-28)	4.5 V or more
IGT3 (E4-10) - E1 (E5-28)	4.5 V or more
IGT4 (E4-11) - E1 (E5-28)	4.5 V or more


- (c) Reconnect the ignition coil and igniter connector.

**NG****REPLACE ECM (See page 10-24 )****OK**

## 7 INSPECT IGNITION COIL NO.1(POWER SOURCE)

### Wire Harness Side:

Ignition Coil and Igniter Connector



- Disconnect the I1, I2, I3 or I4 ignition coil and igniter connector.
- Turn the power switch ON (IG).
- Measure the voltage between the terminal of the wire harness side connector and body ground.

### Standard:

Tester Connection	Specified Condition
+B (I1-1) - GND (I1-4)	9 to 14 V
+B (I2-1) - GND (I2-4)	9 to 14 V
+B (I3-1) - GND (I3-4)	9 to 14 V
+B (I4-1) - GND (I4-4)	9 to 14 V

- Reconnect the ignition coil and igniter connector.

OK


REPLACE IGNITION COIL NO.1

NG

## 8 CHECK HARNESS AND CONNECTOR(IGNITION COIL NO.1 - IG2 RELAY)

### Wire Harness Side:

Ignition Coil and Igniter Connector



- Disconnect the I1, I2, I3 or I4 ignition coil and igniter connector.
- Remove the integration relay from engine room R/B.
- Check the resistance between the wire harness side connectors.

### Standard (Check for open):

Tester Connection	Specified Condition
+B (I1-1) - IG2 relay(3I-4)	Below 1 $\Omega$
+B (I2-1) - IG2 relay(3I-4)	Below 1 $\Omega$
+B (I3-1) - IG2 relay(3I-4)	Below 1 $\Omega$
+B (I4-1) - IG2 relay(3I-4)	Below 1 $\Omega$
GND (I1-4) - (Body ground)	Below 1 $\Omega$
GND (I2-4) - (Body ground)	Below 1 $\Omega$
GND (I3-4) - (Body ground)	Below 1 $\Omega$
GND (I4-4) - (Body ground)	Below 1 $\Omega$

### Standard (Check for short):

Tester Connection	Specified Condition
+B (I1-1) or IG2 relay(3I-4) - Body ground	10 k $\Omega$ or higher
+B (I2-1) or IG2 relay(3I-4) - Body ground	10 k $\Omega$ or higher
+B (I3-1) or IG2 relay(3I-4) - Body ground	10 k $\Omega$ or higher
+B (I4-1) or IG2 relay(3I-4) - Body ground	10 k $\Omega$ or higher

- Reconnect the ignition coil and igniter connector.
- Reinstall the integration relay.

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE IGNITION COIL NO.1