

FOREWORD

To assist you in your service activities, this manual explains the main characteristics of the new SEQUOIA in particular providing a technical explanation of the construction and operation of new mechanism and new technology used.

Applicable models: UCK60, 65, USK60, 65 series

This manual is divided into 3 sections.

- 1. New Model Outline** – Explanation of the product to give a general understanding of its features.
- 2. Technical Description** – Technical explanation of the construction and operation of each new system and component.
- 3. Appendix** – Major technical specifications of the vehicle.

CAUTION, **NOTICE**, **REFERENCE** and **NOTE** are used in the following ways:

CAUTION	A potentially hazardous situation which could result in injury if instructions are ignored.
NOTICE	Damage to the vehicle or components may occur if instructions are ignored.
REFERENCE	Explains the theory behind mechanisms and techniques.
NOTE	Notes or comments not included under the above 3 titles.

For detailed service specifications and repair procedures, refer to the following Repair Manuals:

Manual Name	Pub. No.
● 2008 SEQUOIA Repair Manual	RM08L0U
● 2008 SEQUOIA Electrical Wiring Diagram	EM08L0U

All information contained herein is the most up-to-date at the time of publication. We reserve the right to make changes without prior notice.

TOYOTA MOTOR CORPORATION