

EK25BMH

SERVICE MANUAL

290404

69T-28197-ZA-11

NOTICE

This manual has been prepared by Yamaha primarily for use by Yamaha dealers and their trained mechanics when performing maintenance procedures and repairs to Yamaha equipment. It has been written to suit the needs of persons who have a basic understanding of the mechanical and electrical concepts and procedures inherent in the work, for without such knowledge attempted repairs or service to the equipment could render it unsafe or unfit for use.

Because Yamaha has a policy of continuously improving its products, models may differ in detail from the descriptions and illustrations given in this publication. Use only the latest edition of this manual. Authorized Yamaha dealers are notified periodically of modifications and significant changes in specifications and procedures, and these are incorporated in successive editions of this manual.

EK25BMH

SERVICE MANUAL

©2000 Yamaha Motor Co., Ltd.

1st Edition, October 2000

All rights reserved. Any reprinting or unauthorized use without the written permission of Yamaha Motor Co., Ltd. is expressly prohibited.

Printed in Japan

HOW TO USE THIS MANUAL

MANUAL FORMAT

All of the procedures in this manual are organised in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspection operations.

In this revised format, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol, e.g.,

- Bearings
Pitting/scratches → Replace.

To assist you in finding your way through this manual, the section title and major heading is given at the top of every page.

MODEL INDICATION

Multiple models are referred to in this manual and their model indications are noted as follows.

Model name	EK25BMH
Indication	EK25BMH

ILLUSTRATIONS


The illustrations within this service manual represent all of the designated models.

CROSS REFERENCES

The cross references have been kept to a minimum. Cross references will direct you to the appropriate section or chapter.

IMPORTANT INFORMATION

In this Service Manual particularly important information is distinguished in the following ways.

 The safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

WARNING

Failure to follow **WARNING** instructions could result in severe injury or death to the machine operator, a bystander or a person inspecting or repairing the outboard motor.

CAUTION:

A **CAUTION** indicates special precautions that must be taken to avoid damage to the outboard motor.

NOTE:


A **NOTE** provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

- ① The main points regarding removing/installing and disassembling/assembling procedures are shown in the exploded views.
- ② The numbers in the exploded views indicate the required sequence of the procedure and should be observed accordingly.
- ③ Symbols are used in the exploded views to indicate important aspects of the procedure. A list of meanings for these symbols is provided on the following page.
- ④ It is important to refer to the job instruction charts at the same time as the exploded views. These charts list the sequence that the procedures should be carried out in, as well as providing explanations on part names, quantities, dimensions and important points relating to each relevant task.
- ⑤ In addition to tightening torques, the dimensions of the bolts and screws are also mentioned.

Example:

Bolt and screw size 10 × 25 mm : bolt and screw diameter (D) × length (L)



- ⑥ In addition to the exploded views and job instruction charts, this manual provides individual illustrations when further explanations are required to explain the relevant procedure.

LOWR **LOWER UNIT**

LOWER UNIT
REMOVING THE LOWER UNIT

①

②

③

⑤

Step	Job/Part	Q'ty	Remarks
1	Split pin	1	Not reusable
2	Castle nut	1	
3	Washer	1	
4	Spacer	1	
5	Propeller	1	
6	Spacer	1	
7	Nut	1	
8	Shift connector	1	
9	Bolt (with washer)	1	
10	Trim tab	1	
11	Bolt	1	
12	Anode	1	
13	Screw	2	

Continued on next page.

②

LOWR **PROPELLER SHAFT HOUSING**

REMOVING THE PROPELLER SHAFT HOUSING

⑥

②

REMOVING THE PROPELLER SHAFT HOUSING

Remove:

- Propeller shaft housing

	Bearing housing puller claw.....①	90890-06548
	Stopper guide plate.....②	90890-06501
	Center bolt.....③	90890-06504

DISASSEMBLING THE PROPELLER SHAFT HOUSING

1. Remove:

- Reverse gear



























	Bearing separator.....①	90890-06534
	Stopper guide plate.....②	90890-06501
	Stopper guide stand.....③	90890-06538
	Bearing puller ass'y.....④	90890-06535

2. Remove:

- Ball bearing

	Stopper guide plate.....①	90890-06501
	Stopper guide stand.....②	90890-06538
	Bearing puller ass'y.....③	90890-06535

⑥

① GEN INFO 	② SPEC 
③ CHK ADJ 	④ FUEL 
⑤ POWR 	⑥ LOWR 
⑦ BRKT 	⑧ ELEC 
⑨ TRBL ANLS 	⑩ 
⑪ 	⑫ 
⑬ 	⑭ 
⑮ 	⑯ 
⑰ 	⑱ 
⑲ 	⑳ 
㉑ 	㉒ 
㉓ 	㉔ 
㉕ 	㉖ 

SYMBOLS

Symbols ① to ⑨ are designed as thumb-tabs to indicate the content of a chapter.

- ① General information
- ② Specifications
- ③ Periodic check and adjustments
- ④ Fuel system
- ⑤ Power unit
- ⑥ Lower unit
- ⑦ Bracket unit
- ⑧ Electrical systems
- ⑨ Trouble analysis

Symbols ⑩ to ⑮ indicate specific data.

- ⑩ Special tool
- ⑪ Specified liquid
- ⑫ Specified engine speed
- ⑬ Specified torque
- ⑭ Specified measurement
- ⑮ Specified electrical value
[Resistance (Ω), Voltage (V), Electric current (A)]










Symbol ⑯ to ⑳ in an exploded diagram indicate the grade of lubricant and the location of the lubrication point.

- ⑯ Apply Yamaha 2-stroke motor oil
- ⑰ Apply water resistant grease (Yamaha grease A, Yamaha marine grease)
- ⑱ Apply water resistant grease (Yamaha grease C, Yamaha marine grease)
- ⑲ Apply water resistant grease (Yamaha grease D, Yamaha marine grease)
- ⑳ Apply molybdenum disulfide grease

Symbols ㉑ to ㉖ in an exploded diagram indicate the grade of the sealing or locking agent and the location of the application point.

- ㉑ Apply Gasket Maker[®]
- ㉒ Apply Yamabond #4 (Yamaha bond number 4)
- ㉓ Apply LOCTITE[®] No.271 (Red LOCTITE)
- ㉔ Apply LOCTITE[®] No.242 (Blue LOCTITE)
- ㉕ Apply LOCTITE[®] No.572
- ㉖ Apply silicon sealant

CONTENTS



GENERAL INFORMATION	 GEN INFO	1
SPECIFICATIONS	 SPEC	2
PERIODIC CHECK AND ADJUSTMENT	 CHK ADJ	3
FUEL SYSTEM	 FUEL	4
RECOIL STARTER	 POWR	5
LOWER UNIT	 LOWR	6
BRACKET UNIT	 BRKT	7
ELECTRICAL SYSTEM	 ELEC	8
TROUBLE ANALYSIS	 TRBL ANLS	9

CHAPTER 1

GENERAL INFORMATION



IDENTIFICATION	1-1
SERIAL NUMBER	1-1
STARTING SERIAL NUMBERS	1-1
SAFETY WHILE WORKING	1-2
FIRE PREVENTION	1-2
VENTILATION	1-2
SELF-PROTECTION	1-2
OILS, GREASES AND SEALING FLUIDS	1-2
GOOD WORKING PRACTICES	1-3
DISASSEMBLY AND ASSEMBLY	1-4
SPECIAL TOOLS	1-5
MEASURING	1-5
REMOVING AND INSTALLING	1-7
FEATURES AND BENEFITS	1-9
POWER UNIT	1-9
IGNITION SYSTEM	1-10
COOLING SYSTEM	1-11
TILLER HANDLE	1-13
BRACKET AND BOTTOM COWLING	1-14



IDENTIFICATION

SERIAL NUMBER

The outboard motor's serial number is stamped on a label which is attached to the port clamp bracket.

NOTE:

As an antitheft measure, a special label on which the outboard motor's serial number is stamped is bonded to the port clamp bracket. The label is specially treated so that peeling it off causes cracks across the serial number.

- ① Model name
- ② Approval model code
- ③ Transom height
- ④ Serial number

STARTING SERIAL NUMBERS


The starting serial number blocks are as follows:

Model name	Approval model code	Starting serial number
Worldwide		
EK25BMH	62C	S:100101
		L:400101
		Y:750101




SAFETY WHILE WORKING

The procedures given in this manual are those recommended by Yamaha to be followed by Yamaha dealers and their mechanics.




FIRE PREVENTION

Gasoline (petrol) is highly flammable. Petroleum vapor is explosive if ignited. Do not smoke while handling gasoline and keep it away from heat, sparks and open flames.



VENTILATION

Petroleum vapor is heavier than air and is deadly if inhaled in large quantities. Engine exhaust gases are harmful to breathe. When test-running an engine indoors, maintain good ventilation.



SELF-PROTECTION

Protect your eyes with suitable safety glasses or safety goggles, when grinding or when doing any operation which may cause particles to fly off. Protect hands and feet by wearing safety gloves or protective shoes if appropriate to the work you are doing.



OILS, GREASES AND SEALING FLUIDS

Use only genuine Yamaha oils, greases and sealing fluids or those recommended by Yamaha.




Under normal conditions or use, there should be no hazards from the use of the lubricants mentioned in this manual, but safety is all-important, and by adopting good safety practices, any risk is minimized. A summary of the most important precautions is as follows:

1. While working, maintain good standards of personal and industrial hygiene.
2. Clothing which has become contaminated with lubricants should be changed as soon as practicable, and laundered before further use.
3. Avoid skin contact with lubricants; do not, for example, place a soiled wiping-rag in your pocket.
4. Hands and any other part of the body which have been in contact with lubricants or lubricant-contaminated clothing, should be thoroughly washed with hot water and soap as soon as practicable.
5. To protect the skin, the application of a suitable barrier cream to the hands before working, is recommended.
6. A supply of clean lint-free cloths should be available for wiping purposes.




GOOD WORKING PRACTICES

1. The right tools
Use the recommended special tools to protect parts from damage. Use the right tool in the right manner - do not improvise.
2. Tightening torque
Follow the tightening torque instructions. When tightening bolts, nuts and screws, tighten the large sizes first, and tighten inner-positioned fixings before outer-positioned ones.




3. Non-reusable items
Always use new gaskets, packings, O-rings, split-pins, circlips, etc., on reassembly.



DISASSEMBLY AND ASSEMBLY

1. Clean parts with compressed air when disassembling.
2. Oil the contact surfaces of moving parts before assembly.




3. After assembly, check that moving parts operate normally.

4. Install bearings with the manufacturer's markings on the side exposed to view, and liberally oil the bearings.
5. When installing oil seals, apply a light coating of water-resistant grease to the outside diameter.




SPECIAL TOOLS

Using the correct special tools recommended by Yamaha, will aid the work and enable accurate assembly and tune-up. Improvising and using improper tools can damage the equipment.




MEASURING

- ① Dial gauge set
P/N. 90890-01252
- ② Crank stand alignment
P/N. 90890-03107
- ③ Pocket tester
P/N. 90890-03112
- ④ Timing light
P/N. 90890-03141
- ⑤ Compression Gauge
P/N. 90890-03160
- ⑥ Peak voltage adaptor
P/N. 90890-03172
- ⑦ Digital circuit tester
P/N. 90890-03174
- ⑧ Ignition tester
P/N. 90890-06754
- ⑨ Vacuum/pressure pump gauge set
P/N. 90890-06756
- ⑩ Digital tachometer
P/N. 90890-06760
- ⑪ Leakage tester
P/N. 90890-06762
- ⑫ Digital caliper
P/N. 90890-06704




- ⑬ Cylinder gauge
P/N. 90890-06759
- ⑭ Outside micrometer
P/N. 90890-03006
P/N. 90890-03008
- ⑮ Inside micrometer
P/N. 90890-03010
- ⑯ Thickness gauge
P/N. 90890-03079
- ⑰ Shimming plate
P/N. 90890-06701
- ⑱ Pinion height gauge
P/N. 90890-06702
- ⑲ Magnet base
P/N. 90890-06705
- ⑳ Backlash indicator
P/N. 90890-06706
- ㉑ Magnet base plate
P/N. 90890-07003



REMOVING AND INSTALLING

- ① Flywheel puller
P/N. 90890-06521
- ② Flywheel holder
P/N. 90890-06522
- ③ Small end bearing installer
P/N. 90890-06527
- ④ Bearing separator
P/N. 90890-06534
- ⑤ Stopper guide plate
P/N. 90890-06501
- ⑥ Bearing housing puller claw
P/N. 90890-06564
- ⑦ Center bolt
P/N. 90890-06504
- ⑧ Drive shaft holder 3
P/N. 90890-06517
- ⑨ Bearing puller ass'y
P/N. 90890-06535
- ⑩ Stopper guide stand
P/N. 90890-06538
- ⑪ Driver rod LL
P/N. 90890-06605
- ⑫ Driver rod LS
P/N. 90890-06606
- ⑬ Driver rod L3
P/N. 90890-06652
- ⑭ Driver rod SL
P/N. 90890-06602
- ⑮ Driver rod SS
P/N. 90890-06604
- ⑯ Bearing depth plate
P/N. 90890-06603
- ⑰ Needle bearing attachment
P/N. 90890-06608
P/N. 90890-06611
P/N. 90890-06615
- ⑱ Ball bearing attachment
P/N. 90890-06633
- ⑲ Bearing inner race attachment
P/N. 90890-06643
P/N. 90890-06644
P/N. 90890-06645
- ⑳ Bearing outer race attachment
P/N. 90890-06622
P/N. 90890-06628



- Crank jig ass'y
P/N. 90890-02421
- ②① Frange
P/N. 90890-02351
- ②② Body
P/N. 90890-02352
- ②③ Bolt
P/N. 90890-02353
- ②④ Washer
P/N. 90890-02354
- ②⑤ Bushing-5 (D25)
P/N. 90890-02359
- ②⑥ Bushing-12 (D35)
P/N. 90890-02366
- ②⑦ Height ring-13 (H57)
P/N. 90890-02379
- ②⑧ Pressure Plate
P/N. 90890-02384
- ②⑨ Press body
P/N. 90890-02385
- ③① Plate A
P/N. 90890-02386
- ③① Plate B
P/N. 90890-02387
- ③② Pressure pin B
P/N. 90890-02390
- ③③ Bearing pressure B
P/N. 90890-02392
- ③④ Bearing pressure C
P/N. 90890-02393
- ③⑤ Support
P/N. 90890-02394
- ③⑥ Spacer B
P/N. 90890-02396
- ③⑦ Bushing-14
P/N. 90890-02419

FEATURES AND BENEFITS

POWER UNIT

The EK25B is designed to provide superior fuel economy, serviceability, and durability. They are based on the previous EK25A with newly designed linkage to control both throttle opening and ignition timing mechanically and simultaneously. Special attention was paid on the crankshaft bearings. Collar is now added to the upper main journal of the crankshaft. Roller bearing is applied for the center bearing. The collar added on the upper main journal contributes to get and better serviceability.




Fig. 1




Fig. 2

IGNITION SYSTEM

Ignition system on the EK25B consists of flywheel magnet, charge coil, pulser coil, CDI unit, and ignition coil.

Similar to the previous EK25A, the engine has the mechanical ignition timing advance system that works by way of the linkage.

Superior fuel economy is attained by the modified ignition timing control arrangement.

Also the system restricts the ignition timing advance to prevent engine kickback when the shift is in neutral.




Fig. 3

COOLING SYSTEM

New structure applied to the cooling system provides additional cooling capacity in the upper casing.

With additional cooling water passage (indicated by \leftarrow), water walls contained in the new upper casing contribute to the reduction of outer surface temperature.




Fig. 4

COOLING SYSTEM




Fig. 5

TILLER HANDLE

For the throttle grip on the steering handle of the EK25B, 100 degrees of opening angle covers all ranges from full-closed to wide-open positions.

Also, new steering handle parts were developed to assume the long use. Inner diameter of the steering handle engagement area, and both inner and outer diameters of steering bracket are increased.

Please note that if the new steering handle is installed on the previous models, Steering handle 2, Steering bracket, Collar, and Washer must be replaced.




Fig. 6




Fig. 7



BRACKET AND BOTTOM COWLING

The Bracket 1 is modified on the EK25B, and newly designed rubber seal is added to provide better sealing ability for the bottom cowling.




Fig. 8

CHAPTER 2 SPECIFICATIONS

GENERAL SPECIFICATIONS 2-1

MAINTENANCE SPECIFICATIONS 2-3

 POWER UNIT 2-3

 LOWER UNIT 2-5

 ELECTRICAL 2-6

 DIMENSIONS 2-8

 DIMENSIONS 2-9

TIGHTENING TORQUES 2-11

 SPECIFIED TORQUES 2-11

 GENERAL TORQUES 2-12





GENERAL SPECIFICATIONS






Item	Worldwide	Unit	Model
			EK25BMH
DIMENSIONS			
Overall length		mm (in)	843 (33.2)
Overall width		mm (in)	399 (15.7)
Overall height			
(S)		mm (in)	1,146 (45.1)
(L)		mm (in)	1,273 (50.1)
(Y)		mm (in)	1,320 (52.0)
Boat transom height			
(S)		mm (in)	381 (15.0)
(L)		mm (in)	508 (20.0)
(Y)		mm (in)	559 (22.0)
WEIGHT			
(S)		kg (lb)	53.0 (116.9)
(L)		kg (lb)	54.5 (120.2)
(Y)		kg (lb)	55.0 (121.3)
PERFORMANCE			
Maximum output (ISO)		kW (hp) @5,000 r/min	18.4 (25.0)
Full throttle operating range		r/min	4,500 - 5,500
Maximum fuel consumption		L (US gal, Imp gal) @5,500 r/min	13.8 (3.6, 3.0) Gasoline / Kerosene
POWER UNIT			
Type			2 stroke
Number of cylinders			2
Displacement		cm ³ (cu. in)	496 (30.3)
Bore and stroke		mm (in)	72.0 × 61.0 (2.83 × 2.40)
Compression ratio		kPa (kgf/cm ² , psi)	#1: 5.3 (0.05, 0.8), #2: 5.7 (0.06, 0.8)
Compression pressure		kPa (kgf/cm ² , psi)	#1: 680 (6.8, 98.6), #2: 730 (7.3, 105.9)
<Minimum>		kPa (kgf/cm ² , psi)	#1: 540 (5.4, 78.3), #2: 580 (5.8, 84.1)
Spark plug(NGK)			B7HS-10
Number of carburetor			1
Enrichment system			Chock valve
Intake system			Reed valve
Induction system			Loop charge
Exhaust system			Through propeller boss








Item	Worldwide	Unit	Model
			EK25BMH
Lubrication system			Mixed (Gasoline and oil, Kerosene and oil)
Cooling system			Water
Ignition control system			CDI
Alternator output		V - W	12 - 80
POWER UNIT			
Starting system			Manual
Control system			Mechanical
Advanced system			Mechanical
CARBURETOR			
ID mark			69T00
FUEL AND OIL			
Fuel type (Main)			Kerosene
Mixing ratio (Sub)			30 : 1
Mixing ratio			Unleaded regular gasoline
Engine oil type			50 : 1
Engine oil grade			2 stroke outboard engine oil
Gear oil			TC - W3
Gear oil grade			Hypoid gear oil
Gear oil capacity		cm ³ (US oz, Imp oz)	SAE #90 (API GL - 4)
			320 (10.8, 11.3)
BRACKET			
Tilt angle		Degree	4, 8, 12, 16, 20
Tilt-up angle		Degree	76
Shallow water angle from transom		Degree	Tilt angle + 20
Steering angle		Degree	40 + 40
DRIVE UNIT			
Gear shift positions			F - N - R
Gear ratio			2.08 (27/13)
Gear type			Spiral bevel
Propeller direction (rear view)			Clockwise
Propeller drive system			Spline
Propeller mark			F



**MAINTENANCE SPECIFICATIONS
POWER UNIT**

Item	Worldwide	Unit	Model
			EK25BMH
CYLINDER HEAD			
Warpage limit		mm (in)	0.1 (0.004)
 <p>(lines indicate straightedge position)</p>			
CYLINDERS			
Bore size		mm (in)	72.00 - 72.02 (2.8346 - 2.8354)
Wear limit		mm (in)	72.10 (2.8386)
Taper limit		mm (in)	0.08 (0.0031)
Out-of-round limit		mm (in)	0.05 (0.0020)
PISTON			
Piston side "D"		mm (in)	71.94 - 71.96 (2.8323 - 2.8331)
Measuring point "H"		mm (in)	10.0 (0.3937)
			
Piston-cylinder clearance		mm (in)	0.060 - 0.065 (0.0024 - 0.0026)
<Limit>		mm (in)	0.1 (0.0039)
Oversize piston diameter	1st	mm (in)	72.25 (2.8445)
	2nd	mm (in)	72.50 (2.8543)
Pin boss inside diameter		mm (in)	19.904 - 19.915 (0.7836 - 0.7841)
PISTON PINS			
Outside diameter		mm (in)	19.895 - 19.900 (0.7833 - 0.7835)
PISTON RING (1st)			
Type			Keystone
(B)		mm (in)	2.0 (0.079)
(T)		mm (in)	3.0 (0.118)
End gap (installed)		mm (in)	0.20 - 0.35 (0.008 - 0.014)
<Limit>		mm (in)	0.35 (0.014)
Side clearance		mm (in)	0.03 - 0.05 (0.0012 - 0.0020)
<Limit>		mm (in)	0.05 (0.0020)



Item	Worldwide	Unit	Model	
			EK25BMH	
PISTON RING (2nd)				
Type			Plain	
(B)		mm (in)	2.0 (0.079)	
(T)		mm (in)	3.0 (0.118)	
End gap (installed)		mm (in)	0.20 - 0.35 (0.0079 - 0.0137)	
<Limit>		mm (in)	0.35 (0.014)	
Side clearance		mm (in)	0.03 - 0.07 (0.0012 - 0.0028)	
<Limit>		mm (in)	0.07 (0.0028)	
CRANKSHAFT				
Crank width (A)		mm (in)	56.90 - 56.95 (2.2401 - 2.2421)	
(B)		mm (in)	153.7 - 154.0 (6.0512 - 6.0630)	
(C)		mm (in)	39.9 - 40.1 (1.5709 - 1.5787)	
Runout limit (D)		mm (in)	0.03 (0.0012)	
Side clearance (E)		mm (in)	0.2 - 0.7 (0.0079 - 0.0276)	
Maximum axial play (F)		mm (in)	2.0 (0.079)	
CONNECTING ROD				
Small end diameter		mm (in)	23.904 - 23.917 (0.941 - 0.942)	
CARBURETOR				
Main jet (M.J.)		#	Kerosene carburetor 155	Gasoline carburetor —
Main air jet (M.A.J.)		φmm (in)	1.3 (0.051)	—
Main nozzle (M.N.)		φmm (in)	2.8 (0.110)	—
Pilot jet (P.J.)		#	50	48
Pilot air jet (P.A.J.)		mm (in)	0.92 (0.036)	0.90 (0.035)
Pilot screw (P.S.)		turns out	1/2 + 2 1/2 - 1/2	1 - 1/2 ± 1/2
Valve seat size (V.S.)		mm (in)	1.4 (0.055)	1.2 (0.047)
Float height		mm (in)	18 (0.079)	—
Float arm height		mm (in)	—	3 (0.118)
Idle speed		r/min	1,300 ± 50	



Item	Worldwide	Unit	Model
			EK25BMH
REED VALVES			
Thickness			0.2 (0.008)
Valve stopper height (Standard)		mm (in)	3.46 - 3.50 (0.136 - 0.138)
(for Sri Lanka)		mm (in)	4.20 - 4.60 (0.165 - 0.181)
Valve bending limit		mm (in)	0.2 (0.008)
THERMOSTAT			
Valve opening temperature		°C (°F)	48 - 52 (118 - 126)
Full-open temperature		°C (°F)	60 (140)
Minimum valve lift		mm (in)	3 (0.12)

LOWER UNIT

Item	Worldwide	Unit	Model
			EK25BMH
GEAR BACKLASH			
Pinion - forward gear		mm (in)	0.31 - 0.72 (0.012 - 0.028)
Pinion - reverse gear		mm (in)	0.93 - 1.65 (0.037 - 0.065)
Pinion gear shims		mm	0.7 / 1.0 / 1.1 / 1.2 / 1.3 / 1.4 / 1.5 / 1.6
Forward gear shims		mm	1.0 / 1.1 / 1.2 / 1.3 / 1.4
Reverse gear shims		mm	1.0 / 1.1 / 1.2 / 1.3
PROPELLER			
Material			Aluminium
No. of blades × diameter × pitch		in	3 × 9 - 7/8 × 11 - 1/4 3 × 9 - 7/8 × 8 3 × 9 - 7/8 × 9 3 × 9 - 7/8 × 10 - 1/2 3 × 9 - 7/8 × 12 3 × 9 - 7/8 × 13 3 × 9 - 7/8 × 14
Test propeller		P/N.	90890-01629
		r/min	5,250 - 5,450



ELECTRICAL

Item	Worldwide	Unit	Model
			EK25BMH
IGNITION SYSTEM			
Ignition timing (Full retard)		Degree	ATDC 2 ± 2
(Full advanced)		Degree	BTDC 22 ± 2
Spark plug gap		mm (in)	0.9 - 1.0 (0.035 - 0.039)
Ignition spark gap (Minimum)		mm (in)	8.0 (0.31)
Ignition coil resistance (Primary)		Ω	0.18 - 0.24
(Secondary)		k Ω	2.70 - 3.70
Charge coil resistance (Br - L)		Ω	342 - 418
Charge coil output peak voltage (Br - L)			
@ cranking 1 ^{*1}		V	146
@ cranking 2 ^{*1}		V	146
@ 1,500 r/min		V	150
@ 3,500 r/min		V	150
Pulser coil resistance (W/R - B , W/B - B)		Ω	311 - 381
Pulser coil output peak voltage (W/R - B , W/B - B)			
@ cranking 1 ^{*1}		V	6.8
@ cranking 2 ^{*1}		V	6.7
@ 1,500 r/min		V	16.0
@ 3,500 r/min		V	26.0
CDI unit resistance		Ω	Refer to the "CDI UNIT" on page 8-10
CDI unit output peak voltage (B/O - B , B/W - B)			
@ cranking 1 ^{*1}		V	5.5
@ cranking 2 ^{*1}		V	130.0
@ 1,500 r/min		V	135.0
@ 3,500 r/min		V	135.0

*1 Cranking 1: Open circuit.
Cranking 2: Related parts are connected.




Item	Worldwide	Unit	Model
			EK25BMH
CHARGING SYSTEM			
Lighting coil resistance (G - G)		Ω	0.31 - 0.37
Lighting coil output peak voltage (G - G)			
@ cranking 1 ^{*1}		V	4.6
@ cranking 2 ^{*1}		V	—
@ 1,500 r/min		V	—
@ 3,500 r/min		V	—
@ 1,500 r/min (Open circuit)		V	14.7
@ 3,500 r/min (Open circuit)		V	30.0

*1 Cranking 1: Open circuit.
Cranking 2: Related parts are connected.




DIMENSIONS





DIMENSIONS

Symbol	Worldwide	Unit	Model
			EK25BMH
L1		mm (in)	429 (16.89)
L2		mm (in)	180 (7.09)
L3		mm (in)	420 (16.54)
L4		mm (in)	385 (15.16)
L5	(S)	mm (in)	61 (2.40)
	(L)	mm (in)	83 (3.27)
	(Y)	mm (in)	83 (3.27)
L6	(S)	mm (in)	736 (28.98)
	(L)	mm (in)	854 (33.62)
	(Y)	mm (in)	897 (35.31)
L7		mm (in)	405 (15.94)
L8		mm (in)	195 (7.68)
L10		mm (in)	74.2 (2.92)
H1	(S)	mm (in)	707 (27.83)
	(L)	mm (in)	834 (32.83)
	(Y)	mm (in)	881 (34.68)
H2		mm (in)	439 (17.28)
H3		mm (in)	144 (5.67)
H4	(S)	mm (in)	423 (16.65)
	(L)	mm (in)	550 (21.65)
	(Y)	mm (in)	597 (23.50)
H5		mm (in)	466 (18.35)
H6	(S)	mm (in)	621 (24.45)
	(L)	mm (in)	701 (27.60)
	(Y)	mm (in)	730 (28.74)
H7		mm (in)	118 (4.65)
H8		mm (in)	30 (1.18)
H9		mm (in)	596 (23.46)
H10		mm (in)	40.3 (1.59)
W1		mm (in)	166 (6.54)
W2		mm (in)	233 (9.17)
W3		mm (in)	148 (5.83)
W4		mm (in)	192 (7.56)
W5		mm (in)	302 (11.89)
W6		mm (in)	472 (18.58)
A1		Degree	40
A2		Degree	68
C1		mm (in)	35 (1.38)
C2		mm (in)	65 (2.56)



Symbol	Worldwide	Unit	Model
			EK25BMH
B1		mm (in)	89 (3.50)
B2		mm (in)	140 (5.51)
B3		mm (in)	112.5 (4.43)
B4		mm (in)	96.5 (3.80)
B5		mm (in)	122.5 (4.82)
B6		mm (in)	176 (6.93)
B11		mm (in)	85 (3.35)
B12		mm (in)	51 (2.01)
D1		ømm (in)	8.5 (0.33)



TIGHTENING TORQUES


SPECIFIED TORQUES

Part to be tightened	Part name	Thread size	Q'ty	Tightening torques			Remarks	
				N•m	kgf•m	ft•lb		
POWER UNIT								
Recoil starter mounting	Bolt	M6	3	12	1.2	8.9		
Recoil starter center bolt	Bolt	M12	1	15	1.5	11		
Recoil starter center Nut	Nut	—	1	10	1.0	7.4		
Flywheel magnet	Nut	M12	1	140	14	103		
Power unit mounting	1st	Bolt	M8	6	11	1.1	8.1	
	2nd				22	2.2	16	
Intake manifold mounting	1st	Bolt	M6	9	4	0.4	3.0	
	2nd				8	0.8	5.9	
Spark plug	—	M14	2	25	2.5	18		
Cylinder head mounting	1st	Bolt	M8	11	15	1.5	11	
	2nd				30	3.0	22	
Exhaust cover mounting	1st	Bolt	M6	15	4	0.4	3.0	
	2nd				8	0.8	5.9	
Crankcase mounting	1st	Bolt	M8	10	15	1.5	11	
	2nd				30	3.0	22	
LOWER UNIT								
Propeller	Nut	—	1	35	3.5	26		
Lower unit mounting	Bolt	M10	6	37	3.7	27		
	Nut	M10	6	37	3.7	27		
Propeller shaft housing	Bolt	M6	2	11	1.1	8.1		
Pinion gear nut	Nut	M8	1	50	5.0	37		
Water inlet	Bolt	M5	2	5	0.5	3.7		
BRACKET								
Shift actuator mounting	Bolt	M6	4	11	1.1	8.1		
	Nut	M10	1	17	1.7	13		
Shift lever	Bolt	M6	1	11	1.1	8.1		
Mount rubber(side upper)	Nut	M10	2	17	1.7	13		
Mount rubber(lower front)	Bolt	M8	2	17	1.7	13		
Steering bracket mounting	Bolt	M6	4	11	1.1	8.1		
Clamp bracket nylon	Nut	—	2	45	4.5	33		
ELECTRICAL								
CDI unit	Bolt	M6	2	4	0.4	3.0		
Ignition coil	Bolt	M6	2	8	0.8	5.9		
Engine stop switch	Nut	M16	1	35	3.5	26		

* Do not apply too much torque.



Nut (A)	Bolt (B)	General torque specifications		
		N•m	kgf•m	ft•lb
8 mm	M5	5	0.5	3.7
10 mm	M6	8	0.8	5.9
12 mm	M8	18	1.8	13
14 mm	M10	36	3.6	27
17 mm	M12	43	4.3	32



GENERAL TORQUES

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided in applicable sections of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross fashion and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.

CHAPTER 3

PERIODIC CHECK AND ADJUSTMENT

MAINTENANCE INTERVAL CHART	3-1
TOP COWLING	3-2
CHECKING THE TOP COWLING FIT	3-2
FUEL SYSTEM	3-2
CHECKING THE FUEL LINE	3-2
CHECKING THE FUEL FILTER	3-3
CHECKING THE FUEL PUMP	3-3
CHECKING THE FUEL JOINT	3-3
CONTROL SYSTEM	3-4
ADJUSTING THE IGNITION TIMING	3-4
ADJUSTING THE ENGINE IDLE SPEED	3-15
ADJUSTING THE START-IN-GEAR PROTECTION DEVICE	3-17
POWER UNIT	3-18
MEASURING THE COMPRESSION PRESSURE	3-18
COOLING SYSTEM	3-19
CHECKING THE COOLING WATER DISCHARGE	3-19
LOWER UNIT	3-19
CHECKING THE GEAR OIL LEVEL	3-19
CHANGING AND CHECKING THE GEAR OIL	3-19
CHECKING THE LOWER UNIT (FOR AIR LEAKS)	3-20
GENERAL	3-21
CHECKING THE ANODE	3-21
CHECKING THE SPARK PLUGS	3-22
CHECKING THE PROPELLER	3-23
CHECKING BOLTS AND NUTS	3-23
LUBRICATION POINTS	3-24

MAINTENANCE INTERVAL CHART

Frequency of maintenance operations may be adjusted according to the operating conditions, but the following table gives general guidelines.

The mark (●) indicates the check-ups which may be carried out by owner.




The mark (○) indicates work to be carried out by Yamaha dealer.

Item	Remarks	Initial		Every		Refer page
		10 hours	50 hours (3 months)	100 hours (6 months)	200 hours (1 year)	
FUEL SYSTEM						
Fuel filter	Clean	●	●	●		3-3
Fuel system	Check			○		3-2
Fuel tank	Clean				●	—
POWER UNIT						
Carburetor setting	Check	○		○		3-15
	Adjust	○		○		3-15
Cooling water passage	Clean	●		●	○	—
Exhaust leakage	Check	○	○	○		—
Water leakage	Check	○	○	○		—
CONTROL SYSTEM						
Ignition timing	Check	○		○		3-4
	Adjust	○		○		3-4
Idle speed	Check			○		3-15
	Adjust			●		3-15
LOWER UNIT						
Gear oil	Change	●		●		3-19
Propeller	Check		○	○		3-23
GENERAL						
Spark plug	Clean	●	●	●		3-22
	Adjust	●	●	●		3-22
	Replace	●	●	●		3-22
Wiring and connectors	Check	○	○	○		—
Grease points	Grease			●		3-24
Bolts and nuts	Retighten	○		○		3-23
Anode	Check	○	○	○		3-21
Motor exterior	Check		○	○		—

NOTE:

Cooling water passages:

When operating in salt water, turbid or muddy water, the engine should be flushed with clean water after each use.



TOP COWLING

CHECKING THE TOP COWLING FIT

Check:

- Top cowling
Cracks/damage → Replace.
- Hook
Bent → Correct.
- Rivet
Damage → Repair.
- Rubber of trim
Peel/tear → Repair.

NOTE: _____


Hooks and latches are unadjustable.

FUEL SYSTEM

CHECKING THE FUEL LINE

Check:


- Fuel hose
Cracks/damage/leak → Replace.
Refer to "FUEL JOINT, FUEL FILTER,
AND FUEL PUMP" on page 4-1.



CHECKING THE FUEL FILTER

Check:

- Fuel filter element ①
Foreign matter → Clean.
- Fuel filter cup ②
Cracks/damage/leak → Replace.
- O-ring ③
Cracks/damage → Replace.




CHECKING THE FUEL PUMP

Check:

- Fuel pump
Cracks/damage/leak →
Repair/replace.
Refer to "DISASSEMBLING THE
FUEL PUMP" on page 4-4.

NOTE: _____

Observe pump with naked eyes.



CHECKING THE FUEL JOINT

Check:

- Fuel joint ①
Cracks/damage/leak → Replace.
- Seal ②
Cracks/damage → Replace.



CONTROL SYSTEM ADJUSTING THE IGNITION TIMING

CAUTION:

Ignition timing adjustment on the running engine must be performed in the test tank with a test propeller installed on the engine.



Test propeller
90890-01629

⚠ WARNING

While checking the engine, do not touch the rotating part (flywheel), CDI unit, ignition coil, and any other hazardous areas.


1. Check:
 - Ignition timing
 Out of specification → Adjust.



Ignition timing (at idle)
ATDC $2^\circ \pm 2^\circ$
Ignition timing (at full advance)
BTDC $22^\circ \pm 2^\circ$



Engine idle speed
 $1,300 \pm 50$ r/min
Full throttle operating range
 $5,350 \pm 100$ r/min




Checking steps


- (1) Install the timing light (a) onto the spark plug lead of cylinder #1.
- (2) Install the digital tachometer (b) onto the spark plug lead of cylinder #1.
- (3) Press the position key "C" on the digital tachometer.
- (4) Start the engine and allow it to warm up for a few minutes.



Timing light (a)
90890-03141
Digital tachometer (b)
90890-06760




(5) Set the shift lever ① in forward position.




(6) Fully open the throttle by moving the throttle ② to the "FAST" position.

	Full throttle operating range 5,350 ± 100 r/min
--	--



(7) Check the ignition timing by pointing the timing light at the timing indicator on the starter case.

	Ignition timing (at full advance) BTDC 22° ± 2°
--	--




(8) Move the throttle ② to full-close position.

	Engine idle speed 1,300 ± 50 r/min
--	---






(9) Check the ignition timing by pointing the timing light at the timing indicator on the starter case.

	Ignition timing (at idle) ATDC 2° ± 2°
--	---



NOTE: _____

- Ignition timing adjustment is not required if the timing indicator reading falls within the specification.
- If the reading is out of specification, adjust the timing by the following procedure.



2. Adjustment with full-open throttle:
 - Magnet base stopper

CAUTION:

- Make sure that engine is not running.
- Remove the plug caps.


Adjustment steps

- (1) Set the shift lever ① in forward position.
- (2) Move the throttle ② to full-open position.
- (3) Slowly turn the flywheel clockwise to align the full advanced timing mark with the specified position on the timing indicator.




Ignition timing (at full advance)
BTDC 22° ± 2°

- (4) Turn the magnet base ③ until the timing mark (a) on the port side comes in line with the ignition mark (b) on the rotor.
- (5) Check that the magnet base stopper ④ is in contact with the stopper on the engine body (full-open end stopper) ⑤.



(6) If they are not in contact, loosen the set bolt (6), adjust until they are correctly in contact with each other, and secure the bolt again.




3. Adjusting the carburetor control link:


- Accelerator cam
- Carburetor control link

Adjustment steps


(1) Set the shift lever (1) in forward position.




(2) Move the throttle (2) to full-open position.



(3) Make sure that the magnet base stopper (3) is in contact with the stopper on the engine body (full-open end stopper) (4).




(4) Check to see that the full-open marking "C" on the accelerator cam aligns with the center of the cam roller.





(5) "Loosen the bolt, and align the full-open marking "C" with the center of carburetor throttle roller, and tighten the set-bolt."

NOTE: _____
Remove the manual starter before adjusting.



(6) "Loosen the rod tightening screw (a). While pushing the rod with your finger, tighten the screw so that the throttle is full-open (the full-open stopper (b) is pushed against the stopper (c)), and lock the screw."


NOTE: _____
After adjustment, open and close the throttle repeatedly for several times to reassure that the full-open position of the accelerator cam and the positioning of the carburetor control link stopper are correct.




4. Adjustment with full-closed throttle:
- Accelerator cam
 - Carburetor control link

Adjustment steps


(1) Set the shift lever (1) in forward position.




(2) Move the throttle (2) to full-close position.




(3) Make sure that the magnet base stopper ③ is in contact with the stopper on the engine body (full-close end stopper) ④.




(4) Make sure that the lever is in contact with the carburetor throttle stop screw.



(5) Correct adjustment has been established if the cam roller is not in contact with the accelerator cam.








(6) If the lever is not in contact with the throttle stop screw move the plate cam to the left so that the lever comes to contact with the throttle stop screw.



NOTE:

- When shifting the plate cam slightly, do not shift it more than 2 mm (0.079 in) to the left from the point at which the marking line of the full-open mark "C" aligns with the centerline of the roller cam at full-throttle.
- After adjustment, open and close the throttle for several times, and reassure that the lever is in contact with the throttle stop screw on the carburetor, and that the cam roller is not in contact with the accelerator cam.



5. Adjusting the throttle cable
- Throttle cable

Adjusting steps

NOTE: _____

After adjustment, open and close the throttle for several times for reassurance.


- (1) Set the shift lever ① in forward position.

- (2) Move the throttle ② to full-open position.


- (3) Check that the magnet base stopper ③ is in contact with the stopper on the engine body (full-open end stopper) ④.

- (4) If the stoppers come in contact before the throttle is fully open, loosen the lock nut ⑥ on the throttle-opening cable, turn-in the adjusting nut ⑤ until the correct positioning is attained, and then secure it by the lock nut ⑥.


- (5) If the stoppers do not come in contact at full-open throttle, then turn-out the adjusting nut ⑤ on the throttle-opening cable until the correct positioning is attained, and secure it by the lock nut ⑥.




(6) After confirming the positive contact of stoppers at full-open throttle position, turn the adjusting nut ⑦ on the throttle-closing cable so that the cable has a little slack, and then secure it by the lock nut ⑧.




(7) Once the adjustment under full-open throttle is completed, move the throttle ② to full-close position.



(8) Make sure that the magnet base stopper ③ is in contact with the stopper on the engine body (full-close end stopper) ④.




(9) Move the throttle ② to full-open position.




(10) In this condition, make sure that the full-open stopper is in contact with the stopper.

NOTE: _____
If they are not in contact, adjust the carburetor control link.

Refer to "Adjusting the carburetor control link:" on page 3-7.



(11) Move the throttle ② to full-close position.




(12) At this point, make sure that the throttle lever is in contact with the throttle stop screw on the carburetor.

NOTE:

- After adjustment, open and close the throttle for several times for reassurance.
- If they are not in contact, adjust the carburetor control link.

Refer to "Adjusting the carburetor control link:" on page 3-7.




6. Adjusting the throttle control lever:


- Throttle control lever

Adjustment steps


(1) Set the shift lever ① at the forward position.




(2) Move the throttle ② to full-open position.



(3) Check that the magnet base stopper ③ is in contact with the stopper on the engine body (full-open end stopper) ④.




(4) Check that the throttle control lever ⑤ is in contact with the stopper ⑥ on the bottom cowling.



(5) If they are not in contact, adjust the length of the joint link (C) that the throttle control lever seats on the stopper on the bottom cowling.

NOTE:

After adjustment, open and close the throttle repeatedly for several times to reassure the correct positioning.




(6) Check that the magnet base stopper ③ is in contact with the stopper on the engine body (full-open end stopper) ④.

NOTE:

If they are not in contact, perform the adjustment with full-open throttle.

Refer to "Adjustment with full-open throttle:" on page 3-6.





(7) In this condition, make sure that the full-open stopper is in contact with the stopper.

NOTE:

If they are not in contact, adjust the carburetor control link.

Refer to "Adjusting the carburetor control link:" on page 3-7.



7. Adjusting the engine idle speed:
- Engine idle speed

Adjustment steps

- (1) Adjust the pilot screw.



Pilot screw turn-out

Gasoline carburetor:

1 - 1/2 ± 1/2

Kerosene carburetor:

1/2 + 2

1/2 - 1/2

- (2) Adjust the idling stop screw



Engine idle speed

1,300 ± 50 r/min

Refer to "ADJUSTING THE ENGINE IDLE SPEED" on page 3-15.



ADJUSTING THE ENGINE IDLE SPEED

NOTE:

- The engine should be warmed up for the adjustment. Correct adjustment cannot be obtained when the engine is cold.
- Make sure that the pilot screw adjustment is normal before implementing idling stop screw adjustment.

1. Measure:

- Engine idle speed
Out of specification → Adjust.




Engine idle speed
1,300 ± 50 r/min

CAUTION:

Install the engine in the test tank to check the engine idle speed.

Measuring steps

- (1) Start the engine and allow it to warm up for a few minutes.
- (2) Install the digital tachometer ① onto the spark plug lead of cylinder #1.
- (3) "Press the position key "C" on the digital tachometer."



Digital Tachometer.....①
90890-06760

2. Adjust:


- Carburetor pilot screw

CAUTION:



Do not adjust the carburetor when it is operating properly. Excessive adjustment may cause the engine poor performance.

Adjustment steps

- (1) Turn in the pilot screw (①:Gasoline, ②:Kerosene) until they are lightly seated.
- (2) Turn out the pilot screws by specified number of turns.



Pilot screw turn-out
Gasoline carburetor:
1 - 1/2 ± 1/2
Kerosene carburetor:
1/2 + 2
1/2 - 1/2



(3) Make sure that the idle speed is stable when the throttle is opened and closed for several times.

NOTE: _____
If the idle speed is not stable, disassemble and readjust the carburetor.

3. Adjust:
- Engine idle speed





Adjustment steps

(1) Turn the idling stop screw ② of carburetor in direction (a) or (b) until the specified engine idle speed is obtained.

Direction (a)	Engine idle speed increases .
Direction (b)	Engine idle speed decreases .

(2) Check the engine idling stability by opening and closing the throttle for several times. If engine idling is unstable, adjust the pilot screw.

NOTE: _____
After adjustment, open and close the throttle for several times and keep it idling for at least 15 seconds. Check if engine idle speed is stable.



ADJUSTING THE START-IN-GEAR PROTECTION DEVICE

CAUTION:

- Make sure that the engine is not running.
- Remove the plug caps.

1. Check:

- Start-in-gear protection device

Checking steps

- (1) Set the shift lever ① in forward or reverse position.
- (2) Check that the starter rope ② cannot be pulled out.
- (3) If the starter rope can be pulled out, perform the adjustment.

2. Adjust:




Adjustment steps

- (1) Set the shift lever ① in neutral position.

- (2) Turn in or out the adjusting nut ③ on the starter stop wire so that the starter stopper end ④ is aligned with the hole on the starter case ⑤.

NOTE:

- Check again that the starter rope can not be pulled out when the shift is engaged.
- Check again that the starter rope can be pulled out when the shift is in neutral.



POWER UNIT MEASURING THE COMPRESSION PRESSURE

NOTE:

The engine should be warmed up before measuring the compression pressure. Correct measurement cannot be obtained when the engine is cold.

1. Measure:

- Compression pressure

Below minimum compression pressure → Check or replace piston, piston rings, cylinder head, and cylinder head gasket.



Compression pressure (reference value)

#1: 680 kPa (6.8 kgf/cm², 98.6 psi)

#2: 730 kPa (7.3 kgf/cm², 105.9 psi)

Minimum compression pressure

#1: 540 kPa (5.4 kgf/cm², 78.3 psi)

#2: 580 kPa (5.8 kgf/cm², 84.1 psi)

Measuring steps

- (1) Remove the spark plug ①.

CAUTION:

Before removing the spark plug, clean the spark plug well area to prevent any dirt from falling into the cylinder that is being checked.

- (2) Install the compression gauge ② into the spark plug hole.




Compression gauge 90890-03160

- (3) Fully open the throttle.
- (4) Fully open the choke. (Make the choke valve ineffective.)
- (5) Crank the engine by means of recoil starter (MH model) or starter motor (W, WC, and WH models) until the compression gauge gives stable reading.
- (6) Remove the compression gauge ②.
- (7) Install the spark plug ①.



Spark plug 25 N·m (2.5 kgf·m, 18 ft·lb)



COOLING SYSTEM CHECKING THE COOLING WATER DISCHARGE

Check:

- Pilot water
Does not flow → Clean and check the cooling water passage.


Checking steps

- (1) Place the lower unit in water.
- (2) Start the engine.
- (3) Check that water flows from the pilot water outlet.

LOWER UNIT CHECKING THE GEAR OIL LEVEL

Check:

- Gear oil level
Level is low → Add gear oil to the proper level.




CHANGING AND CHECKING THE GEAR OIL

1. Check:

- Gear oil
Milky oil → Replace the oil seal.
Slug oil → Check the oil gears, bearings, and clutch dog.

Checking steps

- (1) Tilt up the outboard slightly.
- (2) Place a container under the gear oil drain screw ①.
- (3) Remove the gear oil drain screw and gear oil level check screw ②.



2. Fill:

- Gear oil
(with the specified amount of the recommended gear oil.)

	Recommended gear oil
	Hypoid gear oil, SAE #90 (API GL-4)
	Oil capacity 320 cm³ (10.8 US oz, 11.3 Imp oz)

Filling steps

- (1) Place the outboard in an upright position.
- (2) Insert the gear oil tube into the drain hole and slowly fill the gear oil until oil flows out of the check hole and no air bubbles are visible.
- (3) Install the gear oil level check screw and then quickly install the gear oil drain screw.

**CHECKING THE LOWER UNIT
(FOR AIR LEAKS)**

Check:

- Lower unit holding pressure
Pressure drops → Check the seal and components.

	Lower unit holding pressure
	100 kPa (1.0 kg/cm², 14.5 psi) for
	10 seconds

Checking steps


CAUTION:


Do not overpressurize the lower unit. Excessive pressure may damage the oil seals.

- (1) Remove the gear oil level check screw.
- (2) Install the pressure tester into the check hole.

	Leakage tester
	90890-06762

- (3) Apply the specified pressure.
- (4) The lower unit should hold the specified pressure for 10 seconds.






GENERAL CHECKING THE ANODE

Check:

- Anodes
 - Scales → Clean.
 - Oil/grease → Clean.
 - Excessive wear → Replace.

CAUTION: _____

Do not oil, grease, or paint the anode, or it will not operate properly.



CHECKING THE SPARK PLUGS

1. Check:
 - Electrodes ①
Cracks/excessive wear → Replace.
 - Insulator color ②
Distinctly different color → Check the engine condition.

Color guide:

Medium to light tan color

Normal

Whitish color


- Lean fuel mixture
- Plugged jet (s)
- Wrong setting

Blackish color

- Rich mixture
- Excessive oil usage
- Defective ignition system
- Defective spark plug

2. Clean:


- Spark plug
(use a spark plug cleaner or wire brush)



3. Check:

- Spark plug type ①
Incorrect → Replace.

**Standard spark plug
NGK B7HS-10**




4. Measure:

- Spark plug gap ①
Out of specification → Replace.



**Spark plug gap
0.9-1.0 mm (0.035-0.039 in)**




5. Tighten:
- Spark plug



Spark plug
25 N•m (2.5kgf•m, 18 ft•lb)

NOTE:


- Before installing the spark plug, clean the gasket surface and spark plug surface. Also, it is suggested to apply a thin film of anti-seize compound to the spark plug threads to prevent thread seizure.
- If a torque wrench is not available, a good estimate of the correct tightening torque is to finger tighten (a) the spark plug and then tighten it another 1/4 to 1/2 of a turn (b).



CHECKING THE PROPELLER

Check:

- Propeller
 - Spline
- Wear/cracks/damage → Replace.




CHECKING BOLTS AND NUTS

Check:

- Power unit mount bolt
 - Flywheel nut
- Loose bolts / nuts → Tighten to the specified torque.




Power unit mount bolt
1st 11 N•m (1.1 kgf•m, 8.1 ft•lb)
2nd 22 N•m (2.2 kgf•m, 16 ft•lb)
Flywheel nut
140 N•m (14 kgf•m, 103 ft•lb)




LUBRICATION POINTS

1. Apply:
 - Yamaha grease A


NOTE: _____
Using a grease gun, fill in the grease until it comes out of the bushing.




NOTE: _____
Use a grease gun.




NOTE: _____
Using a grease gun, fill in the grease until it comes out of the bushing.




NOTE: _____
Using a grease gun, fill in the grease until it comes out of the bushing.




NOTE: _____
Use a grease gun.




NOTE: _____
Use a grease gun.




NOTE: _____
Grease the area where shift rod, shift connector, and the nut are fastened.



NOTE: _____
Grease the sliding face of the choke knob.



NOTE: _____
Grease the inner cable and the lock nut.



2. Apply:
- Yamaha grease D

CHAPTER 4


FUEL SYSTEM

FUEL JOINT, FUEL FILTER, AND FUEL PUMP	4-1
REMOVING THE FUEL JOINT, FUEL FILTER AND FUEL PUMP	4-1
CHECKING THE FUEL JOINT	4-3
CHECKING THE FUEL FILTER	4-3
ASSEMBLING THE FUEL FILTER	4-3
FUEL PUMP	4-4
DISASSEMBLING THE FUEL PUMP	4-4
CHECKING THE FUEL PUMP	4-6
ASSEMBLING THE FUEL PUMP	4-7
CARBURETOR	4-9
REMOVING THE CARBURETOR	4-9
DISASSEMBLING THE CARBURETOR	4-10
CHECKING THE CARBURETOR	4-16
ASSEMBLING THE CARBURETOR	4-17
INSTALLING THE CARBURETOR	4-20




FUEL JOINT, FUEL FILTER, AND FUEL PUMP

REMOVING THE FUEL JOINT, FUEL FILTER AND FUEL PUMP






Step	Job/Parts	Q'ty	Remarks
1	Clip	2	
2	Fuel hose (fuel pump to carburetor)	1	Gasoline
3	Clip	2	
4	Fuel hose (fuel pump to carburetor)	1	Kerosene
5	Clip	2	
6	Fuel hose (fuel filter to fuel pump)	1	Gasoline
7	Clip	2	
8	Fuel hose (fuel filter to fuel pump)	1	Kerosene
9	Clip	2	
10	Fuel hose (fuel joint to fuel filter)	1	Gasoline
11	Clip	2	
12	Fuel hose (fuel joint to fuel filter)	1	Kerosene
13	Bolt	2	

Continued on next page.



Step	Job/Parts	Q'ty	Remarks
14	Fuel pump	1	Not reusable Gasoline Kerosene
15	Gasket	1	
16	Nut	2	
17	Fuel filter	1	
18	Fuel filter	1	
19	Bolt	1	
20	Bolt	1	
21	Filter bracket	1	
22	Bolt	1	
23	Fuel joint	1	
24	Seal	1	



CHECKING THE FUEL JOINT

1. Check:
 - Fuel joint ①
Cracks/damage/leak → Replace.
 - Seal ②
Cracks/damage → Replace.
2. Measure:
 - Fuel joint operation
Impossible to maintain the specified pressure for 10 sec. → Replace.

Measuring steps

- (1) Attach the vacuum/pressure pump gauge.

	Vacuum/pressure pump gauge set 90890-06756
--	---

- (2) Apply the specified pressure.

	Specified pressure 50 kPa (0.5 kg/cm², 7.25 psi)
--	--

CHECKING THE FUEL FILTER

- Check:
- Filter cap ①
Cracks/damage → Replace.
 - Filter element ②
Cracks/damage/leak → Replace.
 - O-ring ③
Cracks/damage → Replace.
 - Cup ④
Foreign matter → Clean.

ASSEMBLING THE FUEL FILTER


- (1) Install filter element to cap.
- (2) Install O-ring to filter cup.
- (3) Assemble cap and filter cup.

NOTE: _____
Start the engine and confirm the proper function.




FUEL PUMP

DISASSEMBLING THE FUEL PUMP




Step	Job/Part	Q'ty	Remarks
1	Screw (with washer)	3	
2	Body	1	
3	Diaphragm	1	
4	Gasket	1	Not reusable
5	Body	1	
6	Diaphragm gasket	2	Not reusable
7	Diaphragm	1	
8	Body	1	
9	Screw	2	
10	Seat valve	2	
11	Nut	2	
12	Screw	3	
13	Washer	3	

Continued on next page.




Step	Job/Part	Q'ty	Remarks
14	Body	1	
15	Diaphragm	1	
16	Diaphragm gasket	1	



CHECKING THE FUEL PUMP

1. Check:

- Body ①
Cracks/damage/leak → Replace.
Foreign matters → Clean.
- Body ②
- Body ③
- Body ④
- Seat valve ⑤
Cracks/ damage → Replace.
- Diaphragm ⑥
Damage → Replace.



2. Check:

- Fuel pump
Reverse air flow → Replace.

Checking steps

NOTE: _____
Do not overpressurize the fuel pump. Excessive pressure may cause air to leak out.

- (1) Install the Vacuum/pressure pump gauge set onto the fuel pump as shown.

	Vacuum/pressure pump gauge set 90890-06756
--	---

- (2) Apply the specified pressure with the Vacuum/pressure pump gauge set.

	Fuel pump pressure 50 kPa (0.5 kg/cm², 7.25 psi)
--	--

NOTE: _____

- Make sure no air comes out of the opposite side of the fuel pump.
- Start the engine and confirm the proper function.



ASSEMBLING THE FUEL PUMP

NOTE:

Clean all parts before assembly.

Assembly steps






(1) Assemble Body ① and seat valve.


(2) Insert the diaphragm between the diaphragm gaskets, and set them on Body ②.

(3) Set Body ① on the diaphragm gasket.


(4) Fit diaphragm and gasket on Body ③.

(5) Assemble Body ③ as has been fitted in (4) to Body ①.





(6) Assemble body ④, diaphragm, and diaphragm gasket in this order.




(7) Assemble body ④ and body ①, and fasten them with the screw.



CARBURETOR


REMOVING THE CARBURETOR



Step	Job/Part	Q'ty	Remarks
1	Rod	1	
2	Bolt	2	
3	Intake silencer	1	
4	O-ring	1	Not reusable
5	Nut	2	
6	Carburetor	1	
7	Gasket	1	Not reusable




DISASSEMBLING THE CARBURETOR




Step	Job/Part	Q'ty	Remarks
1	Drain screw	1	
2	Drain gasket	1	Not reusable
3	Drain screw	1	
4	Drain gasket	1	Not reusable
5	Drain screw	1	
6	Packing	1	Not reusable
7	Steel ball seat	1	
8	Steel ball	1	
9	Check valve spring	1	
10	Check valve seat packing	1	
11	Rod	1	
12	Lever joint	2	
13	Hose	1	

Continued on next page.




Step	Job/Part	Q'ty	Remarks
14	Bolt	4	
15	Bolt	3	
16	Float chamber	1	
17	Float chamber packing	1	
18	Chamber packing	1	
19	Starter jet	1	
20	Check valve	1	
21	O-ring	1	Not reusable
22	Pump spring	1	
23	Pump plunger	1	
24	Float	1	
25	Pilot jet	1	
26	Pin	1	

Continued on next page.




Step	Job/Part	Q'ty	Remarks
27	Float arm	1	
28	Needle valve	1	
29	Chamber cover	1	
30	Set screw	1	
31	Washer	1	
32	Pump lever	1	
33	Coller	1	
34	Pin	1	
35	Float	1	
36	Needle valve	1	
37	Valve seat	1	
38	Packing	1	Not reusable
39	Main jet	1	

Continued on next page.




Step	Job/Part	Q'ty	Remarks
40	Main nozzle	1	
41	Steel ball seat	1	
42	Steel ball	1	
43	Check valve spring	1	
44	Check valve seat packing	1	
45	Screw	1	
46	Rod	1	
47	Lever joint	1	
48	Nut	1	
49	Spring washer	1	
50	Collar	1	
51	Accel arm	1	
52	Cotter pin	1	Not reusable

Continued on next page.







Step	Job/Part	Q'ty	Remarks
53	Washer	1	
54	Accel roller	1	
55	Accel link shaft	1	
56	Coller	1	
57	Pilot screw	1	Kerosene
58	Spring	1	
59	Pilot screw	1	Gasoline
60	Spring	1	
61	Idling stop screw	1	
62	Spring	1	
63	Bolt	3	
64	Plate	1	
65	Damper	1	

Continued on next page.



Step	Job/Part	Q'ty	Remarks
66	Hose	1	
67	Hose	1	
68	Cover plate	1	
69	Cover plate packing	1	
70	Plunger spring	1	
71	Guide screw	1	
72	Starter lever	1	
73	Starter plunger	1	
74	Pilot jet	1	
75	Drain screw	1	
76	O-ring	1	Not reusable
77	Carburetor body	1	



CHECKING THE CARBURETOR

CAUTION:

Do not use steel-wire to clean the jets. This may enlarge the jet diameters and seriously affect performance.

Check:




- Carburetor body ①
Cracks/damage → Replace.
Contamination → Clean.
- Needle valve ②
Grooved wear → Replace.
- Pilot screw ③
Bent/wear → Replace.
- Main jet
Contamination → Clean.
- Pilot jet
Contamination → Clean.
- Main nozzle
Contamination → Clean.
- Float
Cracks/damage → Replace.
- Pump plunger ④
Cracks/damage → Replace.
- Fuel passage
Clog → Clean.
- Air passage
Clog → Clean.

NOTE:

Use a suitable cleaning solvent and blow out clogged passages with compressed air.

⚠ WARNING

Protect your eyes with suitable safety spectacles or safety goggles when using compressed air.




ASSEMBLING THE CARBURETOR

1. Install:

- Main nozzle ①
- Main jet ②
- Valve seat ③
- Needle valve ④
- Float ⑤
- Float pin ⑥

NOTE:

When installing the float into the carburetor, place the needle valve into the needle valve seat.



2. Measure:


- Float height (a)
Out of specification → Replace



Float height
18.0 mm (0.709 in)


NOTE:

- The float should be resting on the needle valve, but not compressing the needle valve.
- Take measurement at the top of the float flange opposite to its pivoted side.
- Float height which is out of specification cannot be adjust. Replace the float with a new one.




3. Install:

- Float chamber packing (1)
- Float chamber (2)



4. Install:

- Accel arm (1)
- Accel link shaft (2)




5. Install:

- Pilot screw (1) (Gasoline)
- Pilot screw (2) (Kerosene)


CAUTION:

Do not cause damage to the tip of the pilot screw by over-tightening it.




6. Install:

- Cover plate ①
- Damper ②



7. Install:

- Float arm ①
- Pin ②
- Needle valve ③




8. Measure:

- Float arm height ①a
Out of specification → Adjust

	<p>Float arm height 3.0 mm (0.118 in)</p>
--	---


NOTE: _____
Adjust the heights of both float arms so that they are on the same level.



9. Install:

- Pump plunger ①
- Float ②
- Chamber packing ③

NOTE: _____
 Make sure the plunger seal is not turned up.




INSTALLING THE CARBURETOR

1. Install:

- Gasket ①
- Carburetor ②
- Nut ③
- O-ring ④
- Intake silencer ⑤
- Bolt ⑥

NOTE: _____
 Insert the projection of choke lever ⑦ into the choke knob hole ⑧.



2. Adjust:

- Pilot screw

Adjusting steps

- (1) Turn in all of the pilot screw until they are lightly seated.
- (2) Turn out the pilot screws to specified number of turns.



Pilot screw turn-out

Gasoline carburetor :


1 - 1/2 ± 1/2

Kerosene carburetor :

1/2 + 2

1/2 - 1/2

- (3) Make sure that the idle speed is stable when the throttle is opened and closed for several times.



3. Measure:

- Engine idle speed
Out of specification → adjust.



Engine idle speed
1,300 ± 50 r/min

Measuring steps

- (1) Start the engine and allow it to warm up for a few minutes.
- (2) Install the Digital tachometer ① onto the spark plug lead of cylinder #1.



Digital Tachometer
90890-06760

CHAPTER 5 RECOIL STARTER

RECOIL STARTER	5-1
REMOVING THE RECOIL STARTER	5-1
DISASSEMBLING THE RECOIL STARTER	5-2
CHECKING THE RECOIL STARTER	5-4
ASSEMBLING THE RECOIL STARTER	5-6
INSTALLING THE RECOIL STARTER	5-9
FLYWHEEL MAGNET	5-10
REMOVING THE FLYWHEEL MAGNET	5-10
INSTALLING THE FLYWHEEL MAGNET	5-11
POWER UNIT	5-12
DISCONNECTING THE LEADS AND STAYS	5-12
REMOVING THE POWER UNIT	5-14
MAGNET BASE AND CONTROL LEVER	5-15
REMOVING THE MAGNET BASE AND MAGNET CONTROL LEVER	5-15
INTAKE MANIFOLD AND REED VALVES	5-17
REMOVING THE INTAKE MANIFOLD AND REED VALVES	5-17
CHECKING THE REED VALVES	5-18
INSTALLING THE INTAKE MANIFOLD	5-18
CYLINDER HEAD	5-19
REMOVING THE CYLINDER HEAD	5-19
CHECKING THE CYLINDER HEAD	5-20
CHECKING THE THERMOSTAT	5-21
INSTALLING THE CYLINDER HEAD AND CYLINDER HEAD COVER	5-22
INSTALLING THE THERMOSTAT	5-22
EXHAUST COVER	5-23
REMOVING THE EXHAUST COVER	5-23
CHECKING THE EXHAUST COVER	5-24
INSTALLING THE EXHAUST COVER	5-24
CRANKCASE	5-25
REMOVING THE CRANKCASE	5-25
ASSEMBLING THE OIL SEAL HOUSING	5-26
INSTALLING THE CRANKCASE	5-26
CRANKSHAFT AND CYLINDER BODY	5-28
REMOVING THE CRANKSHAFT AND CYLINDER BODY	5-28
CHECKING THE CYLINDER BODY	5-29
CHECKING THE PISTON	5-30




CALCULATING THE PISTON-TO-CYLINDER CLEARANCE 5-31
 CHECKING THE PISTON PINS AND SMALL-END BEARINGS 5-32
 CHECKING THE PISTON RINGS 5-33
 CHECKING THE CRANKSHAFT 5-34
 INSTALLING THE PISTON AND PISTON RINGS 5-37
 INSTALLING THE CRANKSHAFT AND PISTON 5-37
 CHECKING THE ANODE 5-38

CRANK SHAFT 5-39
 DISASSEMBLING THE CRANKSHAFT 5-39
 REMOVING THE CRANKSHAFT BEARING 5-41
 ASSEMBLING THE CRANKSHAFT 5-44
 INSTALLING CRANKSHAFT BEARING 5-50
 CHECKING THE CRANKSHAFT 5-51


RECOIL STARTER

REMOVING THE RECOIL STARTER




Step	Job/Parts	Q'ty	Remarks
1	Starter stop wire	1	
2	Bolt (with washer)	3	
3	Nut	2	
4	Recoil starter	1	
5	Collar	2	

DISASSEMBLING THE RECOIL STARTER




Step	Job/Parts	Q'ty	Remarks
1	Starter stop wire	1	
2	Starter stop plunger	1	
3	Spring	1	
4	Cover	1	
5	Starter handle-grip	1	
6	Damper	1	
7	Bolt (with washer)	2	
8	Rope guide	1	
9	Nut	1	
10	Center bolt	1	
11	Thrust washer	1	
12	Friction plate	1	
13	Collar 1	1	

Continued on next page.



Step	Job/Parts	Q'ty	Remarks
14	Friction spring	1	
15	Drive pawl	1	
16	Return spring	1	
17	Bushing	1	
18	Sheave drum	1	
19	Starter rope	1	
20	Spiral spring	1	
21	Thrust washer	1	
22	Starter case	1	




CHECKING THE RECOIL STARTER

1. Remove:
 - Cover ①
 - Starter handle-grip ②

NOTE: _____
 Undo the knot in the starter rope, and wind the rope around the sheave drum.


CAUTION: _____
Be careful not to touch the sheave drum which is rotating at high speeds.



2. Remove:
 - Sheave drum ①

NOTE: _____
 When removing the sheave drum from the starter case, hold down the spiral spring with screwdriver inserted into the hole in the sheave drum, so that the spiral spring will not spring out.

⚠ WARNING _____
 When removing the sheave drum, be sure to set the spring free and remove the sheave retainer bolt. Otherwise, the spiral spring may jump out, endangering other person.




3. Remove:
 - Spiral spring ①

NOTE: _____
 Hold the spring with one hand, and unfold the spring from its center with the other hand. Be careful so that the spring does not jump out.




⚠ WARNING

When removing or installing the spiral spring, use care not to injure your hand. It is advisable to wear gloves.




4. Check:

- Bushing ①
Cracks/damage/wear → Replace.




5. Check:

- Spiral spring ①
Bent/broken/damage → Replace.




6. Check:

- Starter rope ①
Damage/frays/wear → Replace.




7. Check:

- Sheave drum ①
- Starter case ②
Cracks/damage/wear → Replace.



8. Check:

- Drive pawl ①
Cracks/damage/wear → Replace.
- Return spring ②
- Friction spring ③
Bent/broken/damage → Replace.



ASSEMBLING THE RECOIL STARTER

CAUTION:

New spiral springs come held in a steel hoop. To install, hook the outer end onto the spring pin first, place into the starter case, and then remove the steel hoop.

1. Install:






- Starter case ①
- Thrust washer ②
- Spiral spring ③

NOTE:

Hook the outer end ④ of the spiral spring onto the spring pin attached to the starter case, and put the spring into the starter case by winding it counterclockwise.

⚠ WARNING

When removing or installing the spiral spring, use care not to injure your hand. It is advisable to wear gloves.



2. Install:

- Starter rope ①
- Sheave drum ②

NOTE:

- Insert the rope through the rope hole and knot the end as shown.
- Wind the rope 1-1/2 turns counterclockwise onto the sheave drum.
- Place the rope at the cutaway ③.

⚠ WARNING

- Do not use a damaged starter rope, it could cause injury.

3. Install:

- Bushing ①

NOTE:

Mount the bushing on the starter case shaft.

4. Install:

- Sheave drum ①

NOTE:


While turning the sheave drum, fit the sheave drum shaft slot into the spiral spring hook, and then place the sheave drum shaft into the starter case boss.

5. Install:

- Return spring ①
- Drive pawl ②


NOTE:

Hook the end of the return spring onto the drive pawl, and check to see that the drive pawl returns smoothly.



6. Install:

- Friction plate ①
- Collar 1 ②
- Friction spring ③



7. Install:

- Friction plate ①
(with friction spring etc.)
- Center bolt ②
- Nut ③




Center bolt

15 N·m (1.5 kgf·m, 11 ft·lb)




Nut

10 N·m (1.0 kgf·m, 7.4 ft·lb)



8. Install:

- Starter rope ①
- Damper ②
- Starter handle-grip ③
- Cover ④



NOTE:

- Set the sheave drum so that the cut in the sheave drum is diametrically opposite the starter handle-grip.
- Pass the rope through the starter handle-grip, and make a knot in the end of the rope as shown.
- After assembling, wind the rope 3 turns counterclockwise around the sheave drum to contract the spring.
- By pulling out the rope, check the operation of the starter.

INSTALLING THE RECOIL STARTER


Install:

- Recoil starter ①
- Starter stop wire ②


Refer to the "ADJUSTING THE START-IN-GEAR PROTECTION DEVICE" on page 3-17.

FLYWHEEL MAGNET

REMOVIING THE FLYWHEEL MAGNET



Step	Job/Part	Q'ty	Remarks
1	Bolt	3	
2	Starter pulley	1	
3	Nut	1	
4	Washer	1	
5	Flywheel magnet	1	
6	Woodruf key	1	



Remove:

- Flywheel magnet

Removing steps


- (1) Remove the starter pulley
- (2) Remove the flywheel magnet nut.



Flywheel holder
90890-06522

NOTE:

The major load should be applied in the direction of the arrows. If the load is not applied as shown, the flywheel holder may easily slip off of the flywheel magnet.



- (3) Remove the flywheel magnet.




Flywheel puller
90890-06521

NOTE:

- The major load should be applied in the direction of the arrows.
- Apply the load until the flywheel magnet comes off the tapered portion of the crankshaft.

CAUTION:

To prevent damage to the engine or tools, screw in the flywheel puller set-bolts evenly and completely so that the puller plate is parallel to the flywheel magnet.



INSTALLING THE FLYWHEEL MAGNET

Install:


- Flywheel magnet



Flywheel holder
90890-06522


NOTE:

The major load should be applied in the direction of the arrows. If the load is not applied as shown, the flywheel holder may easily slip off of the flywheel magnet.




POWER UNIT

DISCONNECTING THE LEADS AND STAYS




Step	Job/Part	Q'ty	Remarks
1	Bolt	4	
2	Washer	2	
3	Bolt	1	
4	Electrical unit	1	
5	Bolt	1	
6	Earth lead	1	
7	Bolt	2	
8	Bolt	1	
9	Stay	1	
10	Bolt	2	
11	Stay	1	
12	Bolt	1	
13	Stay	1	

Continued on next page.



Step	Job/Part	Q'ty	Remarks
14	Bolt	2	
15	CDI unit	1	
16	Bolt	2	
17	Ignition coil	2	
18	Bracket	1	
19	Pipe	4	
20	Damper	4	
21	Grommet	1	


REMOVING THE POWER UNIT



Step	Job/Part	Q'ty	Remarks
1	Cotter pin	1	Not reusable
2	Washer	1	
3	Wavewasher	1	
4	Throttle cable 1	1	
5	Throttle cable 2	1	
6	Bolt (with washer)	6	
7	Power unit	1	
8	Dowel pin	2	
9	Gasket	1	Not reusable


MAGNET BASE AND CONTROL LEVER

REMOVING THE MAGNET BASE AND MAGNET CONTROL LEVER



Step	Job/Part	Q'ty	Remarks
1	Clamp	1	
2	Joint link	1	
3	Bolt	4	
4	Magnet base	1	
5	Screw	2	
6	Change coil	1	
7	Screw	2	
8	Lighting coil	1	
9	Screw	4	
10	Pulser coil	2	
11	Screw	4	
12	Magnet base retainer 2	1	
13	Magnet base retainer 1	1	


Continued on next page.




Step	Job/Part	Q'ty	Remarks
14	Magnet base friction plate	1	
15	Joint link	1	
16	Bolt (with washer)	1	
17	Collar	1	
18	Magneto control lever	1	
19	Bolt (with washer)	1	
20	Throttle cable stay	1	
21	Bolt (with washer)	1	
22	Collar	1	
23	Arm	1	

INTAKE MANIFOLD AND REED VALVES

REMOVING THE INTAKE MANIFOLD AND REED VALVES




Step	Job/Part	Q'ty	Remarks
1	Bolt (with washer)	1	
2	Bolt (with washer)	2	
3	Clamp (Fuel hose)	1	
4	Bolt (with washer)	6	
5	Intake manifold	1	
6	Intake manifold gasket	1	Not reusable
7	Reed valve	1	
8	Gasket	1	Not reusable



CHECKING THE REED VALVES


1. Check:
 - Reed valve ①
Cracks/damage → Replace.



2. Measure:
 - Valve bending ②
Out of specification → Replace.




Valve bending limit
0.2 mm (0.008 in)



3. Measure:
 - Valve stopper height ③
Out of specification → Replace.



Valve stopper height
Standard:
3.46 - 3.50 mm (0.136 - 0.138 in)
for Sri Lanka:
4.20 - 4.60 mm (0.165 - 0.181 in)



INSTALLING THE INTAKE MANIFOLD

- Install:
- Intake manifold


- NOTE:**
- Tighten the intake manifold mounting bolts in two steps of torque.
 - Apply LOCTITE® No.572 on the bolts.




Intake manifold mounting bolt
1st: 4 N•m (0.4 kgf•m, 3.0 ft•lb)
2nd: 8 N•m (0.8 kgf•m, 5.9 ft•lb)

CYLINDER HEAD

REMOVING THE CYLINDER HEAD



Step	Job/Part	Q'ty	Remarks
1	Spark plug	2	
2	Hose	1	
3	Bolt (with washer)	3	
4	Thermostat cover	1	
5	Gasket	1	Not reusable
6	Plain washer	1	
7	Thermostat	1	
8	Bolt (with washer)	11	
9	Bolt (with washer)	2	
10	Cylinder head cover	1	
11	Head cover gasket	1	Not reusable
12	Cylinder head	1	
13	Cylinder head gasket	1	Not reusable




CHECKING THE CYLINDER HEAD

1. Check:
 - Combustion chamber
Carbon deposits → Clean.
 - Water jacket
Mineral deposits/rust → Clean.

CAUTION:


Do not scratch the contacting surface of the cylinder head and cylinder head cover.



2. Measure:
 - Cylinder head warpage
(use a straightedge and thickness gauge)
Out of specification → Resurface/
replace.



**Warpage limit
0.1 mm (0.004 in)**



Resurfacing steps

- (1) Place a 400 – 600 grit wet sandpaper on the surface plate.
- (2) Resurface the cylinder head by moving it in a figure-eight motion along the sandpaper.


NOTE:

Rotate the cylinder head several times to ensure an even surface.





CHECKING THE THERMOSTAT

1. Check:
 - Thermostat
Damage/stick → Replace.




2. Measure:
 - Valve opening temperature
 - Valve lift
 Out of specification → Replace.

	Water temperature	Valve lift
	Below 48 – 52°C (118 – 126°F)	0 mm (0 in)
	Above 60°C (140°F)	Min. 3 mm (0.12 in)



Measuring steps

- (1) Suspend the thermostat in a container filled with water.
- (2) Place a thermometer in the water.
- (3) Slowly heat the water.
- (4) While stirring the water, check that the thermostat opens at the specified temperature.



INSTALLING THE CYLINDER HEAD AND CYLINDER HEAD COVER

Install:

- Cylinder head (3) and cylinder head cover (1)


NOTE:

- Temporarily assemble; cylinder head cover (1), cylinder head cover gasket (2), cylinder head (3), and cylinder head gasket (4) in that order, and then install the assembled parts onto the crankcase.
- Apply LOCTITE® No.572 on the bolts.
- Tighten the cylinder head mounting bolts and nut in sequence and in two steps of torque.



Cylinder head mounting bolts

- 1st: 15 N·m (1.5 kgf·m, 11 ft·lb)
- 2nd: 30 N·m (3.0 kgf·m, 22 ft·lb)



INSTALLING THE THERMOSTAT

Install:

- Thermostat (1)
- Plain washer (2)
- Gasket (3)
- Thermostat cover (4)
- Bolt (5)

NOTE:

- Always use the new gasket.
- Tighten the bolts in sequence.




Thermostat cover bolts


- 8 N·m (0.8 kgf·m, 5.9 ft·lb)

EXHAUST COVER

REMOVING THE EXHAUST COVER



Step	Job/Part	Q'ty	Remarks
1	Bolt (with washer)	12	
2	Bolt (with washer)	3	
3	Exhaust outer cover	1	
4	Gasket	1	Not reusable
5	Exhaust inner cover	1	
6	Gasket	1	Not reusable




CHECKING THE EXHAUST COVER

Check:

- Exhaust inner cover
Cracks/damage → Replace.
Carbon deposits → Clean.
(use a round scraper)
- Exhaust outer cover
Cracks/damage → Replace.

CAUTION: _____

Do not scratch the fitting surfaces of the cylinder and exhaust cover.



INSTALLING THE EXHAUST COVER

Install:

- Exhaust cover


NOTE: _____

- Apply LOCTITE® No.572 on the bolts.
- Tighten the exhaust cover mounting bolts in sequence and in two steps of torque.






Exhaust cover mounting bolts
1st: 4 N·m (0.4 kgf·m, 3.0 ft·lb)
2nd: 8 N·m (0.8 kgf·m, 5.9 ft·lb)

**CRANKCASE
REMOVING THE CRANKCASE**



Step	Job/Part	Q'ty	Remarks
1	Bolt (with washer)	8	
2	Bolt (with washer)	2	
3	Crankcase	1	
4	Bolt (with washer)	1	
5	Oil seal housing	1	
6	O-ring	1	Not reusable
7	Oil seal	1	Not reusable
8	Oil seal	2	Not reusable



ASSEMBLING THE OIL SEAL HOUSING

- Install:
- Oil seal

	Needle bearing attachment ①
	90890-06608
	Ball bearing attachment..... ②
	90890-06633
	Driver rod L3..... ③
	90890-06652

NOTE: _____
 Apply Yamaha grease A (water resistant grease) on the oil seals.


INSTALLING THE CRANKCASE

1. Apply:
 - Gasket Maker®

Applying steps


- (1) Clean the matching surfaces of the crankcase and cylinder body.
- (2) Apply Gasket Maker® onto the matching surfaces of the cylinder body and the crankcase.
- (3) Also apply Gasket Maker® on the oil seal housing.

NOTE: _____
 Do not allow any sealant to overflow from the matching surfaces.



2. Install:
 - Oil seal housing ①

NOTE: _____
 Do not give any damage to the lip when installing the oil seal.



3. Install:
- Crankcase

NOTE:

- Apply LOCTITE[®] No.572 on the bolts.
- Tighten the crankcase mounting bolts in sequence and in two steps of torque.


**Crankcase mounting bolts**

1st: 15 N·m (1.5 kgf·m, 11 ft·lb)


2nd: 30 N·m (3.0 kgf·m, 22 ft·lb)

CRANKSHAFT AND CYLINDER BODY

REMOVING THE CRANKSHAFT AND CYLINDER BODY



Step	Job/Part	Q'ty	Remarks
1	Crankshaft	1	
2	Cylinder body	1	
3	Piston pin clip	4	
4	Piston pin	2	
5	Piston pin washer	4	
6	Small end bearing	68	34 pins/1set
7	Piston ring	4	
8	Piston	2	



CHECKING THE CYLINDER BODY

1. Check:
 - Cylinder inner surface
Score mark → Repair/replace.
(use #600 – 800 grit wet sandpaper)
 - Water jacket
Mineral deposits/rust/corrosion → Clean/replace.


CAUTION: _____

Do not scratch the contacting surfaces of the crankcase and cylinder head.

2. Check:
 - Exhaust passage
Cracks/damage → Replace.
Carbon deposits → Clean.
(use a round scraper)

CAUTION: _____

Do not scratch the contacting surfaces of the cylinder and exhaust cover.




3. Measure:
 - Cylinder bore "D"
(use a cylinder gauge)
Out of specification → Rebore/replace.




Cylinder gauge
90890-06759


NOTE: _____

Measure the cylinder bore diameter at three positions for both D1 and D2. Then, average the measurement.



	Standard	Wear limit
Cylinder bore diameter "D"	72.00 -72.02 mm (2.8346 – 2.8354 in)	72.10 mm (2.8386 in)
Taper limit "T"	–	0.08 mm (0.0031 in)
Out of round limit "R"	–	0.05 mm (0.0020 in)
D = Maximum D1, D2, D3, D4, D5 or D6 T = (Maximum D1 or D2) – (Minimum D5 or D6) R = Maximum (D1 – D2) or (D3 – D4) or (D5 – D6)		


A: 15 mm (0.59 in) below the cylinder top
 B: 25 mm (0.98 in) above the exhaust port
 C: 100 mm (3.94 in) below the scavenging port




CHECKING THE PISTON

1. Check:
 - Piston wall
Wear/scratch/damage → Replace.
2. Check:
 - Piston head
 - Piston ring groove
Carbon deposits → Clean.

CAUTION: _____
 Take care not to scratch or cut the aluminum surface.






3. Measure:

- Piston diameter
(use an outside micrometer)
Out of specification → Replace.

	Outside micrometer 90890-03008
--	--

	Measuring point "H"	Piston diameter
Standard	10.0 mm (0.3937 in)	71.94 – 71.96 mm (2.8323 – 2.8331 in)
Over size piston diameter:		
1: 72.25 mm (2.8445 in)		
2: 72.50 mm (2.8543 in)		

NOTE: _____
When measuring the piston diameter, position the micrometer in relation to the piston pin hole as shown.






CALCULATING THE PISTON-TO-CYLINDER CLEARANCE

Calculate:

- Piston-to-cylinder clearance.
Out of specification → Replace the piston and piston rings, the cylinder or both.

Piston-to-cylinder clearance	=	Cylinder bore diameter	-	Piston diameter
------------------------------	---	------------------------	---	-----------------

	Piston-to-cylinder clearance 0.060 – 0.065 mm (0.0024 – 0.0026 in)
--	---



CHECKING THE PISTON PINS AND SMALL-END BEARINGS

1. Check:

- Piston pin
 - Small-end bearing
- Heat discoloration → Replace.
Damage/scratches → Replace.

2. Measure:

- Piston pin outside diameter
(use an outside micrometer)
Out of specification → Replace.

	Outside micrometer 90890-03006
--	---



	Piston pin outside diameter 19.895 – 19.900 mm (0.7833 – 0.7835 in)
--	--

3. Measure:

- Piston pin boss inside diameter
(use an inside micrometer)
Out of specification → Replace.

	Inside micrometer 90890-03010
--	--

	Piston pin boss inside diameter 19.904 - 19.915 mm (0.7836 - 0.7841 in)
--	--



4. Check:

- Free play (when piston pin is in place of the piston).

There should be no noticeable play.
Free play exists → Replace the pin and/or piston.


CHECKING THE PISOTN RINGS

NOTE:

- Before checking the piston rings, be sure to check the cylinder body.
- Piston rings should be replaced as a set (per piston).

1. Check:


- Piston ring
Broken/damage → Replace.




2. Measure:

- Piston ring end gap (a)
(use a thickness gauge)
Out of specification → Replace.

	Piston ring end gap
	0.20 - 0.35 mm (0.0079 - 0.0137 in)
	Piston ring end gap limit
	0.35 mm (0.014 in)
	Measuring point "H"
	15 mm (0.591 in)



NOTE: _____
 Push the piston ring into the cylinder with the piston crown.




3. Measure:
- Piston ring side clearance (b)
 (use a thickness gauge)
 Out of specification → Replace.



Piston ring side clearance

- Top: 0.03 - 0.05 mm
 (0.0012 - 0.0020 in)
- 2nd: 0.03 - 0.07 mm
 (0.0012 - 0.0028 in)

NOTE: _____
 When measuring the piston ring side clearance, the outside of the piston ring should be flush with the piston wall.






CHECKING THE CRANKSHAFT

1. Measure:
- Crank width
 (use the digital caliper)
 Out of specification →
 Repair/replace.



- Crank width (a)**
 56.90 - 56.95 mm
 (2.2401 - 2.2421 in)
- Crank width (b)**
 153.7 - 154.0 mm
 (6.0512 - 6.0630 in)
- Crank width (c)**
 39.9 - 40.1 mm
 (1.5709 - 1.5787 in)



2. Measure:

- Runout

(Use a crank stand alignment and dial gauge.)

Out of specification →
Repair/replace.



Crank stand alignment
90890-03107
Dial gauge set
90890-01252



Runout limit ^d
0.03 mm (0.0012 in)

3. Measure:

- Connecting rod side clearance

(Use a thickness gauge.)

Out of specification →
Repair/replace.



Connecting rod side clearance ^e
0.2 - 0.7 mm (0.0079 - 0.0276 in)


4. Measure:

- Axial play

Out of specification →
Repair/replace.



Maximum axial play ^f
2.0 mm (0.079 in)




5. Check:
 - Crankshaft bearings
Abnormal noise/damage / roughness → Replace.

CAUTION: _____

Do not use compressed air to spin the bearings dry. This causes damage to the bearing surfaces.

NOTE: _____

Do not reuse the bearing, always replace it with a new one.



INSTALLING THE PISTON AND PISTON RINGS

Install:


- 2nd piston ring
- Top piston ring

CAUTION: _____

- Install the piston ring with the T mark facing up.
- Align each piston ring end gap with its respective locating pin.
- After installing the piston rings, check that they move smoothly.

NOTE: _____

Apply Yamaha 2-stroke motor oil on the piston ring and piston ring groove.



INSTALLING THE CRANKSHAFT AND PISTON

1. Install:

- Small-end bearing



Needles per piston
34 pieces




Small-end bearing installer
90890-06527

2. Install:

- Piston

Installing steps

- (1) Assemble the washer (a) and the piston to the crankshaft.
- (2) Push out the small-end bearing installer with piston pin.
- (3) Install circlip.





CAUTION: _____

Install the piston with "UP" mark on the piston crown facing towards the flywheel side.

NOTE: _____

Apply Yamaha 2-stroke motor oil on the small-end bearing and piston pin.






3. Install:

- Cylinder body ①
- Crankshaft and piston ②
- Dowel pin ③

NOTE:

- Apply Yamaha 2-stroke motor oil to each cylinder wall and piston and their ring grooves.
- Coat all the crankshaft bearings with the engine oil.
- The crankshaft bearing locating pin should fit into the slit in the cylinder.
- The UP mark on the piston crown should be on the flywheel side.



CHECKING THE ANODE

Check:


- Anode ①
Wear → Replace.
Corrosion → Sand.

NOTE:

When it is reduced to the size of one-third (1/3), replace it.


CRANK SHAFT

DISASSEMBLING THE CRANKSHAFT





Step	Job/Part	Q'ty	Remarks
1	O-ring	1	Not reusable
2	Oil seal	1	Not reusable
3	Bearing	1	
4	Collar	1	
5	Crank 1	1	
6	Crank pin	2	
7	Washer	4	
8	Connecting rod	2	
9	Bearing	2	
10	Crank 2	1	
11	Bearing	1	
12	Labyrinth seal	1	
13	Clip	1	

Continued on next page.



Step	Job/Part	Q'ty	Remarks
14	Crank 3	1	
15	Crank 4	1	
16	Bearing	1	
17	Washer	1	



REMOVING THE CRANKSHAFT BEARING


Upper bearing

1. Remove:
 - Upper bearing ①
Remove the upper bearing with hands.
2. Remove:
 - Collar

	Pressure pin B ①
	90890-02390
	Bearing separator ②
	90890-06534

NOTE:

- By forcing the pressure pin B ① with a hydraulic press, remove the bearing.
- When forcing out the crank pin, use care so that the crankshaft does not fall off.
- The upper bearing and the collar should always be replaced as a set.
- Once removed, do not reuse the collar. Always replace it with a new one.



Lower bearing

Remove:

- Lower bearing ①


	Pressure pin B ①
	90890-02390
	Bearing separator ②
	90890-06534

NOTE:

- By forcing the pressure pin B ① with a hydraulic press, remove the bearing.
- When forcing out the crank pin, use care so that the crankshaft does not fall off.

CAUTION:

- Apply pressure to the pressure pin B ① slowly.
- Hold the pressure pin in line with the press screw spindle.




Crank 1 and crank 4 removal

Remove:

- Crank 1
- Crank 4




Plate A.....	①
90890-02386	
Pressure pin B	ⓐ
90890-02390	




Removing steps

- (1) By forcing the pressure pin B ⓐ with a hydraulic press, remove the crank pin.
- (2) When forcing out the crank pin, use care so that the crankshaft does not fall off.
- (3) To remove crank 4, follow the same procedure.



CAUTION:

- Apply pressure to the pressure pin B ⓐ slowly.
- Hold the pressure pin B ⓐ in line with the press screw spindle.




Crank 2 and crank 3 removal

1. Remove:

- Crank 2
- Crank 3




Support.....	①
90890-02394	
Pressure pin B	ⓐ
90890-02390	




NOTE:

- Place the pressure pin B ⓐ on the crank 2 center shaft ⓑ, and force it out using a press.
- When forcing out the crank pin, use care so that the crank does not fall off.




CAUTION:

- Apply pressure to the pressure pin B (a) slowly.
- Hold the pressure pin B (a) in line with the press screw spindle.



2. Remove:

- Labyrinth seal (1)
- Clip (2)




3. Remove:

- Bearing

Removing steps


(1) Remove roller bearing (outer race)



(2) Remove roller bearing (inner race) using hydraulic press.



**Bearing separator
90890-06534**



Crank pin removal

Remove:

- Crank pin

	Plate A.....①
	90890-02386
	Pressure pin B②
	90890-02390


Removing steps

- (1) By forcing the pressure pin B ② with a hydraulic press, remove the crank pin.
- (2) Remove the crank pins from Crank 2 and Crank 3.
- (3) Pressure pin should be pressed down straight.

ASSEMBLING THE CRANKSHAFT

CAUTION:

- When reassembling the crankshaft, wash all component parts in suitable cleaning solvent.
- Always use new bearings and crank pins.




Fitting the crank pin

(to the crank 2 and crank 4)

1. Install:
 - Spacer B ① (to crank pin hole)
 - Crank 2 ③


	Spacer B①
	90890-02396
	Support.....②
	90890-02394



2. Install:
 - Crank pin ④ (new)

NOTE:

- Insert the crank pin into the pin hole by tapping it with a copper hammer ⑤.
- Apply Yamaha 2-stroke motor oil on the crank pin.



3. Press-fit:


- Crank pin (4)

NOTE:

- Don't apply force in excess of 5 tons.
- The crank pin should be press-fitted into both crank 2 and crank 4.

CAUTION:


Take care so that the crank pin (4) is set squarely to the crank web (6).



Assembling cranks 1 and 2,3 and 4

1. Install (special service tools):


- Flange (1)
- Body (2)
- Bolt
- Washer
- Bushing-5 (D25) (3)
- Height ring-13 (H57) (4)



NOTE:


Align the cut in the height ring (a) with cut in the body (b).

	Flange (1)
	90890-02351
	Body (2)
	90890-02352
	Bolt
	90890-02353
Washer	
90890-02354	
Bushing-5 (D25) (3)	
90890-02359	
Height ring-13 (H57) (4)	
90890-02379	



2. Install:
- Crank 2 (5) or crank 4
 - Washer (6)
 - Bearing (7)


NOTE: _____
Apply Yamaha 2-stroke motor oil on the washer and big end bearing.



3. Install:
- Connecting rod (8)
 - Washer (9)


CAUTION: _____

- The model No. (C) facing upward (crank 1 or crank 3 side).
- Apply Yamaha 2-stroke motor oil on the connecting rod and washer.



4. Install (special service tools):
- Pressure plate (1)
 - Bushing-14 (for crank 1) or Bushing-12 (for crank 3) (2)
5. Install:
- Crank 1 (3) or crank 3 (on the bushing)


	Bushing-14 (for crank 1) (2) 90890-02419
	Bushing-12 (D35) (for crank 3) (2) 90890-02366
	Pressure plate (1) 90890-02384



6. Install:
- Crank 1 (1) or crank 3 (use pressure plate)

NOTE: _____

- Align the crank pin hole (2) with the crank pin (3) fitted to crank 2 or crank 4.
- Apply Yamaha 2-stroke motor oil on the crank 1 or crank 3.




7. Press-fit:
- Crank 1 or crank 3

	Press body ④ 90890-02385
--	---

CAUTION: _____


- Be sure to press-fit the crank 1 or crank 3 squarely onto the crank pin.
- Apply Yamaha 2-stroke motor oil on the crank pin.



8. Measure:
- Crank width ①
- Use the digital caliper.
Out of specification → Reassemble/ repress.


	Digital caliper 90890-06704
--	--

Measurements should be made at ① to ⑤.



	Crank width ① 56.90 - 56.95 mm (2.2401 - 2.2421 in)
--	--

NOTE: _____
If either distance is out of specification, reassemble or repress the crankshaft.



9. Measure:

- Connecting rod side clearance (e)
(Use the thickness gauge.)
Out of specification → Reassemble.




Thickness gauge (mm)
90890-06054



Connecting rod side clearance (e)
0.2 - 0.7 mm (0.0079 - 0.0276 in)

NOTE:

If side clearance exceeds tolerance, disassemble the crankshaft and replace any worn parts.



10. Install:

- Roller bearing (on the crank 2) (1)

11. Press-fit:

- Roller bearing (inner race) (2)

NOTE:

- Position the roller bearing with the stamped mark (a) facing upward and press-fit it until it contacts the crank 2.
- Apply Yamaha 2-stroke motor oil on the roller bearing.





Plate A.....(b)
90890-02386
Bearing pressure B.....(c)
90890-02392

CAUTION:

Be sure to press-fit the roller bearing squarely onto crank 2.

12. Install:

- Roller bearing (outer race) (3)




Connecting the No. 1 cylinder crankshaft to the No. 2 cylinder crankshaft

1. Install:

- Labyrinth seal ① (to crank 3 ②)
- Clip ③

	Plate A 90890-02386
--	--------------------------------------

NOTE: _____
 Apply Yamaha 2-stroke motor oil on the labyrinth seal.




2. Install:

- Plate B ① (between crank 1 and crank 2)
- Crank 1 and crank 2 ② (on the crank 3 ③)

	Plate B.....① 90890-02387
--	--


CAUTION: _____

- Align the match marks (a) on crank 3 and 2.
- Apply Yamaha 2-stroke motor oil on the crank 3 and 2.



3. Press-fit:


- Crank 2 and crank 3 (apply a force of 7 ton)



	Height ring-13 (H57)① 90890-02379 Press body② 90890-02385
--	--

CAUTION:

Be sure to press-fit the No. 1 crank squarely onto No. 2 crank.



INSTALLING CRANKSHAFT BEARING

Lower bearing (for crank 4)


1. Install:
 - Bearing ① (to crank 4 ②)



Bearing pressure B
90890-02392

CAUTION:

- Install the bearing with its stamped mark ① facing upward.
- Apply Yamaha 2-stroke motor oil on the bearing.
- Be sure to press-fit the ball bearing squarely onto crank 4.



Upper bearing (for crank 1)


1. Install:
 - Collar ③




Bushing-5 (D25) ①
90890-02359
Bearing pressure C..... ②
90890-02393

2. Install:
 - Upper bearing ④ (to crank 1)
 - Install the upper bearing with hands.

NOTE:
Apply Yamaha grease A (water resistant grease) on the collar and upper bearing.





Run-out check

1. Measure:
 - Runout

Use the crank stand alignment ① and digital gauge ②. Out of specification → Adjust.

	<p>Crank stand alignment 90890-03107 Digital gauge set 90890-01252</p>
--	---

	<p>Runout limit 0.03 mm (0.0012 in)</p>
--	--

NOTE: _____
 If the dial gauge reading is 0.03 mm (0.0012 in) or more, adjust the crankshaft so that the reading is less than 0.03 mm (0.0012 in). Use a copper hammer, as shown.

2. Measure:
 - Axial play

Out of specification → Repair/replace.

	<p>Maximum axial play "f" 2.0 mm (0.079 in)</p>
--	--

CHECKING THE CRANKSHAFT

Refer to "CHECKING THE CRANKSHAFT" on page 5-34.

CHAPTER 6 LOWER UNIT

LOWER UNIT	6-1
REMOVING THE LOWER UNIT	6-1
REMOVING THE PROPELLER	6-3
CHECKING THE PROPELLER	6-3
INSTALLING THE PROPELLER	6-3
INSTALLING THE TRIM TAB	6-3
WATER PUMP	6-4
REMOVING THE WATER PUMP	6-4
CHECKING THE WATER PUMP HOUSING	6-5
CHECKING THE IMPELLER AND INSERT CARTRIDGE	6-5
CHECKING THE WOODRUFF KEY	6-5
INSTALLING THE IMPELLER AND WATER PUMP HOUSING	6-5
SHIFT ROD	6-6
REMOVING THE SHIFT ROD	6-6
PROPELLER SHAFT HOUSING	6-7
REMOVING THE PROPELLER SHAFT HOUSING	6-7
DISASSEMBLING THE PROPELLER SHAFT HOUSING	6-8
DISASSEMBLING THE PROPELLER SHAFT	6-9
REMOVING THE PROPELLER SHAFT HOUSING	6-10
DISASSEMBLING THE PROPELLER SHAFT HOUSING	6-10
CHECKING THE REVERSE GEAR	6-11
CHECKING THE BEARING	6-11
CHECKING THE PROPELLER SHAFT HOUSING	6-11
ASSEMBLING THE PROPELLER SHAFT HOUSING	6-12
CHECKING THE DOG CLUTCH	6-13
CHECKING THE PROPELLER SHAFT	6-13
CHECKING THE SHIFT PLUNGER	6-13
CHECKING THE SHIFT SPRING	6-13
DRIVE SHAFT	6-14
REMOVING THE DRIVE SHAFT	6-14
REMOVING THE DRIVE SHAFT	6-15
REMOVING THE DRIVE SHAFT BEARING	6-15
DISASSEMBLING THE FORWARD GEAR	6-15
CHECKING THE PINION AND FORWARD GEAR	6-16
CHECKING THE DRIVE SHAFT	6-16
CHECKING THE BEARINGS	6-16
ASSEMBLING THE FORWARD GEAR	6-16
INSTALLING THE DRIVE SHAFT BEARING	6-16
INSTALLING THE DRIVE SHAFT	6-17
LOWER CASE	6-18
DISASSEMBLING THE LOWER CASE	6-18

CHECKING THE DRIVE SHAFT SLEEVE 6-19
CHECKING THE NEEDLE BEARING 6-20
ASSEMBLING THE LOWER CASE 6-20


SHIMMING 6-21
 SELECTING THE PINION SHIMS 6-22
 SELECTING THE FORWARD GEAR SHIMS 6-24
 SELECTING THE REVERSE GEAR SHIMS 6-26

BACKLASH 6-28
 MEASURING THE FORWARD GEAR BACKLASH 6-28
 MEASURING THE REVERSE GEAR BACKLASH 6-29




LOWER UNIT

REMOVING THE LOWER UNIT




Step	Job/Part	Q'ty	Remarks
1	Cotter pin	1	Not reusable
2	Castle nut	1	
3	Washer	1	
4	Spacer	1	
5	Propeller	1	
6	Spacer	1	
7	Nut	1	
8	Shift connector	1	
9	Bolt (with washer)	1	
10	Trim tab	1	
11	Bolt	1	
12	Anode	1	
13	Screw	2	

Continued on next page.



Step	Job/Part	Q'ty	Remarks
14	Nut	2	
15	Water inlet cover 1	1	
16	Water inlet cover 2	1	
17	Gear oil level check screw	1	
18	Gasket	1	
19	Gear oil drain screw	1	
20	Gasket	1	
21	Bolt	4	Transom S, L
22	Nut	4	Transom Y
23	Lower unit	1	
24	Pin	2	
25	Extension	1	Transom Y
26	Pin	2	Transom Y



REMOVING THE PROPELLER

Remove:

- Propeller

⚠ WARNING

Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.

CHECKING THE PROPELLER

Check:

- Blades
- Splines
- Bent/cracks/damage/wear → Replace.
- Bushing
- Slippage → Replace.

INSTALLING THE PROPELLER

Install:

- Propeller

⚠ WARNING

Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.

NOTE:

If the groove in the propeller nut is not aligned with the cotter pin hole, tighten the nut further until they are aligned.


INSTALLING THE TRIM TAB

Install:


- Trim tab

NOTE:

- To ease installation, mark the original position of the trim tab.
- Steering load varies depending on the trim tab position as installed.



**WATER PUMP
REMOVING THE WATER PUMP**



Step	Job/Part	Q'ty	Remarks
1	Bolt	4	
2	Plate	1	Transom S, L
3	Water tube	1	
4	O-ring	1	Not reusable
5	O-ring	1	Not reusable
6	Water seal rubber	1	
7	Water pump housing	1	
8	Insert cartridge	1	
9	O-ring	1	Not reusable
10	Impeller	1	
11	Impeller plate	1	
12	Dowel pin	1	
13	Woodruff key	1	



CHECKING THE WATER PUMP HOUSING

Check:

- Water pump housing
Cracks/damage → Replace.

CHECKING THE IMPELLER AND INSERT CARTRIDGE



Check:

- Impeller
- Insert cartridge
Cracks/damage/wear → Replace.

CHECKING THE WOODRUFF KEY

Check:

- Woodruff key
Damage/wear → Replace.



INSTALLING THE IMPELLER AND WATER PUMP HOUSING

Install:

- Impeller ①
- Insert cartridge ②
- Water pump housing ③


NOTE:

- When installing the insert cartridge ②, align its projection with the hole in the water pump housing ③.
- When installing the water pump housing, turn the drive shaft clockwise.
- Apply Yamaha grease A (water resistant grease) on the impeller ①, the insert cartridge ②, and the water pump housing ③.




SHIFT ROD

REMOVING THE SHIFT ROD




Step	Job/Part	Q'ty	Remarks
	Impeller plate		Refer to "WATER PUMP" on page 6-4.
1	Bolt	2	
2	Bracket	1	
3	Plate	1	
4	O-ring	1	Not reusable
5	Oil seal housing	1	
6	Lower casing packing	1	Not reusable
7	Dowel pin	1	
8	Shift rod	1	
9	Rubber seal	1	
10	Oil seal	2	



PROPELLER SHAFT HOUSING


REMOVING THE PROPELLER SHAFT HOUSING



Step	Job/Part	Q'ty	Remarks
	Gear oil		Refer to "CHANGING AND CHECKING THE GEAR OIL" on page 3-19.
	Shift rod assembly		Refer to "SHIFT ROD" on page 6-6.
1	Bolt	2	
2	Propeller shaft housing	1	
3	Washer	1	
4	Propeller shaft	1	




DISASSEMBLING THE PROPELLER SHAFT HOUSING





Step	Job/Part	Q'ty	Remarks
1	O-ring	1	Not reusable
2	O-ring	2	Not reusable
3	Reverse gear	1	
4	Reverse gear shim	*	
5	Ball bearing	1	
6	Oil seal	2	
7	Needle bearing	1	
8	Propeller shaft housing	1	
9	Washer	1	

* As required

DISASSEMBLING THE PROPELLER SHAFT



Step	Job/Part	Q'ty	Remarks
1	Shift plunger	1	
2	Cross pin ring	1	
3	Cross pin	1	
4	Spring	1	
5	Dog clutch	1	
6	Propeller shaft	1	




REMOVING THE PROPELLER SHAFT HOUSING

Remove:

- Propeller shaft housing



- Bearing housing puller claw ①**
90890-06546
- Stopper guide plate ②**
90890-06501
- Center bolt ③**
90890-06504




DISASSEMBLING THE PROPELLER SHAFT HOUSING



1. Remove:

- Reverse gear



- Bearing separator ①**
90890-06534
- Stopper guide plate ②**
90890-06501
- Stopper guide stand ③**
90890-06538
- Bearing puller ass'y ④**
90890-06535






2. Remove:
- Ball bearing

	Stopper guide plate①
	90890-06501
	Stopper guide stand②
	90890-06538
	Bearing puller ass'y③
	90890-06535

NOTE: _____
Do not reuse the bearing. Always replace it with a new one.



3. Remove:
- Oil seal
 - Needle bearing

	Driver rod L3①
	90890-06652
	Needle bearing attachment②
	90890-06615

CHECKING THE REVERSE GEAR


- Check:
- Teeth
 - Dogs
- Damage/wear → Replace.


CHECKING THE BEARING

- Check:
- Bearing
- Pitting/rumbling → Replace.

CHECKING THE PROPELLER SHAFT HOUSING

- Check:
- Propeller shaft housing
- Cracks/damage → Replace.






ASSEMBLING THE PROPELLER SHAFT HOUSING

1. Install:
 - Needle bearing

	Needle bearing position (a) 31.0 - 31.5 mm (1.24 in)
--	---

	Driver rod-SS (1) 90890-06604
	Needle bearing attachment (2) 90890-06615
	Bearing depth plate (3) 90890-06603

NOTE: _____
Install the needle bearing with its manufacturer's marks (b) facing up. Apply Yamaha motor oil.







2. Install:
 - Oil seals

	Oil seal position (a) 6.0 - 6.5 mm (0.26 in)
--	---

	Driver rod L3 (1) 90890-06652
	Needle bearing attachment (2) 90890-06611

CAUTION: _____

It is essential that the oil seals are installed correctly (as shown in the illustration). If they are installed the wrong way round, oil or water will leak out.



3. Install:

- Reverse gear ①
- Reverse gear shim(s) ②
- Ball bearing ③
- Propeller shaft housing ④

NOTE:

- Before press-fitting the ball bearing, install the reverse gear shim(s).
- Install the ball bearing with its manufacturer's marks (a) facing the reverse gear.

CAUTION:

Place a suitable base under the gear to protect it from damages.

CHECKING THE DOG CLUTCH

Check:

- Dog clutch
Damage/wear → Replace.

CHECKING THE PROPELLER SHAFT

Check:

- Propeller shaft
Damage/wear → Replace.

	Maximum runout 0.1 mm (0.004 in)
--	---

CHECKING THE SHIFT PLUNGER

Check:


- Shift plunger
Wear → Replace.

CHECKING THE SHIFT SPRING



Check:

- Spring
Wear → Replace.

**DRIVE SHAFT
REMOVING THE DRIVE SHAFT**



Step	Job/Part	Q'ty	Remarks
	Propeller shaft housing		Refer to "PROPELLER SHAFT HOUSING" on page 6-7.
1	Pinion gear nut	1	
2	Pinion gear	1	
3	Drive shaft	1	
4	Forward gear	1	
5	Drive shaft bearing	1	



REMOVING THE DRIVE SHAFT


Remove:

- Pinion gear nut
- Drive shaft

	Drive shaft holder 3 ① 90890-06517
---	---

Removing Steps


- (1) Apply 12mm wrench on the pinion gear nut.
- (2) Support the lower case with rags to hold the wrench in position.
- (3) Turn the drive shaft holder ①.




REMOVING THE DRIVE SHAFT BEARING

Remove:

- Taper roller bearing

	Bearing inner race attachment ① 90890-06643
---	---



DISASSEMBLING THE FORWARD GEAR

Remove:

- Taper roller bearing ①
- Forward gear ②

	Bearing separator 90890-06534
---	--

CAUTION:


Place a suitable base on the gear axle to prevent damage to the top of the axle.



CHECKING THE PINION AND FORWARD GEAR

Check:

- Teeth
 - Dogs
- Damage/wear → Replace.




CHECKING THE DRIVE SHAFT

Check:

- Drive shaft
- Damage/wear → Replace.




**Maximum runout
0.5 mm (0.020 in)**



CHECKING THE BEARINGS

Check:

- Bearings
- Pitting/rumbling → Replace.




ASSEMBLING THE FORWARD GEAR

Install:

- Forward gear
- Taper roller bearing



**Bearing inner race attachment①
90890-06644**




INSTALLING THE DRIVE SHAFT BEARING

Install:

- Drive shaft bearing




**Bearing inner race attachment①
90890-06645**




INSTALLING THE DRIVE SHAFT

1. Install:
 - Forward gear
(with the tapered roller bearing)
 - Drive shaft
(with the tapered roller bearing)
 - Pinion gear

	Drive shaft holder 3 ① 90890-06517
---	---

2. Tighten:
 - Pinion gear nut

	Pinion gear nut 50 Nm (5.0 kgf·m, 37 ft·lb)
---	--




Tightening steps

- (1) Apply 12mm wrench on the pinion gear nut.
- (2) Support the lower case with rags to hold the wrench in position.
- (3) Turn the drive shaft holder ①.

NOTE: _____
Tighten the pinion gear nut with the same tools that were used for removal.


LOWER CASE

DISASSEMBLING THE LOWER CASE




Step	Job/Part	Q'ty	Remarks
1	Drive shaft bearing outer race	1	
2	Pinion gear shim	*	
3	Drive shaft sleeve	1	
4	Needle bearing	1	
5	Tapered roller bearing outer race	1	
6	Forward gear shim	*	

* As required




1. Remove:
 - Drive shaft bearing outer race
 - Pinion gear shim(s)

	Stopper guide plate① 90890-06501
	Bearing puller ass'y② 90890-06535
	Stopper guide stand③ 90890-06538




2. Remove:
 - Drive shaft needle bearing and sleeve

	Driver rod L3① 90890-06652
	Needle bearing attachment② 90890-06615




3. Remove:
 - Forward gear bearing outer race and shim (s)

	Stopper guide plate① 90890-06501
	Bearing puller ass'y② 90890-06535



CHECKING THE DRIVE SHAFT SLEEVE


- Check:
- Drive shaft sleeve
Damage/wear → Replace.



CHECKING THE NEEDLE BEARING

Check:

- Needle bearing
- Pitting/rumbling → Replace.




ASSEMBLING THE LOWER CASE

1. Install:

- Forward gear shim(s) ①
- Tapered roller bearing outer race ②

	Bearing outer race attachment 90890-06622 Driver rod LL 90890-06605
--	--



2. Install:


- Drive shaft needle bearing

	Depth (a) 185.0 - 186.0 mm (7.32 in)
--	---

	Needle bearing attachment ① 90890-06615 Driver rod SL ② 90890-06602 Bearing depth plate ③ 90890-06603
--	--

NOTE: _____

Install the drive shaft needle bearing with the manufacturer's marks facing up.



3. Install:


- Pinion gear shim(s) (a)
- Drive shaft bearing outer race (b)




	Driver rod LS ① 90890-06606 Bearing outer race attachment.... ② 90890-06628
--	--

SHIMMING

NOTE:

- There is no need to select shims when reassembling with the original case and inner parts.
- Shim calculations are required when reassembling with the original inner parts and a new case (the difference between the original inner parts and the new case).
- Measurements and adjustments are required when replacing the inner part(s).





SELECTING THE PINION SHIMS

NOTE: _____
 Select the shim thickness (T3) by using the specified measurement(s) and the calculation formula.

- Select:
- Shim thickness (T3)

Selecting steps

(1) Install the pinion height gauge, drive shaft and bearing (with bearing race).

	Pinion height gauge ① 90890-06702
	Drive shaft holder 3 ② 90890-06517


NOTE: _____

- Attach the pinion height gauge to the drive shaft so that the shaft is at the center of the hole.
- After the wing nuts contact the fixing plate, tighten them another 1/4 of a turn.

(2) Install the pinion gear and pinion gear nut.


	Pinion gear nut 50 N•m (5.0 kgf•m, 37 ft•lb)
---	---

(3) Measure (M).

	Digital caliper 90890-06704
---	--

NOTE: _____

- Measure the clearance between the pinion height gauge and the pinion, as shown.
- Perform the same measurement at three points on the pinion.
- Find the average of the measurements (M).
- When using the digital caliper, be sure to place it at right angles to the pinion. Otherwise, measurement will be incorrect.



(4) Calculate the pinion gear shim thickness (T3).

Pinion gear shim thickness (T3) =
 $M - 27 \text{ mm} - P/100 \text{ mm}$

NOTE:

- "P" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01 mm units. If the "P" mark is missing or unreadable, assume a "P" value of "0", and check the backlash when the unit is assembled.
- If the "P" mark is negative (-), then add the "P" value to the measurement.

Example:

If M is "28.30 mm" and "P" is "+5", then:

$$T3 = 28.30 \text{ mm} - 27 \text{ mm} - (+5)/100 \text{ mm}$$

$$= 1.3 \text{ mm} - 0.05 \text{ mm}$$

$$= 1.25 \text{ mm} (0.049 \text{ in})$$

If M is "28.24 mm" and "P" is "-3", then:

$$T3 = 28.24 \text{ mm} - 27 \text{ mm} - (-3)/100 \text{ mm}$$


$$= 1.24 \text{ mm} + 0.03 \text{ mm}$$

$$= 1.27 \text{ mm} (0.05 \text{ in})$$

(5) Select the pinion gear shim(s) (T3).

Calculated numeral at 1/100th place		Using shim
more than	or less	
1.10	1.20	1.2
1.20	1.30	1.3
1.30	1.40	1.4
1.40	1.50	1.5
1.50	1.60	1.6
1.60	1.70	0.7, 1.0
1.70	1.83	0.7, 1.1

Available shim thickness
 0.7, 1.0, 1.1, 1.2, 1.3, 1.4, 1.5 and 1.6 mm



SELECTING THE FORWARD GEAR SHIMS

NOTE:


Select the shim thickness (T1) by using the specified measurement(s) and the calculation formula.

Select:

- Shim thickness (T1)

Selecting steps


(1) Measure (M).




	Shimming plate ① 90890-06701
	Digital caliper ② 90890-06704


NOTE:

- Turn the tapered roller bearing outer race two or three times so that the rollers seat. Then, measure the height of the bearing, as shown.
- Perform the same measurement at three points on the tapered roller bearing outer race.
- Find the average of the measurements (M).
- When using the digital caliper, be sure to place it at right angles to the shimming plate. Otherwise, measurement will be incorrect.



(2) Calculate the forward gear shim thickness (T1).



	Forward gear shim thickness (T1) = 17.5 mm + F/100 mm - M
---	--

NOTE:

- "F" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01 mm units. If the "F" mark is missing or unreadable, assume an "F" value of "0", and check the backlash when the unit is assembled.
- If the "F" mark is negative (-), then subtract the "F" value from the measurement.

Example:


If M is "16.25 mm" and "F" is "+4", then:


$$\begin{aligned}
 T1 &= 17.5 \text{ mm} + (+4)/100 - 16.25 \text{ mm} \\
 &= 17.5 \text{ mm} + 0.04 - 16.25 \text{ mm} \\
 &= 1.29 \text{ mm (0.051 in)}
 \end{aligned}$$

If M is "16.26 mm" and "F" is "-3", then:

$$\begin{aligned}
 T1 &= 17.5 \text{ mm} + (-3)/100 - 16.26 \text{ mm} \\
 &= 17.5 \text{ mm} - 0.03 - 16.26 \text{ mm} \\
 &= 1.21 \text{ mm (0.048 in)}
 \end{aligned}$$

(3) Select the forward gear shim(s) (T1).

Calculated numeral at 1/100th place		Using shim
more than	or less	
1.00	1.10	1.0
1.10	1.20	1.1
1.20	1.30	1.2
1.30	1.40	1.3
1.40	1.50	1.4
 Available shim thickness 1.0, 1.1, 1.2, 1.3 and 1.4 mm		




SELECTING THE REVERSE GEAR SHIMS

NOTE: _____
 Select the shim thickness (T2) the specified measurement(s) and the calculation formula.

- Select:
- Shim thickness (T2)

Selecting steps


(1) Measure (M2).




	Shimming plate ① 90890-06701
	Digital caliper ② 90890-06704

- NOTE:** _____
- Measure the height of the gear as shown.
 - Perform the same measurement at three points on the gear.
 - Find the average of the measurements (M2).
 - When using the digital caliper, be sure to place it at right angles to the shimming plate. Otherwise, measurement will be incorrect.

(2) Calculate the reverse gear shim thickness (T2).



	Reverse gear shim thickness (T2) = 80 mm + R/100 - M2
---	--

- NOTE:** _____
- "R" is the deviation of the lower case dimension from standard. It is stamped on the anode mounting surface of the lower case in 0.01 mm units. If the "R" mark is missing or unreadable, assume a "R" value of "0", and check the backlash when the unit is assembled.
 - If the "R" mark is negative (-), then subtract the "R" value from the measurement.



Example:

If M2 is "78.79 mm" and "R" is "+5", then:


$$\begin{aligned}
 T2 &= 80 \text{ mm} + (+5)/100 - 78.79 \text{ mm} \\
 &= 80 \text{ mm} + 0.05 \text{ mm} - 78.79 \text{ mm} \\
 &= 1.26 \text{ mm (0.050 in)}
 \end{aligned}$$

If M2 is "78.75 mm" and "R" is "-3", then:

$$\begin{aligned}
 T2 &= 80 \text{ mm} + (-3)/100 - 78.75 \text{ mm} \\
 &= 80 \text{ mm} - 0.03 \text{ mm} - 78.75 \text{ mm} \\
 &= 1.22 \text{ mm (0.048 in)}
 \end{aligned}$$

(3) Select the reverse gear shim(s) (T2).

Calculated numeral at 1/100th place		Using shim
more than	or less	
1.00	1.10	1.0
1.10	1.20	1.1
1.20	1.30	1.2
1.30	1.32	1.3


	Available shim thickness 1.0, 1.1, 1.2 and 1.3 mm
--	--



BACKLASH

NOTE:

- Do not install the water pump components when measuring the backlash.
- Measure both the forward and reverse gear backlashes.
- If both the forward and reverse gear backlashes are larger than specification, the pinion gear may be too high.
- If both the forward and reverse gear backlashes are smaller than specification, the pinion gear may be too low.



MEASURING THE FORWARD GEAR BACKLASH



1. Measure:
 - Forward gear backlash
 Out of specification → Adjust.



Forward gear backlash
0.31 - 0.72 mm (0.012 - 0.028 in)

Measuring steps


- (1) Set the shift rod into the neutral position.
- (2) Install the propeller shaft housing puller so it pushes against the propeller shaft.



Bearing housing puller claw ①
90890-06564
Stopper guide plate..... ②
90890-06501
Center bolt..... ③
90890-06504



Center bolt
5 N·m (0.5 kgf·m, 3.7 ft·lb)



(3) Install the backlash indicator onto the drive shaft (16mm (0.63 in) diameter).

	Backlash indicator (4) 90890-06706
--	---

(4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.

	Magnet base plate (5) 90890-07003
	Dial gauge set (6) 90890-01252
	Magnet base (7) 90890-06705

(5) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.

2. Adjust:

- Forward gear backlash
Remove or add shim(s).

	Forward gear backlash	Shim thickness
	Less than 0.31 mm (0.012 in)	To be decreased by $(0.52 - M) \times 0.49$
	More than 0.72 mm (0.028 in)	To be increased by $(M - 0.52) \times 0.49$
Available shim thickness: 1.0, 1.1, 1.2, 1.3 and 1.4 mm		




M : Measurement

MEASURING THE REVERSE GEAR BACKLASH

1. Measure:

- Reverse gear backlash
Out of specification → Adjust.

	Reverse gear backlash 0.93 - 1.65 mm (0.037 - 0.065 in)
--	--



Measuring steps


- (1) Set the shift rod into the neutral position.
- (2) Load the reverse gear by installing the propeller without the collar ①, and then tighten the propeller nut.

	Propeller nut 5 N·m (0.5 kgf·m, 3.7 ft·lb)
---	---

- (3) Install the backlash indicator onto the drive shaft (16 mm (0.63 in) diameter).

	Backlash indicator ② 90890-06706
---	---


- (4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.

	Magnet base plate ③ 90890-07003
	Dial gauge set ④ 90890-01252
	Magnet base ⑤ 90890-06705

- (5) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.

2. Adjust:

- Reverse gear backlash
Remove or add shim(s).


	Reverse gear backlash	Shim thickness
	Less than 0.93 mm (0.037 in)	To be decreased by (1.29 - M) × 0.49
	More than 1.65 mm (0.065 in)	To be increased by (M - 1.29) × 0.49
Available shim thickness 1.0, 1.1, 1.2 and 1.3 mm		

M : Measurement

CHAPTER 7 BRACKET UNIT


STEERING HANDLE	7-1
DISASSEMBLING THE STEERING HANDLE	7-1
CHECKING THE STEERING HANDLE	7-3
ASSEMBLING THE STEERING HANDLE	7-3
BOTTOM COWLING	7-5
REMOVING THE BOTTOM COWLING	7-5
CHECKING THE BOTTOM COWLING	7-7
INSTALLING THE BOTTOM COWLING	7-7
SHIFT ACTUATOR	7-8
DISASSEMBLING THE SHIFT ACTUATOR	7-8
REMOVING THE BRACKET	7-11
CHECKING THE SHIFT ACTUATOR	7-11
ASSEMBLING THE SHIFT ACTUATOR	7-12
UPPER CASE	7-14
REMOVING THE UPPER CASE	7-14
CHECKING THE UPPER CASE	7-16
INSTALLING THE UPPER CASE	7-16
DISASSEMBLING THE UPPER CASE	7-17
CHECKING THE EXHAUST MANIFOLD	7-18
ASSEMBLING THE UPPER CASE	7-18
STEERING ARM	7-19
REMOVING THE STEERING ARM	7-19
CHECKING THE STEERING ARM	7-20
INSTALLING THE STEERING ARM	7-20
CLAMP BRACKETS	7-21
REMOVING THE CLAMP BRACKETS	7-21
CHECKING THE CLAMP BRACKETS	7-24
INSTALLING THE CLAMP BRACKETS	7-25

**STEERING HANDLE
DISASSEMBLING THE STEERING HANDLE**




Step	Job/Part	Q'ty	Remarks
1	Throttle cable	1	
2	Throttle cable	1	
3	Grommet	1	
4	Bolt (with washer)	1	
5	Bolt (with washer)	1	
6	Steering handle cover	1	
7	Collar	1	
8	Collar	1	
9	Plain washer	2	
10	Wave washer	1	
11	Screw	1	
12	Handle	1	
13	Washer	1	

Continued on next page.




Step	Job/Part	Q'ty	Remarks
14	Compression spring	1	
15	Bushing	1	
16	Bolt	1	
17	Self-locking nut	1	
18	Steering friction	1	
19	Throttle lever	1	
20	Steering handle 1	1	



CHECKING THE STEERING HANDLE

Check:

- Steering friction ①
- Throttle lever ②
Crack/damage → Replace.
- Throttle cable ③
Bent/broken → Replace.




ASSEMBLING THE STEERING HANDLE

1. Install:

- Steering handle 1 ①
- Throttle lever ②
- Throttle friction ③


2. Connect:

- Throttle cable ① (loose cable side)
- Throttle cable ② (tight cable side)



NOTE:

- Connect the inner cable end in the groove, and fit the outer cable end into the hole.
- Apply Yamaha grease A (water resistant grease) to the throttle lever and throttle cable.




3. Install:

- Bushing ①
- Compression spring ②
- Washer ③
- Handle ④

NOTE:

- Align the throttle lever shaft end with the hole in the handle.
- After installing steering handle, make sure the movement of throttle cables by moving it.




4. Install:

- Plain washer ①
- Wave washer ②
- Collar ③
- Steering handle ④
- Collar ⑤
- Steering handle cover ⑥
- Bolt ⑦

NOTE:

Apply Yamaha grease A (water resistant grease) to the throttle cables, washers and the steering handle crown.



5. Install:

- Throttle cables ①
(through bottom cowling)
- Grommet ②


NOTE:

Pass the throttle cables through the steering handle on the steering bracket. Be sure the throttle cable is routed correctly.




BOTTOM COWLING

REMOVING THE BOTTOM COWLING




Step	Job/Part	Q'ty	Remarks
1	Nut	4	
2	Collar	4	
3	Grommet	4	
4	Washer	4	
5	Bottom cowling	1	
6	Grommet	1	
7	Engine stop switch	1	
8	Choke knob	1	
9	Grommet	1	
10	Grommet	1	
11	Grommet	1	
12	Spring pin	1	
13	Throttle lever	1	

Continued on next page.




Step	Job/Part	Q'ty	Remarks
14	Bushing	2	
15	Throttle control shaft	1	
16	Friction spacer	1	
17	Bolt (with washer)	1	
18	Clamp lever 2	1	
19	Bushing	2	
20	Wave washer	1	
21	Clamp lever 1	1	



CHECKING THE BOTTOM COWLING


1. Check:
 - Bottom cowling
Crack/damage → Replace.



2. Check:
 - Clamp lever
Wear/damage → Replace.

NOTE:

Apply Yamaha grease A (water resistant grease) or replace parts as required.




INSTALLING THE BOTTOM COWLING

1. Install:
 - Bushing ①
 - Throttle control shaft ②
 - Throttle lever ③
 - Spring pin ④

NOTE:

Always use the new spring pin.



2. Install:

- Bottom cowling ①
- Nuts ②


NOTE:

Apply Yamaha grease A (water resistant grease) to the clamp lever shaft.




SHIFT ACTUATOR

DISASSEMBLING THE SHIFT ACTUATOR




Step	Job/Part	Q'ty	Remarks
1	Rubber seal	1	
2	Rubber seal 2	1	
3	Bolt (with washer)	4	
4	Nut	1	
5	Washer	1	
6	Bracket	1	
7	Gasket	1	
8	Nut	2	
9	Washer	2	
10	Bolt	2	
11	Bolt (with washer)	1	
12	Bracket	1	
13	Dowel pin	1	

Continued on next page.




Step	Job/Part	Q'ty	Remarks
14	Bushing 2	1	
15	Compression spring	1	
16	Compression spring	1	
17	Shift cam plunger	1	
18	Cotter pin	1	Not reusable
19	Washer	2	
20	Cotter pin	1	Not reusable
21	Washer	1	
22	Joint	1	
23	Bolt	1	
24	Shift lever	1	
25	Grommet	1	
26	Cam plate	1	

Continued on next page.



Step	Job/Part	Q'ty	Remarks
27	Bushing	2	
28	Grease nipple	1	
29	Cotter pin	1	Not reusable
30	Washer	1	
31	Plate washer	2	
32	Shift rod 1	1	
33	Spring pin	1	Not reusable
34	Shift rod lever	1	
35	Plate washer	2	
36	Collar	1	
37	Shift rod	1	
38	Torsion spring	1	




REMOVING THE BRACKET

Remove

- Bolts ① (upper side)
- Bolt ② (under side)

NOTE:

The bolt ② (under side) must be removed from the bottom side of the upper case.



CHECKING THE SHIFT ACTUATOR


1. Check:

- Shift lever ①
- Shift cam plunger ②
- Cam plate ③
- Joint ④
- Shift rod lever ⑤
- Shift rod ⑥
- Shift rod 1 ⑦

Wear/damage → Replace.

NOTE:


Apply Yamaha grease A (water resistant grease) or replace parts as required.



2. Check:

- Bracket ①
- Bracket ② (remote control attachment)

Crack/damage → Replace.



3. Check:

- Rubber seal ①
 - Rubber seal ②
- Crack/damage → Replace.


ASSEMBLING THE SHIFT ACTUATOR

1. Install:

- Bracket ①
- Collar ②
- Shift rod lever ③
- Shift rod ④
- Spring pin ⑤
- Joint ⑥
- Cotter pin ⑦
- Grease nipple ⑧

NOTE:

- Always use the new spring pin and the cotter pin.
- Apply Yamaha grease A (water resistant grease) to the collar inner surface, grease nipple and shift rod 1.




2. Hook:

- Torsion spring ①

NOTE:

Hook it onto the shift rod lever and the bracket.





3. Install:

- Cam plate ①

NOTE:

Apply Yamaha grease A (water resistant grease) to the cam plate shaft.






4. Install:

- Shift cam plunger ①
- Compression spring
- Bushing ②


NOTE:

Apply Yamaha grease A (water resistant grease) to the shift cam plunger.



5. Install:

- Shift lever ①
- Bolt ②
- Arm ③

**Bolt ②****11 N·m (1.1 kgf·m, 8.1 ft·lb)**


6. Install:

- Bracket ① (to upper casing)
- Bolts ②
- Nut ③ (mount rubber front upper)
- Rubber seal ④ (over the bracket)

**Bolt ②****11 N·m (1.1 kgf·m, 8.1 ft·lb)****Nut ③****17 N·m (1.7 kgf·m, 13 ft·lb)**


UPPER CASE

REMOVING THE UPPER CASE




Step	Job/Part	Q'ty	Remarks
1	Bolt (with washer)	2	
2	Nut	2	
3	Bolt (with washer)	2	
4	Nut	2	
5	Bolt (with washer)	2	
6	Lower mount rubber housing	2	
7	Mount rubber (side lower)	2	
8	Lower mount cover	1	
9	Mount rubber (front lower)	1	
10	Nut	2	
11	Washer	2	
12	Upper case	1	
13	Nut	2	

Continued on next page.




Step	Job/Part	Q'ty	Remarks
14	Bolt	2	
15	Washer	2	
16	Nut	2	
17	Mount rubber (side upper)	2	
18	Gasket	4	
19	Bolt (with washer)	2	
20	Mount rubber (front upper)	1	



CHECKING THE UPPER CASE

Check:

- Upper case ①
Crack/damage → Replace.
- Mount rubber ②
Wear/crack/damage → Replace.



INSTALLING THE UPPER CASE

Install:

- Mount rubber ① (front upper)
- Mount rubber ② (side upper) – with gaskets
- Nut ③
- Upper case ④ (to swivel bracket)
- Nut ⑤ (side upper)
- Mount rubber ⑥ (side lower)
- Mount rubber ⑦ (front lower)
- Lower mount cover ⑧
- Lower mount rubber housing ⑨




Nut ⑤

17 N•m (1.7 kgf•m, 13 ft•lb)

Bolt

(lower mount rubber housing ⑨)

17 N•m (1.7 kgf•m, 13 ft•lb)




NOTE:


Make sure the lower mount rubber housing is installed with the "UP" mark pointing upward.



DISASSEMBLING THE UPPER CASE




Step	Job/Part	Q'ty	Remarks
1	Bolt	1	
2	Exhaust guide	1	
3	Bolt	4	
4	Exhaust manifold	1	
5	Exhaust seal 2	1	Not reusable
6	Exhaust seal 1	1	Not reusable
7	Cotter pin	1	Not reusable
8	Gasket	1	
9	Gasket	1	Not reusable
10	Water tube	1	
11	Water seal rubber	1	



CHECKING THE EXHAUST MANIFOLD

Check:

- Exhaust manifold ①
- Exhaust guide ②
Carbon deposits → Clean.
Crack/corrosion → Replace.



ASSEMBLING THE UPPER CASE

1. Install:

- Exhaust manifold ①
- Exhaust guide ②
- Exhaust seals ③
- Gasket ④

NOTE:


Always use new gaskets and exhaust seals. If old ones are used, gas leakage may result due to invisible scratches or stretches.

2. Install:

- Water seal rubber
- Water tube

NOTE:


Install the water seal rubber so that it aligns with the locating hole (a) in the upper case.






STEERING ARM

REMOVING THE STEERING ARM




Step	Job/Part	Q'ty	Remarks
1	Bolt	1	
2	Seal rubber	1	
3	Bolt	4	
4	Bracket	1	
5	Dowel pin	2	
6	Steering pivot shaft	1	
7	Washer	1	
8	Bushing	1	
9	Friction piece	1	
10	Bushing	1	
11	O-ring	1	Not reusable
12	Bushing	1	



CHECKING THE STEERING ARM

1. Check:
 - Bracket ①
 - Steering pivot shaft ②
Crack/damage → Replace.
2. Check:
 - Bushing ③
 - Bushing ④
 - Friction piece ⑤
Wear/damage → Replace.



INSTALLING THE STEERING ARM

Install:

- Bracket ①
- Steering pivot shaft ②
- Bushing ③
- Bushing ④
- Friction piece ⑤
- O-ring ⑥
- Washer ⑦
- Washer ⑧
- Dowel pin ⑨ (to pivot shaft)
- Bolt ⑩
- Bolt ⑪ (steering friction)


NOTE:

- Always use the new O-ring.
- Apply Yamaha grease A (water resistant grease) to the bushing, O-ring and the grease nipples.
- After installing the steering bracket, make sure the movement of steering pivot shaft by moving it.




CLAMP BRACKETS

REMOVING THE CLAMP BRACKETS




Step	Job/Part	Q'ty	Remarks
1	Tension spring	1	
2	Tilt rod	1	
3	Conical spring	1	
4	Nut	1	
5	Washer	1	
6	Bolt	1	
7	Collar	1	
8	Clamp bracket cap	2	
9	Nut	2	
10	Clamp bracket plate	1	
11	Clamp bracket 1	1	
12	Clamp bracket 2	1	
13	Clamp bracket bolt	1	

Continued on next page.



Step	Job/Part	Q'ty	Remarks
14	Washer	2	
15	Bushing	2	
16	Tilt lever cover	1	
17	Tilt lever	1	
18	Torsion spring	1	
19	Circlip	1	
20	Pin	1	
21	Spring return lever	1	
22	Tilt lock rod	1	
23	Tilt lock rod	1	
24	Cotter pin	1	
25	Pin	1	
26	Tilt lock plate (outer)	2	


Continued on next page.



Step	Job/Part	Q'ty	Remarks
27	Pin	2	
28	Tension spring	2	
29	Bolt	2	
30	Shallow water lever	1	
31	Cover	1	
32	Tilt lock plate (inner)	1	
33	Grease nipple	4	
34	Swivel bracket	1	
35	Spring pin	1	
36	Stopper knob	1	
37	Stopper shaft	1	




CHECKING THE CLAMP BRACKETS




1. Check:

- Clamp bracket ① (port side)
 - Clamp bracket ② (starboard side)
 - Swivel bracket ③
- Crack/damage → Replace.




2. Check:

- Tilt lock plate ① (outer)
 - Tilt lock plate ② (inner)
 - Shallow water lever ③
 - Tension spring ④
 - Tension springs ⑤
- Bent/crack/damage → Replace.




3. Check:

- Tilt rod ①
- Bent/damage → Replace.
- Conical spring ②
- Crack/damage → Replace.




4. Check:

- Tilt lever 1 ①
 - Tilt lever 2 ②
 - Tilt lock rod ③
 - Torsion spring ④
- Crack/damage → Replace.



5. Check:

- Bushing ①
- Wear/damage → Replace.




INSTALLING THE CLAMP BRACKETS

1. Install:

- Swivel bracket ① (with bushings)
- Shallow water lever ②
- Tension springs ③
- Tilt lock lever ④ (inner) – front side
- Tilt lock lever ⑤ (outer) – rear side
- Pin ⑥
- Cotter pin ⑦

NOTE:

- Always use the new cotter pin.
- Apply grease to parts when specified.






2. Install:

- Swivel bracket ①
- Pin ②
- Tilt lever ③
- Circlip ④
- Tilt lock rod ⑤
(hook to inner tilt lock plate)
- Tilt lock rod ⑥ (hook to tilt lever 1
⑦)
- Torsion spring ⑧

NOTE:

- Always use the new circlip.
- Apply water resistant grease to the pin and tilt levers.



3. Install:

- Clamp bracket ① (port side)
- Clamp bracket ② (starboard side)
- Transom clamp handle ③
- Stopper shaft ④
- Stopper knob ⑤
- Spring pin ⑥

NOTE:

- Always use the new pin and a spring pin.
- Apply Yamaha grease A (water resistant grease) to the transom clamp screw, stopper shaft and the grease nipple.

4. Install:

- Clamp bracket bolt ①
- Clamp bracket ② (starboard side)
- Washer ③
- Swivel bracket ④
- Torsion spring ⑤
- Tilt lever ⑥
- Washer ⑦
- Clamp bracket ⑧ (port side)
- Nut ⑨ (clamp bracket bolt)
- Bolt ⑩
- Collar ⑪
- Nut ⑫
- Tilt rod ⑬ (with conical spring ⑭)
- Tension spring ⑮


NOTE:

Place the tilt lever ⑥ inside the clamp bracket ⑧ (port side) as shown.



Nut ⑨


45 N·m(4.5 kgf·m, 33 ft·lb)




CHAPTER 8

ELECTRICAL SYSTEM

ELECTRICAL COMPONENT	8-1
ELECTRICAL COMPONENTS ANALYSIS	8-2
DIGITAL CIRCUIT TESTER	8-2
MEASURING THE PEAK VOLTAGE	8-2
PEAK VOLTAGE ADAPTER	8-2
MEASURING A LOW RESISTANCE	8-3
IGNITION SYSTEM	8-4
WIRING DIAGRAM	8-4
CHECKING THE SPARK PLUGS	8-5
CHECKING THE IGNITION SPARK GAP	8-5
CHECKING THE SPARK PLUG CAPS	8-6
REMOVING THE SPARK PLUG CAPS (STANDARD TYPE)	8-6
INSTALLING THE SPARK PLUG CAPS (STANDARD TYPE)	8-6
CHECKING THE IGNITION COILS	8-7
CHECKING THE CHARGE COIL	8-8
CHECKING THE PULSER COIL	8-9
CDI UNIT	8-10
CHECKING THE CDI UNIT	8-11
IGNITION CONTROL SYSTEM	8-13
WIRING DIAGRAM	8-13
CHECKING THE ENGINE STOP SWITCH	8-14
CHARGING SYSTEM	8-15
WIRING DIAGRAM	8-15
CHECKING THE LIGHTING COIL	8-16





ELECTRICAL COMPONENT



- ① Ignition coil
- ② Charge coil
- ③ Pulser coil
- ④ CDI unit
- ⑤ Engine stop switch
- ⑥ Lighting coil

- B : Black
- Br : Brown
- G : Green
- L : Blue
- W : White
- B/O : Black/Orange
- B/W : Black/White
- W/B : White/Black
- W/R : White/Red



ELECTRICAL COMPONENTS ANALYSIS

DIGITAL CIRCUIT TESTER



Digital circuit tester
90890-03174

NOTE: _____

"○—○" indicates a continuity of electricity which means a closed circuit at the respective switch position.


MEASURING THE PEAK VOLTAGE

⚠ WARNING _____

When checking the peak voltage, do not touch any of the connections of the digital tester lead wires.

NOTE: _____

- When checking the condition of the ignition system, it is useful to know the peak voltage.
 - Cranking speed is dependant on many factors (e.g., fouled or weak spark plugs, a weak battery). If one of three is defective, the peak voltage will be lower than specification.
 - If the peak voltage measurement is not within specification, the engine will not operate properly.
-





PEAK VOLTAGE ADAPTER

NOTE: _____


The peak voltage adapter should be used with the digital circuit tester.



Peak voltage adapter
90890-03172

**NOTE:**

- When measuring the peak voltage, set the selector to the DC voltage mode.
- Make sure the peak voltage adapter lead are properly installed in the digital tester.
- Make sure the positive pin (the “+” mark facing up as shown) on the peak voltage adapter is installed into the positive terminal of the digital tester.
- The test harness is needed for the following tests.

**Measuring steps**

- (1) Connect the peak voltage adapter probes to the connectors.
- (2) Start or crank the engine and observe the measurement.


MEASURING A LOW RESISTANCE

When measuring a resistance of 10Ω or less with the digital tester, the correct measurement cannot be obtained because of the tester's internal resistance.


To obtain the correct value, subtract the internal resistance from the displayed measurement.

**Correct value****Displayed measurement - internal resistance****NOTE:**

The internal resistance of the digital tester can be obtained by connecting both of its probes.





**IGNITION SYSTEM
WIRING DIAGRAM**



- ① Spark plug
- ② Ignition coil
- ③ Charge coil
- ④ Pulser coil
- ⑤ CDI unit


- B : Black
- Br : Brown
- L : Blue
- B/O : Black/Orange
- B/W : Black/White
- W/B : White/Black
- W/R : White/Red



CHECKING THE SPARK PLUGS

Refer to "CHECKING THE SPARK PLUGS" on page 3-22.


**Standard spark plug
NGK B7HS-10**



CHECKING THE IGNITION SPARK GAP

⚠ WARNING

- Do not touch any of the connections of the spark gap tester lead wires.
- Do not let sparks leak out of the removed spark plug cap.
- Keep flammable gas or liquids away, since this test can produce sparks.




Check:

- Ignition spark gap

Below specification → Check the ignition system.



**Minimum ignition spark gap
8.0 mm (0.31 in)**



Checking steps

- (1) Remove the spark plugs from the engine.
- (2) Connect a spark plug cap to the ignition tester.






**Ignition tester
90890-06754**

- (3) Adjust the ignition spark gap to 11 mm (0.43 in) by turning the adjust knob.

NOTE:

Be careful so that the spark gap does not come excessively off the measuring position [11 mm (0.43 in)].






(4) Crank the engine and observe the spark through the discharge window of the ignition tester.

NOTE:


- If there is no spark or the spark is weak, check spark plug cap, ignition coil, pulser coil, charge coil and CDI unit.
- If a good spark is obtained, the problem is not with the ignition system, but possibly with the spark plug(s) or another component.



CHECKING THE SPARK PLUG CAPS

Check


- Spark plug cap ①
Crack/damage → Replace.



REMOVING THE SPARK PLUG CAPS (STANDARD TYPE)

Removing steps

- (1) Remove the spark-plug cap ① by pulling the cap, and remove the plug-cup spring ② from the high-tension cable ③.





INSTALLING THE SPARK PLUG CAPS (STANDARD TYPE)


Installing steps

- (1) Cut about length ① off the end of the high-tension cable ③.

	<p>Length ① 5mm (0.20 in)</p>
--	-----------------------------------




(2) Press in the plug cap spring (4) until it touches the high tension cable at (b), then bend (c) as shown.



CHECKING THE IGNITION COILS


1. Check:


- Ignition coil (1)
Crack/damage → Replace.





2. Measure:

- Ignition coil resistance
Out of specification → Check the peak voltage (charge coil, pulser coil, CDI unit)/Replace.

	Ignition coil resistance	
	Primary B/W - B	Secondary B - output
	0.18 - 0.24 Ω	2.70 - 3.70 kΩ




NOTE: _____
When making secondary leads resistance test, disconnect spark plug cap.



CHECKING THE CHARGE COIL

1. Measure:
 - Charge coil resistance
 Out of specification → Check the peak voltage.

Charge coil resistance
Br - L
342 - 418 Ω




Measuring steps

- (1) Disconnect the Brown (Br) and Blue (L) leads from the wire harness.
 - (2) Connect the tester to the charge coil as shown.
2. Measure:
 - Charge coil output peak voltage
 Below specification → Replace.



Charge coil output peak voltage
Br - L

r/min	Cranking		1,500	3,500
	Opened	Closed		
D.C.V.	146	146	150	150



NOTE:

For the peak voltage measurement, connect the adaptor as the illustration **A** for the open circuit, and as the illustration **B** for the closed circuit.




CHECKING THE PULSER COIL

1. Measure:
 - Pulser coil resistance
 Out of specification → Check the peak voltage.

Pulser coil resistance
W/R - B (#1), W/B - B (#2)
311 - 381 Ω


Measuring steps

- (1) Disconnect the White/Red (W/R), White/Black (W/B) and Black (B) leads from the wire harness.
 - (2) Connect the tester to the pulser coil as shown.
2. Measure:
 - Pulser coil output peak voltage
 Below specification → Replace.




Pulser coil output peak voltage
W/R - B (#1), W/B - B (#2)


r/min	Cranking		1,500	3,500
	Opened	Closed		
D.C.V.	6.8	6.7	16.0	26.0



NOTE: _____
 For the peak voltage measurement, connect the adaptor as the illustration **A** for the open circuit, and as the illustration **B** for the closed circuit.





CDI UNIT



① CDI unit

- B : Black
- Br : Brown
- L : Blue
- W : White
- B/O : Black/Orange
- B/W : Black/White
- W/B : White/Black
- W/R : White/Red



CHECKING THE CDI UNIT

1. Measure:

- CDI unit ① resistance

Out of specification → Check the peak voltage.



Pocket tester
90890-03112

NOTE:



- Digital circuit tester cannot be used for this check. Use analogue tester.
- CDI resistance values will vary from meter to meter, especially with electronic digital meters. For some testers, polarity of leads is reversed.

Measuring steps


- (1) Disconnect the CDI unit ① leads from the wire harness.
- (2) Connect the pocket tester ($\Omega \times 1K$) to the CDI unit as shown list.
Refer to "CDI UNIT" on page 8-10.

NOTE:


There is a point at which the pointer swings greatly and swings back. Read the point where the point has returned to stop.




2. Measure:
- CDI unit output peak voltage
Below specification → Replace.

 CDI unit output peak voltage B/O - B, B/W - B				
r/min	Cranking		1,500	3,500
	Opened	Closed		
D.C.V.	5.5	130.0	135.0	135.0


NOTE: _____
 Before measuring CDI unit output peak voltage, make sure that no abnormality is observed on the charge coil and the pulser coil.



NOTE: _____
 For the peak voltage measurement, connect the adaptor as the illustration **A** for the open circuit, and as the illustration **B** for the closed circuit.





**IGNITION CONTROL SYSTEM
WIRING DIAGRAM**



- ① CDI unit
- ② Engine stop switch

B : Black
W : White




CHECKING THE ENGINE STOP SWITCH


Check:

- Continuity

Out of specification → Replace.




	Lead color	
	White	Black
Remove the lock-plate A	○ — ○	○ — ○
Install the lock-plate B		
Push the button C	○ — ○	○ — ○

CHARGING SYSTEM
WIRING DIAGRAM



① Lighting coil

G : Green



CHECKING THE LIGHTING COIL

1. Measure:

- Lighting coil resistance

Out of specification → Checking the peak voltage.

	Lighting coil resistance:
	G – G
	0.31 - 0.37 Ω

Measuring steps

- (1) Connect the tester to the lighting coil as shown.

NOTE:

When measuring the resistance of 10 Ω or less using the digital tester, the correct measurement cannot be obtained. Refer to "MEASURING A LOW RESISTANCE" on page 8-3.

2. Measure:

- Lighting coil output peak voltage

Below specification → Replace.

	Lighting coil output peak voltage			
	G – G			
r/min	Cranking			
	Opened		Closed	
D.C.V.	4.6		-	
r/min	1,500	3,500	1,500	3,500
	Closed		Opened	
D.C.V.	-	-	14.7	30.0

CHAPTER 9 TROUBLE ANALYSIS

TROUBLE ANALYSIS	9-1
TROUBLE ANALYSIS CHART	9-1
TROUBLE SHOOTING FOR PEAK VOLTAGE	9-4

TROUBLE ANALYSIS

NOTE:

The following items should be checked before the "TROUBLE ANALYSIS CHART" is consulted.

1. The battery is charged and its specific gravity is within specification.
2. There are no incorrect wiring connections.
3. Wiring connections are properly secured and are not rusty.
4. The lanyard is installed onto the engine stop switch.
5. The shift position is in neutral.
6. Fuel is reaching the carburetor/vapor separator.
7. The rigging and engine setting are correct.
8. The engine is free from any "Hull problem".

TROUBLE ANALYSIS CHART

Trouble mode													Check elements		
ENGINE WILL NOT START	HARD STARTING	ROUGH IDLING	HIGH IDLING	ENGINE STALLS	POOR ACCELERATION	ENGINE WILL NOT STOP	POOR PERFORMANCE	LIMITED ENGINE SPEED	OVERHEATING	LOOSE STEERING	HARD SHIFTING	IRREGULAR WARNING INDICATION	POOR BATTERY CHARGING	Relative part	Reference Chapter
													FUEL SYSTEM		
<input type="radio"/>				<input type="radio"/>			<input type="radio"/>							Fuel line	4
<input type="radio"/>				<input type="radio"/>			<input type="radio"/>							Fuel joint	4
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>			<input type="radio"/>							Fuel filter	4
<input type="radio"/>				<input type="radio"/>			<input type="radio"/>							Fuel pump	4
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>							Carburetor	4
		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>							• Idle speed adjustment	3
<input type="radio"/>				<input type="radio"/>			<input type="radio"/>							• Pilot screw adjustment	3
		<input type="radio"/>	<input type="radio"/>				<input type="radio"/>							Link adjustment	3
													POWER UNIT		
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>					<input type="radio"/>							Compression	3
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>										Reed valves	5
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>					<input type="radio"/>	<input type="radio"/>						Cylinder head gasket	5

Trouble mode													Check elements		
ENGINE WILL NOT START	HARD STARTING	ROUGH IDLING	HIGH IDLING	ENGINE STALLS	POOR ACCELERATION	ENGINE WILL NOT STOP	POOR PERFORMANCE	LIMITED ENGINE SPEED	OVERHEATING	LOOSE STEERING	HARD SHIFTING	IRREGULAR WARNING INDICATION	POOR BATTERY CHARGING	Relative part	Reference Chapter
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			<input type="radio"/>									Seal	5
<input type="radio"/>							<input type="radio"/>							Cylinder body	5
<input type="radio"/>							<input type="radio"/>							Pistons	5
<input type="radio"/>							<input type="radio"/>							Piston rings	5
<input type="radio"/>							<input type="radio"/>							Crankcase	5
<input type="radio"/>							<input type="radio"/>							Crankshaft	5
							<input type="radio"/>							Bearing	5
								<input type="radio"/>						Thermostat	5
								<input type="radio"/>						Water passage	5
													LOWER UNIT		
<input type="radio"/>				<input type="radio"/>							<input type="radio"/>			Neutral position	6
				<input type="radio"/>							<input type="radio"/>			Dog clutch	6
											<input type="radio"/>			Gears	6
							<input type="radio"/>		<input type="radio"/>					Water inlets	6
							<input type="radio"/>		<input type="radio"/>					Water pump	6
							<input type="radio"/>							Propeller shaft	6
							<input type="radio"/>							Propeller	6
											<input type="radio"/>			Shift rod joint/Pin	6
											<input type="radio"/>			Shift rod	6
						<input type="radio"/>								Lower case	6
													BRACKET UNIT		
										<input type="radio"/>				Bracket	7
										<input type="radio"/>				Rubber mount	7
											<input type="radio"/>			Shift actuator	7
													ELECTRICAL SYSTEMS		
													Ignition system		
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>					• Spark plugs	8


Trouble mode													Check elements	
ENGINE WILL NOT START													Relative part	Reference Chapter
HARD STARTING	<input type="radio"/>													
ROUGH IDLING		<input type="radio"/>												
HIGH IDLING			<input type="radio"/>											
ENGINE STALLS				<input type="radio"/>										
POOR ACCELERATION					<input type="radio"/>									
ENGINE WILL NOT STOP						<input type="radio"/>								
POOR PERFORMANCE							<input type="radio"/>							
LIMITED ENGINE SPEED								<input type="radio"/>						
OVERHEATING									<input type="radio"/>					
LOOSE STEERING														
HARD SHIFTING														
IRREGULAR WARNING INDICATION														
POOR BATTERY CHARGING														
													Ignition control system	
	<input type="radio"/>					<input type="radio"/>							• Engine stop switch 8	
													Charging system	
												<input type="radio"/>	• Lighting coil 8	

TROUBLE SHOOTING FOR PEAK VOLTAGE


Items	Symptoms
1. Poor starting	<ul style="list-style-type: none"> No firing. The starter motor cranks the engine, but no firing takes place in the cylinder. Firing takes place in the cylinder, but the engine stops soon. Start-up time is too long. The engine will not start up easily.
2. Unstable idle speed	<ul style="list-style-type: none"> The engine speed is not stable at idle. The engine stalls when the throttle lever is opened. The engine stalls after it is warmed up.
3. Unstable engine speed	<ul style="list-style-type: none"> The engine does not run smoothly. The engine speed drops during acceleration.

Check the ignition system.


1) Check the lead to ignition coil, CDI unit, pulser coil and charge coil.




2) Check the spark gap.




3) Check the plug cap (resistance).




4) Check the ignition coils (resistance).




5) Check the CDI unit resistance and output peak voltage.



6) Check the charge coil resistance and output peak voltage.



7) Check the pulser coil resistance and output peak voltage.



Replace the CDI unit.



Printed in Japan
Oct. 2000-0.3 × 1 ©
(EK25BMH)

(英)

Printed on recycled paper

WIRING DIAGRAM EK25BMH

- B Black
- Br Brown
- G Green
- L Blue
- R Red
- W White
- B/O Black/orange
- B/W Black/white
- G/W Green/white
- W/B White/black
- W/R White/red

