



REPAIR MANUAL FOR CHASSIS & BODY

CORONA & CARINA 8

AT190 series
ST191 series
CT190 series

Feb., 1992

FOREWORD

This repair manual has been prepared to provide information covering general service repairs for the chassis and body of the TOYOTA CORONA and CARINA 8.

Applicable models: AT190 series
ST191 series
CT190 series

For the service specifications and repair procedures of the above model other than those listed in this manual, refer to the following manuals.

Manual Name	Pub. No.
• 4A-FE Engine Repair Manual	RM296E
• 5S-FE, 3S-GE, 3S-GTE Engine Repair Manual	RM164E
• 3S-GE, 3S-FE Engine Repair Manual Supplement	RM165E
• 1C, 2C, 2C-T Engine Repair Manual	RM025E
• 2C Engine Repair Manual Supplement	RM297E
• A241L, A241E Automatic Transaxle Repair Manual	RM177E
• Corona & Carina 8 Electrical Wiring Diagram Manual	EWD146Y
• Carina 8 New Car Features	NCF085E
• Corona New Car Features	NCF084E


All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

TOYOTA MOTOR CORPORATION

©1993 TOYOTA MOTOR CORPORATION
All rights reserved. This book may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Corporation.

AIR CONDITIONING SYSTEM

GENERAL INFORMATION	AC- 2
DESCRIPTION.....	AC- 8
PREPARATION	AC- 17
USE OF MANIFOLD GAUGE SET.....	AC- 20
TROUBLESHOOTING	AC- 22
REFRIGERANT VOLUME	AC- 29
DRIVE BELT TENSION.....	AC- 30
IDLE-UP SPEED	AC- 32
REFRIGERANT LINES	AC- 33
AIR CONDITIONING UNIT	AC- 35
BLOWER UNIT	AC- 37
COMPRESSOR	AC- 38
RECEIVER	AC- 54
CONDENSER	AC- 56
EVAPORATOR	AC- 58
HEATER RADIATOR.....	AC- 61
WATER VALVE	AC- 62
EXPANSION VALVE.....	AC- 63
VACUUM SWITCHING VALVE (VSV)	AC- 64
BLOWER MOTOR.....	AC- 66
CONDENSER FAN MOTOR	AC- 67
AIR INLET CONTROL SERVOMOTOR.....	AC- 68
AIR MIX CONTROL SERVOMOTOR.....	AC- 70
AIR VENT MODE CONTROL	
SERVOMOTOR	AC- 72
BLOWER RESISTOR.....	AC- 73
PRESSURE SWITCH.....	AC- 74
EVAPORATOR TEMPERATURE	
SENSOR.....	AC- 76
REVOLUTION DETECTING SENSOR	AC- 77
RELAYS	AC- 78
AIR CONDITIONER AMPLIFIER	AC- 80
AIR CONDITIONING CONTROL	
ASSEMBLY	AC- 81
SERVICE SPECIFICATIONS.....	AC- 87



N04157

GENERAL INFORMATION

NEW AIR CONDITIONING SYSTEM WITH R134a


AC0EN-01

Refrigerant R 12 (CFC 12), previously used in automobiles' air conditioning systems is believed to contribute towards the depletion the earth's ozone layer. The ozone layer help to protect us against the harmful ultraviolet rays of the sun.


A newly developed refrigerant, R 134 a (HFC 134 a), reduces the destruction of the ozone layer. This refrigerant is used in the specially redesigned air conditioning systems fitted into the AT190, ST191 and CT190 series vehicle.




N04154



N04323



N04156



N04158

PRECAUTIONS FOR SERVICING R134a AIR CONDITIONERS

1. USE OF NEW REFRIGERANT R134a

The very different characteristics of refrigerants R134 a and R12 have determined the design of their respective air conditioning systems. Under no circumstances allow R12 to enter an R134a system, or vice versa, because serious damage could occur.


2. USE OF PROPER COMPRESSOR OIL

Compressor oil used in conventional R12 air conditioning systems cannot be used in R134a air conditioning systems.

Always use genuine Toyota R134a air conditioning oil ND-OIL 8, made expressly for use with R134a.

If even a small amount of the wrong oil is changed, it will result in clouding of the refrigerant.

A large amount will cause the compressor to seize up.




N04183

3. USE OF PROPER O-RINGS AND SEALS


O-rings and seals used for conventional R12 air conditioning systems cannot be used for R134a air conditioning systems.

Always use genuine Toyota R134a system O-rings and seals for R134a air conditioning systems.



N04141

If O-rings and/or seals for R12 air conditioning systems are used by mistake in the connections of an R134a air conditioning system, the O-ring and seals will foam and swell resulting in leakage of refrigerant.



N04510

4. TIGHTEN CONNECTING PARTS SECURELY

Securely tighten the connecting parts to prevent leaking of refrigerant gas.

- Apply a few drops of compressor oil to O-ring fittings for easy tightening and to prevent leaking of refrigerant gas.


CAUTION: Apply only ND-OIL 8 compressor oil

- Tighten the nuts using two wrenches to avoid twisting the tube.
- Tighten the O-ring fittings or the bolted type fittings to the specified torque.

5. INSERT PLUG IMMEDIATELY IN DISCONNECTED PARTS

Insert a plug immediately in the disconnected parts to prevent the ingress of moisture and dust.


6. DO NOT REMOVE PLUG FROM NEW PARTS UNTIL IMMEDIATELY BEFORE INSTALLATION



AC1608

7. DISCHARGE GAS IN NEW COMPRESSOR FROM CHARGING VALVE BEFORE INSTALLING IT


If the gas in the new compressor is not discharged first, compressor oil will spray out with gas when the plug is removed.



N04324


SERVICE TOOLS FOR R134a AIR CONDITIONER

When servicing R 134 a air conditioning systems always use the R134a dedicated manifold gauges, gas leak detector and vacuum pump adaptor.




1. USE MANIFOLD GAUGES FOR R134a AIR CONDITIONER

Always use R 134 a dedicated manifold gauges to prevent R12 and R12 compressor oil contaminating the R134a system.



2. USE R134a GAS LEAK DETECTOR

Similarly, always use an R134a dedicated leak detector. The R12 leak detector is not sufficiently sensitive.



3. USE VACUUM PUMP ADAPTER

By correcting a vacuum pump adapter, the vacuum pump can be used for both R134a and R12 air conditioning systems.



The vacuum pump adaptor has an internal magnetic valve. When evacuation is completed and the vacuum pump switch is turned off, the magnetic valve opens allowing the introduction atmospheric air into the manifold gauges to prevent the back flow of oil from the vacuum pump into the gauge hose.

CAUTION:

Be sure to turn off the manifold gauge valve immediately after evacuating the system. Then you may switch off the vacuum pump. If this order is reversed, the line will be temporarily open to atmosphere.

CHARGING AND LEAK – CHECK METHODS

Evacuate the refrigeration system according to the following procedures.




CAUTION:

- Be sure to connect both the high and low pressure quick – connectors onto the A / C system when evacuating. If only one side is connected, the system would be open to atmosphere through the other connector, making it impossible to maintain vacuum.
- Be sure to turn off the manifold gauge valve immediately after evacuating the system. Then you may switch off the vacuum pump.

PRECAUTIONS WHEN CHARGING REFRIGERANT

1. **DO NOT OPERATE COMPRESSOR WITHOUT ENOUGH REFRIGERANT IN REFRIGERANT CYCLE**
If there is not enough refrigerant in the refrigerant cycle, oil lubrication will be insufficient and compressor burnout may occur, so take care to avoid this.
2. **DO NOT OPEN HIGH PRESSURE MANIFOLD VALVE WHILST COMPRESSOR IS OPERATING**
If the high pressure valve is opened, refrigerant flows in the reverse direction and could cause the charging cylinder to rupture, so open and close the low pressure valve only.
3. **BE CAREFUL NOT TO OVERCHARGE WITH REFRIGERANT IN SYSTEM**

If refrigerant is overcharged, it causes problems such as insufficient cooling, poor fuel economy, engine overheating etc.




ELECTRICAL PARTS

AG0EP-01

Before removing and inspecting the electrical parts, set the ignition switch to the LOCK position and disconnect the negative (–) terminal cable from battery.


DESCRIPTION
PARTS LOCATION

AC0E0-01



N04938

PARTS LOCATION (CONT'D)




N04531

ELECTRICAL WIRING DIAGRAM


AC08R-01

■ 4A-FE, 3S-FE, 3S-GE ENGINE MODEL (DIAL TYPE HEATER CONTROL)




N04386

ELECTRICAL WIRING DIAGRAM (CONT'D)




N04387


ELECTRICAL WIRING DIAGRAM (CONT'D)




ELECTRICAL WIRING DIAGRAM (CONT'D)




ELECTRICAL WIRING DIAGRAM (CONT'D)



ELECTRICAL WIRING DIAGRAM (CONT'D)




DAMPERS POSITION




* This damper is provided only on models with the "fresh feeling" heater system.

Air Outlet Mode	Mode Control Damper Position	Vent		Foot		Defroster	
		(A) Center	(B) Side	(C) Front	(D) Rear	(E) Front	(F) Side
Face	① ④ ⑥ ⑧	○	○	-	-	-	-
Bi-Level	① ③ ⑥ ⑧	○	○	○	○	-	-
Foot	② ③ ⑥ ⑦	●	○	○	○	○	○
Foot/Defroster	② ③ ⑤ ⑦	●	○	○	○	○	○
Defroster	② ④ ⑤ ⑦	●	○	-	-	○	○

- NOTES:**
- The size of the circle ○ and ● indicates the proportion of air flow volume.
 - ○ indicates temperature-controlled (heated) air flow.
 - ● indicates cool air flow (not heated).
 - The circle ● indicates blowers exclusively for models with the "fresh feeling" heater system.




VACUUM SWITCHING VALVE (VSV) (4A – FE, 3S – FE and 3S – GE) VACUUM HOSE CIRCUIT




VSV INSPECTION


1. REMOVE VSV
2. CHECK VACUUM CIRCUIT CONTINUITY IN VSV BY BLOWING AIR INTO PIPES
 - (a) Connect the VSV terminals to the battery terminals as illustrated.
 - (b) Blow into pipe "A" and check that air comes out of pipe "B".




- (c) Disconnect the battery.
 - (d) Blow into pipe "A" and check that air does not come out of pipe "B".
- If a problem is found, replace the VSV.




3. CHECK FOR SHORT CIRCUIT
- Using an ohmmeter, check that there is no continuity between each terminal and the VSV. If there is continuity, replace the VSV.



4. CHECK FOR OPEN CIRCUIT
- Using an ohmmeter, measure the resistance between the two terminals.
- Resistance:**
30 – 34 Ω at 20°C (68°F)
- If resistance value is not as specified, replace the VSV.




(2C) VACUUM HOSE CIRCUIT




VSV INSPECTION


1. REMOVE VSV
2. CHECK VACUUM CIRCUIT CONTINUITY IN VSV BY BLOWING AIR INTO PIPES
 - (a) Connect the VSV terminals to the battery terminals as illustrated.
 - (b) Blow into pipe "A" and check that air comes out of pipe "B".




- (c) Disconnect the battery.
 - (d) Blow into pipe "A" and check that air does not come out of pipe "B".
- If a problem is found, replace the VSV.



3. CHECK FOR SHORT CIRCUIT
- Using an ohmmeter, check that there is no continuity between each terminal and the VSV body. If there is continuity, replace the VSV.





4. CHECK FOR OPEN CIRCUIT
- Using an ohmmeter, the resistance between the two terminals.
- Resistance:**
30 – 34 Ω at 20°C (68°F)
- If the resistance is not within specification, replace the VSV.



BLOWER MOTOR BLOWER MOTOR REMOVAL

ACOFM-01

1. REMOVE INSTRUMENT LOWER PANEL AND UNDER COVER NO.2
(See page BO-59)
2. DISCONNECT CONNECTOR
3. REMOVE A/C AMPLIFIER
4. REMOVE MOTOR
Remove the three screws and the motor.



BLOWER MOTOR INSPECTION

AC01D-02


INSPECT BLOWER MOTOR OPERATION

Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, then check that the motor operation is smooth.

BLOWER MOTOR INSTALLATION

ACOFM-01


INSTALL BLOWER MOTOR BY FOLLOWING
REMOVAL SEQUENCE IN REVERSE



CONDENSER FAN MOTOR CONDENSER FAN MOTOR INSPECTION


AC0FF-01

1. DISCONNECT CONNECTOR
2. INSPECT CONDENSER FAN MOTOR
 - (a) Using the wire harness, apply battery voltage to the connector. Connect the positive (+) lead from the battery to terminal 1 and negative (-) lead to terminal 2.
 - (b) Confirm smooth rotation of the motor within the specified current flow.
Standard current:
Vehicles for Europe (3S-GE, 2C)
 $6.5 \pm 1.0 \text{ A}$
Others
 $6.0 \pm 1.5 \text{ A}$
 If current is not as specified, replace the motor.




CONDENSER FAN REMOVAL

1. DISCONNECT CONNECTOR
2. REMOVE CONDENSER FAN
Remove three bolts and pull out the condenser fan upward.




AIR INLET CONTROL SERVOMOTOR AIR INLET CONTROL SERVOMOTOR REMOVAL


1. REMOVE INSTRUMENT PANEL UNDER TRAY, GLOVE COMPARTMENT DOOR AND BOX UPPER SHELL
(See page BO-59)
2. REMOVE AIR DUCT NO.2



3. REMOVE BLOWER UNIT
 - (a) Disconnect connectors.
 - (b) Remove the bolt, the nut and two screws.
 - (c) Remove the blower unit.




4. REMOVE SERVOMOTOR
 - (a) Disconnect the connector.
 - (b) Remove two screws and the servomotor.



AIR INLET CONTROL SERVOMOTOR INSPECTION

INSPECT SERVOMOTOR OPERATION


- (a) Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 4, check that the arm rotates to the "FRESH" side smoothly.
- (b) Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 3, check that the arm rotates to the "RECIRC" side smoothly.
If operation is not as specified, replace the servo motor.




AIR MIX CONTROL SERVOMOTOR AIR MIX CONTROL SERVOMOTOR REMOVAL

ACOFB-01


1. REMOVE INSTRUMENT PANEL
(See page BO-59)



2. REMOVE AIR DUCT




3. REMOVE CONTROL LINK



4. REMOVE SERVOMOTOR

- (a) Disconnect the connector.
- (b) Remove the three screws and the servomotor.






- (c) Disconnect the control cable from the servomotor.

ACOFU-01

AIR MIX CONTROL SERVOMOTOR INSPECTION

1. INSPECT SERVOMOTOR OPERATION

- (a) Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 1, check that the lever moves smoothly from HOT to COOL.
- (b) Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, check that the lever moves smoothly from COOL to HOT.
If operation is not as specified, replace the motor.



2. INSPECT POSITION SENSOR OPERATION

- (a) Measure the resistance between terminals 5 and 4.
Resistance: Approx. 6 kΩ
- (b) Set the arm to COOL position.
- (c) Check that the resistance between terminals 3 and 4 decreases from approx. 4.8 kΩ to 1.2 kΩ, when the arm is rotated from COOL to HOT position.
If resistance value is not as specified, replace the motor.

AIR MIX CONTROL SERVOMOTOR INSTALLATION



ACOFU-01

INSTALL SERVOMOTOR BY FOLLOWING
REMOVAL SEQUENCE IN REVERSE

AIR VENT MODE CONTROL SERVOMOTOR MODE CONTROL SERVOMOTOR REMOVAL

AC0FV-01

1. REMOVE INSTRUMENT FINISH LOWER PANEL AND DUCT (HEATER TO RESISTER NO.2)
(See page BO-59)
2. REMOVE SERVOMOTOR
 - (a) Disconnect the connector.
 - (b) Remove three screws and the servomotor.



MODE CONTROL SERVOMOTOR INSPECTION

AC0SF-02

INSPECT SERVOMOTOR OPERATION

- (a) Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 1.
- (b) Connect the negative (-) lead from the battery to each terminal and check that the arm rotates to each position as shown below.

Connected terminal	Position
4	DEF
5	FOOT/DEF
6	FOOT
7	B/L
8	FACE

If operation is not as specified, replace the servomotor.

MODE CONTROL SERVOMOTOR INSTALLATION


AC0FW-01

INSTALL SERVOMOTOR BY FOLLOWING REMOVAL SEQUENCE IN REVERSE

BLOWER RESISTOR BLOWER RESISTOR REMOVAL

AC0FX-01


1. DISCONNECT CONNECTOR
2. REMOVE BLOWER RESISTOR
Remove two screws and the resistor.



BLOWER RESISTOR INSPECTION

AC0FY-01

INSPECT BLOWER RESISTOR CONTINUITY



V00882

If continuity is not as specified, replace the blower resistor.

BLOWER RESISTOR INSTALLATION




AC0FZ-01

INSTALL BLOWER RESISTOR BY FOLLOWING REMOVAL SEQUENCE IN REVERSE

PRESSURE SWITCH ON – VEHICLE INSPECTION

AC01R-01

1. INSTALL MANIFOLD GAUGE SET
(See page AC-20)
2. DISCONNECT CONNECTOR FROM PRESSURE SWITCH
3. RUN ENGINE AT APPROX. 2000 RPM
4. INSPECT PRESSURE SWITCH OPERATION



- (Magnetic Clutch Control)
- (a) Connect the positive (+) lead from the ohmmeter to terminal 4 and negative (-) lead to terminal 1.
 - (b) Check continuity between terminals when refrigerant pressure is changed as shown.
If operation is not as specified, replace the pressure switch.


- (Cooling Fan Control)
- (a) Connect the positive (+) lead from the ohmmeter to terminal 2 and negative (-) lead to terminal 3.
 - (b) Check continuity between terminals when refrigerant pressure is changed as shown.
If operation is not as specified, replace the pressure switch.

5. STOP ENGINE AND REMOVE MANIFOLD GAUGE SET
6. CONNECT CONNECTOR TO PRESSURE SWITCH

AC01S-03

PRESSURE SWITCH REMOVAL


1. DISCHARGE REFRIGERANT IN REFRIGERATION SYSTEM
2. REMOVE PRESSURE SWITCH
 - (a) Disconnect the connector.
 - (b) Remove the pressure switch from the liquid tube.
HINT: Lock the switch mount on the tube with an open end wrench, being careful not to deform the tube, and remove the switch.



PRESSURE SWITCH INSTALLATION

AC000-01

1. INSTALL PRESSURE SWITCH
 - (a) Install the pressure switch to the liquid tube.
Torque: 10.8 N·m (110 kgf·cm, 8 ft·lbf)
HINT: Lock the switch mount on the tube with an open end wrench, being careful not to deform the tube, and install the switch.
 - (b) Connect the connector.
2. EVACUATE AIR IN REFRIGERATION SYSTEM AND CHARGE WITH REFRIGERANT
Specified amount:
750 ± 50 g (26.45 ± 1.76 oz)
3. INSPECT FOR LEAKAGE OF REFRIGERANT
Using a gas leak tester, check for leakage of refrigerant from the pressure switch mount.
4. INSPECT A/C OPERATION



EVAPORATOR TEMPERATURE SENSOR

EVAPORATOR TEMPERATURE SENSOR REMOVAL


AC0G1-01

1. REMOVE LEFT SIDE FLOOR CARPET CENTER COVER.

Remove the clip and the left side floor carpet center cover.

2. REMOVE EVAPORATOR TEMPERATURE SENSOR

- (a) Disconnect the evaporator temperature sensor connector.
- (b) Remove the screw and the evaporator temperature sensor.



EVAPORATOR TEMPERATURE SENSOR INSPECTION

AC01V-02

Check resistance between terminals of evaporator temperature sensor (thermistor) connector at each temperature.

Resistance:

at 0°C (32°F): 4.6 – 5.1 kΩ

at 15°C (59°F): 2.1 – 2.6 kΩ


In addition as temperature increases, the resistance decreases gradually.

EVAPORATOR TEMPERATURE SENSOR INSTALLATION

AC01W-01

INSTALL EVAPORATOR TEMPERATURE SENSOR

Install evaporator temperature sensor in reverse order of removal procedure.



REVOLUTION DETECTING SENSOR

AC01X-02

(Ex. 4A – FE Engine)

ON – VEHICLE INSPECTION

1. DISCONNECT NEGATIVE CABLE FROM BATTERY
2. DISCONNECT CONNECTOR OF REVOLUTION DETECTING SENSOR


3. INSPECT REVOLUTION DETECTING SENSOR

Check the resistance between terminals 1 and 2 of the sensor.

Specified resistance:

100 – 130 Ω at 20°C (68°F)


If the resistance value is not as specified, replace the revolution detecting sensor.



REVOLUTION DETECTING SENSOR REMOVAL

AC01Y-02


1. REMOVE COMPRESSOR
(See page AC – 39)
2. REMOVE REVOLUTION DETECTING SENSOR
 - (a) Using a hexagon wrench, remove two bolts.
 - (b) Pull out the revolution detecting sensor.



REVOLUTION DETECTING SENSOR INSTALLATION

AC01Z-02

1. INSTALL REVOLUTION DETECTING SENSOR
Install the revolution detecting sensor with two bolts.
Torque: 5.9 N·m (60 kgf·cm, 52 in.·lbf)
2. INSTALL COMPRESSOR
(See page AC – 53)




RELAYS

AC02F-03

RELAYS REMOVAL

1. DISCONNECT NEGATIVE (-) CABLE FROM BATTERY
2. REMOVE RELAYS



RELAYS INSPECTION

AC02E-03

1. INSPECT MAGNETIC CLUTCH RELAY CONTINUITY
If continuity is not as specified, replace the relay.

	Terminal Condition	1	2	3	5
	Constant				
	Apply battery voltage to terminal 1 and 2.				

N05145

V01269

2. INSPECT A/C FAN RELAY NO. 2 CONTINUITY
If continuity is not as specified, replace the relay.

	Terminal Condition	1	2	3	4	5
	Constant					
	Apply battery voltage to terminal 1 and 2.					

N01146

V01270

3. INSPECT A/C FAN RELAY NO. 3 CONTINUITY
If continuity is not as specified, replace the relay.

	Terminal Condition	1	2	3	5
	Constant				
	Apply battery voltage to terminal 1 and 2.				

N05145

V01269

4. INSPECT HEATER MAIN RELAY CONTINUITY
If continuity is not as specified, replace the relay.

	Terminal Condition	1	2	3	4	5
	Constant					
	Apply battery voltage to terminal 1 and 3.					


BE1850 BE1844

V00100

RELAYS INSTALLATION

AC022-01

1. INSTALL RELAYS
2. CONNECT NEGATIVE (-) CABLE TO BATTERY



AIR CONDITIONER AMPLIFIER A/C AMPLIFIER INSPECTION


AC062-01

INSPECT AMPLIFIER CIRCUIT

Disconnect the amplifier and inspect the connector on the wire harness side as shown in the chart below.

Test conditions

- (1) Ignition switch : ON
- (2) Temperature control dial : MAX COOL
- (3) Blower switch : HI



Check for	Tester connection	Condition	Specified value
Continuity	5 — ground	Constant	Continuity
Resistance	*1 3 — 8	A/C switch on (MAX. COOL to MAX. WARM)	Approx. 0 to 3 kΩ
		A/C switch off	No continuity
	3 — 12	Constant	1.5 kΩ at 25°C (77°F)
Voltage	*3 1 — ground	Constant	Battery voltage
		Blower switch off	No voltage
	2 — ground	Constant	Battery voltage
		Blower switch off	No voltage
	*4 4 — ground	Start the engine	Approx. 10 — 14 V
		Stop the engine	No voltage
	7 — ground	A/C switch on	Battery voltage
		A/C switch off	No voltage
11 — ground	A/C switch on	Battery voltage	
	A/C switch off	No voltage	

- *1: Without heater
- *2: With revolution detecting sensor
- *3: 2C Engine only
- *4: Except 4A-FE Engine

W01042

If circuit is not as specified, replace the amplifier.

AIR CONDITIONING CONTROL ASSEMBLY

AC024-02



A/C CONTROL ASSEMBLY REMOVAL

(See page BO-59)

AC063-01


A/C CONTROL ASSEMBLY INSPECTION

(Push Type Heater Control)




1. INSPECT A/C INDICATOR

- (a) Connect the positive (+) lead from the battery to terminal B-1 and the negative (-) lead to terminal A-10.
- (b) Push the A/C button in and check that the indicator light up.
If operation is not as specified replace the A/C control assembly.




2. INSPECT MODE INDICATOR

- (a) Connect the positive (+) lead from the battery to terminal B-1 and the negative (-) lead to terminal B-9.
- (b) Push each of the mode buttons in and check that their indicators light up.
If operation is not as specified replace the A/C control assembly.




3. INSPECT AIR INLET INDICATOR


- (a) Connect the positive (+) lead from the battery to terminal B-1 and the negative (-) lead to terminal B-9.
- (b) Check that the FRESH and RECIRC indicators light up alternately each time the air inlet control switch button is pressed.
If operation is not as specified, replace the A/C control assembly.



N04524



N04526



e-20-2-C
e-18-2-A

N04572

4. INSPECT BLOWER SPEED INDICATOR

- (a) Connect the positive (+) lead from the battery to terminal B-1 and the negative (-) lead to terminal B-9.
- (b) Push each of the blower buttons in and check that their indicators light up.
HINT: The indicator will not light up when the blower button is in the OFF position.
If operation is not as specified, replace the A/C control assembly.

5. INSPECT INDICATOR DIMMING OPERATION

- (a) Connect the positive (+) lead from the battery to terminal B-1 and the negative (-) lead to terminals B-9 and B-18.
- (b) Connect the positive (+) lead from the battery to terminal B-8 and check that the mode indicator dims.
If operation is not as specified, replace the A/C control assembly.

6. INSPECT A/C SWITCH CONTINUITY

Terminal	A-8	B-16
Switch position		
OFF		
ON	○	○

W01024

If continuity is not as specified, replace the A/C control assembly.

7. INSPECT MODE CONTROL SWITCH CONTINUITY

If continuity is not as specified, replace the A/C control assembly.

Terminal	B-12	B-11	B-6	B-3	B-2	B-9
Switch position						
FACE	○					○
B/L		○				○
FOOT			○			○
FOOT/DEF				○		○
DEF					○	○

e-18-2-A

W01026

8. INSPECT AIR INLET CONTROL SWITCH CONTINUITY

If continuity is not as specified, replace the A/C control assembly.

Terminal	B-15	B-14	B-9
Switch position			
RECIRC	○		○
FRESH		○	○

e-18-2-A

W01027


9. INSPECT BLOWER SPEED CONTROL SWITCH CONTINUITY

If continuity is not as specified, replace the A/C control assembly.

Terminal	A-13	A-14	A-15	A-17	B-9
Switch position					
OFF					
LO				○	○
●			○	○	○
●		○		○	○
HI	○			○	○

e-20-2-C
e-18-2-A

W01028



10. INSPECT TEMPERATURE CONTROL SWITCH

(a) Measure the resistance between terminals A-19 and B-17.

Resistance: Approx. 3 kΩ


(b) Check that the resistance between terminals B-17 and A-20 increases from 0 to approx. 3 kΩ when the switch knob is turned from COOL to HOT.

If operation is not as specified, replace the A/C control assembly.

A/C CONTROL ASSEMBLY INSPECTION (Dial Type Heater Control)


AC064-01

2. INSPECT BLOWER SPEED CONTROL SWITCH CONTINUITY



V01036

If continuity is not as specified, replace the A/C control assembly.





A/C CONTROL CABLES ADJUSTMENT

AC065-01

1. ADJUST AIR INLET DAMPER CONTROL CABLE

Set the air inlet damper and the control lever to "FRESH" position, install the control cable and lock the clamp while lightly pushing the outer cable in the direction shown by the arrow.



1. INSPECT A/C SWITCH CONTINUITY

Terminal	5	6
Switch position		
OFF		
ON	○	○




V01025

If continuity is not as specified, replace the switch. (Without Heater)

(a) Check that there is no continuity between terminals 2 and 3 with the switch is OFF position.

(b) Check that the resistance between terminals 2 and 3 decreases from 3k to 0 Ω when the switch knob turned to clockwise.

If operation is not as specified, replace the A/C control assembly.



2. ADJUST AIR VENT MODE CONTROL CABLE

A/C CONTROL ASSEMBLY INSTALLATION

(See page BO-59)

AC02B-01

SERVICE SPECIFICATIONS SERVICE DATA

AC06J-02

Refrigerant charge volume	750±50 g 26.45±17.6 oz
Drive belt tension	
(4A-FE) New belt	6.0-7.0 mm (0.24-0.28 in.)
(4A-FE) Used belt	8.5-9.5 mm (0.33-0.37 in.)
(3S-FE) New belt	6.0-9.0 mm (0.24-0.35 in.)
(3S-FE) Used belt	9.0-11.0 mm (0.35-0.43 in.)
(3S-GE) New belt	9.0-11.0 mm (0.35-0.43 in.)
(3S-GE) Used belt	13.0-16.0 mm (0.51-0.61 in.)
(2C) New belt	11.0-13.0 mm (0.43-0.51 in.)
(2C) Used belt	15.0-18.0 mm (0.59-0.71 in.)
Idle speed	
(4A-FE and 3S-FE) Magnetic clutch engaged	Approx. 750 rpm
(3S-GE) Magnetic clutch engaged	Approx. 950 rpm
(2C) Magnetic clutch engaged	Approx. 800 rpm
Starting torque of compressor shaft	2.9 N·m (30 kgf·cm, 26 in.-lbf) or less
Compressor magnet clutch clearance	0.5±0.15 mm (0.020±0.006 in.)


TORQUE SPECIFICATIONS

AC02A-02

Part tightened	N·m	kgf·cm	ft·lbf
Suction hose x Compressor	9.8	100	7
Discharge hose x Compressor	9.8	100	7
Compressor x Engine	25	250	18
Compressor shft bolt	13	135	10
Compressor cylinder x Service valve	25	250	18
Compressor x Front housing	25	250	18
Liquid tube x Receiver	5.4	55	48 in.-lbf
Liquid tube x Condensor	9.8	100	7
Expansion valve x Evaporator	5.4	55	48 in.-lbf
Suction tube x A/C unit	9.8	100	7
Liquid tube x A/C unit	9.8	100	7
Pressure switch x Liquid tube	10.8	110	8

BODY ELECTRICAL SYSTEM

GENERAL INFORMATION	BE-2	COMBINATION METER	
POWER SOURCE		PARTS LOCATION	BE-46
PARTS LOCATION	BE-7	METER CIRCUIT	BE-47
IGNITION SWITCH		TROUBLESHOOTING	BE-49
PARTS LOCATION	BE-11	SPEEDOMETER SYSTEM	BE-52
IGNITION SWITCH	BE-11	TACHOMETER SYSTEM	BE-53
KEY UNLOCK WARNING SWITCH	BE-11	FUEL GAUGE SYSTEM	BE-53
HEADLIGHT AND TAILLIGHT SYSTEM		FUEL LEVEL WARNING SYSTEM	BE-55
PARTS LOCATION	BE-12	WATER TEMPERATURE GAUGE SYSTEM ...	BE-56
TROUBLESHOOTING	BE-13	LOW OIL PRESSURE WARNING SYSTEM ...	BE-56
HEADLIGHT	BE-15	BRAKE WARNING SYSTEM	BE-57
COMBINATION SWITCH	BE-15	LOW OIL PRESSURE WARNING	
HEADLIGHT CONTROL RELAY	BE-16	SWITCH INSPECTION	BE-58
TAILLIGHT CONTROL RELAY	BE-17	ENGINE OIL LEVEL WARNING SWITCH	BE-58
HEADLIGHT DIMMER RELAY	BE-17	OPEN DOOR WARNING SYSTEM	BE-59
HEADLIGHT BEAM LEVEL		DEFOGGER SYSTEM	
CONTROL SYSTEM	BE-17	PARTS LOCATION	BE-60
HEADLIGHT BEAM LEVEL		TROUBLESHOOTING	BE-61
ACTUATOR INSPECTION	BE-18	PREPARATION	BE-62
DOOR COURTESY SWITCH	BE-18	DEFOGGER SWITCH	BE-62
LIGHT-ON WARNING SYSTEM	BE-19	DEFOGGER WIRE	BE-62
ILLUMINATED ENTRY SYSTEM	BE-20	POWER WINDOW CONTROL SYSTEM	
AUTOMATIC LIGHT CONTROL SENSOR	BE-21	PARTS LOCATION	BE-65
DAYTIME RUNNING LIGHT RELAY	BE-21	TROUBLESHOOTING	BE-66
FOG LIGHT SYSTEM		MASTER SWITCH	BE-67
PARTS LOCATION	BE-23	POWER WINDOW SWITCH	BE-70
TROUBLESHOOTING	BE-24	POWER WINDOW MOTOR	BE-70
FOG LIGHT SWITCH	BE-24	POWER MAIN RELAY	BE-72
REAR FOG LIGHT SWITCH INSPECTION	BE-24	POWER DOOR LOCK CONTROL SYSTEM	
FOG LIGHT RELAY	BE-25	PARTS LOCATION	BE-73
TURN SIGNAL AND		TROUBLESHOOTING	BE-74
HAZARD WARNING SYSTEM		MASTER SWITCH	BE-75
PARTS LOCATION	BE-26	DOOR KEY LOCK AND UNLOCK SWITCH ...	BE-75
TROUBLESHOOTING	BE-27	KEY UNLOCK WARNING SWITCH	BE-75
TURN SIGNAL SWITCH	BE-28	DOOR COURTESY SWITCH	BE-75
HAZARD WARNING SWITCH	BE-28	DOOR LOCK MOTOR	BE-76
TURN SIGNAL FLASHER	BE-28	POWER DOOR LOCK CONTROL RELAY	BE-78
INTERIOR LIGHT SYSTEM		DOOR UNLOCK DETECTION SWITCH	BE-79
PARTS LOCATION	BE-29	SLIDING ROOF SYSTEM	
TROUBLESHOOTING	BE-30	PARTS LOCATION	BE-80
GLOVE BOX LIGHT SWITCH	BE-31	TROUBLESHOOTING	BE-81
DOOR COURTESY SWITCH	BE-31	SLIDING ROOF SWITCH	BE-82
ROOM LIGHT ASSEMBLY	BE-32	LIMIT SWITCH	BE-82
METER ILLUMINATION CONTROL SYSTEM ..	BE-33	SLIDING ROOF MOTOR	BE-82
BACK-UP LIGHT SYSTEM		SLIDING ROOF CONTROL RELAY	BE-83
PARTS LOCATION	BE-34	POWER MAIN RELAY	BE-83
TROUBLESHOOTING	BE-35	POWER MIRROR CONTROL SYSTEM	
BACK-UP LIGHT SWITCH	BE-35	PARTS LOCATION	BE-84
NEUTRAL START SWITCH	BE-35	TROUBLESHOOTING	BE-85
STOP LIGHT SYSTEM		POWER MIRROR SWITCH	BE-86
PARTS LOCATION	BE-36	POWER MIRROR MOTOR	BE-87
TROUBLESHOOTING	BE-37	SEAT HEATER SYSTEM	
STOP LIGHT SWITCH	BE-37	PARTS LOCATION	BE-89
WIPER AND WASHER SYSTEM		TROUBLESHOOTING	BE-90
PARTS LOCATION	BE-38	SEAT HEATER SWITCH	BE-91
TROUBLESHOOTING	BE-39	INDICATOR LIGHT OPERATION	BE-91
COMBINATION SWITCH	BE-39	SEAT HEATER INSPECTION	BE-92
WIPER MOTOR	BE-41	AUDIO SYSTEM	
WASHER MOTOR	BE-42	PARTS LOCATION	BE-93
HEADLIGHT CLEANER SYSTEM		SYSTEM DESCRIPTION	BE-94
PARTS LOCATION	BE-44	TROUBLESHOOTING	BE-96
TROUBLESHOOTING	BE-45	ANTENNA MOTOR	BE-118
HEADLIGHT CLEANER SWITCH	BE-45	ANTENNA MOTOR CONTROL RELAY	BE-118
		ANTENNA ROD REMOVAL	
		AND INSTALLATION	BE-119
		CLOCK	
		TROUBLESHOOTING	BE-120




GENERAL INFORMATION

WIRING COLOR CODE

Wire colors are indicated by an alphabetical code.

B = Black	L = Blue	R = Red
BR = Brown	LG = Light Green	V = Violet
G = Green	O = Orange	W = White
GR = Gray	P = Pink	Y = Yellow

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.



CONNECTOR



FEMALE CONNECTOR PIN NUMBER

Numbered in order from upper left to lower right.

MALE CONNECTOR PIN NUMBER

Numbered in order from upper right to lower left.

HINT: When connectors with different or the same number of terminals are used with the same parts, each connector name (letter of the alphabet) and pin number is specified.





MALE AND FEMALE CONNECTORS DISTINCTION

Male and female connectors are distinguished by shape of their internal pins.

- (a) All connectors are shown from the open end, and the lock is on top.
- (b) To pull apart the connectors, pull on the connector itself, not the wires.


HINT: Check to see what kind of connector you are disconnecting before pulling apart.



HOW TO REPLACE TERMINAL

WITH TERMINAL RETAINER TYPE

HINT: To remove the terminal for this type of connector, please construct and use the special tool or like object shown on the left.



CONNECTOR DISCONNECTION



Disconnect the connector according to the instructions on BE-2.

TERMINAL FROM CONNECTOR DISCONNECTION

- (a) Using the special tool, raise the retainer up to the temporary lock position.

HINT: The needle insertion position varies according to the connector's shape (number of terminals, etc.), so check the position before inserting it.

- (b) Using the special tool, release the locking lug and pull the terminal out from rear.



TERMINAL TO CONNECTOR INSTALLATION


- (a) Insert the terminal.




HINT:

1. Make sure the terminal is positioned correctly.
2. Insert the terminal until the locking lug locks firmly.
3. Insert the terminal with retainer in the temporary lock position.

- (b) Push the retainer in as far as the full lock position.

CONNECTOR CONNECTION





FUSE REPLACEMENT


HINT: If replacing the fuse be sure to replace it with a fuse with an equal amperage rating.

NOTICE:

- Turn off all electrical components and the ignition switch before replacing a fuse or fusible link. Do not exceed the fuse or fusible link amperage rating.
- Always use a fuse puller for removing an inserting a fuse. Remove and insert straight in and out without twisting. Twisting could force open the terminals too much, resulting in a bad connection.


If a fuse or fusible link continues to blow, a short circuit is indicated. The system must be checked by a qualified technician.

HINT: The puller is located at Relay Block No.2.




VOLTAGE CHECK

- Establish conditions in which voltage is present at the check point.
Example:
 Ⓐ - Ignition SW on
 Ⓑ - Ignition SW and SW 1 on
 Ⓒ - Ignition SW, SW 1 and Relay on (SW 2 off)
- Using a voltmeter, connect the negative (–) lead to a good ground point or negative(–) battery terminal and the positive (+) lead to the connector or component terminal. This check can be done with a test bulb instead of a voltmeter.



CONTINUITY AND RESISTANCE CHECK


- Disconnect the battery terminal or wire so there is no voltage between the check points.
- Contact the two leads of an ohmmeter to each of the check points.



If the circuit has diodes, reverse the two leads and check again.

When contacting the negative (–) lead to the diode positive (+) side and the positive (+) lead to the negative (–) side, there should be continuity. When contacting the two leads in reverse, there should be no continuity.

HINT: Specifications may vary depending on the type of tester, so refer to the tester's instruction manual before performing the inspection.




Check LED (Light Emitting Diode) in the same manner as that for diodes.

HINT:

- Use a tester with a power source of 3 V or greater to overcome the circuit resistance.
- If a suitable tester is not available, apply battery voltage and check that the LED lights up.

PARTS LOCATION (CONT'D)

Junction Block No.1



FUSES

Medium Current Fuses


- a. AM1 40A
- b. POWER 30A
- c. DEF 40A

Fuses

- 1. STOP 15A
- 2. TAIL 10A
- 3. TAIL MAIN 20A (RHD)
- 4. ECU-IG 15A
- 5. WIPER 20A
- 6. ST 7.5A
- 7. IGN 7.5A
- 8. CIG & RAD 15A
- 9. TURN 10A
- 10. ECU-B 15A
- 11. PANEL 7.5A
- 12. Fr DEF 30A
- 13. GAUGE 10A

Junction Block No.2

S type engine



FUSES

Medium Current Fuses

- a. HTR 50A
- b. MAIN 40A
- c. CDS 30A
- d. RRI

Fuses

- 1. HEAD RH 15A
- 2. HEAD LH 15A
- 3. EFI 15A
- 4. —
- 5. —
- 6. HAZARD 15A
- 7. HORN 10A
- 8. —


RELAY

- A. STARTER
- B. HEATER
- C. EFI MAIN
- D. ENGINE MAIN
- E. HEAD
- F. HORN
- G. FM No.1

PARTS LOCATION (CONT'D)

Junction Block No.2

A type engine



FUSES

Medium Current Fuses

- a. HTR 50A
- b. MAIN 40A
- c. CDS 30A
- d. RDI 30A


Fuses

- 1. HEAD RH 15A
- 2. HEAD LH 15A
- 3. EFI 15A
- 4. —
- 5. —
- 6. HAZARD 15A
- 7. HORN 10A
- 8. —

RELAY

- A. STARTER
- B. HEATER
- C. EFI MAIN
- D. ENGINE MAIN
- E. HEAD
- F. HORN
- G. FM No.1

C type engine



FUSES

Medium Current Fuses

- a. CDS 30A
- b. RDI 30A
- c. MAIN 40A
- d. HTR 50A

Fuses


- 1. —
- 2. HEAD LH 15A
- 3. HORN 10A
- 4. —
- 5. HEAD RH 15A
- 6. HAZARD 15A

RELAY

- A. ENGINE MAIN
- B. FAN No.1
- C. HEAD
- D. STARTER
- E. HORN
- F. HEATER

PARTS LOCATION (CONT'D)


Relay Block No.5



Relays

- A. A/C FAN No.2 Relay
- B. A/C FAN No.3 Relay
- C. A/C MG CLT Relay

Relay Block No.7




Relay

- A. DIMMER (Head Light Dimmer Relay) [Europe LHD]


Fuses

- 1. HEAD HI(LH) 15A [Europe LHD]
- 2. HEAD HI(RH) 15A [Europe LHD]
- 3. HEAD LO(LH) 15A [Europe LHD]
- 4. HEAD LO(RH) 15A [Europe LHD]

**IGNITION SWITCH
PARTS LOCATION**



N04135



BE0900 g-8-2

IGNITION SWITCH

IGNITION SWITCH INSPECTION

○—○ CONTINUITY INSPECTION

Terminal	1	2	3	4	5	7	8
Switch position							
LOCK							
ACC					○—○		
ON		○—○	○—○	○—○	○—○		
START	○—○	○—○	○—○	○—○		○—○	○—○

If continuity is not as specified, replace the switch.


KEY UNLOCK WARNING SWITCH

KEY UNLOCK WARNING SWITCH INSPECTION

○—○ CONTINUITY INSPECTION

Terminal	1	2
Switch position		
OFF (Key removed)		
ON (Key set)	○—○	○—○


If continuity is not as specified, replace the switch.



BE2193 e-2-2-G

HEADLIGHT AND TAILLIGHT SYSTEM

PARTS LOCATION



TROUBLESHOOTING


You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble	Part name	See page
Headlight does not light up. (Taillight is normal.)	1. Headlight Bulb 2. MAIN FL 3. HEAD Fuse 4. Light Control Switch 5. Headlight Dimmer Switch 6. Light Control Sensor (with) 7. Wire Harness	— — BE-8 BE-16 BE-16 BE-21 —
Headlight does not light up. (Taillight does not light up.)	1. Headlight Bulb 2. Light Control Switch 3. Headlight Dimmer Switch 4. Light Control Sensor (with) 5. Wire Harness	— BE-16 BE-16 BE-21 —
Only one light comes ON.	1. Headlight Bulb 2. HEAD Fuse 3. Wire Harness	— BE-8 —
"Lo-Beam" does not light up.	1. Headlight Bulb 2. Headlight Control Relay 3. Daytime Running Light Relay (with) 4. Headlight Dimmer Relay 5. Headlight Dimmer Switch 6. Wire Harness	— BE-16 BE-21 BE-17 BE-16 —
"Hi-Beam" does not light up.	1. Headlight Bulb 2. Headlight Control Relay 3. Daytime Running Light Relay (with) 4. Headlight Dimmer Relay 5. Headlight Dimmer Switch 6. Wire Harness	— BE-16 BE-21 BE-17 BE-16 —
"Flash" does not light up.	1. Headlight Bulb 2. Headlight Control Relay 3. Daytime Running Light Relay (with) 4. Headlight Dimmer Relay 5. Headlight Dimmer Switch 6. Wire Harness	— BE-16 BE-21 BE-17 BE-16 —
Taillight does not light up. (Headlight is normal.)	1. Taillight Bulb 2. TAIL Fuse 3. Light Control Switch 4. Taillight Control Relay 5. Wire Harness	— — BE-16 BE-17 —
Taillight does not light up. (Headlight does not light up.)	1. Taillight Bulb 2. MAIN FL 3. TAIL Fuse 4. Light Control Switch 5. Light Control Sensor 6. Wire Harness	— — BE-8 BE-16 BE-21 —

Trouble	Part name	See page
Only one light goes out of does not light up.	1. Taillight Bulb	—
	2. Wire Harness	—
Rear Combination light does not light up.	1. Taillight Bulb	—
	2. TAIL Fuse	BE-8
	3. Wire Harness	—
Lights-on warning system does not operate.	1. CIG fuse	BE-8
	2. GAUG fuse	BE-8
	3. TAIL fuse	BE-8
	4. Light reminder relay	BE-19
	5. Door courtesy switch	BE-18
	6. Wire Harness	—


HEADLIGHT


HEADLIGHT AIMING ADJUSTMENT



COMBINATION SWITCH

COMPONENTS





COMBINATION SWITCH INSPECTION

LIGHT CONTROL SWITCH CONTINUITY

○—○ CONTINUITY INSPECTION

Terminal	A2	A11	A13	B19
Switch position				
OFF				
TAIL	○—○			
HEAD	○—○	○—○	○—○	
AUTO		○—○	○—○	○—○

HEADLIGHT DIMMER SWITCH CONTINUITY

○—○ CONTINUITY INSPECTION

Terminal	A3	A9	A12	A14
Switch position				
Flash		○—○	○—○	○—○
Low beam	○—○	○—○		
High beam		○—○	○—○	

TURN SIGNAL SWITCH CONTINUITY

○—○ CONTINUITY INSPECTION

Terminal	A1	A5	A8
Switch position			
Left turn	○—○	○—○	
Neutral			
Right turn	○—○	○—○	○—○

If continuity is not as specified, replace the switch.


HEADLIGHT CONTROL RELAY

HEADLIGHT CONTROL RELAY INSPECTION

○—○ CONTINUITY INSPECTION

Terminal	1	2	3	4
Condition				
Constant	○—○			
Apply battery voltage to terminals 1 and 2.			○—○	

If continuity is not as specified, replace the relay.




TAILLIGHT CONTROL RELAY

TAILLIGHT CONTROL RELAY INSPECTION

○—○ CONTINUITY INSPECTION

Terminal	1	2	3	5
Condition				
Constant	○—○			
Apply battery voltage to terminals 1 and 2.			○—○	

If continuity is not as specified, replace the relay.




HEADLIGHT DIMMER RELAY

HEADLIGHT DIMMER RELAY INSPECTION

○—○ CONTINUITY INSPECTION

Terminal	1	2	3	4
Condition				
Constant	○—○	○—○	○—○	○—○
Apply battery voltage to terminals 2 and 4.			○—○	○—○

If continuity is not as specified, replace the relay.




HEADLIGHT BEAM LEVEL CONTROL SYSTEM


HEADLIGHT BEAM LEVEL SWITCH INSPECTION

○—○ CONTINUITY INSPECTION

Terminal	1	2	3	4	6	Illumination	
						7	9
Switch position							
0	○—○						
1		○—○				○—○	○—○
2			○—○				
3				○—○			

If continuity is not as specified, replace the switch.





N03977
N03976 le-8-2

HEADLIGHT BEAM LEVEL ACTUATOR INSPECTION

- (a) Connect the positive (+) lead from the battery to terminal 6 and the negative (-) lead to terminal 5.
- (b) Ground each terminal and check that each mode operates as shown in the chart and illustration.

Terminal	Headlight Beam Level
1 — Ground	“0”
2 — Ground	“1”
3 — Ground	“2”
4 — Ground	“3”


If operation is not as specified, replace the actuator.

DOOR COURTESY SWITCH

DOOR COURTESY SWITCH INSPECTION

- (a) Check that there is continuity between terminal and the switch body with the switch ON (switch pin released).
- (b) Check that there is no continuity between terminal and the switch body with the switch OFF (switch pin pushed in).

If operation is not as specified, replace the switch.




BE4026 BE4027

LIGHT-ON WARNING SYSTEM


DOOR COURTESY SWITCH INSPECTION
(See page BE-18)

LIGHT REMINDER RELAY INSPECTION

OPERATION



N04122




N04121

- (a) Connect the positive (+) lead from the battery to terminal 5 and 7 and the negative (-) lead to terminal 1 and 4.
- (b) Check that the buzzer does not sound when connected terminal 2 and 6 from the positive (+) lead.
- (c) Check that the buzzer sounds when disconnecting terminal 2 and 6 from the positive (+) lead.

If operation is not as specified, replace the relay.

Wire Harness Side



e-10-1


RELAY CIRCUIT

- (a) Disconnect the light reminder relay from wire harness.
- (b) Inspect wire harness and wire harness side as shown.

Tester connection	Condition	Specified value
1 — Ground	Constant	Continuity
2 — Ground	Ignition switch position LOCK or ACC	Below 1V
2 — Ground	Ignition switch position ON	10 ~ 14 V
3 — Ground	Courtesy switch position (Passenger) OFF	10 ~ 14 V
3 — Ground	Courtesy switch position (Passenger) ON	Continuity
4 — Ground	Courtesy switch position (Driver) OFF	10 ~ 14 V
4 — Ground	Courtesy switch position (Driver) ON	Continuity
5 — Ground	Constant	10 ~ 14 V
6 — Ground	Ignition switch position LOCK	Below 1 V
6 — Ground	Ignition ACC or ON	10 ~ 14 V
7 — Ground	Light control switch position OFF	Continuity
7 — Ground	Light control switch position TAIL or HEAD	10 ~ 14 V
8 — Ground	Constant	10 ~ 14 V

ILLUMINATED ENTRY SYSTEM

DOOR COURTESY SWITCH INSPECTION
(See page BE-18)




LIGHT REMINDER RELAY INSPECTION

OPERATION

- (a) Connect the positive (+) lead from the battery to terminal 5.
Connect the negative (-) lead to terminal 1.
- (b) Connect a 3.4 W bulb between terminal 8 and the battery positive (+).
- (c) Connect the negative (-) lead from the battery to terminal 3 or 4, and then check that the bulb lights.


Disconnect the negative (-) lead from the battery to terminal 3 or 4, and check that the bulb goes out approx. 5 seconds later as shown in the chart.



If operation is not as specified, replace the relay.

RELAY CIRCUIT

Disconnect the connector from the relay and inspect the connector on the wire harness side as shown in the chart.
(See page BE-19)




AUTOMATIC LIGHT CONTROL SENSOR

AUTOMATIC LIGHT CONTROL SENSOR INSPECTION

RELAY CIRCUIT

Disconnect the connector from relay and inspect the connector on the wire harness side as shown in the chart.




Tester connection	Condition	Specified value
1 - Ground	Ignition switch position LOCK or ACC	Below 1 V
1 - Ground	Ignition switch position ON or START	10 ~ 14 V
2 - Ground	Constant	10 ~ 14 V
3 - Ground	Courtesy switch position OFF Door closed	10 ~ 14 V
3 - Ground	Courtesy switch position ON Door opened	Continuity
4 - Ground	Light control switch Auto	Continuity
4 - Ground	Light control switch OFF, TAIL or HEAD	Below 1 V
5 - Ground	Light control switch HEAD	Continuity
5 - Ground	Light control switch OFF or TAIL	10 ~ 14 V
6 - Ground	Light control switch TAIL or HEAD	Continuity
6 - Ground	Light control switch OFF	10 ~ 14 V

DAYTIME RUNNING LIGHT RELAY

DAYTIME RUNNING LIGHT RELAY INSPECTION


RELAY CIRCUIT

Disconnect the connector from relay and inspect the connector on the wire harness side as shown in the chart.



Tester connection	Condition	Specified value
1 - Ground	Ignition switch position LOCK or ACC	Below 1 V
1 - Ground	Ignition switch position ON or START	10 ~ 14 V
3 - Ground	Constant	10 ~ 14 V
5 - Ground	Constant	10 ~ 14 V
6 - Ground	Headlight dimmer switch position Low Beam or High Beam	No continuity
6 - Ground	Headlight dimmer switch position Flash	Continuity

Tester connection	Condition	Specified value
8 — Ground	Engine stop	Below 1 V
8 — Ground	Engine running	10 ~ 14 V
10 — Ground	Constant	Continuity
13 — Ground	Headlight dimmer switch position Low beam	No continuity
13 — Ground	Headlight dimmer switch position High beam	Continuity
14 — Ground	Light control switch position OFF or TAIL	Below 1 V
14 — Ground	Light control switch position HEAD	10 ~ 14 V




RELAY CIRCUIT (CONNECTOR CONNECTED)

Connect the wire harness side connector to the relay and inspect wire harness side connector from the back side as shown.

Tester connection	Condition	Specified value
2 — Ground	Light control switch position OFF	Below 1 V
2 — Ground	Light control switch position TAIL or HEAD	10 ~ 14 V
4 — Ground	Light control switch position OFF or TAIL	Below 1 V
4 — Ground	Light control switch position HEAD	10 ~ 14 V
7 — Ground	Light control switch TAIL or HEAD	10 ~ 14 V
7 — Ground	Light control switch OFF	Below 1 V
9 — Ground	Light control switch position front fog switch ON	10 ~ 14 V
9 — Ground	Light control switch position front fog switch OFF	Below 1 V
11 — Ground	Light control switch position rear fog switch ON	10 ~ 14 V
11 — Ground	Light control switch position rear fog switch OFF	Below 1 V

**FOG LIGHT SYSTEM
PARTS LOCATION**




TROUBLESHOOTING

You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble	Part name	See page
Fog light does not light with light control SW HEAD (Headlight is normal.)	1. FOG Fuse 2. Fog Light Relay 3. Fog Light Switch 4. Wire Harness 5. Daytime Running Light Relay	BE-8 BE-17 BE-24 — BE-21
Fog light does not light with light control SW HEAD (Headlight does not light.)* ¹	1. Daytime Running Light Relay 2. Wire Harness	BE-21 —
Only one light does not light.	1. Bulb 2. Wire Harness	— —

*1: Inspect Headlight System




FOG LIGHT SWITCH

FRONT FOG LIGHT SWITCH INSPECTION

○—○ CONTINUITY INSPECTION

Terminal	2	3	7	8
Switch position				
OFF	○	○		
ON	○	○	○	○

If continuity is not as specified, replace the switch.



REAR FOG LIGHT SWITCH INSPECTION

(Europe and LHD Vehicle Country)

○—○ CONTINUITY INSPECTION

Terminal	2	6	5	8
Switch position				
OFF	○	○		
ON	○	○	○	○

(RHD Vehicle Country)


Terminal	8	5	3	2	6
Switch position					
OFF				○	○
ON	○	○	○	○	○

If continuity is not as specified, replace the switch.

FOG LIGHT RELAY

FOG LIGHT RELAY INSPECTION

○—○ CONTINUITY INSPECTION




Terminal	1	2	3	5
Condition				
Constant	○	○		
Apply battery voltage to terminals 1 and 2.			○	○

If continuity is not as specified, replace the relay.

TURN SIGNAL AND HAZARD WARNING SYSTEM

PARTS LOCATION



TROUBLESHOOTING

You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble	Part name	See page
Hazard and Turn do not light up.	1. Hazard Warning Switch	BE-28
	2. Turn Signal Flasher	BE-28
	3. Wire Harness	—
No of blinks for Hazard, Turn is abnormal.	1. Bulb	—
	2. Turn Signal Flasher	BE-28
	3. Wire Harness	—
Hazard does not light up. (Turn is normal.)	1. HAZ - HORN Fuse	BE-8
	2. Wire Harness	—
Hazard light on one side only does not light up.	1. Hazard Warning Switch	BE-28
	2. Wire Harness	—
Turn signal on one side only does not light up.	1. Turn Signal Switch	BE-16
	2. Wire Harness	—
Only one bulb does not light up for hazard Turn.	1. Bulb	—
	2. Wire Harness	—
*1 Turn signal does not light up.	1. Ignition Switch	BE-11
	2. TURN Fuse	BE-8
	3. Turn Signal Switch	BE-16
	4. Wire Harness	—
*2 Turn signal does not light up.	1. TURN Fuse	BE-8
	2. Turn Signal Switch	BE-16
	3. Wire Harness	—


*1 Combination Meter, Wiper and Washer do not operate.

*2 Combination Meter, Wiper and Washer are normal.

TURN SIGNAL SWITCH

TURN SIGNAL SWITCH INSPECTION

See Combination Switch on page BE-16




HAZARD WARNING SWITCH

HAZARD WARNING SWITCH INSPECTION

○—○ CONTINUITY INSPECTION

Terminal Switch position	Terminal							Illumination	
	4	5	6	7	8	9	10	2	3
OFF				○	○	○	○		
ON	○	○	○		○	○		○	○

If continuity is not as specified, replace the switch.



TURN SIGNAL FLASHER

TURN SIGNAL FLASHER INSPECTION

OPERATION


- Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 3.
- Connect the two turn signal light bulbs parallel to each other to terminal 1 and 3, check that the bulbs flash.

HINT: The turn signal lights should flash 60 to 120 times per minute.

If one of the front or rear turn signal light bulbs has an open circuit, the numbers of flashed will be more than 140 per minute.

If operation is not as specified, replace the flasher or check the wattage specification of the bulbs.

INTERIOR LIGHT SYSTEM PARTS LOCATION




N04366

TROUBLESHOOTING

You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble	Part name	See page
Room light does not light up	1. DOME Fuse	BE-8
	2. Door Courtesy Switch	BE-18
	3. Wire Harness	—
	4. Bulb	—
Room light remains always on.	1. Door Courtesy Switch	BE-18
	2. Wire Harness	—



GLOVE BOX LIGHT SWITCH


GLOVE BOX LIGHT SWITCH INSPECTION

○—○ Continuity Inspection

Terminal	1	2
Switch position		
OFF (Closed)		
ON (Opened)	○—○	○—○

If continuity is not as specified, replace the switch.

Wire Harness Side



SWITCH CIRCUIT

Disconnect the connector from the switch and inspect the connector on the wire harness side as shown.


Tester connection	Condition	Specified Value
1 — Ground	Light control switch position OFF	Below 1 V
1 — Ground	Light control switch position TAIL or HEAD	10 ~ 14 V
2 — Ground	Constant	Continuity

If the circuit is not as specified, refer to BE-76 wiring diagram and inspect the circuits connected to other parts.


DOOR COURTESY SWITCH

DOOR COURTESY SWITCH INSPECTION

(See page BE-18)


**ROOM LIGHT ASSEMBLY****ROOM LIGHT ASSEMBLY INSPECTION****w/ SLIDING ROOF**

- Disconnect the connector from room light assembly.
- Turn the room light switch ON, check that there is continuity between terminal 2 and body ground.




- Turn the room light switch DOOR, check that there is continuity between terminal 1 and 2.

If operation is not as specified, replace the switch.


**w/o SLIDING ROOF**

- Disconnect the connector from room light assembly.
- Turn the room light switch ON, check that there is continuity between terminal 2 and body ground.




- Turn the room light switch DOOR, check that there is continuity between terminal 1 and 2.

If operation is not as specified, replace the switch.

**REAR ROOM LIGHT ASSEMBLY INSPECTION**


- Disconnect the connector from room light assembly.
- Turn the room light switch ON, check that there is continuity between terminal 2 and body ground.

**METER ILLUMINATION CONTROL SYSTEM****LIGHT CONTROL RHEOSTAT INSPECTION**

Gradually turn the rheostat knob from the bright side to dark side, check that the resistance between terminals increases from approximately 0 to 4.5 Ω .

If operation is not as specified, replace the rheostat.


BACK-UP LIGHT SYSTEM PARTS LOCATION



TROUBLESHOOTING

You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble	Part name	See page
Back-up light does not light up.	1. GAUGE Fuse	BE-8
	2. Ignition Switch	BE-11
	3. Wire Harness	—
	4. Bulb	—
Back-up light remains always on.	1. Wire Harness	—
Only one light does not light up.	1. Wire Harness	—
	2. Bulb	—



BACK UP LIGHT SWITCH

BACK UP LIGHT SWITCH INSPECTION

Check that there is continuity between terminals as shown.

Switch Position	Specified
Push	Continuity
Free	No continuity


If operation is not as specified, replace the switch.

NEUTRAL START SWITCH

NEUTRAL START SWITCH INSPECTION

See AT section

STOP LIGHT SYSTEM PARTS LOCATION



TROUBLESHOOTING

You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble	Part name	See page
Stop light does not light up.	1. STOP Fuse	BE-8
	2. Stop Light Switch	BE-37
	3. Wire Harness	—
	4. Bulb	—
Stop light remains always on.	1. Stop Light Switch	BE-37
	2. Wire Harness	—
Only one light does not light up.	1. Wire Harness	—
	2. Bulb	—


STOP LIGHT SWITCH

STOP LIGHT SWITCH INSPECTION

○—○ CONTINUITY INSPECTION



Terminal	1	2
Switch position		
Switch pin free (Brake pedal depressed)	○—○	○—○
Switch pin pushed in (Brake pedal released)		

If continuity is not as specified, replace the switch.



WIPER AND WASHER SYSTEM

PARTS LOCATION



TROUBLESHOOTING


You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble	Parts name	See page
Wipers do not operate or return to OFF position.	1. AM1 H-Fuse	BE-8
	2. WIPER Fuse	BE-8
	3. Ignition Switch	BE-11
	4. Wiper and Washer Switch	BE-40
	5. Wiper Motor	BE-41
	6. Wire Harness	—
Wipers do not operate in INT position.	1. Wiper and Washer Switch	BE-40
	2. Wiper Motor	BE-41
	3. Wire Harness	—
Washer do not operate.	1. Wiper and Washer Switch	BE-40
	2. Washer Hose and Nozzle	—
	3. Washer Motor	BE-42
	4. Wire Harness	—

COMBINATION SWITCH

COMBINATION SWITCH DISASSEMBLY
(See page BE-15)

COMBINATION SWITCH ASSEMBLY
(See page BE-15)



COMBINATION SWITCH INSPECTION

INSPECT WIPER AND WASHER SWITCH CONTINUITY

Terminal		B4	B7	B8	B13	B16	B18
Switch position							
OFF	OFF	○—○					
	MIST		○—○				○
INT	OFF	○—○					
	MIST		○—○				○
LO	OFF		○—○				○
	MIST		○—○				○
HI	OFF				○—○		○
	MIST		○—○		○—○		○
WASH	OFF						
	ON			○—○		○—○	




If continuity is not as specified, replace the switch.

OPERATION (INTERMITTENT WIPER)

- Turn the wiper switch to INT position.
- Turn the INT switch to FAST position. (Variable type)
- Connect the positive (+) lead from the battery to terminal B18 and the negative (-) lead to terminal B16.
- Connect the positive (+) lead from the voltmeter to terminal B7 and the negative (-) lead to terminal B16, check that the meter needle indicates battery voltage.
- After connecting terminal B4 to terminal B18, connect it to terminal B16. Then, check that the voltage rises from 0 V to batter voltage with in the times as shown in the table.


INT time control switch position	Voltage
FAST	Approx. 2 sec. Battery voltage 0 V
SLOW	10.7 ± 5 sec. Battery voltage 0 V
Non variable type	3.3 ± 1 sec. Battery voltage 0 V

If operation is not as specified, replace the wiper and washer switch.




OPERATION (WASHER LINKED)

- Connect the positive (+) lead from the battery to terminal B18 and the negative (-) lead to terminal B16.
- Connect the positive (+) lead from the voltmeter to terminal B7 and the negative (-) lead to terminal B16.
- Push in the washer switch, check that the voltage changes as shown in the table.



If operation is not as specified, replace the wiper and washer switch.




WIPER MOTOR

FRONT WIPER MOTOR INSPECTION

OPERATION (LOW SPEED)

Connect the positive (+) lead from the battery to terminal 3 and the negative (-) lead to terminal 1, check that the motor operates at low speed.


If operation is not as specified, replace the motor.



OPERATION (HIGH SPEED)


Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 1, check that the motor operates at high speed.

If operation is not as specified, replace the motor.




OPERATION (STOPPING AT STOP POSITION)

Operate the motor at low speed and stop the motor operation anywhere except at the stop position by disconnecting positive (+) lead from terminal 5.


**REAR WIPER MOTOR INSPECTION OPERATION**

- (a) Connect the positive (+) lead from the battery to terminal 1, and the negative (-) leads to terminal 3 and the motor body, check that the motor operates.




- (b) Disconnect the negative (-) lead from terminal 3, check that the motor stops running at the stop position.

If operation is not as specified, replace the motor with the relay.

**INTERMITTENT OPERATION**

Connect the positive (+) lead from the battery to terminal 1, and the negative (-) leads to terminal 2 and the motor body, check that the motor operates intermittently for 9 – 15 seconds.


If operation is not as specified, replace the motor with the relay.

**WASHER MOTOR****WASHER MOTOR INSPECTION****W/O REAR WIPER**

Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 1, check that the motor operates.


NOTICE: These tests must be performed quickly (within 20 seconds) to prevent the coil from burning out.

If operation is not as specified, replace the motor.

**W/ REAR WIPER**

- (a) Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 1, check that the motor operates.

NOTICE: These tests must be performed quickly (within 20 seconds) to prevent the coil from burning out.




- (b) Disconnect the negative (-) lead from terminal 1, and connect the negative (-) lead from the battery to terminal 3, check that the motor operates.

NOTICE: These tests must be performed quickly (within 20 seconds) to prevent the coil from burning out.

If operation is not as specified, replace the motor.

HEADLIGHT CLEANER SYSTEM


PARTS LOCATION



TROUBLESHOOTING

You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble	Part name	See page
Headlight cleaner do not operate	1. WIPER fuse	BE-8
	2. Cleaner hose or nozzle	—
	3. Cleaner motor	BE-45
	4. Cleaner switch	BE-45
	5. Wiring or ground	—




HEADLIGHT CLEANER SWITCH

1. HEADLIGHT CLEANER SWITCH INSPECTION

○—○ Continuity Inspection

Terminal Switch position	1	4	Illumination	
			2	3
OFF			○	○
ON	○—○	○—○	○—○	○—○

If continuity is not as specified, replace the switch.



2. HEADLIGHT CLEANER RELAY INSPECTION


- Check that there is no continuity between terminals 2 and 5.
- Connect the positive (+) lead from the battery to terminals 1 and 5 and the negative (-) lead to terminal 3.
- Connect the negative (-) lead from the battery to terminal 4, check that there is continuity between terminals 2 and 5 for 0.4 – 0.6 seconds, then there is no continuity.

3. HEADLIGHT CLEANER MOTOR INSPECTION


Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, check that the motor operates.

CAUTION: These test must be performed quickly (with-in 3 – 5 seconds) to prevent the coil from burning out.

If operation is not as specified, replace the motor.




COMBINATION METER PARTS LOCATION



3S-FE Engine

4A-FE Engine


2C Engine




N04375
N02683 N04363 N04364

METER CIRCUIT (W/ TACHOMETER)


Connector "A" Connector "B" Connector "C"





Connector "A"



Connector "B"



Connector "C"




No.	Wiring Connector Side
A	1 Engine & ECT ECU
	Glow timer relay
	4 ABS
	5 Fuel filter warning, switch
	6 Parking brake switch
	7 Hazard warning switch
	8 Oil pressure switch
	9 Dome Fuse
	10 Door courtesy switch
	11 Ground
	12 Fuel sender gauge
	13 Water temperature sender gauge
	B
3 4 pulse output	
4 Oil level gauge	
5 Alternator	
6 Speed sensor	
7 ECT (PWR)	
8 Alternator	
9 Brake fluid level warning switch	
10 Fuel sender gauge	
11 IG	
13 Ground	
14 Ground	
15 Headlight dimmer and turn signal switch	
16 Rear fog light switch	
C	1 Light control rheostat
	2 TAIL fuse
	3 Tacho pulse or Pickup ⊕
	4 O/D OFF
	9 ED Monitor
	11 Headlight dimmer and turn signal switch
	12 Headlight dimmer and turn signal switch
	13 Pickup ⊖


N03970
N04003 N03973
N04006 N03972

METER CIRCUIT (CONT'D) (W/ TACHOMETER)


Connector "A" Connector "B" Connector "C"





Connector "A"



Connector "B"



Connector "C"



TROUBLESHOOTING METERS, GAUGES AND ILLUMINATIONS

You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble	Parts name	See page
Tachometer, Fuel Gauge and Water Temperature Gauge do not operate.	1. GAUGE Fuse 2. Combination Meter Wiring Circuit 3. Wire Harness 4. Meter Circuit Plate	BE-8 BE-47 — —
Speedometer does not operate.	1. Speed Sensor 2. Speedometer Driven Gear and Drive Gear	BE-52 —
Tachometer does not operate.	1. Combination Meter Wiring Circuit 2. Wire Harness 3. Igniter 4. Meter Circuit Plate	BE-47 — — —
Fuel Gauge does not operate or abnormal operation.	1. Fuel Receiver Gauge 2. Fuel Sender Gauge 3. Combination Meter Wiring Circuit 4. Wire Harness	BE-53 BE-54 BE-47 —
Water Temperature Gauge does not operate or abnormal operation.	1. Water Temperature Receiver Gauge 2. Water Temperature Sender Gauge 3. Combination Meter Wiring Circuit 4. Wire Harness	BE-56 BE-56 BE-47 —
All illumination lights do not light up.	1. TAIL Fuse 2. Light Control Rheostat 3. Wire Harness	BE-8 BE-33 —
Brightness does not change even when rheostat turned.	1. Bulb 2. Wire Harness	— —
Only one illumination light does not light up.	1. Bulb 2. Wire Harness	— —

INDICATOR LIGHTS

Trouble	Parts name	See page
O/D OFF indicator light does not light up.	1. Bulb	—
	2. Combination Meter Wiring Circuit	BE-47
	3. O/D OFF Switch	—
	4. Wire Harness	—
High beam indicator light does not light up.	1. Bulb	—
	2. Combination Meter Wiring Circuit	BE-47
	3. Wire Harness	—
	4. Headlight System	BE-12
Turn indicator light does not light up.	1. Bulb	—
	2. Combination Meter Wiring Circuit	BE-47
	3. Wire Harness	—
	4. Turn Signal and Hazard Warning System	BE-26
ECT PWR indicator light does not light up.	1. Bulb	—
	2. Combination Meter Wiring Circuit	BE-47
	3. ECT Pattern Select Switch	—
	4. Wire Harness	—
Shift indicator lights do not light up. (All)	1. Bulb	—
	2. Combination Meter Wiring Circuit	BE-47
	3. Neutral Start Switch	—
	4. Wire Harness	—
Shift indicator lights do not light up. (L.2.D)	1. Bulb	—
	2. Combination Meter Wiring Circuit	BE-47
	3. Neutral Start Switch	—
	4. Light Control Rheostat	BE-33
	5. Wire Harness	—
Only one shift indicator does not light up.	1. Bulb	—
	2. Combination Meter Wiring Circuit	BE-47
Indicator lights do not light up. (Except. Turn, Hi-beam)	1. GAUGE Fuse	BE-8
	2. Wire Harness	—

WARNING LIGHTS AND WARNING CHIME

Trouble	Parts name	See page
Warning lights do not light up. (Except. Discharge)	1. GAUGE Fuse	BE-8
	2. Combination Meter Wiring Circuit	BE-47
	3. Wire Harness	—
Low oil pressure warning light does not light up.	1. Bulb	—
	2. Combination Meter Wiring Circuit	BE-47
	3. Low Oil Pressure Warning Switch	BE-58
	4. Wire Harness	—
Fuel level warning light does not light up.	1. Bulb	—
	2. Combination Meter Wiring Circuit	BE-47
	3. Fuel Level Warning Switch	BE-55
Check engine warning light does not light up.	1. Bulb	—
	2. Engine & ECT ECU	—
	3. Wire Harness	—
Seat belt warning light does not light up.	1. Bulb	—
	2. Integration Relay	—
	3. Wire Harness	—
Discharge warning light does not light up.	1. IG2 Fuse	BE-8
	2. Bulb	—
	3. Wire Harness	—
	4. Alternater	—
Light Failure warning light does not light up.	1. Bulb	—
	2. Light Failure Sensor	—
	3. Wire Harness	—
	4. Taillight and Stop Light System	—
Brake warning light does not light up.	1. Bulb	—
	2. Combination Meter Wiring Circuit	BE-47
	3. Parking Brake Switch	BE-57
	4. Brake Fluid Level Warning Switch	BE-57
Open door warning light does not light up.	1. DOME Fuse	BE-8
	2. Bulb	—
	3. Combination Meter Wiring Circuit	BE-47
	4. Door Courtesy Switch	BE-18
	5. Wire Harness	—

(mph)

Standard Indication	Allowable range
20	21 ~ 23.5
40	41.5 ~ 44
60	62.5 ~ 66
80	83 ~ 87
100	104 ~ 108.5


(km/h)

Except Indonesia, Singapore

Standard Indication	Allowable range
20	21 ~ 25
40	41.5 ~ 46
60	62.5 ~ 67
80	83 ~ 88
100	104 ~ 109
120	125 ~ 130.5
140	145.5 ~ 151.5
160	166 ~ 173

Indonesia, Singapore

Standard Indication	Allowable range
20	18 ~ 23
40	40 ~ 44
60	60 ~ 64.5
80	80 ~ 85
100	100 ~ 105
120	120 ~ 125.5
140	140 ~ 146
160	160 ~ 167

**SPEEDOMETER SYSTEM****SPEEDOMETER INSPECTION****ON-VEHICLE**

- (a) Using a speedometer tester, inspect the speedometer for allowable indication error and check the operation of the odometer.

HINT: Tire wear and tire over or under inflation will increase the indication error.

If error is excessive, replace the speedometer.

- (b) Check the speedometer for pointer vibration and abnormal noise.

HINT: Pointer vibration can be caused by a loose speedometer cable.

SPEED SENSOR INSPECTION

- (a) Connect the positive (+) lead from battery to terminal 1 and negative (-) lead to terminal 2.
- (b) Connect the positive (+) lead from tester to terminal 3 and negative (-) lead to terminal 2.
- (c) Revolve shaft.
- (d) Check that there is voltage change from approx. 0 V to 11 V or more between terminal 3 and 2.

HINT: The voltage change should be 20 times per each revolution of the speed sensor shaft.

If operation is not as specified, replace the sensor.

DC 13.5 V, 25°C (77°F) rpm	
Standard indication	Allowable range
700	610 ~ 750
1000	900 ~ 1100
2000	1875 ~ 2125
3000	2850 ~ 3150
4000	3850 ~ 4150
5000	4850 ~ 5150
6000	5820 ~ 6180
7000	6790 ~ 7210

TACHOMETER SYSTEM**TACHOMETER INSPECTION****(ON-VEHICLE)**


- (a) Connect a tune-up test tachometer, and start the engine.

NOTICE:

- Reversing the connection of the tachometer will damage the transistors and diodes inside.
- When removing or installing the tachometer, be careful not to drop or subject it to heavy shocks.

- (b) Compare the tester and tachometer indications.


If error is excessive, replace the tachometer.

**PICKUP SENSOR INSPECTION**

Measure the resistance between terminals 1 and 2.

Resistance: Approx. 730 Ω


If resistance value is not as specified, replace the sensor.

**FUEL GAUGE SYSTEM****FUEL RECEIVER GAUGE INSPECTION****OPERATION**


- (a) Disconnect the connector from the sub-wire harness of sender gauge.
- (b) Turn the ignition switch ON, check that the receiver gauge needle indicates EMPTY.
- (c) Connect terminals 2 and 3 on the wire harness side connector through a 3 W test bulb.
- (d) Turn the ignition switch ON, check that the bulb lights up and receiver gauge needle moves toward the full side.

HINT: Because of the silicon oil in the gauge, it will take a short time for the needle to stabilize.

If operation is not as specified, inspect the receiver gauge resistance.



w/o TACHOMETER




RESISTANCE

Measure the resistance between terminals.

w/o TACHOMETER

Between terminals	Resistance (Ω)
F — E	Approx. 191
F — IG	Approx. 109
IG — E	Approx. 300

w/ TACHOMETER



w/ TACHOMETER

Between terminals	Resistance (Ω)
F — E	Approx. 181
F — IG	Approx. 123
IG — E	Approx. 304

If resistance value is not as specified, inspect the sender gauge.

FUEL SENDER GAUGE INSPECTION

OPERATION



- Disconnect the connector from the sender gauge.
- Connect a series of three 1.5 V dry cell batteries.
- Connect the positive (+) lead from the dry cell batteries to terminal 2 through a 3.4 W test bulb and the negative (–) lead to terminal 3.
- Check that the voltage rises between terminals 2 and 3 as the float is moved from the top to bottom position.

RESISTANCE

Measure the resistance between terminals 2 and 3 for each float position.

	Float position mm (in.)	Resistance (Ω)
F	Approx. 13 (0.51)	Approx. 4
E	Approx. 127 (5.00)	Approx. 111


If resistance value is not as specified, replace the receiver gauge.



FUEL LEVEL WARNING SYSTEM


FUEL LEVEL WARNING LIGHT INSPECTION

- Disconnect the connector from the sender gauge.
- Connect terminals 1 and 3 on the wire harness side connector.
- Turn the ignition switch ON, check that the warning light lights up.
If the warning light does not light up, test the bulb.




FUEL LEVEL WARNING SWITCH INSPECTION

- Apply battery voltage between terminals 1 and 3 through a 3.4 W test bulb, check that the bulb lights up.
HINT: It will take a short time for the bulb to light up.




- Submerge the switch in fuel, check that the bulb goes out.
If operation is not as specified, replace the sender gauge.



FUEL FILTER WARNING SWITCH

FUEL FILTER WARNING SWITCH INSPECTION


- Check that there is continuity between terminals when the warning switch is ON (float up).
- Check that there is no continuity between terminals when the warning switch is OFF (float down).
If operation is not as specified, replace the warning switch.





FUEL HEATER


FUEL HEATER INSPECTION

- Apply a vacuum of 46.7 ± 86.7 kPa (350 ± 50 mmHg, 13.78 ± 1.97 in.Hg) or more to the vacuum switch port.
- Using an ohmmeter, check that there is continuity between terminal 1 and the switch body.
If operation is not as specified, replace the fuel heater and vacuum switch assembly.







w/o TACHOMETER



w/ TACHOMETER



WATER TEMPERATURE GAUGE SYSTEM

WATER TEMPERATURE RECEIVER GAUGE INSPECTION

OPERATION

- Disconnect the connector from the sender gauge.
- Turn the ignition switch ON, check that the receiver gauge needle indicates COOL.

- Ground terminal on the wire harness side connector through a 3 W test bulb.

- Turn the ignition switch ON, check that the bulb lights up and receiver gauge needle moves toward the hot side. If operation is as specified, replace the sender gauge. Then, recheck the system.

If operation is not as specified, measure the receiver gauge.

OPERATION

Measure the resistance between terminals.

HINT: Connect the test leads so that the current from the ohmmeter can flow according to the chart order.

w/o TACHOMETER

Between terminals	Resistance (Ω)
T — E	Approx. 214
T — IG	Approx. 75
E — IG	Approx. 139

w/ TACHOMETER

Between terminals	Resistance (Ω)
T — E	Approx. 214
T — IG	Approx. 75
IG — E	Approx. 139




If resistance value is not as specified, replace the receiver gauge.

LOW OIL PRESSURE WARNING SYSTEM

LOW OIL PRESSURE WARNING LIGHT INSPECTION

- Disconnect the connector from the warning switch and ground terminal on the wire harness side connector.
- Turn the ignition switch ON, check that the warning light lights up.

If the warning light does not light up, test the bulb.



- Disconnect the connector from the switch.
- Ground terminal 1 on the wire harness connector.
- Turn the ignition switch ON. Check that the warning light lights up approximately 40 seconds later. If the warning light does not light up, inspect bulb or wire harness.


BRAKE WARNING SYSTEM

BRAKE WARNING LIGHT INSPECTION

- Disconnect connector from the brake fluid level warning switch and the parking brake switch.
- Turn the ignition switch to START, check that the warning light lights up.
- Start the engine, check that the warning light goes out. If operation is not as specified, inspect the bulb and the bulb check relay.


BRAKE FLUID LEVEL WARNING SWITCH INSPECTION

- Remove the reservoir tank cap and strainer.
- Disconnect the connector.
- Check that there is no continuity between terminals with the switch OFF (float up).
- Use syphon, etc. to take fluid out of the reservoir tank.
- Check that there is continuity between terminals with the switch ON (float down).
- Pour the fluid back in the reservoir tank. If operation is not as specified, replace the switch.



PARKING BRAKE SWITCH INSPECTION

- Check that there is continuity between terminals with the switch ON (switch pin released).
- Check that there is no continuity between terminals with the switch OFF (switch pin pushed in).




LOW OIL PRESSURE WARNING SWITCH INSPECTION

- (a) Check that there is continuity between terminal and ground with the engine stopped.
- (b) Check that there is no continuity between terminal and ground with the engine running.

HINT: Oil pressure should be over 49 kPa (0.5 kgf/cm, 7.1 psi).


If operation is not as specified, replace the switch.



ENGINE OIL LEVEL WARNING SWITCH


ENGINE OIL LEVEL WARNING SWITCH INSPECTION

- (a) Check that there is continuity between terminal with the switch each position.
- (b) Heat the switch to above 60°C (140°F) in an oil bath.



- (c) Check that there is continuity between terminals with the switch ON (float up.)
- (d) Check that there is no continuity between terminals with the switch OFF (float down).

If operation is not as specified, replace the switch.




CIRCUIT

Disconnect the switch connector and inspect the connector on wire harness side as shown.

Check for	Tester connection	Condition	Specified value
Continuity	2 — Ground	Constant	Continuity

If continuity is not as specified, inspect the wire harness or ground point.



OPEN DOOR WARNING SYSTEM

OPEN DOOR WARNING LIGHT INSPECTION


- (a) Disconnect the connector from the door courtesy switch and ground terminal on the wire harness side connector.
- (b) Turn the ignition switch ON, check that the warning light lights up.

If the warning light does not light up, test the bulb.

DOOR COURTESY SWITCH INSPECTION

(See page BE-18)

DEFOGGER SYSTEM PARTS LOCATION



TROUBLESHOOTING





You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble	Part name	See page
All defogger systems do not operate	1. GAUGE Fuse	BE-8
	2. CB DEFOG	—
	3. Defogger Switch	BE-62
	4. Wire Harness	BE-62
Rear Window defogger does not operate	1. Defogger Wire	BE-62
	2. Wire Harness	—

PREPARATION

SSM (SPECIAL SERVICE MATERIALS)

Part Name	Part No.	Use etc.
Duppont Paste No.4817	—	Rear window defogger wire.



DEFOGGER SWITCH

DEFOGGER SWITCH INSPECTION

○—○: CONTINUITY INSPECTION

Terminal Switch position	2	3	Illumination	
			1	4
OFF			○—○	○—○
ON	○—○	○—○	○—○	○—○

If continuity is not as specified, replace the switch.

TIMER OPERATION

- Connect the positive (+) lead from the battery to terminal 2 and the negative (−) lead to terminal 3.
- Connect between terminals 1 and 4 through a 3.4 W test bulb.
- Push the defogger switch ON, check that the test bulb and the indicator light light up for 12 to 18 minutes, then the bulb and indicator light go out.

If operation is not as specified, replace the switch.

INDICATOR LIGHT OPERATION


Connect the positive (+) lead from the battery to terminal 1 and the negative (−) lead to terminal 4, check that the indicator light lights up. If indicator light does not light up, replace switch.

DEFOGGER WIRE

DEFOGGER WIRE INSPECTION

NOTICE:

- When cleaning the glass, use a soft, dry cloth, and wipe the glass in the direction of the wire. Take care not to damage the wires.
- Do not use detergents or glass cleaners with abrasive ingredients.
- When measuring voltage, wind a piece of tin foil around the top of the negative probe and press the foil against the wire with your finger as shown.




MIRROR DEFOGGER INSPECTION

INSPECT MIRROR DEFOGGER

- Connect the positive (+) lead from the battery to terminal 4 and the negative (−) lead to terminal 5.
- Check that the mirror becomes warm.

HINT: It will take a short time for the mirror to become warm.

If the mirror does not become warm, replace the mirror assembly.




WIRE BREAKAGE

- (a) Turn the ignition switch ON.
- (b) Push in the defogger switch.
- (c) Inspect the voltage at the center of each heat wire as shown.

Voltage	Criteria
Approx. 5 V	Okay (No break in wire)
Approx. 10 V or 0 V	Broken wire


HINT: If there is approximately 10 V, the wire is broken between the center of the wire and the positive (+) end. If there is no voltage, the wire is broken between the center of the wire and ground.



WIRE BREAKAGE POINT


- (a) Place the voltmeter positive (+) lead against the defogger positive (+) terminal.
- (b) Place the voltmeter negative (-) lead with the foil strip against the heat wire at the positive (+) terminal end and slide it toward the negative (-) terminal end.
- (c) The point where the voltmeter deflects from zero to several volts is the place where the heat wire is broken.

HINT: If the heat wire is not broken, the voltmeter indicates 0 V at the positive (+) end of the heat wire but gradually increases to about 12 V as the meter probe is moved to the other end.




DEFOGGER WIRES REPAIR

- (a) Clean the broken wire tips with a grease, wax and silicone remover.
- (b) Place the masking tape along both sides of the wire to be repaired.



- (c) Thoroughly mix the repair agent (Dupont paste No.4817).
- (d) Using a fine tip brush, apply a small amount to the wire.
- (e) After a few minutes, remove the masking tape.
- (f) Allow the repair to stand at least 24 hours.

POWER WINDOW CONTROL SYSTEM PARTS LOCATION



TROUBLESHOOTING

You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble	Parts name	See page
Power Window does not operate.* ¹	1. AM1 FL	BE-8
	2. POWER Fuse	BE-8
	3. GAUGE Fuse	BE-8
	4. Power Main Relay	BE-17
	5. Ignition Switch	BE-11
	6. Power Window Master Switch	BE-67
	7. Wire Harness	—
Power Window does not operate.* ²	1. POWER Fuse	BE-8
	2. GAUGE Fuse	BE-8
	3. Ignition Switch	BE-11
	4. Power Main Relay	BE-17
	5. Power Window Master Switch	BE-67
“One Touch Power Window System” does not operate.	1. Power Window Master Switch	BE-67
Only one window glass does not move.	1. Power Window Master Switch	BE-67
	2. Power Window Switch	BE-70
	3. Power Window Motor	BE-70
	4. Wire Harness	—
“Window Lock System” does not operate.	1. Power Window Master Switch	BE-67
“Window Lock illumination” does not light up.	1. Power Window Master Switch	BE-67



*1: Power door lock control system does not operate.

*2: Power door lock control is normal.

MASTER SWITCH

MASTER SWITCH INSPECTION



○—○ CONTINUITY INSPECTION



BE2594 S-14-2-B

Window operation	Front								Rear								
	Driver's				Passenger's				Left				Right				
Terminal	LHD	1 or 2	6	7 or 8	13	1 or 2	5	7 or 8	12	1 or 2	7 or 8	9	10	1 or 2	7 or 8	11	14
Switch position	RHD	5 or 6	1	13 or 14	8	5 or 6	2	13 or 14	9	5 or 6	13 or 14	7	10	5 or 6	13 or 14	11	12
Window unlock	UP	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○
	OFF	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○
	DOWN	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○
Window lock	UP	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○
	OFF	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○
	DOWN	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○	○—○

If continuity is not as specified, replace the master switch.








LHD:

ILLUMINATION OPERATION

- (a) Set the window lock switch to the unlock position.
- (b) Connect the positive (+) lead from the battery to terminal 7 and the negative (-) lead to terminal 1, check that all the illuminations light up.

- (c) Set the window lock switch to the lock position, check that all the passenger's illuminations go out. If operation is not as specified, replace the master switch.



RHD:

- (a) Set the window lock switch to the unlock position.
- (b) Connect the positive (+) lead from the battery to terminal 14 and the negative (-) lead to terminal 6, check that all the illuminations light up.

- (c) Set the window lock switch to the lock position, check that all the passenger's illuminations go out. If operation is not as specified, replace the master switch.

LHD:

ONE TOUCH POWER WINDOW SYSTEM

(Inspection using an ammeter)






- (a) Disconnect the connector from the master switch.
- (b) Connect the positive (+) lead from the ammeter to terminal 6 on the wire harness side connector and the negative (-) lead to negative (-) terminal of the battery.
- (c) Connect the positive (+) lead from the battery to terminal 13 on the wire harness side.
- (d) As the window goes down, check that the current flows approximately 7 amperes.
- (e) Check that the current increases approximately 14.5 amperes or more when the window stops going down.

HINT: The circuit breaker opens some 4 — 40 seconds after the window stops going down, so that check must be made before the circuit breaker operates.

If the operation is as specified, replace the master switch.

(Inspection using an ammeter with a current-measuring probe.)

- (a) Remove the master switch with connector connected.
- (b) Attach a current-measuring probe to terminal 6 of the wire harness.
- (c) Turn the ignition switch ON and set the power window switch in the down position.
- (d) As the window goes down, check that the current flows approximately 7 amperes.



- (e) Check that the current increases approximately 14.5 amperes or more when the window stops going down.

HINT: The circuit breaker opens some 4 — 40 seconds after the window stops going down, so that check must be made before the circuit breaker operates.

If operation is as specified, replace the master switch.

RHD:

ONE TOUCH POWER WINDOW SYSTEM

(Inspection using an ammeter)

- (a) Disconnect the connector from the master switch.
- (b) Connect the positive (+) lead from the ammeter to terminal 1 on the wire harness side connector and the negative (-) lead to negative (-) terminal of the battery.
- (c) Connect the positive (+) lead from the battery to terminal 8 on the wire harness side.
- (d) As the window goes down, check that the current flows approximately 7 amperes.
- (e) Check that the current increases approximately 14.5 amperes or more when the window stops going down.

HINT: The circuit breaker opens some 4 — 40 seconds after the window stops going down, so that check must be made before the circuit breaker operates.

If operation is as specified, replace the master switch.

(Inspection using an ammeter with a current-measuring probe.)

- (a) Remove the master switch with connector connected.
- (b) Attach a current-measuring probe to terminal 1 of the wire harness.
- (c) Turn the ignition switch ON and set the power window switch in the down position.
- (d) As the window goes down, check that the current flows approximately 7 amperes.
- (e) Check that the current increases approximately 14.5 amperes or more when the window stops going down.

HINT: The circuit breaker opens some 4 — 40 seconds after the window stops going down, so that check must be made before the circuit breaker operates.

If operation is as specified, replace the master switch.


POWER WINDOW SWITCH

POWER WINDOW SWITCH INSPECTION


○—○ CONTINUITY INSPECTION

Terminal Switch position	1	2	3	4	5
UP	○—○			○—○	
OFF	○—○		○—○		
DOWN			○—○		○—○

If continuity is not as specified, replace these switch.



BE2658 G-5-2-A



N03988 N03989

POWER WINDOW MOTOR

POWER WINDOW MOTOR INSPECTION LEFT SIDE DOOR MOTOR OPERATION


- (a) Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, check that the motor turns clockwise.
- (b) Reverse the polarity, check that the motor turns counterclockwise.

If operation is not as specified, replace the motor.


LEFT SIDE DOOR MOTOR CIRCUIT BREAKER OPERATION DRIVER'S DOOR

- (a) Disconnect the connector from the master switch.
- (b) Connect the positive (+) lead from the battery to terminal 6 and the negative (-) lead to terminal 13 on the wire harness side connector, and raise the window to full closed position.
- (c) Continue to apply voltage, check that there is a circuit breaker operation noise within approximately 4 to 40 seconds.

- (d) Reverse the polarity, check that the window begins to descend within approximately 60 seconds.
- If operation is not as specified, replace the motor.




BE2659
BE2615 BE2660




BE2659
BE2617 BE2661

PASSENGER'S DOOR

- (a) Disconnect the connector from the power window switch.
 - (b) Connect the positive (+) lead from the battery to terminal 4 and the negative (-) lead to terminal 1 on the wire harness side connector, and raise the window to full closed position.
 - (c) Continue to apply voltage, check that there is a circuit breaker operation noise within approximately 4 to 40 seconds.
 - (d) Reverse the polarity, check that the window begins to descend within approximately 60 seconds.
- If operation is not as specified, replace the motor.




BE2659
BE2615 BE2663



BE2659
BE2617 BE2662

RIGHT SIDE DOOR MOTOR OPERATION


- (a) Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, check that the motor turns counterclockwise.
 - (b) Reverse the polarity, check that the motor turns clockwise.
- If operation is not as specified, replace the motor.




N03986 N03987

RIGHT SIDE DOOR MOTOR CIRCUIT BREAKER OPERATION DRIVER'S DOOR

- (a) Disconnect the connector from the master switch.
 - (b) Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 8 on the wire harness side connector, and raise the window to full closed position.
 - (c) Continue to apply voltage, check that there is a circuit breaker operation noise within approximately 4 to 40 seconds.
 - (d) Reverse the polarity, check that the window begins to descend within approximately 60 seconds.
- If operation is not as specified, replace the motor.



BE2659
BE2615 BE3109



BE2659
BE2617 BE3110


PASSENGER'S DOOR

See LEFT SIDE DOOR MOTOR OPERATION on page BE-70

POWER MAIN RELAY

POWER MAIN RELAY INSPECTION

○—○ CONTINUITY INSPECTION




BE4049 BE1840

Terminal	1	2	3	5
Condition				
Constant	○—○			
Apply battery voltage to terminals 1 and 2.			○—○	

If continuity is not as specified, replace the relay.

POWER DOOR LOCK CONTROL SYSTEM PARTS LOCATION




N04505

TROUBLESHOOTING

You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble		Parts name	See page
"Door lock control system" does not operate. (All)		1. Door Lock Control Relay (Door Lock Signal)	BE-78
		2. Door Lock Control Relay (Relay Circuit)	BE-78
		3. RADIO & CIG Fuse	BE-8
		4. P/W Fuse	BE-8
		5. Wire Harness	—
		6. Other Parts	—
Multifunction in Door Lock/Unlock	Using door manual switch	1. Door Lock Manual Switch 2. Wire Harness 3. Door Lock Control Relay (Relay Circuit) 4. Other Parts	BE-75 — BE-78 —
	Using door manual switch and key	1. Wire Harness 2. Door Lock Control Relay (Door Lock Signal) 3. Other Parts	— BE-78 —
	Using Key	1. Door Key Lock and Unlock Switch 2. Wire Harness 3. Door Lock Control Relay (Relay Circuit) 4. Other Parts	BE-75 — BE-78 —
Fault in 2-Operation unlock function of Driver's side door key lock and Unlock switch.		1. Door Key Lock and Unlock Switch 2. Wire Harness 3. Door Lock Control Relay (Relay Circuit) 4. Other Parts	BE-75 — BE-78 —
Fault in key confine prevention operation.		1. Key Unlock Warning Switch 2. Door Courtesy Switch 3. Door Lock Switch 4. Wire Harness 5. Door Lock Control Relay (Relay Circuit) 6. Other Parts	BE-75 BE-11 BE-75 — BE-78 —
Only one door lock does not operate.		1. Door Lock Motor 2. Wire Harness	BE-76 —

MASTER SWITCH




MASTER SWITCH INSPECTION

○—○ CONTINUITY INSPECT

Terminal	LHD	1	2	3	4
	RHD	6	5	4	3
LOCK		○—○	○—○	○—○	○—○
OFF		○—○	○—○		
UNLOCK		○—○	○—○	○—○	

If continuity is not as specified, replace the switch.



DOOR KEY LOCK AND UNLOCK SWITCH

DOOR KEY LOCK AND UNLOCK SWITCH INSPECTION

○—○ CONTINUITY INSPECT

Terminal	1	2	3
	Switch position		
LOCK		○—○	○—○
OFF			
UNLOCK	○—○	○—○	


If continuity is not as specified, replace the switch.

KEY UNLOCK WARNING SWITCH


KEY UNLOCK WARNING SWITCH INSPECTION
(See page BE-11)

DOOR COURTESY SWITCH


DOOR COURTESY SWITCH INSPECTION
(See page BE-18)

**DOOR LOCK MOTOR****DOOR LOCK MOTOR INSPECTION****OPERATION (Front door lock)**


- (a) Connect the positive (+) lead from the battery to terminal 5 and the negative (-) lead to terminal 7, check that the door lock link moves to UNLOCK position.



- (b) Connect the positive (+) lead from the battery to terminal 7 and the negative (-) lead to terminal 5, check that the door lock link moves to LOCK position.


**OPERATION (Rear door lock)**

- (a) Connect the positive (+) lead from the battery to terminal 2 and negative (-) lead to terminal 4, check that the door lock link moves to UNLOCK position.




- (b) Reverse the polarity, check that the door lock link moves to LOCK position.

If operation is not as specified, replace the door lock assembly.


**PTC THERMISTER OPERATION****(Inspection using an ammeter)**

- (a) Connect the positive (+) lead from the battery to terminal 5.
- (b) Connect the positive (+) lead from the ammeter to terminal 7 and the negative (-) lead to battery negative (-) terminal, check that the current changes from approximately 3.2 A to less than 0.5 A within 20 to 70 seconds.




- (c) Disconnect the leads from terminals.
- (d) Approximately 60 seconds later, connect the positive (+) lead from the battery to terminal 5 and the negative (-) lead to terminal 7, check that the door lock moves to LOCK position.

If operation is not as specified, replace the door lock assembly.

**(Inspection using an ammeter with a current-measuring probe.)**


- (a) Connect the positive (+) lead from the battery to terminal 5 and the negative (-) lead to terminal 7.
- (b) Attach a current-measuring probe to either the positive (+) lead or the negative (-) lead, check that the current changes from approximately 3.2 A to less than 0.5 A within 20 to 70 seconds.



- (c) Disconnect the leads from terminals.
- (d) Approximately 60 seconds later, reverse the polarity, check that the door lock moves to LOCK position.

If operation is not as specified, replace the door lock assembly.

Wire Harness Side



e-16-1-A

POWER DOOR LOCK CONTROL RELAY

POWER DOOR LOCK CONTROL RELAY INSPECTION

RELAY CIRCUIT

Disconnect the connector from the relay and inspect the connector on the wire harness side as shown in the chart.

Check for	Tester connection	Condition	Specified value	
Continuity	5 — Ground	Passenger's door unlock detection switch position	OFF (Door locked)	No continuity
		ON (Door unlocked)	Continuity	
	6 — Ground	Driver's door unlock detection switch position	OFF (Door locked)	No continuity
		ON (Door unlocked)	Continuity	
	7 — Ground	Key unlock warning switch position	OFF (Ignition key removed)	No continuity
			ON (Ignition key set)	Continuity
	9 — Ground	Parking brake lever position	OFF (Release the PKB lever)	No continuity
			ON (Pull the PKB lever)	Continuity
	10 — Ground	Driver's door key lock and door lock manual switch position	ON (Driver's door key locked)	Continuity
ON (Door lock manual switch locked)			Continuity	
11 — Ground	Driver's door key lock and door lock manual switch position	OFF (Driver's door key unlocked)	Continuity	
		OFF (Door lock manual switch unlocked)	Continuity	
13 — Ground	Constant	—	Continuity	
Voltage	2 — Ground	Driver's door courtesy switch position	ON (Door opened)	Battery voltage
	1 — Ground	Ignition switch position	LOCK	No voltage
			ACC or ON	Battery voltage
8 — Ground	Constant	—	Battery voltage	

DOOR UNLOCK DETECTION SWITCH

DOOR UNLOCK DETECTION SWITCH INSPECTION

○—○ CONTINUITY INSPECTION

Terminal	4	6
Switch position		
OFF (Door lock set to LOCK)		
ON (Door lock set to UNLOCK)	○—○	○—○


If continuity is not as specified, replace the door lock assembly.

DOOR LOCK SIGNAL


HINT: When the relay circuit is as specified, inspect the door lock signal.

- Connect the connector to the relay.
- Connect the positive (+) lead from the voltmeter to terminal 3 and the negative (−) lead to terminal 1.
- Set the door lock manual switch to UNLOCK, check that the voltage rises from 0 volts to battery voltage for approximately 0.2 seconds.
- Connect the positive (+) lead from the voltmeter to terminal 4 and the negative (−) lead to terminal 1.
- Set the door lock manual switch to LOCK, check that the voltage rises from 0 volts to battery voltage for approximately 0.2 seconds.


If operation is not as specified, replace the relay.



N01248




BE2594 N04124



BE2594 N04123

SLIDING ROOF SYSTEM PARTS LOCATION



N04368

TROUBLESHOOTING

You will find the cause of trouble more easily be properly using the table shown below. In this table, the numbers indicate the order of priority of the causes of trouble. Check each part in the order shown. If necessary, replace the part.

Trouble		Parts name	See page
OPEN	Does not move.	*1 1. DOME Fuse 2. GAUGE Fuse 3. POWER Fuse 4. Ignition Switch 5. Power Main Relay 6. Sliding Roof Switch 7. Sliding Roof Control Relay 8. Sliding Roof Limit Switch 9. Sliding Roof Motor 10. Wire Harness	BE-8 BE-8 BE-8 BE-11 BE-17 BE-82 BE-83 BE-82 BE-82 —
		*2 1. Sliding Roof Switch 2. Sliding Roof Control Relay 3. Sliding Roof Limit Switch 4. Sliding Roof Motor 5. Wire Harness	BE-82 BE-83 BE-82 BE-82 —
	Stops halfway.	— 1. Sliding Roof Limit Switch 2. Sliding Roof Control Relay 3. Sliding Roof Motor 4. Wire Harness	BE-82 BE-83 BE-82 —
CLOSE	Does not move.	*1 1. DOME Fuse 2. GAUGE Fuse 3. POWER Fuse 4. Ignition Switch 5. Power Main Relay 6. Sliding Roof Switch 7. Sliding Roof Control Relay 8. Sliding Roof Limit Switch 9. Sliding Roof Motor 10. Wire Harness	BE-8 BE-8 BE-8 BE-11 BE-17 BE-82 BE-83 BE-82 BE-82 —
		*2 1. Sliding Roof Switch 2. Sliding Roof Control Relay 3. Sliding Roof Limit Switch 4. Sliding Roof Motor 5. Wire Harness	BE-82 BE-83 BE-82 BE-82 —
	Stops halfway.	— 1. Sliding Roof Limit Switch 2. Sliding Roof Control Relay 3. Sliding Roof Motor 4. Wire Harness	BE-82 BE-83 BE-82 —
	Does not stop at the stop- ping position.	— 1. Sliding Roof Limit Switch 2. Sliding Roof Control Relay	BE-82 BE-83
	Returns and stop.	— 1. Sliding Roof Limit Switch 2. Sliding Roof Control Relay	BE-82 BE-83


*1: Power window and power seat does not operate.

*2: Power window and power seat are normal operate.

SLIDING ROOF SWITCH

SLIDING ROOF SWITCH INSPECTION

○—○ CONTINUITY INSPECTION




Terminal Switch position		1	3	4	5
SLIDE	OPEN			○—○	
	OFF	○—○		○—○	○—○
	CLOSE	○—○			○—○
TILT	DOWN	○—○	○—○		
	OFF	○—○		○—○	○—○
	UP		○—○	○—○	

If continuity is not as specified, replace the switch.

LIMIT SWITCH

LIMIT SWITCH INSPECTION

○—○ CONTINUITY INSPECTION



Terminal Switch position		1	2	5
No.1 Limit switch	OFF (SW pin released)			
	ON (SW pin pushed in)		○—○	
No.2 Limit switch	OFF (SW pin released)			
	ON (SW pin pushed in)	○—○		○—○



If continuity is not as specified, replace the motor.

SLIDING ROOF MOTOR

SLIDING ROOF MOTOR INSPECTION

OPERATION

- Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2 and 5, check that the motor turns to counterclockwise (moves to the close side.)
- Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 1 and 5, check that the motor turns to clockwise (moves to the open side)




SLIDING ROOF CONTROL RELAY

SLIDING ROOF CONTROL RELAY INSPECTION

RELAY CIRCUIT

Disconnect the relay connector and inspect the connector on the wire harness side as shown in the chart.




Check for	Tester connection	Condition		Specified value
Voltage	1 — Ground	Constant		Battery voltage
	2 — Ground	Ignition switch position	LOCK or ACC	No voltage
			ON	Battery voltage
	3 — Ground	Ignition switch position	LOCK or ACC	No voltage
ON			Battery voltage	
4 — Ground	Constant			No voltage

If circuit is as specified, replace the relay.

POWER MAIN RELAY

POWER MAIN RELAY INSPECTION

○—○ CONTINUITY INSPECTION




Terminal Condition	1	2	3	5
Constant	○—○			
Apply battery voltage to terminals 1 and 2.			○—○	○—○

If continuity is not as specified, replace the relay.

POWER MIRROR CONTROL SYSTEM

PARTS LOCATION



TROUBLESHOOTING


You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble	Parts name	See page
Power mirror on each side does not operate at all.	<ul style="list-style-type: none"> • Fuse RADIO • Mirror Switch • Mirror Motor (Up/Down Control) • Mirror Motor (Left/Right Control) • Wiring and Ground 	BE-8 BE-86 BE-87 BE-87 —
Left or right power mirror does not operate at all.	<ul style="list-style-type: none"> • Mirror Switch • Mirror Motor (Up/Down Control) • Mirror Motor (Left/Right Control) • Wiring and Ground 	BE-86 BE-87 BE-87 —
Up/Down control of left or right power mirror does not operate.	<ul style="list-style-type: none"> • Mirror Motor (Up/Down Control) • Wiring and Ground 	BE-87 —
Left/Right control of left or right power mirror does not operate.	<ul style="list-style-type: none"> • Mirror Motor (Left/Right Control) • Wiring and Ground 	BE-87 —

POWER MIRROR SWITCH

POWER MIRROR SWITCH INSPECTION

○—○ CONTINUITY INSPECTION



w/o Retractable

Left Right adjustment switch position Terminal Control switch position	Left					Right				
	1	3	4	9	10	1	2	3	4	6
UP	○	○—○			○	○				○
DOWN	○		○—○		○	○				○
LEFT	○	○—○			○	○				○
RIGHT	○		○—○		○	○	○—○			○

w/ Retractable

Left Right adjustment switch position Terminal Control switch position	Left					Right				
	1	2	5	6	10	3	5	6	9	10
UP	○		○—○		○	○				○
DOWN	○		○—○		○	○				○
LEFT		○—○			○					○
RIGHT		○—○			○					○

Terminal Control switch position	4	10
Retractable	○	○—○

If continuity is not as specified, replace the switch.

POWER MIRROR MOTOR

POWER MIRROR MOTOR INSPECTION

OPERATION

- Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, check that the mirror turns to upward.
- Reverse the polarity, check that the mirror turns downward.
- Connect the positive (+) lead from the battery to terminal 3 and the negative (-) lead to terminal 2, check that the mirror turns to left side.
- Reverse the polarity, check that the mirror turns to right side.





If operation is not as specified, replace the mirror assembly.


w/ Defogger type

- Connect the positive (+) lead from the battery to terminal 3 and the negative (-) lead to terminal 2, check that the mirror turns to upward.
- Reverse the polarity, check that the mirror turns downward.

- Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, check that the mirror turns left side.
- Reverse the polarity, check that the mirror turns to right side.


If operation is not as specified, replace the mirror assembly.






w/ Retractable type

- (a) Connect the positive (+) lead from the battery to terminal 7 and the negative (–) lead to terminal 6, check that the mirror turns to upward.
- (b) Reverse the polarity, check that the mirror turns downward.




- (c) Connect the positive (+) lead from the battery to terminal 5 and the negative (–) lead to terminal 6, check that the mirror turns to left side.
- (d) Reverse the polarity, check that the mirror turns to right side.



- (e) Connect the positive (+) lead from the battery to terminal 2 and the negative (–) lead to terminal 1, check that the mirror turns to retractable.
- (f) Connect the positive (+) lead from the battery to terminal 3 and the negative (–) lead to terminal 4, check that the mirror returns to its original position.

SEAT HEATER SYSTEM PARTS LOCATION




TROUBLESHOOTING

You will find the cause of trouble more easily by properly using the table shown below. In this table, the numbers indicate the order priority of the causes of trouble. Check each part in the order shown. If necessary, replace the part.

Trouble	Parts name	See page
Seat heaters do not operate. (Driver's and Passenger's)	1. Fuse S/HTR	BE-8
	2. Engine Main Relay	—
	3. Seat Heater Switch	BE-91
	4. Wire Harness	—
	5. Seat Heater	BE-92
Driver's seat heater does not operate.	1. Seat Heater Switch	BE-91
	2. Seat Heater Relay (Left)	—
	3. Wire Harness	—
Passenger's seat heater does not operate.	1. Seat Heater Switch	BE-91
	2. Seat Heater Relay (Right)	—
	3. Wire Harness	—
Seat heater temperature is too hot.	1. Seat Heater	BE-92

SEAT HEATER SWITCH




BE4756 S-6-2-D

SEAT HEATER SWITCH INSPECTION

○—○ CONTINUITY INSPECTION

Terminal Switch position	2	3	5	6	Illumination	
					1	4
HI	○—○		○—○			
OFF					○—○	○—○
LO	○—○		○—○			

If continuity is not as specified, replace the switch.



N04096 N04174

INDICATOR LIGHT OPERATION

- Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 6.
- Push the switch to HI or LO, check that the indicator light of the pushed side lights up.

If operation is not as specified, replace the switch.

SEAT HEATER INSPECTION

INSPECT SEAT HEATER (Continuity/Seat Cushion)

- (a) Heat the thermostat with a light.
- (b) Inspect the seat heater continuity between term.


Check for	Tester connection	Condition	Specified value
Conti-nuity	A1-B2	Seat heater temperature below 25°C (77°F)	Continuity
	A2-B2	Seat heater temperature below 35°C (95°F)	Continuity
	A3-B1	Constant	Continuity

If continuity is not as specified, replace the seat cushion pad.



(Continuity/Seat Back)

Check that there is continuity between terminals.
If operation is not as specified, replace the seat back pad.


Connector "A"




Connector "B"



Thermostat




e-3-2
N04177 e-2-2-A



e-2-1

AUDIO SYSTEM PARTS LOCATION



N04370

SYSTEM DESCRIPTION

RADIO WAVE BAND

The radio wave bands used in radio broadcasting are as follows:

Frequency	30 kHz	300 kHz	3 MHz	30 MHz	300 MHz
Designation	LF	MF	HF	VHF	
Radio wave		AM		FM	
Modulation method	Amplitude modulation			Frequency modulation	

LF: Low Frequency MF: Medium Frequency HF: High Frequency VHF: Very High Frequency

SERVICE AREA

There is great difference in the size of the service area for AM, FM monaural, and FM stereo broadcasting. Thus it may happen that FM broadcast cannot be received even though AM comes in very clearly.

Not only does FM stereo have the smallest service area, but it also picks up static and other types of interference ("noise") the most easily.

RECEPTION PROBLEMS

Besides the problem of static, there are also the problems called "fading", "multipath", and "fade out". These problems are caused not by electrical noise but by the nature of the radio waves themselves.

Fading


Besides electrical interference, AM broadcasts are also susceptible to other types of interference, especially at night. This is because AM radio waves bounce off the ionosphere at night. These radio waves then interfere with the signals from the same transmitter that reach the vehicle's antenna directly. This type of interference is called "fading".

Multipath


One type of interference caused by the bouncing of radio waves off of obstructions is called "multipath". Multipath occurs when a signal from the broadcast transmitter antenna bounces off of buildings and mountains and interferes with the signal that is received directly.

Fade Out


Because FM radio waves are of higher frequencies than AM radio waves, they bounce off of buildings, mountains, and other obstructions. For this reason, FM signals often seem to gradually disappear or fade away as the vehicle goes behind a building or other obstruction. This is called "fade out".




BE2818



BE2819



BE2820




BE2821

MAINTENANCE OF TAPE PLAYER

Head Cleaning

- Raise the cassette door with your finger. Next using a pencil or like object, push in the guide.
- Using a cleaning pen or cotton applicator soaked in cleaner, clean the head surface, pinch rollers and capstans.



C0192

TROUBLESHOOTING

NOTICE: When replacing the internal mechanism (ECU part) of the audio system, be careful that no part of your body or clothing comes in contact with the terminals of the leads from the IC etc. of the replacement part (spare part).

HINT: This inspection procedure is a simple troubleshooting which should be carried out on the vehicle during system operation and was prepared on the assumption of system component troubles (except for the wires and connectors, etc.).

Always inspect the trouble taking the following items into consideration.


- Open or short circuit of the wire harness
- Connector or terminal connection fault

Problem		No.
Radio	Radio not operating when power switch turned to 'ON'.	1
	Display indicates when power switch turned to 'ON', but no sound (including 'noise') is produced.	2
	Noise present, but AM-FM not operating.	3
	Any speaker does not work.	4
	Reception poor.	5
	Sound quality poor.	6
	Preset memory disappears.	7
Tape player	Cassette tape cannot be inserted.	8
	Cassette tape inserts, but no power	9
	Power coming in, but tape player not operating.	10
	Any speaker does not work.	11
	Sound quality poor.	12
	Tape jammed, malfunction with tape speed or auto-reverse	13
Antenna	Cassette tape will not eject.	14
	Antenna-related.	15
Noise	Noise produced by vibration or shock while driving.	16
	Noise produced when engine starts.	17

The term "AM" includes LW, MW and SW, and the term "FW" includes UKW.


HOW TO USE DIAGNOSTIC CHART

Reference:





① : Phenomenon : Problem ② : Check item ③ : Trouble part or disposal


1 Radio **RADIO NOT OPERATING WHEN POWER SWITCH TURNED TO 'ON'**




N04758





N04757




2 Radio **DISPLAY INDICATES WHEN POWER SWITCH TURNED TO 'ON', BUT NO SOUND (INCLUDING 'NOISE') IS PRODUCED**



N04758




N04757



3 Radio NOISE PRESENT, BUT AM-FM NOT OPERATING


Go to No. 15
If radio side faulty → Radio faulty.

4 Radio ANY SPEAKER DOES NOT WORK



N04758


Is hiss produced by non-functioning speaker? Yes → Radio faulty.
No
Is there continuity in speaker wire harness? No → Speaker wire harness faulty.
Yes
Temporarily install another speaker. Functions OK? Yes → Speaker faulty.
No
Radio faulty.



N04757


Is tape player operating normally? Yes → Radio assembly faulty.
No
Is hiss produced by non-functioning speaker? Yes → Radio assembly faulty.
No
Is there continuity in speaker wire harness? No → Speaker wire harness faulty.
Yes
Temporarily install another speaker. Functions OK? Yes → Speaker faulty.
No
Radio assembly faulty.

5 Radio EITHER AM OR FM DOES NOT WORK, RECEPTION POOR (VOLUME FAINT), FEW PRESET TUNING BANDS



N04758

Problem with radio wave signals or location? Yes → Poor signals, poor location.
No
Are both AM or FM defective? No → Radio faulty.
Yes
Is power for the antenna being output from the radio? No → Radio faulty.
Yes
Go to No. 15
Temporarily install another speaker. Functions OK? Yes → Speaker faulty.
No
Radio faulty.





N04757


Problem with radio wave signals or location? Yes → Poor signals, poor location.
No
Are both AM or FM defective? No → Radio assembly faulty.
Yes
Is power for the antenna being output from the radio assembly? No → Radio assembly faulty.
Yes
Go to No. 15

CONTINUED ON NEXT PAGE


CONTINUED FROM PREVIOUS PAGE





N04757




6 Radio **SOUND QUALITY POOR**



N04758






N04757




CONTINUED ON NEXT PAGE



CONTINUED FROM PREVIOUS PAGE




7 Radio PRESET MEMORY DISAPPEARS




N04758




N04757




8 **Tape Player** **CASSETTE TAPE CANNOT BE INSERTED**




NO4757




9 **Tape Player** **CASSETTE TAPE INSERTS, BUT NO POWER**




NO1721




10	Tape Player	POWER COMING IN, BUT TAPE PLAYER NOT OPERATING
----	-------------	---




N04757




11	Tape Player	EITHER SPEAKER DOES NOT WORK
----	-------------	-------------------------------------




N04757




12 Tape Player SOUND QUALITY POOR (VOLUME FAINT)




N01721




13 Tape Player TAPE JAMMED MALFUNCTION WITH TAPE SPEED OR AUTO-REVERSE



14 Tape Player CASSETTE TAPE WILL NOT EJECT




N04757




15	Antenna	ANTENNA-RELATED
-----------	----------------	------------------------


Antenna w/o Motor Type



Motor Antenna Type




Motor Antenna and Glass Printed Antenna Type




CONTINUED ON NEXT PAGE


CONTINUED FROM PREVIOUS PAGE




16 Noise **NOISE PRODUCED BY VIBRATION OR SHOCK WHILE DRIVING**




17 Noise **NOISE PRODUCED WHEN ENGINE STARTS**





BE4127 NO4129
NO4130

Wire Harness Side



e-8-1

ANTENNA MOTOR

ANTENNA MOTOR INSPECTION

- Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 3.
- Check that the motor turns (moves upward).

NOTICE: These tests must be performed quickly (within 3 – 5 seconds) to prevent the coil from burning out.

- Then, reverse the polarity, check that the motor turns the opposite way (moves downward).

NOTICE: These tests must be performed quickly (within 3 – 5 seconds) to prevent the coil from burning out.

If operation is not as specified, replace the motor.

ANTENNA MOTOR CONTROL RELAY

ANTENNA MOTOR CONTROL RELAY INSPECTION

RELAY CIRCUIT

Disconnect the connector from the relay and inspect the connector on wire harness side as shown in the chart.


Check for	Tester connection	Condition		Specified value
Continuity	2 – 3	Constant		Continuity
	6 – Ground	Constant		Continuity
Voltage	1 – Ground	Constant		Battery voltage
	4 – Ground	Ignition switch position	LOCK or ACC	No voltage
			ON	Battery voltage
	5 – Ground	Ignition switch position	LOCK	No voltage
			ACC or ON	Battery voltage
	7 – Ground	Ignition switch position	LOCK	No voltage
ACC or ON			Radio switch OFF or cassette ON	No voltage
		Radio switch ON and cassette OFF	Battery voltage	
8 – Ground	Ignition switch position	ACC or ON	Cassette ON or Radio switch on	Battery voltage
		LOCK	and cassette OFF	No voltage

If circuit is as specified, replace the relay.


GLASS PRINTED ANTENNA

GLASS PRINTED ANTENNA INSPECTION

(Use same procedure as for "INSPECT DEFOGGER WIRES")



BE4671



NO1858

ANTENNA ROD REMOVAL AND INSTALLATION

ANTENNA ROD REMOVAL AND INSTALLATION

1. REMOVE ANTENNA ROD


HINT: Perform this operation with the battery negative (-) cable connected to the battery terminal.

- Turn the ignition switch to "LOCK" position.
- Remove the antenna nut.
- Press the "AM" button on the radio receiver, and simultaneously turn the ignition switch to "ACC" position.

HINT:

- The rod will extend fully and be released from the motor antenna.
- After removing the antenna rod, leave the ignition switch at "ACC".

NOTICE: To prevent body damage when the antenna rod is released, hold the rod while comes out.



NO1859

2. INSTALL ANTENNA ROD

- Insert the cable of the rod until it reaches the bottom.


HINT:

- When inserting the cable, the teeth on the cable must face toward the rear of the vehicle.
- Insert the antenna approx. 290 mm (11.4 in.)

- Wind the cable to retract the rod by turning the ignition switch to "LOCK" position.

HINT:

- If the ignition switch is already in "LOCK" position, perform step 1 (c) first, then turn the ignition switch to "ACC" position.
- In case the cable is not wound, twist it as shown in the illustration.
- Even if the rod has not retracted fully, install the antenna nut and inspect the antenna rod operation. It will finally retract fully.



BE4674


- Inspect the antenna rod operation by pushing the radio wave band select buttons.

CLOCK TROUBLESHOOTING

HINT: Troubleshoot the clock according to the table below.


Clock will not operate	1
Clock loses or gains time	2

± 1.5 seconds/day




e-5-2
BE1847 e-5-1

1 CLOCK WILL NOT OPERATE




e-5-2
e-5-1

- (a) Check that the battery voltage is 10 – 16 V. If voltage is not as specified, replace the battery.
 - (b) Check that the DOME fuse is not blown. If the fuse is blown, replace the fuse and check for short.
 - (c) Troubleshoot the clock as follows.
- HINT: Inspect the connector on the wire harness side.




2 CLOCK LOSES OR GAINS TIME



e-5-2
e-5-1

- (a) Check that the battery voltage is 10 – 16 V. If voltage is not as specified, replace the battery.
 - (b) Inspect the error of the clock.
Allowable error (per day): ± 1.5 seconds
If the error exceeds the allowable error, replace the clock.
 - (c) Check that the clock adjusting button is sticking in position and has failed to return. If the button is not returned, repair or replace the clock.
 - (d) Troubleshoot the clock as follows.
- HINT: Inspect the connector on the wire harness side.



BRAKE SYSTEM

GENERAL DESCRIPTION	BR- 2
DESCRIPTION	BR- 3
OPERATION	BR- 3
PREPARATION	BR- 6
TROUBLESHOOTING	BR- 8
CHECK AND ADJUSTMENT	BR- 9
MASTER CYLINDER	BR- 13
BRAKE BOOSTER	BR- 19
VACUUM PUMP	BR- 21
FRONT BRAKE	BR- 26
(P E57 Disc Brake)	BR- 26
FRONT BRAKE	BR- 34
(P E38T Disc Brake)	BR- 34
REAR BRAKE	BR- 42
(Drum Brake)	BR- 42
REAR BRAKE	BR- 50
(Disc Brake)	BR- 50
REAR BRAKE	BR- 59
(Parking Brake for Rear Disc Brake)	BR- 59
PROPORTIONING VALVE (P VALVE)	BR- 66
LOAD SENSING PROPORTIONING	
VALVE (LSPV)	BR- 68
ANTI-LOCK BRAKE SYSTEM (ABS)	BR- 72
DESCRIPTION	BR- 72
DIAGNOSIS SYSTEM	BR- 76
SPEED SENSOR DIAGNOSIS SYSTEM	BR- 85
ABS ACTUATOR	BR- 88
CONTROL RELAY	BR- 95
FRONT SPEED SENSOR	BR- 96
REAR SPEED SENSOR	BR- 100
ANTI-LOCK BRAKE SYSTEM CIRCUIT	BR- 104
SERVICE SPECIFICATIONS	BR- 107

ANTI–LOCK BRAKE SYSTEM (ABS)


DESCRIPTION

- The ABS is a brake system which controls the brake cylinder hydraulic pressure of all four wheels during sudden braking and braking on slippery road surface, preventing the wheels from locking. This ABS provides the following benefits:
 - (1) Enables steering round an obstacle with a greater degree of certainty even when panic braking.
 - (2) Enables stopping in a panic brake while keeping the effect upon stability and steerability to a minimum, even on curves.
- The function of the ABS is to help maintain directional stability and vehicle steerability on most road conditions. However, the system cannot prevent the vehicle from skidding if the cornering speed limit is exceeded.
- In case a malfunction occurs, a diagnosis function and fail–safe system have been adopted for the ABS to increase serviceability.


COMPONENTS FUNCTION

Component	Function
Front Speed Sensor	Detect the wheel speed of each of the left and right front wheels.
Rear Speed Sensor	Detect the wheel speed of each of the left and right rear wheels.
ABS Warning Light	Lights up to alert the driver when trouble has occurred in the Anti–Lock Brake System.
Actuator	Controls the brake fluid pressure to each brake cylinder through signals from the ECU.
ABS ECU	From the wheel speed signals from each sensor, it calculates acceleration, deceleration and slip values and sends signals to the actuator to control brake fluid pressure.

SYSTEM PARTS LOCATION



WIRING DIAGRAM




SOL: Solenoid S SOL: Sub Solenoid

R03087






CONNECTORS

BR02N-03



1e-62-C 1g-4-2-A BR3999
 1e-2-2-T 1e-2-2-T
 e-2-1-G e-2-1-G
 Vd-34-2

202932



DIAGNOSIS SYSTEM DESCRIPTION

BR02P-03

If a malfunction occurs, the system will identify the problem and the ECU will store the codes for the trouble items.

At the same time, the system informs the driver of a malfunction via the "ABS" warning light in the combination meter.

By turning on the ignition switch, disconnecting the short pin of the check connector and use SST to connect Tc and E1 of the check connector, the trouble can be identified by the number of blinks (diagnostic code) of the warning light.

In the event of two codes, that having the smallest numbered code will be identified first.

HINT: The warning light does not show the diagnostic codes while the vehicle is running.

DIAGNOSIS SYSTEM INSPECTION

BR09B-01

1. INSPECT BATTERY VOLTAGE

Inspect that the battery voltage is about 12 V.

2. CHECK THAT WARNING LIGHT TURNS ON

- Turn the ignition switch on.
- Check that the "ABS" warning light turns on for 3 seconds.


If not, inspect and repair or replace the fuse, bulb and wire harness.

3. READ DIAGNOSTIC CODE

- Turn the ignition switch on.
- Using SST, connect terminals Tc and E1 of the check connector.
SST 09843-18020
- Pull out the short pin from the terminals WA and WB of the check connector in engine room.



















- In event of a malfunction, 4 seconds later the warning light will begin to blink. Read the number of blinks.
(See DIAGNOSTIC CODE)




HINT: The first number of blinks will equal the first digit of a two digit diagnostic code. After a 1.5 second pause, the 2nd number of blinks will equal the 2nd number of a two digit code. If there are two or more codes, there will be a 2.5 second pause between each, and indication will begin after 4.0 second pause from the smaller value and continue in order to larger.



- If the system is operating normally (no malfunction), the warning light will blink once every 0.5 seconds.
- Repair the system.
- After the malfunctioning components has been repaired, clear the diagnostic codes stored in the ECU.
HINT: If you disconnect the battery cable while repairing, all diagnostic codes in the ECU will erased.
- Remove the SST from terminals Tc and E1 of the check connector.
- Install the short pin to the terminals WA and WB.
- Turn the ignition switch on, and check that the "ABS" warning light goes off after the warning light goes on for 3 seconds.

DIAGNOSTIC CODE

Code No.	Light Pattern	Diagnosis	Trouble Part
11	ON OFF 	Open circuit in solenoid relay circuit	<ul style="list-style-type: none"> ● Actuator inside wire harness ● Control relay ● Wire harness and connector of solenoid relay circuit
12		Short circuit in solenoid relay circuit	
13		Open circuit in pump motor relay circuit	<ul style="list-style-type: none"> ● Actuator inside wire harness ● Control relay ● Wire harness and connector of pump motor relay circuit
14		Short circuit in pump motor relay circuit	
21		Open or short circuit in solenoid of front right wheel	<ul style="list-style-type: none"> ● Actuator solenoid ● Wire harness and connector of actuator solenoid circuit
22		Open or short circuit in solenoid of front left wheel	
23		Open or short circuit in solenoid of rear right wheel	
24		Open or short circuit in solenoid of rear left wheel	
31		Front right wheel speed sensor signal malfunction	<ul style="list-style-type: none"> ● Speed sensor ● Sensor rotor ● Wire harness and connector of speed sensor
32		Front left wheel speed sensor signal malfunction	
33		Rear right wheel speed sensor signal malfunction	
34		Rear left wheel speed sensor signal malfunction	
35		Open circuit in front left or rear right wheel speed sensor	
36		Open circuit in front right or rear left wheel speed sensor	
37		Wrong both rear axle hubs	<ul style="list-style-type: none"> ● Rear sensor rotors
41		Abnormal battery voltage (less than 9.5 V/more than 16.2 V)	<ul style="list-style-type: none"> ● Battery ● Voltage regulator
51		Pump motor of actuator locked or open circuit in pump motor circuit in actuator	<ul style="list-style-type: none"> ● Pump motor, relay and battery ● Wire harness, connector and ground bolt or actuator pump motor circuit
Always on		Malfunction in ECU	<ul style="list-style-type: none"> ● ECU



DIAGNOSTIC CODES CLEARING

CLEAR DIAGNOSTIC CODES

- Pull the parking brake lever up.
- Turn the ignition switch on.
- Using SST, connect terminals Tc and E1 of the check connector.

SST 09843-18020

HINT: Keep the vehicle stopped vehicle speed 0 km/h (0 mph).

- Clear the diagnostic codes stored in the ECU by depressing the brake pedal 8 or more times within 3 seconds.

- Check that the warning light shows the normal code.
- Remove the SST from terminals Tc and E1 of the check connector.
- Check that the warning light goes off.


TROUBLESHOOTING

BR09D-01


	Problem	No.
"ABS" warning light	Always comes on after ignition switch is turned on.	1
	Does not come on for 3 seconds after ignition switch on.	2
	Goes on and off.	3
	Comes on while running.	1
Brake condition	Brakes pull. ※	4
	Braking inefficient. ※	4
	ABS operates at ordinary braking.	4
	ABS operates just before stopping at ordinary braking.	4
	Brake pedal pulsates abnormally while ABS is operating.	4
	Skidding noise occurs while ABS operating. (ABS operates inefficiently)	5

※ Also check the parts of the brake system (brake cylinders, pads, hydraulic lines, etc.) not specifically part of the ABS.


W01130




W01131



v011





V011

SPEED SENSOR DIAGNOSIS SYSTEM DIAGNOSIS SYSTEM INSPECTION

BR02V-02

PRECAUTION

While checking the speed sensor diagnosis system, ABS dose not operate and brake system operates as normal brake system.

1. INSPECT BATTERY VOLTAGE


Inspect that the battery voltage is about 12 V.

2. CHECK THAT WARNING LIGHT TURNS ON


- Turn the ignition switch on.
- Check that the "ABS" warning light turns on for 3 seconds.

If not inspect and repair or replace the fuse, bulb and wire harness.


- Check that the "ABS" warning light turns off.
- Turn the ignition switch off.



R03138



R03057



BR1865


3. PERFORM FOLLOWING STEPS

- Using SST, connect terminals T_S and E₁ of the check connector in the engine room.
SST 09843-18020
- Pull the parking brake lever up, and start the engine.

- Check that the warning light blinks about 4 times every 1 second as shown.


4. DRIVE VEHICLE

- Release the parking brake.
- Drive the vehicle faster than 80 km/h (50 mph) for several seconds.



5. READ DIAGNOSTIC CODE


- (a) Stop the vehicle, and warning light will begin to blink.
- (b) Using SST, connect the terminals Tc and E1 of the check connector.



- (c) Read the number of blinks of the "ABS" warning light. (See DIAGNOSTIC CODE)

HINT: If normal, the warning light blinks 2 times every 1 second.

If two or more malfunctions are indicated at the same time, the smallest numbered code will be displayed first.












6. REPAIR MALFUNCTIONING PARTS

Repair or replace the malfunctioning parts.

HINT: When repairing or replacing parts, turn the ignition switch to OFF.


7. REMOVE SST

Remove the SST from terminals Tc and E1 of the check connector.

Code No.	Light Pattern	Diagnosis	Malfunctioning Part
	ON OFF 	All speed sensors and sensor rotors are normal	/
71		Low voltage of front right speed sensor signal	<ul style="list-style-type: none"> ● Front right speed sensor ● Sensor installation
72		Low voltage of front left speed sensor signal	<ul style="list-style-type: none"> ● Front left speed sensor ● Sensor installation
73		Low voltage of rear right speed sensor signal	<ul style="list-style-type: none"> ● Rear right speed sensor ● Sensor installation
74		Low voltage of rear left speed sensor signal	<ul style="list-style-type: none"> ● Rear left speed sensor ● Sensor installation
75		Abnormal change of front right speed sensor signal	<ul style="list-style-type: none"> ● Front right sensor rotor
76		Abnormal change of front left speed sensor signal	<ul style="list-style-type: none"> ● Front left sensor rotor
77		Abnormal change of rear right speed sensor signal	<ul style="list-style-type: none"> ● Rear right sensor rotor
78		Abnormal change of rear left speed sensor signal	<ul style="list-style-type: none"> ● Rear left sensor rotor


ABS ACTUATOR ABS ACTUATOR REMOVAL AND INSTALLATION

Remove and install the parts as shown.






(MAIN POINT OF REMOVAL AND INSTALLATION)

- (LHD)
REMOVE MASTER CYLINDER
(See MASTER CYLINDER REMOVAL)
- DISCONNECT AND CONNECT BRAKE TUBES**
Using SST, disconnect and connect the brake tubes from/to the ABS actuator.
SST 09023-00100 or 09751-36011
Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)
- BLEED BRAKE SYSTEM**
(See BRAKE SYSTEM BLEEDING)







ABS ACTUATOR INSPECTION

- INSPECT BATTERY VOLTAGE**
Battery voltage:
10-14.5 V
- DISCONNECT CONNECTORS**
 - Remove the fender liner and disconnect the two connectors from the control relay.
 - Disconnect the connector from the actuator.



- CONNECT ACTUATOR CHECKER (SST) TO ACTUATOR**
 - Connect the actuator checker (SST) to the actuator, control relay and body side wire harness through the sub-wire harness C and E (SST) as shown.
SST 09990-00150, 09990-00200 and 09990-00210



- (b) Connect the red cable of the checker to the battery positive (+) terminal and black cable to the negative (-) terminal. Connect the black cable of the sub-wire harness to the battery negative (-) terminal or body ground.
- (c) Place the "SHEET A" (SST) on the actuator checker. SST 09990-00163



4. INSPECT MAIN SOLENOID AND PUMP MOTOR OPERATION

- (a) Start the engine, and run it at idle.
- (b) Turn the selector switch of the actuator checker to "FRONT RH" position.
- (c) Push and hold in the MOTOR switch for a few seconds.
- (d) Depress the brake pedal and hold it until the step (g) is completed.
- (e) Push the POWER SWITCH, and check that the brake pedal does not go down.
NOTICE: Do not keep the POWER SWITCH pushing more than 10 seconds.
- (f) Release the switch, and check that the pedal goes down.
- (g) Push and hold in the MOTOR switch for a few seconds, and check that the pedal returns.
- (h) Release the brake pedal.

- (i) Push and hold in the MOTOR switch for a few seconds.
- (j) Depress the brake pedal and hold it for about 15 seconds. As you hold the pedal down, push the MOTOR switch for a few seconds. Check that the brake pedal does not pulsate.



5. (FOR OTHER WHEELS)


- (a) Turn the selector switch to "FRONT LH" position.
- (b) Repeating (c) to (j) of the step 4, check the actuator operation similarly.
- (c) Similarly, inspect "REAR RH" and "REAR LH" position.
HINT: When inspecting "REAR LH" position, push the REAR LH switch instead of the POWER SWITCH, and you can inspect in any selector switch position.

6. PUSH MOTOR SWITCH


Push and hold in the MOTOR switch for a few seconds.

7. INSPECT FRONT SUB SOLENOID OPERATION


- (a) Jack up and support vehicle.
- (b) Check the fluid level in the reservoir. If necessary, add brake fluid.




- (c) Disconnect the MAIN connector of the sub-wire harness E from the actuator checker and connect the SUB connector as shown.



- (d) Turn the selector switch of the actuator checker to "FRONT RH" position.
- (e) Push and hold in the MOTOR switch for a few seconds.




- (f) With the brake pedal depressed, loosen the bleeder plug of the front RH wheel and check the speed of the brake pedal descent.
- (g) Tighten the bleeder plug and release the brake pedal.



- (h) Depress the brake pedal while performing steps (i) to (j).
- (i) With the POWER SWITCH pushed in, loosen the bleeder plug and check that the speed of the brake pedal descent is slower than in (f).
- (j) Release the POWER SWITCH.
- (k) Tighten the bleeder plug, then release the brake pedal. HINT: Tighten the bleeder plug before releasing the brake pedal.
- (l) Push and hold in the MOTOR switch for a few seconds.


(FOR FRONT LH WHEEL)

- (a) Turn the selector switch to "FRONT LH" position.
- (b) Repeating (e) to (l) of step 7, check the front sub solenoid operation the same way.




8. INSPECT REAR PRESSURE INCREASE CONTROL VALVE OPERATION


- (a) Check that the SUB connector of sub-wire harness E is connected to the actuator checker. HINT: The wire harness connection is the same as for inspection of the front sub solenoid.



- (b) Turn the selector switch of the actuator checker to "REAR RH" position.
- (c) Push and hold in the MOTOR switch for a few seconds.




- (d) With the brake pedal depressed, loosen the bleeder plug of the rear RH wheel and check the speed of brake pedal descent.
- (e) Tighten the bleeder plug and release the brake pedal. HINT: Tighten the bleeder plug before releasing the brake pedal.




- (f) Depress the brake pedal while performing steps (g) and (h).
- (g) With the POWER SWITCH pushed in, loosen the bleeder plug.
- (h) Release the POWER SWITCH, then check that the speed of the brake pedal descent is slower than in (d).
- (i) Tighten the bleeder plug and release the brake pedal. HINT: Tighten the bleeder plug before releasing the brake pedal.
- (j) Push and hold in the MOTOR switch for a few seconds.

(FOR REAR LH WHEEL)

- (a) With the brake pedal depressed, loosen the bleeder plug of the rear LH wheel and check the speed of the brake pedal descent.
- (b) Tighten the bleeder plug and release the brake pedal.






- (c) Depress the brake pedal while performing steps (d) and (e).
- (d) With the POWER SWITCH REAR LH pushed in, loosen the bleeder plug.
HINT: Any position of the selector switch will do.
- (e) Release the REAR LH switch and check that the pedal descent speed is slower than in (a).
- (f) Tighten the bleeder plug and release the brake pedal.
HINT: Tighten the bleeder plug before releasing the brake pedal.
- (g) Push and hold in the MOTOR switch for a few seconds.

9. DISCONNECT ACTUATOR CHECKER (SST) FROM ACTUATOR

Remove the "SHEET A" (SST) and disconnect the actuator checker (SST) and sub-wire harness C and E (SST) from the actuator, control relay and body side wire harness.

10. CONNECT CONNECTORS



- (a) Connect the connector to the actuator.



- (b) Connect the two connectors to the control relay and install the fender liner.

11. CLEAR DIAGNOSTIC CODES (See DIAGNOSTIC CODES CLEARING)

12. CHECK FLUID LEVEL IN RESERVOIR TANK
Check the fluid level and add fluid if necessary.
Fluid: SAE J1703 or FMVSS No.116 DOT 3




CONTROL RELAY

CONTROL RELAY INSPECTION

BR02Y-02


1. INSPECT CONTINUITY OF MOTOR RELAY CIRCUIT

- (a) Check that there is continuity between terminals 9 and 10.
- (b) Check that there is no continuity between terminals 7 and 8.
If continuity is not as specified, replace the relay.




2. INSPECT OPERATION OF MOTOR RELAY CIRCUIT

- (a) Connect the positive (+) lead from the battery to terminal 10 and negative (-) lead to terminal 9.
- (b) Check that there is continuity between terminals 7 and 8.
If operation is not as specified, replace the relay.




3. INSPECT CONTINUITY OF SOLENOID RELAY CIRCUIT

- (a) Check that there is continuity between terminals 1 and 9.
- (b) Check that there is no continuity between terminals 2 and 5.



- (c) Connect the positive lead from the ohmmeter to terminal 4 and connect negative lead to terminal 5.
- (d) Check that there is continuity between terminals.
- (e) Connect the two leads in reverse, and check that there is no continuity between terminals.
If continuity is not as specified, replace the relay.
HINT: For the different type ohmmeter, there is no continuity for step (d), and there is continuity for step (e).





4. INSPECT OPERATION OF SOLENOID RELAY CIRCUIT

- (a) Connect the positive (+) lead from the battery to terminal 1 and negative (-) lead to terminal 9.
- (b) Check that there is continuity between terminals 2 and 5.
- (c) Check that there is no continuity between terminals 2 and 6.
If operation is not as specified, replace the relay.

FRONT SPEED SENSOR COMPONENTS

BR022-01




FRONT SPEED SENSOR INSPECTION

BR030-02

1. INSPECT SPEED SENSOR


- Remove the fender liner.
- Disconnect the speed sensor connector.




- Measure the resistance between terminals.

Resistance:
0.92–1.22 kΩ

If resistance value is not as specified, replace the sensor.




- Check that there is no continuity between each terminal and sensor body.
If there is continuity, replace the sensor.
- Connect the speed sensor connector.
- Install the fender liner.



2. INSPECT SENSOR INSTALLATION


Check that the sensor installation bolt is tightened properly. If not, tighten the bolt.

Torque: 8.0 N·m (82 kgf·cm, 71 in.-lbf)



3. VISUALLY INSPECT SENSOR ROTOR SERRATIONS

- Remove the drive shaft.
(See SA section)
 - Inspect the sensor rotor serrations for scratches, cracks, warping or missing teeth.
 - Install the drive shaft.
(See SA section)
- NOTICE:** To prevent damage to the serrations, do not strike the drive shaft.



FRONT SPEED SENSOR AND SENSOR ROTOR SERRATIONS INSPECTION (REFERENCE)

BR031-03

INSPECT FRONT SPEED SENSOR AND SENSOR ROTOR SERRATIONS BY USING AN OSCILLOSCOPE

- Connect an oscilloscope to the speed sensor connector.

- (b) Run the vehicle at 20 km/h (12.4 mph), and inspect speed sensor output wave.
- (c) Check that C is 0.5 V or more.
If not as specified, replace the speed sensor.
- (d) Check that B is 30 % or more of A.
If not as specified, replace the drive shaft.

FRONT SPEED SENSOR REMOVAL

BR032-02


1. DISCONNECT SPEED SENSOR CONNECTOR

- (a) Remove the fender liner.
- (b) Disconnect the speed sensor connector.


2. REMOVE SPEED SENSOR

- (a) Remove the clamp bolts holding the sensor harness to the body, shock absorber and lower arm.

Ex. 3S-GE Engine




3S-GE Engine


R03670
R03302

Z03150

Ex. 3S-GE Engine



3S-GE Engine

R03304
R03306

Z03152

- (b) Remove the speed sensor from the steering knuckle.

FRONT SPEED SENSOR INSTALLATION

BR09F-01

1. INSTALL SPEED SENSOR

Install the speed sensor to the steering knuckle.

Torque: 8.0 N·m (82 kgf·cm, 71 in.-lbf)


2. CONNECT SPEED SENSOR CONNECTOR

- (a) Install the sensor harness with the clamps and bolts in place.

Torque: 5.5 N·m (56 kgf·cm, 49 in.-lbf)


- (b) Connect the speed sensor connector.
- (c) Install the fender liner.

Ex. 3S-GE Engine



R03671 R03305 R03354


3S-GE Engine



Z03153

REAR SPEED SENSOR COMPONENTS

BR034-01



REAR SPEED SENSOR INSPECTION

BR035-02

1. INSPECT SPEED SENSOR




- Remove the seat cushion and side seatback.
- Disconnect the speed sensor connector.

- Measure the resistance between terminals.


Resistance:

1.05–1.45 k Ω

If resistance value is not as specified, replace the sensor.




- Check that there is no continuity between each terminal and sensor body.
If there is continuity, replace the sensor.
- Connect the speed sensor connector.
- Install the side seatback and the seat cushion.



2. INSPECT SENSOR INSTALLATION

Check that the sensor installation bolt is tightened properly. If not, tighten the bolt.

Torque: 8.0 N·m (82 kgf·cm, 71 in.-lbf)



3. VISUALLY INSPECT SENSOR ROTOR SERRATIONS


- Remove the axle hub assembly.
(See SA section)
- Inspect the sensor rotor serrations for scratches, cracks, warping or missing teeth.
- Install the axle hub assembly.
(See SA section)






REAR SPEED SENSOR AND SENSOR ROTOR SERRATIONS INSPECTION (REFERENCE)

BR036-03

INSPECT REAR SPEED SENSOR AND SENSOR ROTOR SERRATIONS BY USING AN OSCILLOSCOPE

- Connect an oscilloscope to the speed sensor connector.
- Run the vehicle at 20 km/h (12.4 mph), and inspect speed sensor output wave.
- Check that C is 0.8 V or more.
If not as specified, replace the speed sensor.
- Check that B is 40 % or more of A.
If not as specified, replace the rear axle hub.





REAR SPEED SENSOR REMOVAL

BR037-02

1. DISCONNECT SPEED SENSOR CONNECTOR

- (a) Remove the seat cushion and side seatback.
- (b) Disconnect the speed sensor connector, and pull out the sensor wire harness with the grommet.

- (c) Remove the two clamp bolts holding the sensor wire harness to the body and shock absorber.

2. REMOVE SPEED SENSOR

Remove the speed sensor from the axle carrier.

REAR SPEED SENSOR INSTALLATION



BR038-02

1. INSTALL SPEED SENSOR

Install the speed sensor to the axle carrier.
Torque: 8.0 N·m (82 kgf·cm, 71 in.-lbf)

2. CONNECT SPEED SENSOR CONNECTOR

- (a) Pass the sensor harness through the body panel hole, and connect the connector.




- (b) Install the grommet securely.

- (c) Install the sensor harness with the clamps and bolts in place.

Torque: 5.5 N·m (56 kgf·cm, 49 in.-lbf)

- (d) Install the side seatback and seat cushion.




ANTI-LOCK BRAKE SYSTEM CIRCUIT

SYSTEM CIRCUIT INSPECTION

1. INSPECT SYSTEM CIRCUIT WITH CONNECTORS CONNECTED

- (a) Remove the ABS ECU.
- (b) Using a voltmeter with high impedance (10 kΩ/V minimum), measure the voltage at each terminal and body ground.



Vd-34-2

Z02954


Tester Connection	Check Item	Condition	Specified Value	Trouble Part
SFR	Voltage	IG switch on and "ABS" warning light goes off	Battery voltage	Actuator
SFRS	Voltage	IG switch on and "ABS" warning light goes off	Battery voltage	
TS	Voltage	IG switch on and check connector T _S -E ₁ not connected	Battery voltage	ABS ECU
		IG switch on and check connector T _S -E ₁ connected	About 0 V	
IG	Voltage	IG switch on	Battery voltage	ECU-IG Fuse
FSS	Continuity	IG switch off	Continuity	ABS ECU
FL-	Continuity	IG switch off	Continuity	
W	Voltage	IG switch on and "ABS" warning light goes on	About 0 V	ABS ECU "ABS" warning light
		IG switch on and "ABS" warning light goes off	Battery voltage	
TC	Voltage	IG switch on and check connector T _C -E ₁ not connected	Battery voltage	ABS ECU
		IG switch on and check connector T _C -E ₁ connected	About 0 V	
SR	Voltage	IG switch on and "ABS" warning light goes on	About 0 V	ABS ECU
		IG switch on and "ABS" warning light goes off	Battery voltage	
SFL	Voltage	IG switch on and "ABS" warning light goes off	Battery voltage	Actuator
SFLS	Voltage	IG switch on and "ABS" warning light goes off	Battery voltage	
BAT	Voltage	IG switch off	Battery voltage	ECU-B Fuse
FR-	Continuity	IG switch off	Continuity	ABS ECU
R-	Continuity	IG switch off	Continuity	
RR-	Continuity	IG switch off	Continuity	

W01113

Tester Connection	Check Item	Condition	Specified Value	Trouble Part
RL-	Continuity	IG switch off	Continuity	ABS ECU
SRR	Voltage	IG switch on and "ABS" warning light goes off	Battery voltage	Actuator
PKB	Voltage	IG switch on and PKB lever pulled	About 0 V	Parking brake switch
		IG switch on and PKB lever returned	Battery voltage	Level warning switch
GND	Continuity	IG switch off	Continuity	Wiring harness
STP	Voltage	IG switch off and brake pedal depressed	Battery voltage	Stop light switch Stop light
	Continuity	IG switch off and brake pedal returned	Continuity	
GND	Continuity	IG switch off	Continuity	Wiring harness
SRL	Voltage	IG switch on and "ABS" warning light goes off	Battery voltage	Actuator

W01114

If the circuit is not as specified, check and repair or replace the trouble part shown in the table above.



R03143

2. INSPECT SYSTEM CIRCUIT WITH CONNECTORS DISCONNECTED

- (a) Disconnect the connectors from the ECU, inspect at the wire harness side connector.

Tester Connection	Check Item	Specified Value	Trouble Part	Tester Connection	Check Item	Specified Value	Trouble Part
SFR ↔ Body ground	Resistance	About 2.2 Ω	Actuator	FL + ↔ FL -	Resistance	0.92 – 1.22 kΩ	Front LH speed sensor
SFRS ↔ Body ground	Resistance	About 2.2 Ω	Actuator	MR + ↔ R -	Resistance	50 – 80 Ω	Control relay
FR + ↔ FR -	Resistance	0.92 – 1.22 kΩ	Front RH speed sensor	RR + ↔ RR -	Resistance	1.05 – 1.45 kΩ	Rear RH speed sensor
SR ↔ R -	Resistance	60 – 100 Ω	Control relay	RL + ↔ RL -	Resistance	1.05 – 1.45 kΩ	Rear LH speed sensor
SFL ↔ Body ground	Resistance	About 2.2 Ω	Actuator	SRR ↔ Body ground	Resistance	About 2.2 Ω	Actuator
SFLS ↔ Body ground	Resistance	About 2.2 Ω	Actuator	SRL ↔ Body ground	Resistance	About 2.2 Ω	Actuator
MT ↔ Body ground	Continuity	Continuity	Actuator				

V01115

If the circuit is not as specified, check and repair or replace the trouble part shown in the table above.

- (b) Connect the connectors, and install the ECU in place.

SERVICE SPECIFICATIONS

SERVICE DATA

BRO3A-06

Brake pedal height (from asphalt sheet)		
LHD vehicles		138 – 148 mm (5.43 – 5.83 in.)
RHD vehicles		159 – 169 mm (6.26 – 6.65 in.)
Brake pedal freeplay		1 – 6 mm (0.04 – 0.24 in.)
Brake pedal reserve distance at 490 N (50 kgf, 110.2 lbf)		More than
For General	4A – FE, 3S – FE engine (RHD)	85 mm (3.35 in.)
	4A – FE, 3S – FE engine (LHD)	65 mm (2.56 in.)
	2C engine	60 mm (2.36 in.)
For Europe	4A – FE, 3S – FE engine (RHD) w/o ABS	90 mm (3.54 in.)
	4A – FE, 3S – FE engine (RHD) w/ ABS	85 mm (3.35 in.)
	3S – GE engine (RHD)	90 mm (3.54 in.)
	4A – FE, 3S – FE engine (LHD) w/o ABS	70 mm (2.76 in.)
	4A – FE, 3S – FE engine (LHD) w/ ABS	65 mm (2.56 in.)
	3S – GE engine (LHD)	70 mm (2.76 in.)
	2C engine (RHD) w/o ABS	85 mm (3.35 in.)
	2C engine (RHD) w/ABS	80 mm (3.15 in.)
	2C engine (LHD) w/o ABS	65 mm (2.56 in.)
	2C engine (LHD) w/ABS	60 mm (2.36 in.)
Brake booster push rod to piston clearance (w/SST)		0 mm (0 in.)
Vacuum pump blade height	Limit	13.3 mm (0.524 in.)
Vacuum pump blade thickness	Limit	5.95 mm (0.2343 in.)
Vacuum pump blade length	Limit	22.98 mm (0.9047 in.)
Front brake pad thickness (Ex. 3S – GE engine)	STD	12.0 mm (0.472 in.)
Front brake pad thickness (Ex. 3S – GE engine)	Limit	1.0 mm (0.039 in.)
Front brake pad thickness (3S – GE engine)	STD	10.0 mm (0.394 in.)
Front brake pad thickness (3S – GE engine)	Limit	1.0 mm (0.039 in.)
Front brake disc thickness (3S – FE engine)	STD	28.0 mm (1.102 in.)
Front brake disc thickness (3S – FE engine)	Limit	26.0 mm (1.024 in.)
Front brake disc thickness (Ex. 3S – FE engine)	STD	25.0 mm (0.984 in.)
Front brake disc thickness (Ex. 3S – FE engine)	Limit	23.0 mm (0.906 in.)
Front brake disc runout	Limit	0.05 mm (0.0020 in.)
Rear brake drum inside diameter	STD	200.0 mm (7.874 in.)
Rear brake drum inside diameter	Limit	201.0 mm (7.913 in.)
Rear brake drum lining thickness	STD	4.0 mm (0.157 in.)
Rear brake drum lining thickness	Limit	1.0 mm (0.039 in.)
Rear brake drum to shoe clearance		0.6 mm (0.024 in.)
Rear drum brake clearance between rear shoe and lever		Less than 0.35 mm (0.0138 in.)
		0.2 mm (0.008 in.)
		0.3 mm (0.012 in.)
		0.4 mm (0.016 in.)
		0.5 mm (0.020 in.)
		0.6 mm (0.024 in.)
		0.9 mm (0.035 in.)
Rear drum brake adjusting shim thickness		
Rear brake disc pad thickness	STD	10.0 mm (0.394 in.)
Rear brake disc pad thickness	Limit	1.0 mm (0.039 in.)
Rear brake disc thickness	STD	10.0 mm (0.394 in.)

Rear brake disc thickness	Limit	9.0 mm (0.354 in.)
Rear brake disc runout	Limit	0.15 mm (0.0059 in.)
Rear brake disc inside diameter	STD	170 mm (6.69 in.)
Rear brake disc inside diameter	Limit	171 mm (6.73 in.)
Parking brake lining thickness	STD	2.0 mm (0.079 in.)
Parking brake lining thickness	Limit	1.0 mm (0.039 in.)
Parking brake lever travel at 196 N (20 kgf, 44 lbf)		4–7 clicks
Parking brake clearance between rear shoe and lever		Less than 0.35 mm (0.0138 in.)
Parking brake adjusting shim thickness for rear disc brake		0.3 mm (0.012 in.)
		0.6 mm (0.024 in.)
		0.9 mm (0.035 in.)

B9028-07

TORQUE SPECIFICATIONS

Part tightened	N·m	kgf·cm	ft·lbf
Master cylinder x Piston stopper bolt	10	100	7
Master cylinder x Reservoir	1.7	17.5	15.2 in·lbf
Master cylinder x Brake booster	13	130	9
Brake tube union nut	15	155	11
Brake booster clevis lock nut	25	260	19
Brake booster x Pedal bracket	13	130	9
Vacuum pump x Alternator	7.8	80	69 in·lbf
Vacuum pump x Check valve	74	750	54
Vacuum pump x Vacuum union	14	140	10
Vacuum pump x Oil outlet union	32	325	24
Front disc brake cylinder installation bolt	34	350	25
Bleeder plug	8.3	85	74 in·lbf
Front disc brake torque plate x Steering knuckle	94	960	69
Front disc brake cylinder x Flexible hose	30	310	22
Rear drum brake wheel cylinder x Backing plate	10	100	7
Parking brake cable bracket x Backing plate	7.8	80	69 in·lbf
Flexible hose x Shock absorber	29	300	22
Rear disc brake cylinder installation bolt	20	200	14
Rear disc brake torque plate x Dust cover	47	475	34
Rear disc brake cylinder x Flexible hose	30	310	22
Proportioning valve installation nut	7.8	80	69 in·lbf
Load sensing proportioning valve x Suspension arm	25	260	19
Load sensing proportioning valve x Body	39	400	29
ABS actuator x ABS actuator No.1 bracket	5.4	55	48 in·lbf
ABS actuator x ABS actuator No.3 bracket	13	130	9
ABS actuator No.3 bracket x Body	19	195	14
Front speed sensor installation bolt	8.0	82	71 in·lbf
Rear speed sensor installation bolt	8.0	82	71 in·lbf
ABS ECU bracket x Body	5.5	56	49 in·lbf

ELECTRICAL WIRING DIAGRAMS


ABBREVIATION

The following abbreviations are used in this wiring diagram.

ABS	= Anti-Lock Brake System
A/C	= Air Conditioner
A/T	= Automatic Transaxle
COMB.	= Combination
ECT	= Electronic Controlled Transmission
ECU	= Electronic Control Unit
EFI	= Electronic Fuel Injection
EGR	= Exhaust Gas Recirculation
Ex.	= Except
FL	= Fusible Link
ISC	= Idle Speed Control
J/B	= Junction Block
L/B	= Liftback
LH	= Left-Hand
M/T	= Manual Transaxle
O/D	= Overdrive
RH	= Right-Hand
S/D	= Sedan
SRS	= Supplemental Restraint System
SW	= Switch
TEMP.	= Temperature
VSV	= Vacuum Switching Valve
w/	= With
w/o	= Without

HOW TO READ THIS SECTION

* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the wiring diagram section.



(A): System Title


(B): Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

B = Black	L = Blue	R = Red
BR = Brown	LG = Light Green	V = Violet
G = Green	O = Orange	W = White
GR = Gray	P = Pink	Y = Yellow

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.


Example: L - Y



(C): Indicates the connector to be connected to a part (the numeral indicates the pin No.)


(D): Indicates the pin number of the connector. The numbering system is different for female and male connectors.

Example: Numbered in order from upper left to lower right



Female

Numbered in order from upper right to lower left



Male


The numbering system for the overall wiring diagram is the same as above.

(E): Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.

Example: ① Indicates Relay Block No. 1.

(F): Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts (different junction blocks are shaded differently for further clarification).


Example:



3B indicates that it is inside Junction Block No.3.


(G): Indicates related system.

(H): Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (↘). Outside numerals are pin numbers.



(I): () is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.

(J): Indicates a shielded cable.








































(K): Indicates a ground point.


(L): The same code occurring on the next page indicates that the wire harness is continuous.

SYSTEM INDEX


1991 Model (Location No. 1 to 44)

SYSTEMS	LOCATION	SYSTEMS	LOCATION	SYSTEMS	LOCATION
ABS (Anti-Lock Brake System)	 25-2	Glow and Emission Control	 9-2	Radio and Player	 30-2
Air Conditioner	 38-2 (RHD Push SW type) 39-2 (LHD Lever SW type) 40-2 (RHD Lever SW type)	Glow Plug	 2-3	Rear Fog Light	 15-2
Auto Antenna	 34-3	Headlight	 11-2 (LHD w/Daytime Running Light) 12-3 (LHD in Europe w/o Daytime Running Light) 13-3 (Ex. LHD in Europe)	Rear Wiper and Washer	 32-3
Back-Up Light	 33-2	Headlight Beam Level Control	 14-2	Remote Control Mirror	 26-2
Charging	 1-4	Headlight Cleaner	 22-2	Seat Heater	 34-2
Cigarette Lighter and Clock	 31-2	Horn	 29-2	Starting and Ignition	 1-2
Combination Meter	 35-2 (w/ Tachometer) 36-2 (w/o Tachometer)	Illumination	 19-2 (LHD) 20-2 (RHD)	Stop Light	 12-2 (S/D) 17-4 (L/B) 16-2 (LHD in Europe) 17-2 (L/B.Ex. LHD in Europe) 18-2 (S/D Ex. LHD in Europe)
Door Lock	 28-2	Interior Light	 21-2	Taillight	 23-2 (LHD) 24-2 (RHD)
ECT (Electronic Control Transmission)	 10-2	Light Auto Turn Off	 31-3	Turn Signal and Hazard Warning Light	
Engine Control	 3-2 (3S-GE) 4-2 (3S-FE, A/T) 5-2 (3S-FE, M/T) 6-2 (4A-FE Lean Burn type) 7-2 (4A-FE Ex. Lean Burn type, A/T) 8-2 (4A-FE Ex. Lean Burn type, M/T)	Light Reminder	 22-3	Junction Block and Wire Harness Connector	41-1
Front and Rear Window Defogger	 29-3	Moon Roof	 33-3	Connector Joining Wire Harness and Wire Harness	41-1 42-1 43-1 44-1
Front Fog Light	 13-2	Power Source	 1 ~ 40-1		
Front Wiper and Washer	 32-2	Power Window	 27-2		
Fuel Heater (2C)	 2-2	Radiator Fan and Condenser Fan	 37-2		


1 CORONA & CARINA E




2 CORONA & CARINA E



3 CORONA & CARINA E




4 CORONA & CARINA E




5 CORONA & CARINA E

ELECTRICAL WIRING DIAGRAMS


EWD-9




6 CORONA & CARINA E




7 CORONA & CARINA E




8 CORONA & CARINA E




9 CORONA & CARINA E




10 CORONA & CARINA E




11 CORONA & CARINA E



12 CORONA & CARINA E




13 CORONA & CARINA E




ELECTRICAL WIRING DIAGRAMS

EWD-17


14 CORONA & CARINA E




16 CORONA & CARINA E




17 CORONA & CARINA E




18 CORONA & CARINA E




19 CORONA & CARINA E



20 CORONA & CARINA E




21 CORONA & CARINA E




ELECTRICAL WIRING DIAGRAMS

EWD-25


22 CORONA & CARINA E




23 CORONA & CARINA E




24 CORONA & CARINA E




25 CORONA & CARINA E




27 CORONA & CARINA E




28 CORONA & CARINA E




29 CORONA & CARINA E




30 CORONA & CARINA E




31 CORONA & CARINA E




32 CORONA & CARINA E




33 CORONA & CARINA E



34 CORONA & CARINA E




35 CORONA & CARINA E




ELECTRICAL WIRING DIAGRAMS

EWD-39

36 CORONA & CARINA E




37 CORONA & CARINA E




ELECTRICAL WIRING DIAGRAMS

EWD-41






Air Conditioner (RHD Push SW type)




39 CORONA & CARINA E

EWD-44

ELECTRICAL WIRING DIAGRAMS




40 CORONA & CARINA E




41 CORONA & CARINA E


Junction Block and Wire Harness Connector
J/B No.1 (LHD : Left Kick Panel, RHD : Right Kick Panel)




J/B No.2 (Engine Compartment)




J/B No.3 (Behind Combination Meter)



Connector Joining Wire Harness and Wire Harness
(E Group : Engine Compartment area)




(I Group : Instrument Panel and Surrounding area)




1 2 3 4

(I Group : Instrument Panel and Surrounding area)




(B Group : Body and Surrounding area)



1 2 3 4

(B Group : Body and Surrounding area)



TOYOTA
QUALITY SERVICE