

KZ650F1

1980



Kawasaki 650 Four Owners Workshop Manual

by Pete Shoemark

Models covered:

652 cc ZR50 Four cylinder dohc
October 1976 on (UK only)

652 cc KZ550 Four cylinder dohc
September 1976 on (USA only)

ISBN 0 85996 373 9

© Haynes Publishing Group 1978

All rights reserved. No part of this book may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage or retrieval system, without permission in writing from the copyright holder.



Printed in England



HAYNES PUBLISHING GROUP
SPARKFORD YEOVIL SOMERSET ENGLAND
distributed in the USA by

HAYNES PUBLICATIONS INC
801 LAWRENCE DRIVE
NEWBURY PARK
CALIFORNIA 91320
USA

Acknowledgements

The thanks are due to Kawasaki Motors SRI Ltd, who supplied the test machine used in the photographic sequences. We would like to thank in particular Nick Jeffery and Eric Steves of the above Company, for their assistance with the project.

Ben Howarth assisted with the polishing and rebuilding, and devised the ingenious methods for recovering the teeth of service tools. Les Shuster arranged and took the cast and mould over photographs, also the photographs which accompany the

text.

Jeff Clegg edited the text and compiled the stocks of technicalities used in the explanation of the manual.

Finally, we would also like to thank the Acme Rubber Company, who supplied information and technical assistance on tyre fitting; 1994 Super Progs SRI Ltd for information on spark plug maintenance and electrode conditions, and Harold Ltd for advice on chain care and renewal.

About this manual

The author of this manual has the conviction that the only way to obtain a meaningful and easy to follow text can be written in to find into the work itself, under conditions similar to those found in the average home. As a result, the funds sent to the photographer on the basis of the author or those of another engineer who assisted. The machine photographed was a cast model that had covered three thousand miles, so that the conditions encountered would be similar to those found by the average rider.

Unless specially mentioned, and therefore considered essential, Kawasaki service tools have not been used. There is included some alternative means of disassembling or removing some vital component when service tools are not available and the risk of damage has to be avoided at all costs.

Each of the six Chapters is divided into numbered sections, within the sections are numbered paragraphs. In consequence, cross reference throughout this manual is both straightforward

and logical. When a reference is made 'See Section 1.6', it means see Section 1, paragraph 6 in the same Chapter. If another Chapter were meant, the text would read 'See Chapter 4, Section 1.6'. All the photographs are captioned with a Section paragraph number to which they refer and are directed returned to the Chapter text relevant.

Figure numbers, usually five digitational appear in numerical order, within a given Chapter. Figure 1.2 therefore refers to the first figure in Chapter 1.


Left-hand and right-hand descriptions of parts of the machine or the machine itself, refer to the right and left side of the machine, with the rider seated in the normal riding position.

Whilst every care is taken to ensure that the information in this manual is correct, no liability can be accepted by the author or publishers for loss, damage or injury, caused by any errors or omissions from the information given.

Contents


Chapter	Section	Page	Section	Page
Introductory sections	Acknowledgements	2	Routine maintenance	8-14
	Basic info manual	2	Daily general maintenance	2
	Introduction to Kawasaki Power	6	adjustments and cautions	16
	Dimensions and weight	6	Recommended lubricants	18
	Ordering spare parts	7	Working conditions and tools	18
Chapter 1 Engine, clutch and gearbox	Operation: Unit in frame	20	Examination and renovation	38
	Engine removal	20	Crankshaft, tappets and drive	38
	Removal of engine/gearbox	20	Clutch	60
	Disassembly – general	21	Gearbox components	61
	Examination and re-assembly general	21	Engine – reassembly general	66
	Reassembling	23	Refitting unit in frame	68
Frame grinding	24	Starting in re-built unit	69	
Chapter 2 Fuel system and lubrication	Fuel tank	65	Air cleaner	73
	Fuel tap and filter	65	Lubrication	73
	Carburettor:		Engine and gearbox	78
	Description and removal	66	Checking oil pressure	84
	Disassembly and reassembly	68	Oil pressure relief valve	78
	Adjustment	71	Oil filter	78
	Synchronisation	71	Oil pressure warning switch	78
Settings	71			
Chapter 3 Ignition system	Checking ignition coils	80	Timing – ignition	84
	Adjustments – Contact breaker	80	Sparking plugs	84
	Capacitors	81	Ignition switch	85
Chapter 4 Frame and forks	Fuel tank legs	88-90	Rear suspension units	91
	Fork tubes	88	Chain-and-pipe stands	91
	Spinning tool bearings	88	Footrests and rear brake pedal	91
	Frame – examination	90	Speedometer and tachometer	91
	Swinging arm fork	92	Handle and drive	98
Chapter 5 Wheels, brakes and tires	Front wheel	100-106	Rear wheel bearings	101
	Disc brake – front	100	Rear brake – drum	100
	Master cylinder	100	Rear clutch drive	100
	Front wheel bearing	104	Final drive chain	100
	Rear wheel	104	Tires	101
Chapter 6 Electrical system	Alternator	112	Starter solenoid switch	118
	Blower resistor	114	Headlamp	120
	Voltage regulator	115	Horn – buzzer	120
	Battery	67	Handbrake switches	120
	Fuse location	115	Stop lamp switch	120
	Starter motor	118	Oil pressure switch	120

Note: General descriptions and specifications are given in each Chapter immediately after list of contents. Troubleshooting is given at the end of the appropriate Chapter.



Right-hand view of 1971 Kawasaki 900D

1952 Harley-Davidson 200 cc. motorcycle.



Introduction to the Kawasaki 650 Four

When the 650 GZ model was first introduced in 1972 it was obvious that Kawasaki had scored a huge success. The growth of the company had been little short of phenomenal, perhaps causing some people to wonder how it was achieved. The answer lay in the vast resources of the firm and the quality of their technological know-how, which extended into product, styling, and service competition on a grand scale. All these activities rolled into one term, Kawasaki Motor Industries, a giant manufacturing complex that produces an astonishing variety of products and markets them all over the world.

When the 650 GZ four was introduced in 1976, it was no real surprise that it proved superior to the Z1 model, the latter having proven to be both fast and reliable. A comparison of the two machines will show just how close the resemblance is.

In just a few years Kawasaki have become the fourth largest motorcycle manufacturer in the world and that in itself is quite an accomplishment when it is recalled that some European companies have been manufacturing machines for over 50 years. Kawasaki have now become seriously involved with racing to such an extent that their flag factory teams in trials, road racing and motocross, and were the only Japanese manufacturer to participate in the 48th 5001 hour in Scotland, USA. More important to the readers of Kawasaki is incorporation of the hard learned lessons, acquired at the race track, in their road going machines. In this way they have successfully capitalized on their competition successes, putting the knowledge they have gained at the disposal of all those who purchase their high-quality products.

Dimensions and weight

Dimensions	European models	US models
Overall length	2220 mm (87.4 in)	2170 mm (85.43 in)
Overall width	850 mm (33.5 in)	
Overall height	1140 mm (45.1 in)	
Wheelbase	1420 mm (55.91 in)	
Ground clearance	140 mm (5.51 in)	140 mm (5.71 in)
Weight (dry)	211 kg (465.2 lbs)	

Ordering spare parts

When ordering spare parts for a Kawasaki it is advisable to deal direct with an official Kawasaki agent who should be able to supply most of the parts from stock. Parts cannot be obtained direct from Kawasaki UK; all orders must be routed via an approved agent as is common with most other makes.

Always quote the frame and engine numbers in full. The frame number is stamped on the left-hand side of the steering head and the engine number on top of the crankcase in the rear of the cylinder block, on the right-hand side.

It is always best to quote the colour scheme for any of the

cycle parts that have to be ordered. Use only genuine Kawasaki parts. Pattern parts should be avoided as they are usually inferior in quality. Some of the more susceptible parts such as bulbs, spark plugs, chains, tyres, oils and greases etc., can be obtained from accessories stores and motor factors, who have convenient opening hours and can often be found near home. It is also possible to obtain parts on a Mail Order basis from a number of specialists who advertise regularly in the motorcycle magazines.



Engine Number Location



Frame Number Location

Routine maintenance

Introduction

Periodic routine maintenance is a continuous process that commences immediately the machine is used. It must be carried out at specified mileage intervals, or on a calendar basis if the machine is not used frequently, whichever is the sooner. Maintenance should be regarded as an insurance policy, in keeping the machine in the peak of condition and to ensure long, trouble-free service. It has the additional benefit of giving early warning of any faults that may develop and will act as a regular safety check, to the obvious advantage of both rider and machine alike.

The various maintenance tasks are described under their respective mileage and calendar headings. Accompanying diagrams are provided, where necessary. It should be emphasized that the interval between the various maintenance tasks varies only as a guide. As the machine gets older or is used under particularly adverse conditions, it would be advisable to reduce the period between each check.

For ease of reference each service operation is described in detail under the relevant heading. However, if further general information is required, it can be found either the manual under the pertinent service heading or the relevant Chapter.

In order that the routine maintenance tasks are carried out with as little fuss as possible, it is essential that a good selection of general workshop tools is available.

Included in the kit must be a range of metric ring and combination spanners, a selection of crescent screwdrivers and at least one pair of strip-piers.

Additionally, owing to the extreme tightness of most bearing screws on Japanese machines, an impact screwdriver together with a choice of large or small crosshead screw bits, is absolutely indispensable. This is particularly so if the engine has not been dismantled when leaving the factory.

Daily

A daily check of the motorcycle is essential both for mechanical and safety aspects. It is a good idea to develop the checking procedure in a specific sequence so that it will ultimately become as instinctive as actually riding the machine. Done properly, this simple checking sequence will give advanced warning of impending mechanical failures and any condition which may jeopardize the safety of the rider.

F Oil level

The level of the engine oil is quickly checked by use of the oil sight glass set in the right-hand outer casing. With the machine standing on level ground, the oil should be visible half way up the plastic window. Markings are provided on the rim of the window, indicating the maximum and minimum oil levels; if necessary, top up the oil by use of the filler cap at the rear of the casing. Should too much oil have been added, it should be removed, using a syringe or an empty plastic squeeze pack such as that used for gun oil.



Top up the engine oil level to half way up the window.

2 Tyre pressures

Check the tyre pressures with a pressure gauge that is known to be accurate. Always read the pressure when the tyre is cold. If the machine has travelled a number of miles, the tyres will have become hot and consequently the pressure will have increased. A false reading of therefore result.

It is well worth purchasing a small pocket pressure gauge which can be relied on to give consistent readings, and which will remove any reliance on gauge/flexometer gauges which tend to be too dependent.

Tyre pressures	Front	Rear
From:	1.0 kg/cm ² (2.8 psi)	2.0 kg/cm ² (2.8 psi)
Max:	1.5 kg/cm ² (2.8 psi)	2.5 kg/cm ² (3.5 psi)

Make pressure readings should be taken when the tyre is cold, i.e. before a run.

3 Hydraulic fluid level

Check the level of the fluid in the master cylinder reservoir. This may be observed through the transparent side of the reservoir. During normal service, it is unlikely that the fluid level will fall dramatically, unless a leak has developed in the system. If this occurs, the fluid should be corrected as soon as the level will fall evenly as the brake lever is used and the fluid deficiency should be corrected, when required. Always use an hydraulic fluid of DOT 3 or SAE 47763 specifications, and do not mix different types of fluid, even if the specifications appear the same. This will preclude the possibility of two incompatible fluids being mixed and the resultant chemical reaction, damaging the seals.

If the level in the reservoir has been allowed to fall below the specified limits, and air has entered the system, the brake in operation must be bled as described in Chapter 5.

In addition to the above points, a timing check of the machine in general should be made. It will be found that camshaft lock-up control valves receiving bleed will soon create themselves apparent during riding, necessitating adjustment as soon as possible. The electrical system should also be fully functional, noting that in the UK, and in many other countries, it is illegal to use the machine with a defective horn or lights even if they are not in-use.

Washers or every 250 miles (400 km)

1 Final drive shafts — cleaning and lubrication

The final drive chain (not the engine type, having no joining link in an effort to eliminate any tendency towards foreage). The rollers are equipped with an 'O' ring at each end which seals the lubricant inboard and prevents the ingress of water or abrasive grit. It should not, however, be supposed that the need for lubrication is lessened. On the contrary, frequent fuel system lubrication is essential to minimize wear between the chain and sprockets. This can be accomplished by using one of the special chain lubricants, which have been specifically designed to cling to chains operating at high speeds. Such special engine oil grade oils will be found at the shops, and are not really suitable. The chain and sprockets should be wiped clean before the lubricant is applied, to ensure adequate penetration.

In particularity adverse weather conditions, or when towing, lubrication should be undertaken more frequently.

A final word of caution: The importance of chain lubrication cannot be overemphasised in view of the cost of replacement, and the fact that a considerable amount of dismantling work, including swinging arm removal, will need to be undertaken should replacement be necessary.

Adjust the chain after lubrication, so that there is approximately 25 mm (1 in) slack in the middle of the lower run, always check with the chain at the highest point as a chain being under steady loading tends to stretch.

Adjustment is accomplished after placing the machine on the centre stand and removing the wheel nut, so that the wheel can be drawn backwards by means of the bracket adjusters in the fork tube.

The torque arm nuts and the rear brake adjuster must also be readjusted during this operation. Adjust the drive shafts an equal amount to preserve wheel alignment. The top nuts are clearly marked with a series of parallel lines above the adjusters, to provide a simple check stand.

2 Battery — topping up

A Trosser 18 SC1 battery, rated at 12 volts 18Ah is fitted as standard and is located in a compartment beneath the dashboard. It is covered by a rubber wing which can be released to allow the battery to be filled/gassed as described.

The transparent plastic case of the battery permits the upper and lower levels of the electrolyte to be observed when the battery is lifted from its housing below the dashboard. Maintenance is normally limited to keeping the electrolyte level between the prescribed upper and lower limits and by making sure that the vents also is not blocked. The lead plates and their separators can be seen through the transparent case, a further guide to the general condition of the battery.

Unless acid is split, an easy issue if the machine falls over, the electrolyte should always be topped up with distilled water to restore the correct level. If acid is split on any part of the machine, it should be neutralised with an alkali such as washing soda and washed away with plenty of water, otherwise serious corrosion will occur. Top up with sulphuric acid if the correct specific gravity (1.280 — 1.285) only when spillage has occurred. Check that the vent plate is well clear of the frame tubes or any of the other upper parts, for obvious reasons.



Check the tyre pressure using an accurate gauge



Clean and lubricate the drive chain using special lubricant



Correct assemblies have alignment marks to ensure that the wheel is high square

3 Control cable lubrication

Apply a few drops of motor oil to the exposed inner portion of each control cable. This will prevent drying-up of the cables between the stops through lubrication that should be carried out during the 2000-mile/3200-km service.

d Safety check

Give the machine a close visual inspection, checking for loose nuts and fittings, frayed control cables etc. Check the tyres for damage, especially splitting of the sidewalls. Remove any stones or other objects caught between the treads. This is particularly important on the front tyre, where rapid deflation due to penetration of the inner tube will almost certainly cause total loss of control.

5 Legal check

Ensure that the lights, horn and flashing indicators function correctly after the speedometer.

3 monthly or every 3000 miles/5000 km

Carry out the checks listed under the weekly/100 mile heading and then complete the following:

1 Cleaning and adjusting the contact breaker points

Remove the contact breaker inspection cover and gasket. The cover is retained by two screws. Inspect the faces of the two sets of contact breaker points. Spacers due to being cut be removed when the contact breaker unit is in situ on the machine, using a very fine series file or wirey paper (Fin. 000) backed by a thin strip of oil. If the pitting or burning is excessive, the contact breaker unit in question should be removed for further cleaning or renewal (see Chapter 3).

Move the engine until one set of points is in the fully open position. The correct gap is within the range 0.2 - 0.4 mm (0.02 - 0.016 in). Adjustment is effected by sliding the screw holding the fixed contact breaker point in position and moving the plate either closer to or further away with a screwdriver inserted between the small upright post and the oil in the fixed contact plate. Make sure that the points are in the fully open position when the adjustment is made: if a free reading will result, then the gap is correct. Tighten the screw and recheck.

Repeat the procedure with the other set of points.



Use feeler gauge to check the contact breaker gaps

2 Checking and resetting the ignition timing

The ignition timing should be checked at the same time as contact breaker adjustment is undertaken. It is desirable to use a multimeter for this purpose, but a battery and bulb arrangement may be used as an alternative.

Referring to the decompression line diagram, connect 'W' to the terminal post on spring blade of the left-hand contact breaker set (located from left-hand side of the machine). 'B' should be connected to a convenient earth point. Using a 12 mm spanner, turn the crankshaft clockwise until the 1.4 F timing/mark is visible in the aperture at the top of the backplate. The numbers 1-4 refer to the left-hand contact breaker assembly, also marked 1-4, which triggers the spark on stroke numbers 1 and 4.

If the crankshaft is eased very gradually a few degrees either side of this point, it will be possible to establish the precise point at which the contacts separate. This is indicated by the bulb going out in the case of the battery and bulb apparatus, and by a deflection of the needle when the multimeter is used. Having established the exact point of separation, check that the timing marks still align. If this is not the case, rotate the two screws which retain the left-hand segment, and move this so that separation occurs at the correct point.

Tighten the securing screws, and run the engine over a few times, then recheck the timing. If all is well, repeat the procedure with the right-hand set of points (2-3) using the appropriate timing mark. Before setting the contact breaker inspection cover, check that the last lubricating work has not dried-out. If this should be the case, apply one or two drops of light machine oil, being sure not to over-lubricate it, which would almost certainly cause the contact breaker points to become fused.

3 Grease/pieces and brake lubricants and pivots


Apply a small amount of EP 80 gear oil to the stand pivot pins, and grease the brake lubricant-and-pivots.

4 Control cable lubrication

Lubricate the control cables thoroughly with motor oil or all-purpose oil. A good method of lubricating the cables is shown in the accompanying illustration, using a plastic funnel. This method has the disadvantage that the cables usually need removing from the machine. An alternative cable oiler which prevents the lubricant compressing this problem. Do not lubricate nylon fixed cable-connections may have been fitted as replacement, as the oil may cause the nylon to swell, thereby causing free-ride conditions.



Apertures make use of plastic through apertures in housing



Alternative methods of checking the ignition timing

- A To connect breaker terminal
- g To spark
- C Volt
- D Battery
- E Voltmeter or an oscilloscope



Timing control cable

8 Changing the engine oil

The oil should be changed with the engine at its normal operating temperature, preferably after a run. This ensures that the oil is relatively thin and will drain more quickly and completely. Obtain a container of at least 3.0 litres (8.2 imp pints/7.7 US gal) and separate, and arrange it beneath the crankcase drain plug location and remove the plug, noting that the oil filter cover should be fully undrained and allow the oil to drain.

When the crankcase is completely emptied, clean the drain plug with a wire and refill the plug, tightening it to 7.5–9 – 7.7 kg m (5.5–12 lb ft). Remove the filler plug, and add sufficient MAA (Quaker) or 20W/50 motor oil to bring the level half way up the window in the sight glass. This will normally give about 5 litres, the oil filter cover requiring about 1 litre if this has been removed.

6 Camshaft tensioner adjustment

This operation can be performed to some advantage during the checking and adjustment of the ignition timing as much of the work involved is common to both operations. The object is to compensate for wear in the timing chain which would otherwise cause delay and inaccurate valve operation.

After the contact breaker cover is removed, turn the crankshaft clockwise so that either the 1.4 or 2.3 timing marks are aligned. This is to arrange the camshafts so that the slackest cut is against the tensioner blade. Slacken the locknut and both on

the side of the tensioner body. This will release the plunger and allow the helical springs to apply the correct amount of pressure to the chain. Finally, tighten the lock nut and locknut.

If other considerable misadjustments have been caused, this operation fails to restore correct, and chain noise persists, it is indicative of the need to dismantle the tensioner and chain components, and to renew worn parts as necessary.

WARNING: DO NOT USE ELECTRIC STARTER TO ROTATE ENGINE WHEN TENSIONER BOLT IS LOOSE.

7 Clutch adjustment

Accurate adjustment of the clutch is necessary to ensure efficient operation of the whole unit, and to prevent wear of the pulley assembly. Two adjustment points are available on the cable lever, one at the operating lever, and a second midway along the cable next to the horn damper. The latter should be adjusted fully inward to give the maximum free play in the cable, and the hornbar adjuster set in a central position to give adjustment either way.

Remove the small clutch adjuster cover which is located in the middle of the left-hand outer cover. Slacken the locknut and adjusting screw a few turns, then turn the adjuster inward until resistance is felt. At this point, all free play in the system is taken up and the screw must be locked off by a nut. Bend the screw in this position, and tighten the lock nut. Refit the cover, and check the amount of free play in the cable, which should be adjusted at the hornbar lever to give 2–3 mm clearance.



Set clutch adjustment by map of screw and locknut

5. Valve clearances

It is important that valve clearances be maintained whenever damage, or at least poor performance and noisy operation, will occur. To gain access to the camshafts, it will be necessary to detach the fuel tank and the 2-stage camshaft cover to expose the two camshafts and their associated components.

Each valve is operated by a bucket-shaped follower which contains a shim to provide the correct clearance between it and the cam lobe. The gap should be measured with the peak of the cam lobe upward, at which point it should be possible to insert a feeler gauge between the bucket tip and the shim lobe. The specified clearance is between 0.08 mm and 0.18 mm (0.003 - 0.007 in).

To set the camshafts in the correct position, proceed as follows: Turn the camshaft until the '0' mark on the exhaust camshaft is aligned with the cylinder head mating surface, and then check numbers 1 and 2 exhaust valves. Turn the engine so that the '0' mark faces the top of the cylinder head mating surface, and check valves 3 and 4.

Repeat this procedure on the inlet camshaft, using the 'T' mark aligned first with the rear of the cylinder head surface to check valves 5 and 7, and then at the front to check 6 and 8.

If any of the clearances are outside the specified limits, step 4-mm (0.157 in) shims of the correct size of shim(s) may be obtained. For example, if valve 2 shows a clearance of 0.2 mm, it will be necessary to obtain a shim 0.05 mm thicker which, when fitted, will reduce the clearance to 0.15 mm. The shim range from 2.0 mm to 3.2 mm (0.0787 to 0.126 in) is available.

It will be necessary to remove the camshaft as described in Chapter 1, Section 1, so that the bucket can be withdrawn using a wire grinding stick with a rubber buffer end, or some similar method. The shim may adhere to the inside of the bucket or may stay in position on the valve stem; it should be removed and the new shim placed in position. Reassemble the camshaft and refit the cylinder head cover.

In the event that a new shim will not give the required clearance, it is likely that the shim and/or valve is in need of renewal. Do not attempt to grind down existing shims or pack them with wear plate material (an attempt to save the cost of new shims). The risk of failure in service, and the consequent damage to the engine makes this a very false economy. For details of shim sizes refer to the accompanying table of sizes (Pg. RM 2).

6. Carburettor adjustment

This important operation affects both the performance and

fuel consumption of the machine to a marked degree, and should not be ignored despite its complexity. The adjustment operation is described, in greater detail than is possible in this Section, in Chapter 2, Section 6.

10. Air cleaner element: cleaning and renewal

The air cleaner element is located in a compartment underneath the machine, and may be withdrawn after the petrol cap has been removed. Wash the element carefully in petrol or a similar solvent, then blow it dry with compressed air. The efficiency of the filter will be slightly impaired with each successive cleaning, and it should be renewed after every fifth cleaning operation or after every 2000 miles (3200 km). If there is any sign of damage during cleaning, the element must be renewed as a matter of course.

Six monthly or every 8800 miles (14000 km)

Carry out the operations listed under the preceding service intervals, then proceed with the following:

7. Brake wear

Check that when applied, the rear brake wear indicator is within the visible range scale marked on the brake pedal. The front disc brake pads should also be examined for wear, and if this end are marked with a red line denoting the maximum wear limit - if necessary, change the pads and/or brake shoes, referring to Chapter 5 for details. Look out for signs of leaking on the front disc brake. This may be caused by leakage from the front leg or from the carrier nuts, in either case attention must be given to locating and rectifying the source of the leak.

8. Wheel condition

Check the spoke tension by gently tapping each one with a metal object. A loose spoke is identifiable by the low pitch noise generated if any spoke needs considerable tightening, it will be necessary to remove the tyre and inner tube in order to fit down the protruding spoke end. This will prevent the spoke from chafing through the rim band and pinching the inner tube. Rotate the wheel and test for rim round. Excessive round will cause handling problems and should be corrected by tightening or loosening the relevant spokes. Care must be taken, when rotating the tension in the wrong direction may create more problems.



Check clearance between shim and bucket



An filter element is located in a compartment beneath the seat

VALVE NUMBER (LEFT)	PREFERRED SHIM SIZE																											
	276	277	278	279	280	281	282	283	284	285	286	287	288	289	290	291	292	293	294	295	296	297	298	299	300	301	302	303
INCHES	2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20	3.25	3.30	3.35

VALVE CLEARANCE	SPECIFIED CLEARANCE / PWD CHANGE REQUIRED																											
	276	277	278	279	280	281	282	283	284	285	286	287	288	289	290	291	292	293	294	295	296	297	298	299	300	301	302	303
0.00 - 0.01				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20
0.01 - 0.02				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20
0.02 - 0.03				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20
0.03 - 0.04				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20
0.04 - 0.05				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20
0.05 - 0.06				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20
0.06 - 0.07				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20
0.07 - 0.08				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20
0.08 - 0.09				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20
0.09 - 0.10				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20
0.10 - 0.11				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20
0.11 - 0.12				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20
0.12 - 0.13				2.00	2.05	2.10	2.15	2.20	2.25	2.30	2.35	2.40	2.45	2.50	2.55	2.60	2.65	2.70	2.75	2.80	2.85	2.90	2.95	3.00	3.05	3.10	3.15	3.20



Shim selection table

3 Changing the oil filter element

Change the engine oil as described under the 2 monthly/3000 mile heading. In addition, remove and remove the oil filter element which is housed in a chamber in the underside of the crankcase.



Oil filter element screws into the bottom of the crankcase

4 Changing the front fork damping oil

Place the machine on the centre stand so that the front wheel is clear of the ground. Place support blocks behind the crankcase in order to prevent the machine from tipping forward. Loosen and remove the pressure cap bolts. Insert the drain plug from each fork leg, located directly above the wheel spindles, and allow the damping fluid to drain into a suitable container. This is accomplished most easily if the legs are extended as in turn. Take care not to spill any fluid onto the brake disc or tyre. The forks can be pumped up and down slowly to equal any remaining fluid. Refill and tighten the drain plugs. Refill each fork leg with 183 – 191 cc of SAE 15W engine oil, or a good quality fork oil. If a straight grade fork oil is chosen, either SAE 15, 20 or 30 may be used, depending on climate. The thicker the oil the longer the damping will be. Refill and tighten the chrome 180-0005.

5 General checks

In addition to the above operations, the various frame and engine fittings should be checked for tightness and lubricated where necessary. It is recommended that the topnuts, bolt (4) changed, by following the brake bleeding procedure in Chapter 5. Check for free play in the steering head bearings, and adjust if necessary, following the sequence in Chapter 4.

Every two years (4 11 000 miles (20 000 km))

Remove the front wheel and inspect the front wheel bearings with high melting point grease. At the same time, remove and re-grease the speedometer drive assembly. The rear wheel bearings and brake call (should not be re-greased). Details of dismantling and reassembly will be found in Chapter 5. The steering head should also be dismantled for examination and re-lubrication as described in Chapter 5.

Quick glance maintenance adjustments and capacities

Engine/gearbox unit	2-Cylinder 2-Stroke engine 1.1L oil capacity (SAE 15W40, 15W50 or 20W50 engine oil if filter is removed, an extra ½ liter (0.5 Imp pints) 0.5L(1)–quart will be required.
Front forks	100 – 101 (open leg) SAE 10W engine oil or Park oil
Contact breaker gap	0.3 – 0.4 mm (0.011 – 0.016 in)
Spark plug gap	0.7 – 0.8 mm (0.027 – 0.031 in)
Tire pressures:	
SD	Front 2.0 kg/cm ² (28 psi) Rear 2.25 kg/cm ² (32 psi)
Filler, at high speed	Front 2.0 kg/cm ² (28 psi) Rear 2.50 kg/cm ² (35 psi)

Recommended lubricants

Engine/gearbox unit	SAE 15W40, 15W50 or 20W50 engine oil
Front forks	SAE 15W50 engine oil, or Park oil
Final drive chain	Aerzal chain lubricant
Pivot points	High melting point grease or gear oil
Wheel bearings	High melting point grease

Working conditions and tools

When a major overhaul is contemplated, it is important that a clean, well-lit working space is available, equipped with a workbench and vice, and with space for laying out or storing the dismantled assemblies in an orderly manner where they are unlikely to be disturbed. The use of a good workbench will give the satisfaction of work done in comfort and without haste, where there is little chance of the machine being dismantled and reassembled in anything other than clean surroundings. Unfortunately, these ideal working conditions are not always practicable and under these latter circumstances when improvisation is called for, extra care and time will be needed.

The other essential requirement is a comprehensive set of good quality tools. Quality is of prime importance since cheap tools will prove expensive in the long run if they slip or break and damage the components to which they are applied. A good quality tool will last a long time, and more than justify the cost. The basis of any tool kit is a set of open-ended spanners, which can be used on almost any part of the machine to which there is reasonable access. A set of five spanners makes a useful addition, since they can be used on nuts that are very tight or where access is restricted. Where the cost has to be kept within reasonable bounds, a compromise can be effected with a set of combination spanners - open-ended at one end and having a ring of the same size on the other end. Socket spanners may also be considered a good investment, a handle in or in a drive kit comprising a variety handle and a small number of socket heads, if money is limited. Additional sockets can be purchased as and when they are required. Provided they are still in profile, sockets will reach nuts or bolts that are deeply recessed. When purchasing spanners of any kind, make sure the correct size standard is purchased. Almost all machines manufactured outside the UK and the USA have metric nuts and bolts, while those produced in Britain have IBSF or BSWF sizes. The standard used in the USA is SAE, which is also found on some of the later British machines. Some tools that should be included in the kit are a range of crescent wrenches, a pair of pliers and a hammer.

When considering the purchase of tools, it should be remembered that by carrying out the work oneself, a large proportion of the initial repair cost, made up by labour charges, will be saved. The necessary result is that a slight outlay will go a long way towards the improvement of a tool kit.

In addition to the basic tool kit, certain additional tools can prove invaluable when they are close to hand, to help speed up a multitude of operations. For example, an impact screwdriver will save the removal of screws that have been

tightened by a similar tool, during assembly, without a risk of damaging the screw heads. Instead of using, it can be used again to tighten the screws, to ensure an ill-fitting tool remains.

Clutch plates have their own too, since gear plates, shafts and similar components are frequently retained by pins that are not too easily displaced by a screwdriver. There are two types of clutch pins, one for internal and one for external clutches. They may also have straight or right-angled ends.

One of the most useful of all tools is the torque wrench, a form of spanner that can be adjusted to slip when a measured amount of force is applied to any bolt or nut. Torque wrench settings are given in almost every modern workshop or service manual, where the extent to which a complete component, such as a cylinder head, can be tightened without fear of distortion or leakage. The tightening of bearing caps is yet another example. Over-tightening will result in worn break bolts, necessitating their work to replace the broken portions.

As may be expected, the more sophisticated the machine, the greater the number of tools likely to be required if it is to be kept in first class condition by the home mechanic. Unfortunately there are certain jobs which cannot be accomplished successfully without the correct equipment and although there is inevitably a specialist who will undertake the work for a fee, the home mechanic will have to dig more deeply in his pocket for the purchase of similar equipment if he does not wish to employ the services of others. Here a word of caution is necessary, since some of these jobs are best left to the expert. Although an electrical instrument of the AVO type will prove helpful in testing electrical faults, an inexperienced hand is very likely to damage some of the electrical components if a test current is passed through them in the wrong direction. This can apply to the synchronization of valve or multiple carburettors too, where a certain amount of expertise is needed when setting them up with vacuum gauges. There are, however, exceptions. Some instruments, such as a motor lamp, are virtually essential when checking the timing of a machine powered by EMI ignition systems. In short, do not purchase any of these special tools unless you have the experience to use them correctly.

Although the manual states how components can be removed and replaced without the use of special service tools (unless obviously essential), it is worthwhile giving considerable thought to the purchase of the more commonly used tools if the machine is regarded as a long term purchase. While the alternative methods suggested will remove and replace parts without risk of damage, the use of the special tools recommended and sold by the manufacturer will inevitably save time.

Chapter 1 Engine, clutch and gearbox

Contents

General description	1	Cylinder block examination and renovation	35
Operations with the engine/gearbox unit in the frame	2	Pistons and piston rings: examination and renovation	34
Operations with the engine/gearbox unit removed from the frame	3	Cylinder head: examination and renovation	33
Removal of engine/gearbox unit	4	Valves, valve seats and valve guides: examination and renovation	34
Method of engine/gearbox removal	5	Camshaft, tappets and tappet lifters mechanism: examination and renovation	37
Disassembling the engine/gearbox general	6	Clutch: examination and renovation	38
Disassembling the engine/gearbox (removing the camshaft, cylinder head and cylinder block)	7	Examination and renovation: gearbox components	39
Disassembling the engine and gearbox: removing the pistons and piston rings	8	Engine assembly: general	30
Disassembling the engine and gearbox: removing the contact breaker assembly	9	Engine and gearbox assembly: replacing the crankshaft	31
Disassembling the engine and gearbox: removing the clutch and related spring	10	Reassembling the lower crankcase half components	32
Disassembling the engine and gearbox unit: removing the alternator	11	Engine and gearbox assembly: refitting the gearbox	33
Disassembling the engine and gearbox unit: removing the primary mechanism (clutch) and components	12	Engine and gearbox assembly: fitting the upper and lower crankcase halves	34
Disassembling the engine and gearbox unit: removing the oil filter, pump and oil pump	13	Engine and gearbox assembly: refitting the clutch assembly and contact breaker unit	35
Disassembling the engine and gearbox unit: removing the secondary shaft	14	Engine and gearbox assembly: refitting the gearings mechanism and alternator assembly	37
Disassembling the engine and gearbox unit: repairing the crankcase halves	15	Engine and gearbox assembly: replacing the pistons and cylinder head	36
Disassembling the engine and gearbox unit: removing the upper crankcase half components	16	Engine and gearbox assembly: replacing the cylinder head and gaskets	38
Disassembling the engine and gearbox unit: removing the lower crankcase half components	17	Refitting the engine and gearbox unit into the frame	40
Examination and renovation: general	18	Engine and gearbox unit installation: final assembly and adjustment	41
Big end and connecting rod: examination and renovation	19	Starting and running the rebuilt engine unit	42
Examination and renovation: primary assembly	20	Putting the machine running on the road	43
Secondary shaft: components, examination and renovation	21	Four-Stroke: Engine	44
Oil seals: examination and replacement	22	Four-Stroke: Clutch	45
		Four-Stroke: Gearbox	46

Specifications

Engine

Type	4 cylinder horizontal OHV in-line overhead valve
Bore	62 mm
Stroke	64 mm
Displacement	652 cc
Compression ratio	8.5 : 1
Maximum horsepower	64 hp @ 5500 rpm
Maximum torque	5.8 kgm @ 1500 rpm
Construction	Aluminium alloy, horizontally split incorporating gearbox and oil pump
Cylinder block	Aluminium alloy, steel liners
Cylinder head	Aluminium alloy

Values

Type	Aluminium alloy, cast/blank
Piston ring groove width	Top 1.25 – 1.26 mm (lower limit 1.23 mm) Jaco 1.25 – 1.24 mm (lower limit 1.22 mm) Oil 1.51 – 1.53 mm (lower limit 1.48 mm) S.S. 1.52 mm
Overlays available	S.S. 1.52 mm

Piston rings

Number per piston	Two compression, one oil control
End gap limit	8 mm (lower limit 6.5 mm)
End gap (installed)	0.18 – 0.20 mm (lower limit 0.10 mm)
Ring thickness	Top 1.57 – 1.58 mm (lower limit 1.53 mm) Jaco 1.57 – 1.58 mm (lower limit 1.53 mm) Oil 1.94
Piston ring segment clearance	Top 0.04 – 0.08 mm (lower limit 0.15 mm) Jaco 0.03 – 0.07 mm (lower limit 0.15 mm) Oil 1/4

Cylinder bores

Standard bore diameter	61.835 – 62.083 mm
Wear limit	62.139 mm
Max/bore clearance	0.032 – 0.056 mm (0.0013 – 0.0022 in)

Small end assembly

Coupler pin OD	14.836 – 14.986 mm (lower limit 14.95 mm)
Piston pin diameter	15.800 – 15.950 mm (lower limit 15.07 mm)
Small end bush diameter	15.800 – 15.914 mm (lower limit 15.06 mm)
Piston pin to gudgeon pin clearance	0.056 – 0.115 mm (0.0022 – 0.0046 in)
Coupler pin to small end bush clearance	0.065 – 0.073 mm (0.0026 – 0.0029 in)

Big end assembly

Bearing to journal clearance	0.041 – 0.057 mm (lower limit 0.1 mm)
.....	0.0045 – 0.0039 in (0.0019 in)
Big end oil clearance	0.16 – 0.26 mm (lower limit 0.48 mm) (0.0063 – 0.0102 in) (0.0171 in)

Big end journal diameter

Marked '1'	34.934 – (34.954 mm (1.3715) – 1.3773 in)
Wear limit	34.935 – 35.000 mm (1.3716 – 1.3780 in)
Connecting rod big end diameter	
Marked '2'	38.008 – 38.016 mm (1.4966 – 1.4967 in)
Marked '3'	38.008 – 38.004 mm (1.4964 – 1.4964 in)
Wash bearing journal diameter	25.994 – 26.000 mm (1.0194 – 1.0194 in)
Wear limit	26.04 mm (1.0118 in)
Wash bearing journal clearance	0.034 – 0.016 mm (0.0013 – 0.0003 in)
Wear limit	0.11 mm (0.0043 in)

Valves

Valve stem diameter, inlet	8.988 – 9.080 mm (0.3534 – 0.3574 in)
.....	8.980 – 9.070 mm (0.3530 – 0.3574 in)
Valve limit, inlet	8.80 mm (0.3472 in)
.....	8.85 mm (0.3484 in)
Valve clearance (cold engine)	0.26 – 0.38 mm (0.0102 – 0.0150 in)

Valve timing

Inlet opens at	23° BTDC
Inlet closes at	52° ABDC
Duration	264°
Exhaust opens at	80° BBDC
Exhaust closes at	52° BTDC
Duration	265°

Clutch

Number of plate plates	4
Number of friction plates	7
Friction plate thickness	0.7 – 0.8 mm (0.140 – 0.0314 in)
Wear limit	0.5 mm (0.198 in)
Friction plate spring	less than 0.15 mm (0.0059 in) nominal
.....	less than 0.28 mm (0.0110 in) (wear limit)
Plate plate overlap	less than 0.12 mm (0.0047 in) nominal
.....	less than 0.40 mm (0.0157 in) (wear limit)

Gearbox		5 speed constant mesh
Type		1 to 2.33 : 1 (25/10)
Gear ratio		2nd 1.65 : 1 (33/20)
		3rd 1.17 : 1 (33/28)
		4th 1.04 : 1 (33/32)
		Top 0.88 : 1 (24/27)
Primary reduction ratio		2.88 (27/9) x 0.279
Final reduction ratio		2.83 (27/9)
Output drive ratio		5.90 (2nd gear)

Torque wrench settings

Component	Part size	Quantity	kg m	N m	lb ft	locking agent required
Cylinder head nuts	10 mm	12	3.5–4.0	25.0–29.0	–	No
Cylinder head bolts	8 mm	2	2.2–2.8	16.0–20.0	–	No
Cylinder head cover bolts	8 mm	24	0.7–0.8	–	01–78	No
Camshaft cap bolts	8 mm	16	1.1–1.5	–	05–113	No
Cam chain tensioner-adjustment bolt	8 mm	1	0.6–1.1	–	38–95	No
Cam chain tensioner body bolts	8 mm	2	0.7–0.8	–	01–78	No
Cam chain locker-wheel spindle bolt	8 mm	1	0.8–1.0	–	02–07	Yes
Camshaft sprocket-mounting bolts	8 mm	4	1.2–1.7	9.5–13.0	–	Yes
Camshaft bolts						
upper	8 mm	12	0.9–1.1	–	38–95	Yes
lower	8 mm	16	0.8–1.1	–	38–95	Yes
Camshaft drive sprocket	10 mm	1	1.2–1.7	9.5–13.0	–	Yes
Timing-mechanism bolts	8 mm	16	0.7–0.8	–	01–78	No
Engine mounting bolts	10 mm	4	2.4–4.6	20–30	–	No
	8 mm	8	2.0–2.8	14.5–20.0	–	No
Seawater sprayer gland bolts	8 mm	8	N/A	N/A	N/A	Yes
Seawater sprayer nut	10 mm	1	3.5–6.4	24–45	–	No
Dutch centre nut	20 mm	1	1.7–1.9	10–108	–	No
Dutch spring bolts	8 mm	5	0.9–1.1	–	38–95	No
Oil pressure switch	–	1	1.2–1.7	9.5–13.0	–	No
Oil pressure relief valve	12 mm	1	1.2–1.7	9.5–13.0	–	Yes
Oil pump mounting bolts	8 mm	2	–	–	–	Yes
Screws	–	1	–	–	–	Yes
RTU bolt	8 mm	1	2.0–2.7	14.5–19.0	–	No

1 General description

The engine unit fitted to the Kawasaki Z850 series is of the 4 cylinder in-line type, fitted transversely across the frame. The valves are operated by double overhead camshafts driven off the crankshaft by a timing chain. The two camshafts are located in the cylinder head casing, and the camshaft chain drive operates through a centre link between the two cylinders. Adjustment of the chain is effected by a chain tensioner, fitted to the rear of the cylinder block.

The engine/gear unit is of aluminium alloy construction, with the crankcase divided horizontally.

The Z850 series has a wet sump, pressure fed lubrication system, which incorporates a gear driven oil pump, an oil filter, a safety by-pass valve, and an oil pressure switch.

Oil vapours created in the crankcase are vented through an oil breather to the air stream, from where they are recirculated into the atmosphere, providing an oil tight system.

The oil pump is a twin shaft dual mesh unit, which is driven off the crankshaft by a gear.

An oil strainer is fitted to the intake side of the oil pump, which serves to prevent the pump mechanism from any impurities which it may pick-up during damage.

The oil filter unit, which is housed in the sump, is an alloy canister with a paper element. As the oil filter becomes clogged

with impurities, its ability to operate efficiently is reduced, and when it becomes so clogged that it begins to impede the oil flow, the by-pass valve opens and routes the oil around the filter. This oil route results in unfiltered oil being circulated throughout the engine, a condition that will be avoided if the filter element is changed at the pressure level increase.

The lubrication flow is as follows: Oil is drawn from the sump, through the oil strainer to the pump, then it passes through the oil filter to around it if the by-pass valve is not operated by the rise in which the oil pressure switch is mounted. It is then routed through three branch systems. The first system lubricates the crankshaft main bearings and connecting. The oil is drawn by the crankshaft's rotating motion into the cylinder walls providing the splash lubrication for the pistons. The oil then flows down into the sump, to be recirculated.

The second system lubricates the cylinder head assembly. Oil flows up through passages in the cylinder block, through the camshaft bushes, down over the cams, through the cam followers (or tappets) and back to the sump by way of holes in the base of the tappets, and the cam chain journal in the cylinder head.

The third system feeds the transmission bearings and then drains back to the sump for recirculation.

The engine is built in unit with the gearbox. This means that when the engine is completely dismantled, the clutch and gearbox are dismantled too. This task is made easy by arranging the crankcase to separate horizontally.

2 Operations with the engine/gearbox unit in the frame

It is not necessary to remove the engine from the frame to carry out certain operations. In fact it can be an advantage. Tasks that can be carried out with the engine in place are as follows:

- Removal and replacement of the clutch
- Removal and replacement of the flywheel/generator
- Removal and replacement of the generator rotor
- Removal and replacement of the carburettors
- Removal and replacement of the starter motor
- Removal and replacement of the secondary shaft components

When several tasks have to be undertaken simultaneously, it will probably be advantageous to remove the complete engine unit from the frame. This gives the advantage of much better access and more working space.

3 Operations with the engine/gearbox unit removed from the frame

- Removal and replacement of the cylinder head unit
- Removal and replacement of the cylinder block
- Removal and replacement of the pistons
- Removal and replacement of the crankshaft assembly
- Removal and replacement of the main bearings
- Removal and replacement of the gear elements and axles
- Removal and replacement of the clutch mechanism, gearbox bearings and gear change mechanism

4 Method of engine/gearbox removal

As mentioned previously, the engine and gearbox are bolted to each other. It is necessary to remove the complete unit to gain access to either assembly.

The engine unit is secured to the frame with 12 mounting bolts. After these have been removed, and the necessary electrical connections disconnected, together with the carburettor fuel pipes, oil pump and water pump system, the engine is ready for removal. Disassembly of the engine unit can only be accomplished after the engine unit has been removed from the frame and lifting control take place until the engine unit has been reassembled.

5 Removing the engine/gearbox unit

1 Place the machine firmly on its centre stand so that it stands on a smooth level surface. The ideal position for working is to place the machine on a robust wooden stand about 18 inches high, resting on its centre stand.

2 Make sure you have a clean, suitable place to work in and a good set of tools. You will need a great many sizes of conventional and special screwdrivers, small, medium and large, and plenty of clean lint free rag.

3 Remove the oil sump plug, oil filter cover and element, and drain the oil into a suitable tray. Approximately 2.8 litres of oil will drain off.

4 Disconnect and remove the battery. The battery is located beneath the skidplate, in a plastic compartment. It should be disconnected by using careful means split the contents.

5 Switch off the petrol tap and disconnect the petrol feed pipe from the shut-off tap/body. The tap is held by a rubber

tip of the tap that engages in a lip welded into the tap of the tank. Undo the rubber band and pull the fuel tank off, leaving the tap.

6 Remove the front clamps from all four exhaust pipes. They are held by two nuts per clamp, secured to studs fitted into the cylinder head. It is a good idea to wash these nuts in penetrating oil before cranking them, to safeguard against breakage of the studs in the cylinder head. Fasten the clamps which hold the exhaust balance pipe, beneath the carburettor, to the system if such side of the machine. The two alternate mounting bolts can now be released, and the system pulled clear of the machine. The balance pipe will remain on and part of the system.

7 Remove the rear drive covers to reveal the electrical components housed either side of the frame. Disconnect the rubber-mounted starter solenoid from the left-hand side of the machine, which will then allow the air cleaner bracketing mounting foot to be released. The bracket to which this solenoid will be attached from the plastic casing, and should be removed for safe keeping. Detach the right-hand mounting in a similar manner.

8 The carburettors can now be removed as a complete unit. It should be noted that this is not an easy task, and it is preferable to have an assistant to hand to help manoeuvre the assembly clear. Slacken the clamps which retain each carburettor to its rubber inlet pipe, and cut the spring bands up the hoses which connect the instruments to the air filter assembly. Pull the carburettor assembly back away from the inlet studs and note it to disengage the instrument mounts. This operation calls for a fair degree of patience if damage is to be avoided. Once free, lift the assembly away, complete with the various drain and breather hoses. Disconnect the throttle cables, which will be more accessible as the assembly is withdrawn.

9 Remove the handlebars which secure the starter motor cover, and lift the cover away. Remove the left-hand bearing, gear-change pedal and the left-hand casing mounting bolts, then remove the casing. Knock back the oil wiper which holds the gearbox sprocket nut. Apply the rear brake to immobilise the sprocket. Then slacken the mounting nut. The sprocket may now be slid off the shaft and disengaged from the chain, the latter remaining in position on the machine.

10 Disconnect the neutral switch lead and disconnect the clutch cable to release the outer casing. Slacken and remove the starter motor mounting bolts, then pull the motor clear of the unit and detach the lead from the solenoid. Working to the right-hand side of the machine, disconnect the rear brake light switch leads, and the earth cable to the top of the motorcycle. Undo the spring which operates the brake switch. Disconnect the contact breaker leads (coloured black, green and blue/red). Remove the right-hand footrest. Slacken the rear brake retaining nut, then detach the rear brake cable.

11 Remove the gland nut which retains the tail-bearing cable to the cylinder head. Disconnect the cable and position it out of the way. Remove the sparking plug, noting that the leads are numbered to avoid confusion during reassembly. Check around the unit carefully to ensure that no cables or leads have been left connected, and that no other components or fittings likely to impede engine removal. Remove the ignition coils and lodge them away from the unit on top of the frame top tube.

12 Slacken and remove the nuts from the engine mounting bars in the sequence shown in the accompanying photograph. Carefully remove the mounting bolts and engine cables, supporting the unit whilst endeavouring to lift them upwards. The unit will now sit on the lower part of the frame. The engine/gearbox unit is heavy, bulky and awkward, and will require two persons at least if damage to the machine and its owner is to be avoided. Lift the unit up squarely and move it to the right, checking that the crankcase clears the front and rear lower mounting leg lugs. Lift the right side of the unit so that the pump will clear the frame, then slide the unit out to the right. Once clear, the unit can be manoeuvred into a suitable sturdy block, leaving the now detached vital parts to take a well earned rest.



5.1 Remove subframe, air filter, throttle spring and timing cables.



5.2a Remove the gear change pedal and left main bearing.



5.2b Lift away the main bearing, and disconnect timing cable.



5.3a Loosen the wheel nuts, then remove speedometer.



5.10a Exhaust cable may be disconnected at lower end and removed with care.



5.10b Separate various leads and connector blocks.



5.11 Tachometer drive cable is removed by twisted ring



5.12 Engine mounting bolts should be removed and tightened in the sequence shown above

6 Dismantling the engine/gearbox assembly

1 Before commencing work on the engine unit, the exterior surfaces should be cleaned thoroughly. A motorcycle engine has very little protection from the hazards of road grit and other foreign matter, due to it having to be constructed to take advantage of air cooling.

2 There are a number of proprietary cleaning solvents on the market including clear and Quik. It is best to soak the parts in one of these solvents, using a cheap spray brush, before the solvent is permitted to dry, and afterwards wash down with water, making sure not to let water penetrate the electrical system or get into the engine, as many parts are now made of plastic.

3 Have a good set of tools ready, including a set of open ring spanners (these have a ring one end and are open ended at the other end), a few metric socket spanners of the smaller sizes, and an impact screwdriver with a selection of bits for the controlled screws. If one is not available, a crosshead screwdriver with a T handle fitted can sometimes be used as a substitute. Work on a clean surface and have a supply of clean lint-free rag available.

4 Spend one hour to remove any stubbornness unless careful attention is made of this requirement in the text. There is inevitably good reason why a part is difficult to remove, either because the dismantling procedure has been looked-out of sequence.

7 Dismantling the engine/gearbox removing the camshaft, cylinder head and cylinder block

1 Remove the H-shaped camshaft cover and place it to one side. Slacken the camshaft chain tensioner mounting bolts, and remove the unit, allowing the chain to become slack. Remove the screws which secure the tachometer drive pinion, and withdraw the latter from the cylinder head. Slacken and remove the several screws which retain the chain guide sprocket to the centre of the cylinder head, and lift the assembly away, together with the top roller chain tensioner bolts.

2 Slacken the camshaft top bolts, and lift off the caps. The camshafts may now be lifted to turn, and brought out of position. Take care not to let the chain drop down into the mechanism, unless a complete stripdown is intended. There is no

need to mark the camshafts, as the adjuster camshaft incorporates the tachometer driving screw and is thus easily identified.

3 The cylinder head is released by raising 10 mm nuts, and ten 6 mm bolts which are recessed into the cam chain tensioner. Slacken and remove these in the reverse order of the tightening sequence (See Fig. 5.10) to avoid the risk of warping the head casting. The cylinder head should now lift off the timing chain shafts. If it proves stubborn, it can be tapped free using a hammer and a block of wood or a fibre mallet. Avoid the temptation to lever the joint apart, as this can result in some damage, and at the very least will mark the surface finish of the casting.

4 Important note: Before removing the cylinder block, it should be noted that there is likely to be an accumulation of mud sludg around the base of the cooling fan studs (see photograph). Unless great care is taken, this will drop down into the cylinder during removal, necessitating excessive separation. Try to arrange the unit so that the block faces downwards, permitting the sludge to drop clear of the crankcase moulds. Clean the studs carefully before raising the unit up the right way again.



5.14 Camshaft chain tensioner body is removed by two bolts



2.10 Remove the connecting-rod drive before carefully disassemble



2.11 Release screws and remove guide sprocket assembly



2.12 Scrape any carbon from piston and its rings

8 Dismantling the engine and gearbox: removing the pistons and piston rings

- 1 Remove the circlip from the pistons by inserting a screwdriver for a piece of readily cut diameter wire into, through the groove at the rear of the piston. Carefully turn the wire and circlip during the removal.
- 2 Using a wire of suitable diameter, tap each gudgeon pin out of position, supporting each piston and connecting rod in turn. Mark each piston inside the skirt so that it is replaced in the appropriate bore. If the gudgeon pins are a tight fit on the piston bosses, it is advisable to warm the pistons. One size 6/70/8084 tag is very hot water, using the water jet and wrap the tag round the piston ring squibs. The resultant expansion should ease the grip of the piston bosses on the steel pins.

9 Dismantling the engine and gearbox: removing the contact breaker assembly

- 1 Remove the contact breaker cover by undoing the two screws that hold the cover on the front (left-hand) side of the engine. Then remove the three screws holding the contact breaker assembly with washers attached. Lift off the plate,



2.13 Take care that road dirt around studs does not enter engine

ensuring the wires by putting them out of the connector. Note that the three backplate screws only should be removed. The position of the backplate can be marked by relation to the engine as an aid to reassembly, although it will still be necessary to re-tune the ignition on reassembly.

- 2 Working the contactplate with a 1.1 mm feeler at the larger hexagon, slacken the automatic timing-unit (ATU) retaining bolt, and put the unit off the shaft. The unit is located by a nut pin which will remain in position in the contactplate end.

10 Dismantling the engine and gearbox: removing the clutch and kickstart spring

- 1 Remove the clutch cover screws, taking care to catch any washer or which was run out as the cover is lifted away. Slacken the five clutch springbolts, and remove them together with the washers and clutch springs. Lift over the clutch cover, and withdraw the mushroom-headed pinhead. Tap the unit to dislodge the small steel ball which fits behind the pinhead.
- 2 Remove the clutch plates. Then slacken a piece of steel wire with which the clutch centre may be supported to prevent its rotation while the clutch centre nut is loosened. Remove the centre nut and the special washer behind it, followed by the clutch centre, washer and outer drum. If the cage needs to be

bearing remains on the shaft, this should also be noted.

2 Remove the upper bearing and end of the ballast spindle, and pull out the upper roller spring guide. Disengage the spring and using a pair of pointed nose pliers and allow it to unwind. The spring can now be removed from the shaft.

11 Dismantling the engine and gearbox units: removing the alternator

1 Remove the screws which secure the left-hand outer cover, and fit the cover and gasket assembly early. It will be necessary to prevent the crankshaft from turning while the rotor is being cut. This can be accomplished by securing the gear and securing the rear brake if the engine is still in the frame. If the unit is being dismantled for overhaul, a bar can be passed through one of the end eyes, and supported by small wooden blocks at each side of the crankcase mouth. The cut can now be machined and removed.

2 In the absence of the official Kawasaki rotor extractor (part number 91001 - 204) a conventional tapered puller can be arranged to draw the rotor off its taper. Ensure that the line of the puller engage squarely on the underside of the rotor, then tighten the centre bolt gradually. If it proves stubborn, a tap on the end of the centre bolt will usually succeed in pulling it free. (Do not attempt to fit the rotor itself during removal.)



11.1 Contact breaker assembly is retained by three screws (shown)

12 Dismantling the engine and gearbox units: removing the valve mechanism cover and components

1 Remove the three gearbox sprocket guard bolts and lift the guard away. The selector mechanism cover can be detached after the retaining screws have been removed. The selector shaft and modification (air) cover be disengaged and lifted away. The selector bearing cover can also be detached and placed on one side. It is retained by two screws.


13 Dismantling the engine and gearbox units: removing the oil filter, pump and oil pump

1 If the oil filter has not already been removed, the centre retaining bolt should be released and the cover (then oil) spring that a certain amount of residual oil will be released from the housing. Remove the filter element, and empty and clean out the housing.

2 Slacken and remove the turbo mounting bolts, then lift the turbo away. It will be noted that the turbo is fitted with an oil pressure relief valve, which need not be disturbed at this stage.



8.2 Pliers (pointed nose) used to catch displaced spring



11.2 Tapered puller may be used to draw rotor off

3 Slacken the two bolts which retain the oil pump assembly to the inside of the casing, and lift the pump unit away complete with the gear train assembly.

14 Dismantling the engine and gearbox units: removing the secondary shaft

1 A secondary shaft, incorporating the starter motor (crankshaft) unit, is located below and to the rear of the oil tank shaft assembly, and is retained to it by way of a Morse chain. The shaft can be displaced from the casing and withdrawn from the right-hand side (lower left-hand when viewed from the underside of the unit), following the procedure detailed below.

2 Slacken and remove the counter-bore screws which secure the retaining plate against the plates on the right-hand side of the casing. The plate will drop free on the shaft (indicated) using a shim. Tap the shaft through from the left-hand side, supporting the Kawasaki and sprocket unit as the shaft is withdrawn. The right-hand bearing will remain in position on the shaft. Dismantle the intermediate unit from the Morse chain and place it and the shaft to one side.



12.11 Remove gearbox sprocket guard and selector mechanism



12.16 Disengage and remove the selector mechanism



13.2 Oil pump retained by two bolts



14.2a Release retaining plate across shaft to disengage



14.2b Shaft can be removed, leaving ...



14.2c ... secondary shaft transmission assembly to be withdrawn

18 Dismantling the engine and gearbox with separating the**crankshaft halves**

1 Remove the crank cover completely first from the top end of the engine, then from the left over, and remove the right 8

over bolt and the top 8 over bolt. The timing belt can now be removed.

2 To get possibly the best view of the crankshaft and flywheel

remove one of the connecting rods at the timing belt end and the other 7

at the timing belt end. To do this, remove the connecting rod and the timing 8

rod nut and lock washer. The nut and the timing rod can be removed in 9

together 1 remove 2 washers at the end of the crankshaft and a 10

locking wedge on the right. Finally the pin and wedge will be removed 11

but 1 may be held in place by the timing belt and the timing belt 12

rod nut and lock washer. (Make sure that the timing belt is removed 13

and the connecting rod is held in place by the timing belt and the 14

rod nut and lock washer. The nut and the timing rod can be removed in 15

together 1 remove 2 washers at the end of the crankshaft and a 16

locking wedge on the right. Finally the pin and wedge will be removed 17

but 1 may be held in place by the timing belt and the timing belt 18

rod nut and lock washer. (Make sure that the timing belt is removed 19

and the connecting rod is held in place by the timing belt and the 20

rod nut and lock washer. The nut and the timing rod can be removed in 21

together 1 remove 2 washers at the end of the crankshaft and a 22

locking wedge on the right. Finally the pin and wedge will be removed 23

but 1 may be held in place by the timing belt and the timing belt 24

rod nut and lock washer. (Make sure that the timing belt is removed 25

and the connecting rod is held in place by the timing belt and the 26

rod nut and lock washer. The nut and the timing rod can be removed in 27

together 1 remove 2 washers at the end of the crankshaft and a 28

locking wedge on the right. Finally the pin and wedge will be removed 29

but 1 may be held in place by the timing belt and the timing belt 30

rod nut and lock washer. (Make sure that the timing belt is removed 31

and the connecting rod is held in place by the timing belt and the 32

rod nut and lock washer. The nut and the timing rod can be removed in 33

together 1 remove 2 washers at the end of the crankshaft and a 34

locking wedge on the right. Finally the pin and wedge will be removed 35

19 Dismantling the engine and gearbox with separating the**crankshaft halves**

1 Remove the crank cover completely first from the top end of the engine, then from the left over, and remove the right 8

over bolt and the top 8 over bolt. The timing belt can now be removed.

2 To get possibly the best view of the crankshaft and flywheel

remove one of the connecting rods at the timing belt end and the other 7

at the timing belt end. To do this, remove the connecting rod and the timing 8

rod nut and lock washer. The nut and the timing rod can be removed in 9

together 1 remove 2 washers at the end of the crankshaft and a 10

locking wedge on the right. Finally the pin and wedge will be removed 11

but 1 may be held in place by the timing belt and the timing belt 12

rod nut and lock washer. (Make sure that the timing belt is removed 13

and the connecting rod is held in place by the timing belt and the 14

rod nut and lock washer. The nut and the timing rod can be removed in 15

together 1 remove 2 washers at the end of the crankshaft and a 16

locking wedge on the right. Finally the pin and wedge will be removed 17

but 1 may be held in place by the timing belt and the timing belt 18

rod nut and lock washer. (Make sure that the timing belt is removed 19

and the connecting rod is held in place by the timing belt and the 20

rod nut and lock washer. The nut and the timing rod can be removed in 21

together 1 remove 2 washers at the end of the crankshaft and a 22

locking wedge on the right. Finally the pin and wedge will be removed 23

but 1 may be held in place by the timing belt and the timing belt 24

rod nut and lock washer. (Make sure that the timing belt is removed 25

and the connecting rod is held in place by the timing belt and the 26

rod nut and lock washer. The nut and the timing rod can be removed in 27

together 1 remove 2 washers at the end of the crankshaft and a 28

locking wedge on the right. Finally the pin and wedge will be removed 29

but 1 may be held in place by the timing belt and the timing belt 30

rod nut and lock washer. (Make sure that the timing belt is removed 31

and the connecting rod is held in place by the timing belt and the 32

rod nut and lock washer. The nut and the timing rod can be removed in 33

together 1 remove 2 washers at the end of the crankshaft and a 34

locking wedge on the right. Finally the pin and wedge will be removed 35



1 The engine mechanism has been partially lifted, but it still needs to be supported on the left by the engine stand. The final gear section has the usual flywheel position.

14 Dismantling the engine and gearbox with removing the lower connecting rod components

1 The connecting rod assembly can be lifted out of the engine block, but only after the connecting rod nut and lock washer have been removed. The nut and the timing rod can be removed in together 1 remove 2 washers at the end of the crankshaft and a locking wedge on the right.

15 Dismantling the engine and gearbox with removing the upper connecting rod components

1 The connecting rod assembly can be lifted out of the engine block, but only after the connecting rod nut and lock washer have been removed. The nut and the timing rod can be removed in together 1 remove 2 washers at the end of the crankshaft and a locking wedge on the right.

1 The connecting rod assembly can be lifted out of the engine block, but only after the connecting rod nut and lock washer have been removed. The nut and the timing rod can be removed in together 1 remove 2 washers at the end of the crankshaft and a locking wedge on the right.

1 The connecting rod assembly can be lifted out of the engine block, but only after the connecting rod nut and lock washer have been removed. The nut and the timing rod can be removed in together 1 remove 2 washers at the end of the crankshaft and a locking wedge on the right.

1 The connecting rod assembly can be lifted out of the engine block, but only after the connecting rod nut and lock washer have been removed. The nut and the timing rod can be removed in together 1 remove 2 washers at the end of the crankshaft and a locking wedge on the right.

1 The connecting rod assembly can be lifted out of the engine block, but only after the connecting rod nut and lock washer have been removed. The nut and the timing rod can be removed in together 1 remove 2 washers at the end of the crankshaft and a locking wedge on the right.



1 The crankshaft mechanism, like the timing and drive shaft, must be supported by the timing belt and the timing belt rod nut and lock washer. The nut and the timing rod can be removed in together 1 remove 2 washers at the end of the crankshaft and a locking wedge on the right.

1 The connecting rod assembly can be lifted out of the engine block, but only after the connecting rod nut and lock washer have been removed. The nut and the timing rod can be removed in together 1 remove 2 washers at the end of the crankshaft and a locking wedge on the right.

1 The connecting rod assembly can be lifted out of the engine block, but only after the connecting rod nut and lock washer have been removed. The nut and the timing rod can be removed in together 1 remove 2 washers at the end of the crankshaft and a locking wedge on the right.

1 The connecting rod assembly can be lifted out of the engine block, but only after the connecting rod nut and lock washer have been removed. The nut and the timing rod can be removed in together 1 remove 2 washers at the end of the crankshaft and a locking wedge on the right.



11.1 Remove split pin and bearing pin to free selector fork




11.2 Withdraw adaptor drum and various shafts



11.3a Remove screws, and circlip on shaft...



11.3b ... withdraw shafts fully...




11.3c ... and fit mechanism out of casing half

18 Examination and renovation: general

- 1 Before examining the parts of the dismantled engine and gearbox, it is essential that they should be cleaned thoroughly, then a comprehensive test to remove all traces of oil and sludge which may have accumulated within the engine.
- 2 Examine the crankcase castings for cracks or other signs of damage. If a crack is discovered it will require a specialist repair.
- 3 Examine carefully each part to determine the extent of wear, checking with the tolerance figures listed in the Specifications section of this Chapter, if there is any question of close fit or side and round.
- 4 Use a clean lint-free rag for cleaning and drying the various components. This will prevent the risk of small particles obstructing the internal circuitry, and causing the lubrication system to fail.

Fig. 5.1 Kickstart mechanism

- 1 Kickstart lever complete
- 2 Rubber
- 3 Kickstart pin
- 4 Bending plate
- 5 Groove ball
- 6 Spring
- 7 Groove corner
- 8 Washer
- 9 Clutch
- 10 Nut
- 11 Clutch
- 12 Spring cap
- 13 Recoil spring
- 14 Recoil cover
- 15 Clutch - 2 off
- 16 Pinion/washer
- 17 Kickstart gear/pinion
- 18 Nut
- 19 Kickstart shaft
- 20 Return spring
- 21 Return spring guide
- 22 Pin
- 23 Screw - 2 off
- 24 Nut - 2 off
- 25 Lock washer
- 26 Kickstart stop



19 Big end and main bearings, assemblies and materials

1. The Kawasaki 250B models are fitted with eight bearings on the crankshaft and the big end assemblies.

2. Applying grease and applying progressively and in proportion to cover the entire end of every bearing while the engine is disassembled completely, especially to cover the entire of each shaft, will be necessary at a later date if any of the bearings fit. Always remove the film area of each bearing before greasing.

3. When it is finally evident in the form of sticking or some marks in the bearing surfaces, it is not possible to permit these marks out to view of the user until most of the bearing surface and the bearing materials are well worked. If some of the marks are not removed, the bearings will wear the crankshaft to the detriment of the engine.

4. Failure of the big end bearings is usually accompanied by a conventional knock within the crankcase. The knock will become progressively worse and vibration will also be experienced. It is essential that bearing failure is attended to immediately because if the engine is used in this condition it is at risk of breaking a connecting rod to ruin the crankcase, causing more extensive damage.

5. Before the big end bearings can be examined the bearing caps must be removed from both connecting rods. Each cap is marked by two light vertical lines. Before removal, each mark cap is necessary so it is necessary that so that it may be replaced

correctly. As with the main bearings, care will be required in handling in storage and the bearing marks must be retained as far as possible.

6. Replacement bearing shells for either the big end or main bearings are supplied as a unit and it is vital that bearings are checked for correct clearance to fit the original bearing dimensions, and it is essential that the parts to be used for replacement of bearings fit.

7. Bearing parts should be selected in accordance with the size marking on both the connecting rod and mainshaft. Use the following table of sizes:

Connecting rod mark:	1	1	2	3	4
Mainshaft size and type:	B	A	C	D	E
Mainshaft Part number:	PCV0303L	B	PCV10304L	E	
Big end Part number:	BE0	BE1	BE2	BE3	BE4
Endurance part:	LA05-1-080	LA06-1-085	LA07-1-085	LA08-1-080	LA09-1-080
Endurance kit:	LS03B	LS03B	LS03B	LS03B	LS03B
Endurance kit:	LS03C	LS03B	LS03B	LS03B	LS03B



18-10 Big end bearings should be removed by rotation.



18-11 Connecting rods, caps and shells are arranged by colour.



18-12 Remove caps bearing the impellers in order.



18-13 Check the position of impellers after caps are removed.




Fig. 1.2 Cylinder block, piston and crankshaft

- 1 Bore pin - 2 off
- 2 O-ring - 2 off
- 3 Epoxide resin
- 4 Rubber plug - 8 off
- 5 O-ring - 4 off
- 6 Cylinder base gasket
- 7 Piston ring seal - 4 off
- 8 Piston - 4 off
- 9 Circlip - 8 off
- 10 Snap-on pin - 4 off
- 11 Connecting rod assembly - 4 off
- 12 Big end ball - 8 off
- 13 Big end nut - 4 off
- 14 Big end bearing seat - 4 off
- 15 Main bearing shell - 12 off
- 16 Crankshaft assembly
- 17 Oil seal
- 18 Oil seal
- 19 Lock washer - 2 off
- 20 Drive pin

20 Examination and re-assembly: crankshaft assembly

1 If wear has accumulated the amount of the big and/or pin main bearing shells, the crankshaft should be checked with a micrometer to verify whether limits have occurred. If the wear on any one journal exceeds by more than 0.02 mm (0.002 inch) the crankshaft should be renewed.

2 Mount the crankshaft by supporting both ends on V-blocks or between centres on a lathe and check the run-out of the seven main bearing surfaces to ensure a flat gear. The run-out will be half that of the gauge readings indicated. The correct run-out is under 0.02 mm (0.002 inch) and if it exceeds 0.05 mm (0.002 inch) the crankshaft should be renewed.

3 The clearance between any set of bearings and their respective journal may be checked by the use of Plastigauge (green grease). Plastigauge is a granulated strip of plastic material that can be compressed between two rotating surfaces. The resulting width of the material after measured with a micrometer will give the amount of clearance. For example if the clearance in the big-end bearing is to be measured, Plastigauge should be used in the following manner:

Get a strip of Plastigauge to the width across the bearing to be measured. Place the Plastigauge strip across the bearing journal so that it is parallel with the crankshaft. Place the connecting rod complete with its half nut on the journal and then carefully rotate the bearing cap clockwise with both ends onto the connecting-rod bolts. Tighten and tighten the bearing nuts to the correct torque and then loosen and remove the nuts and the bearing cap. Without turning or moving the Plastigauge strip, place it at its widest point between a micrometer and read off the measurement. This will indicate the precise clearance. The original size and wear limit of the connecting journals and the journal and main-belt clearance between all the bearings is given in the specifications at the beginning of this Chapter.

4 The crankshaft has drilled off passages which allow oil to be fed under pressure to the rotating surfaces. Care must be taken to clean these out carefully, preferably by using compressed air.

5 Unless refitting the connecting rods and their bearings, none need undergo any disassembly about the shafts be refitted with a shim, wrapped in or the fit protected by fitting the connecting rod and bearing cap or by applying grease directly to the bearing surface. Freshly cut shafts will run free and in diameter if the bearing fit is not good, the parts concerned have not been assembled correctly. This advice also applies to the main



20.1 Examining crankshaft journals, and condition of bearings

bearing shells. Use new big-end bolts too – the originals may have stretched and weakened.

6 Oil the bearing surfaces before re-assembly takes place and make sure the lips of the bearing shells are locked correctly. After the initial tightening of the connecting rods, check that each connecting rod revolves freely, then tighten to a torque setting of 24 – 34 kg-m (19 – 23 ft-lb). Check again that the bearing is quite free.

21 Secondary shaft components: examination and re-assembly

1 Always keep the crankshaft transmitted by use of a Morse shaft to be checked on the secondary shaft, which is run above the clutch. The secondary shaft also incorporates a rubber-impregnated clutch disc which compensates any angle vibration. It is not normally necessary to dismantle the secondary shaft components unless one of the following symptoms has been apparent:

(a) Starter motor not engaging or disengaging correctly, indicating wear in the clutch rollers, wash or breaker springs or damaged clutch bearing.

(b) Gear is primary transmission, indicating wear or damage to the shaft or clutch roller or hub.

If it is a clutch gearbox, the following steps should be taken to check the starter gear off the end of the shaft, together with its needle roller bearing. The clutch body will not be exposed, and will be used to maintain these sets of springs, wash and rollers. These should be removed and examined for wear or damage, although this unit is not especially prone to wear, but for signs of flats appearing on the roller faces, and the signs of wear in the clutch body and on the gear base on which the rollers sit. Wear in these areas can cause the clutch to jam, and prevent the starter motor from disengaging correctly. Occasionally it can also cause slipping, preventing the drive from the starter motor from being transmitted to the engine. The only safe course of action, if wear is evident, is to renew the parts concerned. If the rollers are to be renewed, it may require 22 g of motor oil, to avoid subsequent problems in the event of their failure.

3 Like the starter system, the shock absorber components rarely give any trouble. The unit is, however, very easy to dismantle. The main body, which incorporates the Morse shaft sprocket, is retained by a nut. When this has been released, the body can be slid off and the rubber segments removed for examination. Any damage will be self-evident and normally will be confined to the rubber segments. These will tend to become compressed and rounded off after a very high mileage, and should be renewed if this is the case.

4 Examine the teeth on the outside of the housing looking for chips and signs of wear. If the teeth are only slightly flawed, they may be resurfaced using a fine stone. More severe damage will necessitate renewal.

5 The journal end bearings which support the shaft should be checked for signs of roughness and free play after they have been subjected to clean petrol and dried off. Any sign of grittiness or any play is indicative of the need for renewal. The bearing which is still in place in the casing can be checked out using a large diameter roller as a shim. The remaining bearing can be pulled off the shaft by way of a bearing extractor or small spreader screw.

6 The Morse primary chain has no provision for adjustment, but will normally cover a very high mileage before renewal becomes necessary. Wear can be checked by temporarily fit (inserting the crankshaft) and secondary shaft in the casing head, with the chain fitted in its normal position. Free play should be measured at the inside of the run, and should not exceed 27 mm (1.063 in). If wear beyond this amount, a new chain must be fitted.




Fig. 1.3 Secondary shaft assembly - component parts

- | | | | |
|----|---------------------|----|--------------------|
| 1 | Gear | 10 | Pin - 2 off |
| 2 | Shaft | 11 | Washers - 2 off |
| 3 | Pin | 12 | Secondary shaft |
| 4 | Gear | 13 | Journal bearing |
| 5 | Secondary shaft | 14 | Retaining plate |
| 6 | Pin | 15 | Screw - 2 off |
| 7 | Washer - 1 off | 16 | Screw |
| 8 | Gear | 17 | Clutch driving pin |
| 9 | Secondary shaft | 18 | Clutch |
| 10 | Pin | 19 | Journal bearing |
| 11 | Washer - 2 off | 20 | O ring |
| 12 | Gear | 21 | Retaining cap |
| 13 | Allen screw - 2 off | 22 | Screw - 2 off |
| 14 | Screw | 23 | Clutch pin |



1.21 Pin should be freed away from clutch assembly



1.22 Check valves for wear or flat, ensure that springs seat

22 Oil seals: examination and replacement

1 Oil seal failure is difficult to define precisely. Usually it takes the form of oil pooling on the outside of the machine, and there is nothing worse than those ungrateful puddles of oil on the ground where the machine has been standing. One of the most crucial places to look for an oil leak is behind the gearbox final drive sprocket. The seal and 'O' ring that fits on the shaft should be removed if there is any sign of a leak.

2 Oil seals are relatively inexpensive, and if the unit is being overhauled it is advisable to remove all the seals as a matter of course. This will preclude any risk of an annoying oil leak developing after the unit has been reinstalled in the frame.

23 Cylinder block: examination and renovation

1 The usual indication of badly worn cylinder bores and pistons is excessive smoking from the exhaust. This usually takes the form of blue fumes (indicating development of a white haze as the wear becomes more pronounced).

2 The other indication is piston rings, a flow of metallic waste which occurs when there is little lead on the rings. If the top of the bore is examined carefully, it will be found that there is a ridge on the thrust side, the depth of which will vary according to the rate of wear which has taken place. This marks the limit of travel of the top piston ring.

3 Measure the bore diameter just below the ridge using an internal micrometer or a dial gauge. Compare the reading you obtain with the reading at the bottom of the cylinder bore, which has not been subjected to any piston wear; if the difference in readings exceeds 0.05 mm (0.002") the cylinder block will have to be bored and honed, and fitted with the required oversize pistons.

4 If a measuring instrument is not available, the amount of cylinder bore wear can be measured by inserting the piston (without ring) at the top of the bore. If it is possible to insert a 0.005 inch feeler gauge between the piston and cylinder wall on the thrust side of the piston, immediate action should be taken.

5 Kawasaki engine pistons in two cylinders, 0.8 mm (0.031) and 1.0 mm (0.039) thick. If boring in excess of 1.8 mm becomes necessary, the cylinder block must be re-bored since new liners are not available for Kawasaki.

6 Make sure the external cooling fins of the cylinder block are free from oil and mud film, as this can prevent the free flow of air over the engine and cause overheating problems.

24 Pistons and piston rings: examination and renovation

1 If a rebore becomes necessary, the existing pistons and piston rings can be abandoned because they will have to be tapered to fit their new cylinders.

2 Remove all traces of carbon from the piston crowns, using a thrust metal scraper to avoid scratching the surface. Finish off by polishing the crowns of each piston with metal polish, so that carbon will not adhere so readily in the future. Never use emery cloth on the soft aluminium.

3 Piston wear usually occurs at the skirt or lower end of the piston and takes the form of vertical striations or score marks on the thrust side of the piston. Damage of this nature will necessitate renewal.

4 The piston ring grooves may become enlarged if use, allowing the rings to have a greater side float. If the clearance exceeds 0.15 mm (0.006) at the pistons are due for replacement.

5 To measure the end gap, insert each piston ring into its cylinder bore, using the crown of the low piston to locate it about 1 inch from the top of the bore. Make sure it is square in the bore and insert a feeler gauge in the end gap of the ring. If the end gap exceeds 0.7 mm (0.028 inch) the ring must be renewed. The standard gap is 0.15 - 0.5 mm (0.006 - 0.019 in).

When refitting new piston rings, it is also necessary to check the end gap. If there is insufficient clearance, the rings will break up in the bore while the engine is running and cause extensive damage. The ring gap may be increased by filing the ends of the rings with a file file.

The ring should be supported on the end as much as possible to avoid breakage when filing, and should be filed square with the end. Remove only a small amount of metal at a time and keep checking the clearance in the bore.

25 Cylinder head: examination and renovation

1 Remove all traces of carbon from the cylinder head using a thrust metal scraper. The round end of an old steel tool will do, finish by polishing with metal polish to give a smooth, shiny surface. This will do good work and will also prevent carbon from adhering so freely in the future.

2 Check the condition of the sparking plug hole threads. If the threads are worn or crossed they can be reclaimed by a Helical tap. Most motorcycle dealers possess this tool which is very simple, cheap and effective.

3. Clean the cylinder head face with a wire brush, to prevent overheating through oil blocking the flow.
4. Lay the cylinder head on a sheet of 1/2 inch plate glass to check for distortion. Aluminium alloy cylinder heads distort very easily, especially if the cylinder head bolts are tightened down unevenly. If the amount of distortion is only slight, it is permissible to rub the head down until it is flat once again by wrapping a sheet of very fine emery cloth around the plate glass base and rubbing with a rotary motion.
5. If the cylinder head is distorted badly (one way of determining this is if the cylinder head gaskets have a tendency to keep blowing), the head will have to be straightened by a competent engineer equipped in this line of work. This will, of course, void the compression of the engine, and if too much is removed an advantage often the performance of the engine, if there is not in fact this happening, the only remedy is a new replacement (cylinder head).

26. Valves, valve stems, and valve guides examination and inspection

1. Remove the valve tappets and shims, keeping them separate for installation in their original locations. Compare the valve springs with a valve spring compressor, and remove the split valve collars, also the oil seals from the valve guides, as it is best to remove these latter components.
2. Remove the valves and coil springs, making sure to keep the bottom during assembly, label the valves for inlet, overhead or burning, and replace them as necessary. Normally, the exhaust valves will need removal for more often than the inlet valves, as the latter run at relatively low temperatures. If any of the valve spring faces are heavily coated, do not attempt to turn this by grinding them, as this will inevitably cause the valve seats to become cocked; it is preferable to have the valves refaced by a mechanic specialised in metal engineering work. The valve seating angle is 45°. The valve must be checked if the head thickness (the area between the edge of the seating surface and the top of the head) is reduced to 0.5 mm (0.020 in). The spring thickness is 1.0 mm (0.040 in).
3. Measure the bore of each valve guide in at least four places using a small bore gauge and micrometer. The standard measurement for each guide (internal diameter) is 7.008 + 0.015 mm (0.2758 + 0.0006 in). If the measurement exceeds 7.045 mm (0.2778 in) the guide should be replaced with a new one.
4. If a small bore gauge and micrometer are not available, insert a new wire into the guide, and set a dial gauge against the valve stem. Carefully move the valve back and forth in the guide and measure the amount of the wire in each direction. The guide will have to be replaced if the clearance between the wire and guide exceeds the following figures:

	Working	Wear limit
Inlet	0.020 + 0.005 mm 0.0008 + 0.0020 in	0.24 mm (0.0095 in)
Exhaust	0.021 + 0.004 mm 0.0009 + 0.0016 in	0.26 mm (0.0102 in)

Note that the above method does not give the actual valve to valve guide clearance.

4. It is worthwhile pointing at this juncture to consider the heat shield of valves. It must be borne in mind that valve guide clearance is not set, and will require that the valve seats be used after the guide has been fitted and reamed. It is also remarkably easy to damage the cylinder head unless great care is taken during these operations. It may, therefore, be considered better to entrust these jobs to a competent engineering

company or to a Kawasaki Service Agent. For the more in-depth guide and burner equipment, the procedure is as follows:

5. Heat the cylinder head slowly and evenly, in an oven to prevent warpage, to 100 + 50°C (200 + 100°F). Using a stepped drill, tap the guide lightly out of the head, taking care not to turn coolant on the hot casting. New guides should be fitted in similar manner, making that they seat properly in the head casting. If a valve guide is loose in the head, it may be possible to have an amateur guide machined and fitted by a competent engineering works, making that the cylinder head must be fitted to suit the new guide. The popular method of inserting the outside of the guide is crude and is not recommended.
6. After the guide has been fitted it must be reamed using a Kawasaki reamer (Part Number 51001 + 021Mates) sure that the reamer passes evenly through the valve guide bore, taking care not to accidentally gauge out too much material. The valve seat must now be re-cut in the following manner:
 7. If a valve guide has been removed, or a valve seat face is worn or pitted, it must be re-cut to ensure efficient seating. The process requires the use of three cutters (30°, 45° and 60°). These are normally available as a set. Assemble the tool according to the manufacturer's instructions, with the 60° cutter fitted through the tool with the angle located in the cutter (push and remove just enough to ensure proper fit to the cutting surface. Note that if too much metal is removed, the valve will become cocked, and the concrete cylinder head will have to be replaced.

Kawasaki do not supply valve seat liners, so the amount cut must be taken.

8. The 30° and 60° cutters should be used next, and in that order, to leave the raised 45° seating face on an even base between 0.5 and 1.0 mm in width. The correct should now be ground in in the normal manner.

9. The valve should be ground in, using ordinary oil-based grinding paste, to remove any grinding or to clean off a newly cut seat. Note that it is not highly essential to sport to using the coarse grade of paste which is normally supplied in flat-guide reamers.

Valve grinding is a dirty task. Commence by ensuring a base of fine valve grinding compound (carbide dust) on the valve seat and apply a cushion coat to the head of the valve. (a) the valve stem and insert the valve in the guide so that the two surfaces to be ground in make contact with one another. With a semi-rotary motion, grind in the valve head to the seat, using a backward and forward action. Use the valve occasionally so that the grinding compound is distributed evenly. Repeat the application until an uniform ring of light grey metal finish is obtained on both sides and seat. This denotes the grinding operation is being completed. Before starting to the next valve make sure that all traces of the valve grinding compound have been removed from both the valve and its seat and that only the raised seat of the valve guide. If this procedure is not observed, rapid wear will take place due to the highly abrasive nature of the carbide dust paste.

10. In view of the number of valves past in these engines, it may be thought worthwhile purchasing one of the oscillatory valve tapping tools which have come onto the market in recent years. This tool's consists of a sealed grinding having a driving spindle on one side and a valve tapper on the other. Rotary motion from an electric drill shaft is converted to the correct tapping motion at the handle. These devices are well worth having if more than one or two valves are to be tapped. Do not attempt fit the valve stem or insert into a drill shaft and attempt grinding by that method, as this will quickly destroy the seat.

11. Reassemble the valve and valve springs by reversing the disassembly procedure. fit new oil seals to each valve guide and fit both the valve stem and the valve guide, prior to assembly. Note special care to ensure the valve guide oil seal is not damaged when the valve is inserted. As a final check after assembly, give the end of each valve stem a light tap with a hammer, to make sure the split collars have located correctly.



24.2 Clean all traces of carbon from piston crowns



25.1 To lift off rings and various items, keeping them in order



26. To lift more spring compression so other rings can be removed



27.2 Springs and retainers to be removed for examination



28.2 Check skirt for wear. Remove all oil



28.11 Reassemble valves after they have been ground in




Fig. 1-4 Cylinder head and cover

- | | | | | | |
|----|----------------------------|----|------------------------------------|----|----------------------------|
| 1 | Block - 24 off | 11 | Exhaust valve | 21 | Block cover - 12 off |
| 2 | Cylinder head cover | 12 | O ring | 22 | Cylinder head gasket |
| 3 | Cylinder head cover gasket | 13 | Exhaust valve guide | 23 | Block cover gasket - 2 off |
| 4 | Cylinder head assembly | 14 | Oil seal | 24 | Four pin - 4 off |
| 5 | Pin - 16 off | 15 | Stopper plate | 25 | Screw - 4 off |
| 6 | Pin - 16 off | 16 | Screw | 26 | Washer - 4 off |
| 7 | Pin - 16 off | 17 | Oil - 4 off | 27 | Screw - 2 off |
| 8 | Intake valve guide - 4 off | 18 | Sealing ring - 4 off | 28 | Intake stud bolt - 2 off |
| 9 | Intake valve guide - 8 off | 19 | Cylinder head cover gasket - 4 off | 29 | Sealing ring |
| 10 | Intake valve guide - 8 off | 20 | Cylinder head nut - 8 off | 30 | Cylinder head nut - 4 off |




Fig. 1.2 Camshafts and valves

- 1 Exhaust camshaft
- 2 Camshaft sprocket - 2 off
- 3 Bolt - 4 off
- 4 Nut camshaft
- 5 Tapered - 2 off
- 6 Shim - as required
- 7 Valve spring retainer - 12 off
- 8 Valve spring retainer - 8 off
- 9 Outer valve spring - 8 off
- 10 Inner valve spring - 8 off
- 11 Oil seal - 4 off
- 12 Valve spring seat - 2 off
- 13 Exhaust valve - 4 off
- 14 Inlet valve - 4 off

27 Camshafts, tappets and camshaft drive mechanism: examination and renovation

1 Examine the camshaft lobes for signs of wear or scoring. Wear is normally evident in the form of upper flats worn on the peak of the lobes, and this may be checked by measuring each lobe at its highest point. The standard measurement is 25.72 ± 0.027 mm (1.01081 ± 0.0011 in). If worn to 25.65 mm (1.01024 in) or less the camshaft must be renewed. Scoring or circular damage can usually be attributed to a partial failure of the lubrication system, possibly due to the oil filter element not having been renewed at the specified intervals. Causing oilstarvation is to be avoided by use of the bypass valve. Before fitting new camshafts, examine the bearing surfaces of the camshafts, and cylinder head, and verify the cause of the failure.

2 If the camshaft bearing surfaces are marked, it is likely that removal of both the cylinder head and the camshaft will fix the only solution. This is because the camshaft run directly to the cylinder head casting, using the alloy as a bearing surface. Assemble the bearing caps and measure the internal bore using a bore micrometer. The nominal size is 23.030 ± 0.021 mm (0.90671 ± 0.00082 in). The cylinder head and caps must be renewed if this figure exceeds 22.958 mm (0.90307 in).

3 Measure the camshaft bearing journals, which when new measure between 21.940 ± 0.040 mm (0.86142 ± 0.00157 in), hence the camshaft if worn down to 21.800 mm (0.86173 in) or less. The nominal bearing clearance should be 0.050 ± 0.001 mm (0.00196 ± 0.00003 in), the wear limit being 0.170 mm (0.0067 in). This can be checked by using the Plastigauge method as described in Section 26 of this Chapter.

4 Camshaft run-out can be checked by supporting each end of the shaft on 0-50028, and measuring any run-out using a dial test indicator sprung on the camshaft sprocket face (using the retained tie sprocket). This should not normally be more than 0.01 mm (0.0004 in). The camshaft must be renewed if run-out exceeds 0.1 mm (0.0039 in).

5 The single camshaft drive chain should be checked for wear, particularly if tension adjustment has failed to prevent chain noise. This latter condition being indication that the chain is probably due for renewal. Lay the chain on a flat surface and get an assistant to stretch it out. Using a vernier caliper gauge measure a 20 link run of the chain (repeat this check in one or two other places). The nominal length is 180.00 mm (7.087 in), if this exceeds 182.4 mm (7.177 in), the chain must be renewed.



27.66 ... guide sprockets, ...

6 The various guide sprockets, the roller guide and the tension assembly should be examined for wear or damage, which will normally be fairly obvious. However the roller guide appear worn or are damaged, assemble if a new chain has been fitted. The cone can be applied to the two camshaft sprockets. These components can normally be replaced to give many miles of service if correctly maintained. The tensioner arm, cam disc or the exhaust camshaft is unlikely to suffer under wear.

7 The water drive to the waterpump is an integral part of the camshaft which mates with a pinion attached to the cylinder head. If the water pump is damaged or both worn, it will be necessary to replace the camshaft pinion.

8 The waterpump drive worm gear shaft is fixed in a housing which is a press fit in the cylinder head cover. If the worm gear is chipped or broken the gear and shaft should be renewed.



27.67 Examine the waterpump sprocket, ...



27.68 ... camshaft for wear or damage



27.5a Check the condition of the upper guide sprocket assembly. ...



27.5b ... and the tensioner body mechanism.




Fig. 1.8 Cam-chain and tensioner

- 1 Roller screw - 4 off
- 2 Rubber block - 2 off
- 3 Roller - 2 off
- 4 Cam-chain upper guide bracket
- 5 Cam-chain upper guide sprocket - 2 off
- 6 Roller
- 7 Nut
- 8 Cam-chain
- 9 Lower sprocket shaft - 2 off
- 10 Washer
- 11 Guide roller shaft
- 12 Cam-chain tensioner assembly
- 13 Roller
- 14 Tensioner body
- 15 Nut
- 16 Tensioner adjusting nut
- 17 Plate washer - 2 off
- 18 Wash - 2 off
- 19 Pinion assembly
- 20 Tensioner spring

28 Clutch: examination and renovation

1 After an extended period of service the clutch linkage will wear and promote clutch slip. The limit of wear measured across each inscribed plate and the standard measurement is as follows:

Standard	Service limit
Clutch plate thickness 3.7 – 3.9 mm (0.146 – 0.154 in)	3.5 mm (0.138 in)


When the wear limit is reached the limit, the inscribed plates must be renewed, preferably as a complete set.

2 The plate springs should not show any excessive heating (bluening). Check the message of each plate using plate gear or surface plate and a feeler gauge. The maximum allowable message is 0.40 mm (0.0157 in) in the case of the plate springs.

and 0.38 mm (0.0149 in) in the case of the friction plates.

3 Examine the clutch assembly for burn or indentation on the edges of the protruding tongues of the heated plates and/or side wear in the edges of the outer drum with which they engage. Similar wear can occur between the inner tongues of the plate clutch plates and the sets in the clutch inner drum. Wear of this nature will cause clutch drag and slow down gear-man-shifting gear changes, since the plates will become heated and will not free fully when the clutch is withdrawn. A small amount of wear can be corrected by grinding with a fine file. However, severe wear will necessitate removal of the worn parts. Note that the clearance between the clutch drum sets and the lips of the clutch plates must not exceed 1.0 mm (0.0394 in).

4 The clutch release mechanism attached to the final drive sprocket cover does not normally require attention provided it is greased at regular intervals. It is held to the cover by two cross-head screws and operates on the worm and quick shift thread principle.



20 Examination and reassembly: gearbox components

1 Examine each of the gear pinions to ensure that there are no chips or broken teeth and that the edges on the end of the pinions are not rounded. Gear pinions with any of these defects must be renewed; there is no satisfactory method of rectifying them.

2 After thorough washing in petrol, the bearings should be examined for roughness and pitting. Also check for pitting on the roller tracks.

3 It is advisable to remove the gearbox oil seals irrespective of their condition. Should a seal not seal full at a later date, a considerable amount of work is involved to gain access to it again.

4 Check the gear selector rod for straightness by rolling it on a sheet of plate glass. A bent rod will cause difficulty in selecting gears and will make the gear change particularly noisy.

5 The selector forks should be examined closely, to ensure that they are not bent or badly worn. The case-hardened part which engages with the cam channels are easily scratched if they are worn. Under normal conditions, the gear selector mechanism is unlikely to wear rapidly, unless the gearbox oil

level has been allowed to become low.

6 The bolts in the selector drum, with which the selector forks engage, should not show any undue signs of wear; chips might have led to under-lubrication of the gearbox. Check the condition of the gearchange pawl, gearchange pin and drive proper pin springs. Weakness in the springs will lead to improper gear selection. Check the condition of the gear stopper pin (see 2) and the pins in the change drum and with which it engages. It is unlikely that wear will take place here except after considerable mileage.

7 Check the condition of the lockstar components. If slipping has been encountered a worn lockstar and pawl will inevitably be found at the cause. Any other fittings in wear in the components will be self-evident, if either the rollers or pawl is found to be faulty, both components must be replaced as a pair. Examine the lockstar return spring, which should be renewed if there is any doubt about its condition.

8 If it is found necessary to repair any of the gearbox components or those of the lockstar mechanism, the accompanying drawings will give details of the assembly sequence. In addition, gear shafts necessarily is covered in the accompanying [Inspection/Repair sequence](#).



20. To Remove related components if badly worn or damaged



21. To Ensure that reference marks align before refitting shaft



22. Be 10 (hydraulic) 2nd gear, master and idling...



23. Be... followed by 5th gear pinion as shown

28.19 Apply the water-soluble grease to the mesh and cover area.



28.20 Reinstall the gear from the hub and cover.



28.21 Fit the gear on the input shaft.



28.22 Fit the bearing on the shaft.



28.23 Fit the output shaft into the gear housing.



28.24 Fit another washer and lock washer, followed by the lock nut.





28.21 ... and to the first component to be fitted to shaft



28.22 locks with washer and cotter ...




28.23 ... then fit the intermediate 2nd gear pinion



28.24 fit cotter to groove as shown, then fit washer ...



28.25 ... and split bush. This bush carries ...



28.26 ... the mainshaft 5th gear pinion ...



20.8a ... which is followed by mainshaft 2nd gear pinion



20.8b Fields off with bearing, circlip and cover cap





Fig. 1.8 Gearbox - cross section showing gear positions

Fig. 1.8 Gearbox components (see opposite page)

- | | | |
|----------------------------------|---------------------------------|---------------------------------|
| 1 Bush | 20 Crown | 39 External lock nut |
| 2 Oil ring | 21 Lock washer | 40 1st & 2nd gear selector fork |
| 3 Circlip - 2 off | 22 Pin washer plate | 41 1st gear selector fork |
| 4 Needle roller bearing - 2 off | 23 Change drum pin - 2 off | 42 Nut |
| 5 Steel washer - 2 off | 24 Change drum pin | 43 Pin washer |
| 6 Phosphor bronze washer - 2 off | 25 Gears | 44 Engage sprocket |
| 7 Mainshaft 2nd gear pinion | 26 Needle roller bearing | 45 Engage sprocket/washer |
| 8 Mainshaft 3rd gear pinion | 27 4th & 5th gear selector fork | 46 O-ring |
| 9 Mainshaft 1st gear bush | 28 Drive pin | 47 Oil seal |
| 10 Washer - 2 off | 29 Split pin | 48 Layshaft |
| 11 Circlip - 2 off | 30 Cam plate | 49 Layshaft 2nd gear pinion |
| 12 Mainshaft 2nd gear pinion | 31 Drive pin | 50 Lock washer |
| 13 Mainshaft 4th gear pinion | 32 Circlip | 51 Circlip |
| 14 Mainshaft | 33 Slant plunger | 52 Layshaft 3rd gear pinion |
| 15 Ball bearing - 2 off | 34 Slant spring | 53 Layshaft 5th gear pinion |
| 16 Washer | 35 Slant bush | 54 Layshaft 4th gear pinion |
| 17 Lock nut | 36 Tap washer | 55 Layshaft 1st gear pinion |
| 18 Mount/gear-balance switch | 37 Nut | 56 Bush |
| 19 Gear change drum | 38 Circlip | |



30 Engine reassembly - general

- 1 Before reassembly of the engine/gear unit is commenced, the various component parts should be cleaned thoroughly and placed on a sheet of clean paper, close to the working area.
- 2 Make sure all traces of old gaskets have been removed and that the mating surfaces are clean and undamaged. One of the best ways to remove old gasket cement is to apply a rag soaked in methylated spirit. This acts as a solvent and will ensure that the cement is removed without resort to scraping and the consequent risk of damage.
- 3 Gather together all the necessary tools and have available an oil can filled with clean engine oil. Make sure all new gaskets and oil seals are in hand, plus all replacement parts required. Nothing is more frustrating than having to stop in the middle of a reassembly sequence because a vital gasket or replacement has been omitted.
- 4 Make sure that the reassembly area is clean and that there is adequate working space. Refer to the torque and clearance settings wherever they are given. Many of the smaller bolts are easily checked if over-tightened. Always use the correct size wrenches for the crosshead screws and never an ordinary screwdriver or punch. If the existing screws show evidence of

misalignment in the past, it is advisable to replace them as a complete set.

31 Engine and gearbox reassembly - replacing the crank shaft

- 1 Check that all the bearing shells are laid out in the correct order, then roll them to their respective recesses. Ensure that the locating ring on each shell corresponds with the depression in which it engages. Ensure that each shell is firmly located before proceeding further. (3) each shell clearly.
- 2 Level the upper crankcase and place it on the workbench. Commence reassembly by locating the crankshaft assembly in position, taking care to locate all the bolts in the sure marks of the main bearings with the corresponding shells inserted in the crankcase. Make sure the cam drive chain and Morse primary chain are in position on the crankshaft at this stage. Feed the connecting rods through the apertures in the crankcase and snug the crankshaft in its position, rotate it to make sure all the main bearings rotate freely.
- 3 If the crankshaft does not appear to seat correctly, check that the crankshaft webs, which locate in grooves in the crankcase bosses, are seated properly.



21.1a Fit the main bearing shells into position, using locating tag



21.1b Lubricate bearing shells before fitting crankshaft



21.1c Fit new crankshaft's oil seals



21.1d ... ensuring that they locate correctly in grooves when snug

82 Reassembling the lower crankcase half components

- 1 Push the kickstart mechanism from the inside of the case, sliding the screw into the casing and over the shaft, and retaining it with its lockwasher and nut.
- 2 The selector drum and third gear fork should be fitted next, following the removal sequence in reverse (See Section 1.3). Do not omit the detent plungers and locating balls. Fit the selector forks and shaft, ensuring that they are in their correct positions.
- 3 Ensure that the main oil gallery is cleared out. This can be achieved by removing the large plug at each end and blowing it out with compressed air. Refit and tighten the end plugs.



82.1 Refit kickstart mechanism, starting retaining screw



82.3a Refit selector drum bearing, if necessary...



82.3b ...max refit selector drum, complete and check



82.3c Fit pins to selector fork, and locate main gear pin



82.3d Check that detent plunger assembly functions correctly...



22.24... and verify to carburetor as shown.



22.25 Bolt and tighten locating bolts, and bend over locking tab.



22.26 Check that accelerator operates smoothly, adjust master.



22.27 Drive in ribs slowly on selector fork shaft.



22.28 Remove the main oil gallery and plugs.



22.29... and clean out using compressed air.

33 Engine and gearbox assembly: refitting the gearbox clutch

1 The gearbox mainshaft and layshaft assemblies should be placed in position in the upper crankcase half. Note that each shaft is located by a half ring on one end, and a bearing housing pin at the other. Ensure that these engage correctly, and that the shafts seat squarely. Lubricate the assembly with clean engine oil, and check that the gears run and mesh correctly.

2 Check, particularly if any gearbox components have been removed, that the mainshaft, 1st gear and layshaft 2nd gear splines run freely. If this is not the case, it may be necessary to fit a thinner third washer between the splines concerned and its adjacent bearing. It is helpful if counsel is found by moving the gear to the full distance between the mainshaft and layshaft is discontinued. Set the selector sleeve in the lower casing half in the neutral position. When set correctly, the smallest interference in the cam plate will engage with the detent plunger.

34 Engine and gearbox assembly: joining the upper and lower crankcases

1 Wipe off the mating surfaces of the crankcase halves to ensure any residual oil, dirt, and if necessary salt, any of the bearing/shaft oils that may have come loose.

2 Apply a thin film of non-hardening grease compound to the mating surfaces of the lower crankcase half, taking care not to obstruct the oil passages. Where provisions to accommodate a water pump exist, it is so that the gasket compound will not get squeezed into it where the joint is tightened. If the mating face has been marked or scratched, and oil leakage has been a problem in the past, it is preferable to use one of the Elcom-Bly® (Bayer Temperature Vervandlungs) liquid gasket compounds now available. The rubbery nature of this substance will take up any small discrepancies in the mating faces, but additional care must be taken to avoid obstructing oilways. Place new crankshaft seals in position, ensuring that they locate correctly.

3 Lower the lower crankcase half into position, checking to ensure that the selector fork engage in their respective grooves. Push the casing down evenly, ensuring that the bearing shells also correctly fit the pin 8 mm and eight 6 mm retaining bolts in place. Tighten slightly only.

4 The lower crankcase half, each of the 8 mm bolts (having a number denoting in which order they are to be tightened). Fit a torque wrench to about 1.5 kgm (11 lb ft) initial, and tighten the 8 mm bolts

in sequence from rear over the torque wrench to 2.5 - 3.0 kg m (18 - 22 lb ft) and re-tighten the bolts to their final torque setting. The remaining eight 6 mm bolts should be tightened evenly and in a diagonal sequence to 0.8 - 1.1 kg m (18 - 26 lb ft) if possible.

5 Check at this stage that the mainshaft will turn freely and that there are no tight spots in rotation. The gearbox assembly should also be checked carefully for signs of resistance or rubbing, and the gear selector checked for binding (the crankshaft should mesh easily). This checking sequence is important, as it is far preferable to spot any problems at this stage, rather than find them after assembly is complete.

6 It is likely that the mainshaft will be a little stiff in its movement, particularly if new shafts have been fitted. However, any undue resistance in either the crankshaft or gear components will necessitate modification before rebuilding is continued. Turn the unit over and fit the upper upper crankcase half, tighten in sequence to 0.8 - 1.1 kgm (26 - 26 lb ft).

35 Engine and gearbox assembly: refitting the secondary shaft, oil pump and sump

1 Lower the secondary shaft sprocket/water pump assembly into the casing, and fit the 8 mm chain around the sprocket. Slide the secondary shaft into position, guiding the end of the shaft through the sprocket/water seal boss. Before driving the bearing home, fit the retaining pins, and fit this in position while the shaft is topped into position. Refit the counterweights, retaining screws, and reinsertion to push these into position after tightening.

2 Place the oil pump in position in the casing, then fit and tighten the mounting bolt and the two long screws which also retain the secondary shaft retaining plate. Note that the latter screws must be tightened after tightening.

3 Refit the secondary shaft bearing cap, and tighten the bearing screws. Check that three new olive O-rings are fitted in their respective positions. Two of the O-rings fit into recesses in the casing and a third is fitted in the base of the oil pump. Make sure that the lower casing and sump mating faces are clean, and that a new O-ring is fitted to the oil filler chamber groove. A new O-ring (which should be placed in position on the lower crankcase face, and the pump fitted and secured) tighten the retaining bolts evenly to 0.7 - 0.8 kgm (6.1 - 18 lb ft) of tension. A new oil filler cap is fitted at this stage, and the cover fitted and tightened. It is worth priming the system by filling the lowermost chamber with engine oil. This will speed up oil circulation when the engine is first started.



33. 1a Fit half rings and sleeves in bearing journals




35. 1a Refit gearbox clutch, and sump operation



24-1 Crankshaft assembly may move to lubricated 5th position.



25-1 Both primary chain and sprocket teeth.



26-1 Slide secondary shaft away from



28-1 If both pistons, tightening and pressing screws.



29-2a Lower oil pump into casing.



29-2b ... and fit firm and square. Pushing either no pressure
bearing.



25.24 Bearing cap may now be refitted. Note O-ring



25.25 O-ring being fitted to all parts-increase of sealing...



25.26... and also to the rear of the casing



25.28 O-ring filter chamber is seated to large O-ring



25.29 Flange cover pump gears in position and with pump

24 Engine and gearbox assembly: refitting the clutch assembly and contact breaker unit

1 Fit the special weather into the end of the gearbox mainshaft, noting that the splined face must be horizontal. The clutch centre roller-bearing can be fitted next, followed by the clutch drum and thrust washes. Slide the clutch cone to top position, followed by the special washers, note that the latter is marked 'OUTSIDE' and must be fitted accordingly. Fit and tighten the clutch centre nut to 12-15 kg m (87-108 lb ft), locking the crankshaft in a similar manner to that used to hold it for top dead centre.

2 Place the clutch plates in position, starting and finishing with a friction plate. Before fitting the cover, grease and insert the $\frac{1}{2}$ in steel ball in the centre of the mainshaft, followed by the mushroom-headed pinion. The cover can now be refitted, the springs and washers placed in position, and the coupling bolts tightened down diagonally to 0.8-1.1 kg m (5.8-8.1 lb ft) of torque.

3 If the kickstart shaft oil seal or (less likely) the oil level window, has shown signs of leaking, this should be driven out of the clutch cover. These seals can be carefully tapped back into position, taking great care not to damage the sealing edge.

4. The cover should be fitted using a new gasket. To prevent oil leakage, a smear of gasket cement should be applied at the two points where the covercase halves are joined. Offer up the outer casing and tighten down the securing screws firmly.

5. Place the automatic timing unit in position on the end of the crankshaft, ensuring that the timing pin engages in the corresponding hole at the base of the coil fit and tighten the retaining bolt to 2.2-2.7 kg (18.5-19.5 N m), holding the crankshaft with a 17 mm spanner.

6. Connect the oil pressure switch lead (blue and red) to the terminal on the top of the sender. It is important that the tag is positioned well away from the contact breaker linkages, as it can easily short out the points, giving a spurious indication of an oil pressure failure. Fit the contact breaker assembly in position, but do not fit the cover as the ignition timing must be checked after installation but before the splined lead cover has been fitted. (For further details, refer to the Routine Maintenance section and Chapter 3).

27 Engine and gearbox assembly: refitting the selector mechanism and alternative assembly

1. Check that the shaft is correctly located in its groove in the end of the selector fork shaft. Offer up the selector case



26.1 Note that the chamfered face must fit against bearing



26.2 ... Rotatably fitted needle roller bearing ...

assembly, guiding the pawls each side of the selector drum and. Make sure that the coating spring engages on the locating pin. It is worthwhile temporarily refitting the gear change pedal to check that gear selection is positive.

2. Examine the seals in the outer cover. These can be renewed as necessary by sliding the seal out and using a suitable sized socket as a drift. The sealing procedure emerges in give as much support as possible to the boss. The new seals may be driven into place in the same manner, taking care not to damage the sealing lip.

3. Slide a new 'O' ring into position on the end of the shaft, and place a new gasket in position. Offer up the casing, using the seal as a drift. Fit and tighten the retaining screws, not forgetting to position the speaker guard. The speaker guard can now be slid into position, as can the clutch pawl nut. Lubricate the two latter components with high boiling point grease prior to fitting.

4. Place the alternator rotor in position on the crankshaft with the rotor fit and tighten the securing nut to 6.8-8.2 kg (62-80 N m). The crankshaft may be prevented from turning by use of the hexagon on the opposite end of the crankshaft, or by the method described in the removal sequence.

5. Ensure that the screws and gasket are correctly positioned, then fit the water cover. Do not forget to reconnect the neutral indicator switch lead.



26.3a Fit chamfered rotor and inner bearing race ...




26.3b ... Chamfered outer drum and thrust washer



21. To: Slide the clutch cover to the pulley.



22. To: Rotate the gears until the teeth are meshed.



23. To: Lock clutch while center nut is tightened.



24. To: Shift the clutch plate and friction plate.



25. To: Do not forget to grease and verify oil seal/cover.



26. To: Fit the clutch cover, and replace the springs.



26.2a Tighten the clutch retaining bolts



26.2 Remove any seals which appear worn or damaged



26.3 Remove the clutch which engages to hold in base of 8.7a



27.1 Reassemble gear selector mechanism as shown



27.2a Fit new seals to cover as required ...



27.2b ... to avoid any risk of subsequent oil leakage

26 Engine and gearbox assembly: replacing the pistons and cylinder block

- 1 Before replacing the pistons, and the results of the gearbox setting in order to prevent any displaced component from accidentally dropping into the crankcase.
- 2 Fit the pistons in their original order onto the cross on the piston crown painting toward the front of the engine.
 - ↳ If the gudgeon pins are a tight fit, heat with the pistons to expand the metal. Use the gudgeon pins and small end-bearing surfaces, after the piston leaves, before fitting the pistons.
- 3 Always use new shims, never the originals. Always check that the shims are located properly in their groove in the cylinder head. If displacement strip will cause severe leakage to the cylinder bore, applicable to engine rebuild.
- 4 Place a new cylinder liner gasket (dry) over the crankcase mouth. Roll the bottom guide roller. Now clean the cylinder block over the cylinder studs (make sure the four 'O' rings are fixed to the base of the cylinder), support the cylinder block while the camshaft chain is threaded through the tunnel between the bases. This task is best achieved by using a piece of jiffy wire to hook the chain through, and put it through the tunnel. The chain link engage with the crankshaft drive sprocket.
- 5 The cylinder bores have a generous lead in for the pistons at the bottom, and although it is an advantage on an engine with an oil sump to use this specific flangeless ring compressor, in the absence of this, it is essential to gently lead the pistons into the bore, working down from one side. Great care has to be taken NOT to put too much pressure on the fitted piston rings. When the pistons have finally engaged, remove the rag packing from the crankcase mouth and lower the cylinder block off further until it seats firmly on the base gasket.
- 7 Make care to enter the camshaft chain throughout this operation to save the chain dropping down into the crankcase. The new life assembly sprockets that guide the cam shaft, can now be replaced, with their shafts and rubbers, into the top of the cylinder block.

28 Engine and gearbox assembly: replacing the cylinder head and camshaft

- 1 Rotate the camshaft until the 'T' mark on the advance and retard mechanism is aligned with the timing mark on a screw in the corresponding sprocket. Do this position, number and antifuse pistons are at top dead centre.
- 2 Replace the valve tappets and the shims in their original locations and use a new cylinder head gasket to prevent any compression leakage. Note that if the cylinder head, camshaft or tappets have been reversed, the correct shims will almost certainly require changing. The valve clearance must, of course be checked in any event. The cylinder head can now be bolted down, tightening the nuts diagonally.
- 3 After the cylinder head has been secured, the next operation is to fit the camshaft. Start by fitting the rubber camshaft bush. To fit the camshaft, feed the camshaft through the cam cover, position the camshaft so that the mark on the sprocket is aligned with the cylinder head surface, as shown in the accompanying photograph.
- 4 Now pull the cam chain taut and fit the chain on to the camshaft sprocket. Starting with the rear chain link pin allow the one that coincides with the sprocket mark, ease the pin, until you reach the 26th pin and slide the inlet camshaft into position so that the 26th pin coincides with the 'T' mark on the rubber portion of the inlet camshaft sprocket.
- 5 Having assembled the camshaft and replaced the cam chain, the next task is to set the camshaft down.

↳ Lubricate the camshaft thoroughly, then fit the bearing caps in position. The caps are marked 'to fit' with the cylinder head, and so it is very important that they are replaced with the number on the cap corresponding to the number on the cylinder head. Also the arrows marked on the caps must point to the front.

7 Partially tighten the left-hand caps first, to seat the camshaft in place. All the bolts can now be fully tightened down to 1.1–1.3 tpm (26–1.8 in ft) of torque. They should be tightened down in numerical sequence.

8 Make sure all the camshaft bearings and valve tappets are lubricated with clean engine oil. The top chain guide sprocket can now be installed. Adjust the cam chain tension by refitting the tensioner. Before this is installed loosen the locknut on the cylinder so that the plunger end is free to move, rotate the engine slowly a couple of times to make sure the spring loaded tensioner takes up the slack in the chain evenly, and then tighten the bolt first and head the locknut. It will adjust to the correct tension automatically.

9 To make double sure that the timing is right, rotate the engine until pistons number one and number four are at TDC and check that both the mark on the exhaust camshaft sprocket and the mark on the inlet camshaft sprocket are aligned level with the cylinder head surface. This will indicate that the cam timing is correct. **CAUTION.** Always use a square on the large cut on the crankshaft when turning the engine over for timing inspection.

DO NOT run the engine by turning the camshaft sprocket.

10 Note that the valve timing check is critical, as any error in this setting, however small, can result in the valves hitting the pistons in each other, causing serious (and expensive) engine damage. It is, therefore, advisable to be absolutely certain that the timing is set correctly at this stage. Do not account with this operation.

11 Check the valve clearance, following the procedure detailed in the Specific Maintenance section. If the clearance on either these sprockets, it will be necessary to remove the camshaft and tappets in order to fit smaller or larger shims. If, do not be tempted to skip this operation, as excessive clearance will result in noisy operation and impaired efficiency. Conversely, too small a clearance will rapidly burn out the valve concerned. Once set, the clearance will not need adjustment for long periods.



28.2 Setting timing on pistons must face forward



28.6 Replace pistons using the straps



28.6a Fit a new cylinder head gasket and O-rings



28.6b Make sure the piston is positioned correctly



28.6c Fast piston into cylinder block, then lower block



28.7 Align T-marks on pistons 1 and 4 w/ TDC



28.7a How the cylinder head gasket (marked TOP) fits O-rings



25.25 Lower cylinder head, supporting assembly shown.



25.26 Bolt the head and bearing cap(s).



25.28 ... ensuring that the timing mark on each sprocket ...



25.29 ... is aligned as described in text.



25.30 Distributor timing marks must fit as shown when timing assembly.



25.31 Oil vanes only contact cylinder head and



25-8 Camshaft caps are numbered and arranged for reference.



25-9 Reassemble the upper chain guide sprocket assembly.



25-10 Hold the camshaft chain tensioner, and adjust.



25-11 Insert the tachometer drive and left retaining plate.



25-12 Check valve cover(s), and tight where necessary.



25-13 Shim (265) are checked on one side (left).




Fig. 1.10 Cylinder head nut tightening sequence




Fig. 1.11 Valve timing

- 1 Intake camshaft timing mark
- 2 Intake camshaft spacer
- 3 Exhaust camshaft spacer
- 4 Exhaust camshaft timing mark
- 5 Crankshaft timing mark (1 = 1 cylinder)

40 Reinstalling the engine and gearbox unit into the frame

1 As mentioned during the engine removal sequence, the engine/gearbox unit is sensitive, requiring at least two, or preferably three, people to ease it back into position. This is even more important during reassembly, as the unit must be lowered up at the right angle, and then manoeuvred into position. Care must be taken not to damage the finish on the frame tubes, and it is advisable to protect these with rag or masking tape.

2 Once the unit is set on the frame rails, refit the engine mounting COB's, referring to the photograph showing their location, which indicates the correct sequence in the early part of this Chapter. Assemble the front and rear engine plate bolts and fit the nuts and spring washers from right to left: the rear of the unit so that the upper rear bolt hole (17) is aligned, and slide the bolt into place, noting that a spacer is also required. Next, fit the front mounting bolt (11) and the two rear mounting bolts (27 and 41).

4. For ease of identification, note that the mounting bolt lengths are as follows:

Front upper mounting bolt:	266 mm (11.7 in) (fit 1)
Front lower mounting bolt:	252 mm (10.7 in) (fit 2)
Rear upper mounting bolt:	250 mm (9.8 in) (fit 3)
Rear lower mounting bolt:	223 mm (8.8 in) (fit 4)

The four engine plate bolts should be tightened to 2-3.2-3 kg m (14.5-20.5 lb ft) and the engine mounting bolts to 3.4-4.8 kg m (25-35 lb ft) torque.

41 Engine and gearbox unit installation: final assembly and adjustment

1 Place the final drive chain over the rear sprocket, and fit it over the splined end of the forkshaft. Refit the idler pulley and nut, tightening the latter to 7.5-8.5 kg m (53-61 lb ft). Set the rear assembly applying the new leader before the nut is tightened. Keep your eye on the leading weather to prevent the nut from slipping out.

2 Reconnect the clutch cables, and refit it to the frame using cable ties. Check that the neutral switch lead has been reconnected. Fit the starter motor lead to the terminal, and slide the protective rubber lead into position to protect the terminal from staining. Offer up the upper motor, taking care not to damage the 10 mm adjuster the two mounting bolts.

3 Check that the alternator output leads are routed correctly, then fit the outer casing and tighten the retaining screws. Refit the left-hand footrest, then fit the gearchange pedal, checking that it is in the right position in relation to the footrest. Assemble the right-hand footrest, reconnect the brake light switch operating spring and leads. If necessary, readjust the rear chain tension, brake pedal free play and rear brake switch operation.

4 Check the ignition timing as described in the Routine Maintenance section of Chapter 3, then refit the cylinder head cover and contact breaker cover. Check that the contact breaker leads (blue/red, black and green) and the alternator output leads (blue/grey, green and green/red) are reconnected and correctly routed.

5 Make sure the timing plate is secured tightly to the four fasteners with the eight mounting screws before replacing the wheel end covers. Also check that the throttle control cable wheel operates and returns freely on the return spring, and that the choke lever operates the chokes of all four carburetors. Fit the carburetor bank to its inlet duct, refit the air filter assemblies, if available.

6 Secure the carburetors to the intake hoses on the cylinder head by the securing clips fitted round the intake hoses. Make sure these clips are tight, otherwise leakage will occur on the intake side of the carburetor and cause irregular running.

7 Cleaned the rear of the engine, adjust it to the oil filler cap. 8 Refit the air cleaner mounting brackets, and secure them with the single mounting bolts at each side. Remove the breather cover cap if this has been detached, then reconnect the large breather pipe, routing it behind the oilcooler to the oil cleaner housing.

5. Reassemble the ignition coils and refit the numbered sparking plug leads to their appropriate plugs. Refit each half of the exhaust system, using new exhaust joint gaskets. Note that the half-pipe can be held in place with strips of masking tape while the clamps are refitted. Make sure that the balance pipe which runs beneath the catalyser is joined together firmly, and the clamp/bolt tightened securely. Refit the petrol fare and ensure that petrol filter/strainer is in the combustion. Reconnect the tachometer alarm cable.

10. Check that the clutch cable is correctly adjusted. (See Routine Maintenance) and that the throttle cables operate smoothly and without excessive play (See Chapter 2). Reconnect the battery, making that the system is negative (-) earthed, then refit the side panels. Refit the catalyser with 100 154153 or 100150 engine oil, bringing the level to halfway up the oil level window. Note that this level should be checked after running the engine for a few minutes, and replenished as necessary. Check around the machine for any components which may have been overlooked, and check the workbench for 'spare' parts - there should be none left over.



40.22 Assembling the engine front pipes ...



40.23a ... and the engine rear plates, do not tighten yet



40.23b Note space between front left hand plate and engine



40.24a Refit one front lower mounting bolt ...



40.24b ... and rear lower mounting bolt



41.2a Reconnect the clutch cable before setting clutch cover



41.2b Attach alternator motor head before installing motor



41.2c Alternator cover and rotor assembly can now be utilized



41.2d Do not forget to fit the engine mark head



41.4 Both the piston head cover must be fitted to the cylinder



41.4 All eleven markings is retained by bolt at each side



41.2a New wheel nut (left) can be held in place with grease



41.2b If necessary, hood hinge repairs by bolting with tape



41.2c Reconnect the pressure gauge drive cable



41.2d Top up engine oil to end point of level window

42 Starting and running the rebuilt engine unit

1. Make sure that all the components are assembled correctly. The electrical connections can only be fitted one way, so the wires are coloured differently. Make sure all the control cables are adjusted correctly. Check that the fan is in the fan holder, try all the light switches and turn on the ignition switch. Done the checks listed below.

2. Switch on the ignition and start the engine by turning it over a few times until the battery or the electric starter, bearing in mind that the fuel has to reach through the four carburettors. Once the engine starts, run at a fairly high idling speed to enable the oil to work up to the camshaft and valves.

3. Before taking the machine on the road, check that the brakes are correctly adjusted, with the required level of hydraulic fluid in the hydraulic master cylinder.

4. Make sure the rear chain is correctly tensioned to $\frac{1}{2}$ inch up and down play. Also that the front forks are fitted with the correct oil seal/rod.

5. Check the colour of the engine for signs of oil leaks or blowing gaskets. Before taking the machine on the road for the first time, check that all nuts and bolts are tight and nothing has been omitted during the re-assembly sequence.

43 Taking the rebuilt machine on the road

1. Any rebuilt engine will take time to settle down, even if the parts have been replaced in their original order. For this reason it is highly advisable to treat the machine gently for the first few miles, so that the oil circulates properly and any new parts have a reasonable chance to bed down.

2. Even greater care is needed if the engine has been rebuilt or if a new carburettor and main bearings have been fitted. In the case of a rebuild the engine will have to be run in again as if the machine were new. This means much more use of the gearbox and a remaining load on the throttle until at least 500 miles have been covered. There is one much-point in keeping at a set speed (low) the main carburettor aims to so keep a light load on the engine until the gradually work up the performance until the 1500 mile mark is reached. As a general guide, it is inadvisable to exceed 4,000 rpm during the first 500 miles and 5,000 rpm for the next 500 miles. These periods are the same as for a rebuilt engine or one fitted with a new carburettor, experienced in the best guide since it is easy to tell when the engine is running freely.

3. If at any time the oil feed shows signs of failure, stop the engine immediately and investigate the cause. If the engine is run without oil, even for a short period, irreparable engine damage is inevitable.

44 Fault diagnosis engine

Symptom	Cause	Remedy
Engine will not start	Defective sparking plugs	Remove the plugs and lay them on the cylinder head. Check whether spark occurs when engine is cranked/engine rotates. Check the condition of the points and whether the points-gaps is correct. Check whether the plugs are when separated. Remove the condenser if there is evidence of arcing.
	Dirty or closed contact breaker points	
	Faults in disconnected condenser	
Engine runs unevenly	Ignition or fuel system fault	Check each system independently, as though engine will not start.
	Blowing cylinder head gasket	Leak should be evident from oil leakage where gas escapes. Check accuracy and clean if necessary.
	Incorrect ignition timing	
Lack of power	Fault in fuel system or incorrect ignition timing	Check fuel lines or fuel chamber for restriction. Reset ignition timing.
Heavy oil consumption	Cylinder-blank in need of valve	Check valve stem, valves and fit overlap pistons if required.

45 Fault diagnosis clutch

Symptom	Cause	Remedy
Engine speed increases as clutch is disengaged but machine does not respond	Clutch slip	Check clutch adjustment for free play, oil transfer lines, check thickness of insured plates.
Difficult to engage gears, gear changes only and machine proceeds forward when clutch is withdrawn (difficulty in selecting neutral)	Clutch drag	Check clutch for too much freeplay. Check plates for burrs on tangs or burrs on insulations. Dress with file if damage not too great.
Clutch operation stiff	Damage, trapped or frayed control cable	Check cable and repair if necessary. Make sure cable is lubricated and has no sharp bends.

46 Fault diagnosis gearbox

Symptom	Cause	Remedy
Difficulty in engaging gears	Slipster forks bent Gear clusters not assembled correctly	Replace with new forks. Check gear cluster for arrangement and position of thrust washers.
Machine jumps-out of gear	Worn dogs on the ends of gear pinions	Renew worn pinions.
Gear change lever does not return to original position	Broken return spring	Renew spring.
Clutchplate does not return when engine is switched-on or started	Broken or wrongly tensioned return spring	Renew spring or extension.
Clutchplate slips	Pusher assembly worn	Disassemble engine and check all worn parts.

Chapter 2 Fuel system and lubrication

Contents

General description	1	Engine and gearbox lubrication	10
Fuel tank removal and replacement	2	Lubrication system: checking the oil pressure	11
Fuel pump and filter: removal, dismantling and replacement	3	Oil pump: removal, examination and reassembly	12
Carburetors: description and removal	4	Oil pressure relief valve: dismantling, examination and reassembly	13
Carburetors: dismantling and reassembly	5	Oil filter: unscrewing the element	14
Carburetors: adjustment	6	Oil pressure warning switch	15
Carburetors: synchronization	7	Fault diagnosis	16
Carburetors: settings	8		
Air cleaner: location, removal and maintenance	9		

Specifications

Fuel tank capacity

Total	18.8 litres (4.27 imperial/19.4 US gal)
Reserve	3.4 litres (0.8 imp gal/3.8 US gal)

Carburetors

Make	VMJ400
Type	VMJ400
Main jet	100
Pilot jet	18
Needle jet	0.6
Air needle	7-0.6 (1-4)
Throttle valve cutback	1.5
First valve setting	$\frac{1}{8}$ in (3 turns out from stop)
Float level	38 ± 1 mm nominal

*Main jet (S) indicates needle number, (B) is the manufacturer's jet number, and (4) is the needle position, i.e. 4 grooves from top

Oil capacity

Dry	3.4 litres (0.8 imp gal/3.7 US quart)
Oil change	3.8 litres (0.9 imp gal/3.2 US quart)

Oil pump

Type	two-roller (external)
Inner roller to outer roller clearance	0.05 - 0.05 mm (0.002 - 0.002 in) nominal 0.08 mm (0.012 in) max limit
Outer roller to pump-body clearance	0.15 - 0.21 mm (0.006 - 0.008 in) nominal 0.30 mm (0.012 in) max limit
Roller to end plate clearance	0.02 - 0.07 mm (0.0008 - 0.0028 in) nominal 0.12 mm (0.005 in) max limit
Oil pressure at 4,000 rpm/90°C (118°F)	2.0 - 2.6 kg/cm ² (29 - 36 psi)

1 General description

The fuel system is comprised of a steel petrol tank, from which fuel is fed to gauges in the four M168 V6T4500 carburetors. The tap has three positions, giving a normal supply of petrol, an emergency reserve position and an off position. A gauge cluster is incorporated in the tap, to tap any leakage meter which might otherwise block the venturi jets. The petrol tank filler cap is of the quick-action type, incorporating a lock operated by the ignition key.

The four carburetors are interconnected by a linkage to ensure synchronization. The two throttle cables are connected to a pulley mounted between the two control levers, the throttle linkage operating and closing positively. The engine draws air in via a moulded plastic housing which contains the air cleaner element.

The engine oil is contained in a sump formed at the bottom of the crankcase.

The gearbox is also lubricated from the same source, the shaft engine unit being pressure fed by a mechanical oil pump that is driven off the crankshaft. The oil pump intake extends into the sump to pump the oil up to the angles. A screen at the pump inlet (and pumps) traps any matter from entering the pump before it can damage the mechanism, from the pump the oil passes to the oil filter to be cleaned. If the filter becomes clogged, a safety-by-pass valve routes the oil around the filter. It is then routed through a passage in which an oil pressure switch is mounted and through an oil hole in the crankcase, from which point it is sent in three different directions (the decision is to the crankshaft's main bearings and connecting pins. After lubricating the connecting pins, the oil is drawn out by overhead lines and the spray bars on the cylinder walls, the plates and gudgeon pins, to lubricate these parts. The oil eventually drops down from all these points and accumulates in the bottom of the crankcase sump to be recirculated.

The second passage for oil from the pump, is through the oil passage at each end of the cylinder head and up into the cylinder head. After passing through holes into the connecting bearings, the oil flows up over the rings and down around the outer layers to lubricate these areas. The oil returns to the sump via the oil holes at the base of the tappets, and the cam chain tension in the points of the cylinder head and cylinder block.

The third passage for the oil is from the gearbox bearings where it is pumped to the gearbox main-bearing on the mainshaft and also to the bearing on the layshaft. After this the

oil drops down back into the oil sump, to be recirculated through the engine.

2 Petrol tank, removal and replacement

1 The petrol tank fixed to the M168 4-cylinder models is secured to the frame by means of a short channel that projects from the rear of the tank and engages with a rubber buffer surrounding a pin welded to the frame immediately behind the steering head. This arrangement is duplicated either side of the rear of the tank and the frame. The rear of the tank is secured by a rubber strip that houses a nut & fly washed on to the back of the tank. The tank also has two rubber buffers on which it rests on the rear. A petrol tap is fixed with a reserve pipe that is isolated used, when the fuel level falls below that of the main feed pipe.

2 The petrol tank can be removed from the machine without detaching the petrol, although the rubber fuel lines to the carburetors will have to be disconnected. The detached fuel line should be kept up to release the rubber tip at the base of the tank, then the tank raised at the rear and pulled upwards and backwards to cut-off the front rubber. When releasing the fuel tank, lift at the rear and push down onto the front rubber buffers, then secure the rubber strap to the rear and reassemble the fuel lines.

3 Petrol tap and filter - removal, dismantling and replacement

- 1 It is not necessary to drain the petrol tank if it is only half or under half full, as the tank can be laid on its side on a clean cloth or soft material to prevent the spillage, so that the petrol tap is uppermost. The petrol pipe should be removed before unscrewing the petrol tap. To remove the tap and filter first undo the two mounting bolts fixed to the tank, the tap body can then be detached completely with the filter. When the filter bowl is removed this will reveal the rubber O-ring gasket and the gudgeon. Remove the gasket and clean its grooves before reassembling the tap, fit a new gasket between the body and the tap and a new rubber O-ring to the filter bowl if the old one is noticeably compressed. Do so against overhead the bowl, as it is made of soft metal and the threads will easily strip.
- 2 There is no necessity to remove either the tap or the petrol tank if only the filter bowl has to be detached for cleaning.



2.1a Tap is retained to petrol tank by two bolts



2.1b Bowl can be unscrewed and detached ...



2.13 ... to expose gauge film lens



2.14 Single screw in top body ...



2.15 ... adjust the top lever assembly



2.16 Examine and remove top components as necessary

4 Carburettor description and removal

1 The method of mounting the four carburettors is on a bearing plate with eight counterbore screws, the whole built of the carburettors being connected to the intake side of the engine (in other induction types). The four plunger type throttle valves are operated by a single shaft. Similarly the manually operated choke also has a single shaft operating four levers, one to each carburettor.

2 The throttle are operated by two cables from the throttle, one to open the throttle and the other to close them. A heavy return spring is incorporated in one throttle return system. When closing the throttle the use of a separate return cable helps to close the throttle more positively. This ensures smooth throttle action.

3 A vacuum gauge fitting is incorporated in each inlet manifold as an aid to balancing manifold pressure, and when used in conjunction with a vacuum gauge area, allows the carburettors to be accurately synchronised.

4 Starting in extreme cold weather is aided by a separate starter system which acts by vacuum pressure and serves in place of a choke. The starter system takes the form of four

slender valves through the starter pipe to the starter plunger chamber, where fuel is atomised. The rich mixture is then sprayed into the combustion zone where a small fuel jet opens from the pilot system is mixed with it. The final mixture is then delivered to the engine.

It is essential that the starter plunger be fully raised by the choke lever and the starter jet, open, and the air bleed hole completely free of any blockage. The throttle must be fully closed so that sufficient vacuum is developed for efficient atomisation to take place.

5 The pilot system is made up of the pilot jet, the pilot air screw, and the pilot needle. In control operation from the idle position to approximately one eighth throttle opening. The pilot mixture strength is determined by the amount of fuel passed through the pilot jet, and also by the amount of air which is allowed to pass the pilot air screw. If the screw is turned in, this restricts the mixture, and when the screw is turned out this weakens the mixture. The correct position for the air screw is normally one and a quarter turns out from the fully closed position.

7 The main carburetor system comprises the main jet, the bleed pipe, the jet needle, the throttle valve, and the air jet. The main system ceases fuel operation after the throttle is opened

beyond one eighth of a turn. It is only after this that sufficient vacuum is created as the jet needle to draw fuel up through the main jet. The fuel flows up through the main jet and bleed pipe, then between the needle jet and jet needle, and into the main bore when it is fully raised. The fuel in fact is partially atomized before it reaches the bore, because the air bleed hole in the bleed pipe admits air to the fuel as it passes through the pipe.

8 When the throttle is opened, the slide rises up the bore of the carburettor. The jet needle is connected to this slide and because the needle is tapered, the more it is raised the more the fuel is drawn to flow. This is how engine speed increases. The substance on the slide regulates the air flow and the vacuum produced into the carburettor bore. Finally, when the throttle slide is raised to its limit, the flow of fuel is limited by the size of the main jet rather than the spray between the jet needle and needle jet. The mixture is then spraying on the main jet.

9 The float system is made up of the float, the float needle valve, and the valve seat. The float is maintained by the float assembly at a constant level in the fuel bowl, to meet the engine's needs. As fuel flows into the bowl the float rises which in turn raises the float valve. When the float reaches a predetermined height, the valve closes onto its seat and this stops off the flow of fuel to the carburettor. Consequently as the engine

runs the fuel, the level in the fuel bowl drops, causing the valve to leave its seat and admit more fuel to flow into the float chamber. Equilibrium is the most important thing when working on the carburettor. To insure the carburettors below the four intake manifolds by undoing the crosshead screws in the clamp and remove the air cleaner boxes at the rear. Then pull off the whole bank of four carburettors.

10 To separate the carburettors, loosen the throttle cable mounting nuts, and disconnect the cables from the pulley. Remove the throttle stop screw locknut from both the 120-horsepower to be detached and its companion, then detach the lock piece. Remove the throttle stop screw and the screw spring, together with the spring seat. Remove the idler nut from the carburettor linkage of the carburettor that is to be detached, and then remove the spring and seat. Make the careful not to lose the spring that will rise up when the jet gun is disconnected.

11 Loosen the four mounting bolts from the mounting plate and remove the first pair of carburettors. It is easier to remove the carburettors in pairs as they are joined by a link. After all the carburettors have been removed from the mounting plate they are ready for dismantling.

12 Alternatively, the carburettors may be removed as an assembly as described in Chapter 1, Section 5, and then detached from their mounting plate.



4.1(a) Carburettor assembly carburettors as a unit



4.1(b) Remove carburettor top and gasket



4.1(c) Separate needle assembly. Remove clamp bolt



4.1(d) Float instrument is retained by two screws



4.12a Being carburetor away from engine to discharge fuel.




4.12b Carburetor can be disconnected coupling shaft.

4 Carburetors: dismantling and reassembly

1. The throttle lever and puller, and the throttle return spring (and not be removed from the mounting plate, when dismantling the carburetor). The fuel may be drained from the fuel bowl by detaching the drain plug and washer. Remove the top cover screws, then remove the cover and gasket, bend the jet holder washer and unhook the bolt from the operating arm. The operating arm can now be removed, undo the two screws that secure the bracket assembly to the throttle shaft, and lift the bracket complete with the operating arm and carburetor assembly out of the carburetor housing.

2. Remove the throttle valve and the needle from the bore taking care not to bend the needle. Remove the plunger assembly after first removing the lower cap, and guide down. Undo the float bowl screws, remove the bowl and the gasket, then take out the float pin and remove the float and the float needle valve. Remove the main jet, the air bleed pipe, insert the carburetor and gently press out the needle jet with a wooden dowel. Remove the float valve seat, the pilot jet and the pilot air screw with spring.



4.2a Lift out needle and throttle valve assembly.

3. Clean all the components in clean petrol and then blow them dry with compressed air, taking care to clean all passages. Inspect all the jets and the needle valve and seat, and remove them if they are worn, especially if there is a bright ridge round the needle valve and seat. It is best to renew these as a pair.


4. Inspect the float for leakage. Check whether petrol has entered the float by shaking it. If the float assembly is purchased it must be renewed.

5. Remove the main jet with a wide blade screwdriver, also inspect the needle jet for wear. After lengthy service the needle jet should be renewed along with the needle as these components are in continuous use. If not renewed, petrol consumption will increase.

6. The carburetor slide should be able to slide down the carburetor bore by its own weight. If it will not do this, even when lightly oiled, it will malfunction severely.

7. Assembly of the carburetor is the reverse order of dismantling. Use new gaskets and O-rings. Do not over-tighten the screws when re-attaching the carburetor body.


8. Make certain that the carburetor jet needle is reinserted back in the same position as when it was removed. The needle clip should be in the fourth groove from the top.



4.2b Reinsert needle assembly for wear or damage.



5.2a Valve is retained by two screws in linkage




5.2b Linkage may be released when adjuster is loosened




5.2c Needle cap can be shaken out of valve for examination



5.2d Release combustion fuel lines and air filter




5.2g Fuel pin should be depressed to release fuel assembly




5.2h Needle will drop clear of the valve seat



8.21 Push piston assembly into combustion hole



8.22 Advance slightly



8.23 ... and inserted into



8.24 Piston pin should be removed from adjustment hole



8.25 Piston must cross assembly of combustion



8.26 Check needle clip position. Remove if loose or bent




Fig. 2.1 Carburetor component parts

1	Spring washer	17	Float	35	Screw	55	Clutch stop
2	Clutch ball	18	Spring washer	36	Pin and	56	Screw
3	Spring washer	19	Screw	37	Clutch connecting lever	57	Spring
4	Plastic valve	20	O ring	38	Plastic washer	58	Coupling shaft
5	Plug	21	Drift plug	39	Spring	59	Stop ball
6	O ring	22	Lock nut	40	Carburetor body	60	Spring washer
7	Washers	23	Plain washer	41	Start jet	61	Washer
8	O ring	24	Adjusting screw	42	Sealing ring	62	Spring
9	Air filter tube	25	Screw	43	Float needle seat	63	Diaphragm washer
10	Washer	26	Spring	44	Float needle	64	Spring
11	Washer	27	Washer jet	45	Float pin	65	Flexible pipe screw
12	Washer	28	Spring	46	Float down/gasket	66	Shouldered screw
13	Washer	29	O ring	47	Float bowl	67	Plain washer
14	Washer	30	Limiter	48	Choke	68	Diaphragm screw
15	Washer	31	Plain screw	49	Ball	69	Ball
16	Washer	32	Screw	50	Dust ring	70	O ring
		33	Spring washer	51	Plunger bush	71	O ring
		34	Carburetor jet	52	O ring	72	Float pin
		35	Washer	53	Spring	73	Washer
		36	O-ring	54	Plunger	74	Screw
		37	Washer jet	55	Spring washer	75	Spring washer
		38	O ring	56	Lowering plate	76	Flexible return spring
		39	Needle clip	57	Screw	77	Carburetor mounting bracket
		40	Needle	58	Screw		



2.20 Coupling pipe secured with clamp



2.21 Throttling device ready requires attention

2 Carburettors adjustment

- To check the float height adjustment with the carburettors in situ, first turn the fuel tap to 'OFF'. Then, remove the carburettor vent tube. Be prepared to catch the fuel that will run out. Remove the float bowl drain plug, install the Kawasaki fuel measuring device (part number 1500N-1284) in place of the drain plug and hold the plastic tube against the carburettor float. Turn the fuel tap to the 'ON' position. The petrol level in the tube should be 11.5 - 4.3 mm (0.70 - 0.18 inch) below the edge of the carburettor body. If the petrol level is incorrect the float must be adjusted in the following manner. Drain the fuel from the float chamber and remove the chamber bowl. Be prepared to catch the fuel and float plug pin, also the float needle. Bend the tang on the float slightly to adjust the float height. Bending the tang up will lower the float level. Note: When checking the fuel level of the two intake carburettors, the outside carburettor base may be used as a reference point for the measuring gauge.
 - Adjust the throttle cables by starting with the opening cable first, loosen the rodlock at the throttle opening cable, and use the adjuster to take up any slack in the cable before entering the throttle again. Loosen the locknut on the closing cable, and adjust it so there is about 3 mm (1/8 inch) of play in the throttle grip when you close the throttle.
 - Perform the following tests as a prelude to the actual adjustment of the carburettors at any time they are rebuilt or replaced, and especially if the engine dies roughly.
 - Remove the carburettors from the machine. If this has not already been done, slacken and remove the three screws which retain the top cover on each carburettor, and lift the cover away. It will be noted that each of the opening needles has an adjuster and collar to enable the four throttle valves to be synchronized. Obtain a piece of wire approximately 0.8 - 1.0 mm (0.03 - 0.04 inch) in diameter. Use the metric scales of one carburettor and insert the end of the wire, wedging it between the throat of the carburettor and the valve edge. Slacken the locknut of the opening needle of the carburettor concerned, then arrange the instrument so that the needle, and consequently the wire, points downwards.
 - Gradually screw in the adjuster until the wire just stops free. Note that this setting must be made with the greatest care. When set correctly, hold the adjuster in position and secure the locknut. Repeat this procedure on the remaining three instruments after which the throttle linkage of all four carburettors can be mechanically synchronized. The top mounted throttle stop screw can now be set so that the bottom edge of the throttle cables are just visible in the throat of the carburettors.

- Before setting the carburettors, set the pilot screws to their approximate nominal setting. Where fitted, the intake plastic liners should be pulled off. Screw in each adjuster until it seats tightly, then unscrew it by 1 turn. Refit the liners with the stop followers between to nominal amount of travel. Refit the carburettors, and set up the throttle cables as described in paragraph 2 of this Section.
 - Run the engine and keep it running until normal working temperature is reached, then set the throttle stop screws to achieve a maximum speed of 1800 - 1900 rpm. Check that this speed remains constant after closing the throttle valve of base. By varying the pilot screw of each carburettor in turn, this adjustment should not exceed the range of the limiter, or 1/4 turn in the most. Note the effect that this has on throttle speed, and leave it in whatever setting produces the highest speed. Repeat the throttle speed at 900 - 1200 rpm, then repeat the adjustment on the remaining instruments.

7 Carburettor synchronization

- In order that the carburettors be precisely synchronized it is necessary to balance them using a set of vacuum gauges connected to the fuel manifolds. To perform this operation, it will be necessary to use a set of vacuum gauges having variable resistance, or damping, valves, such as the Kawasaki 15001-123 assembly. It will also be necessary to remove the fuel tank and to arrange a temporary remote fuel tank. For this reason it may be considered worthwhile entrusting the operation to an authorized Kawasaki Service Agent. If however, it is desired that the work be done at home, obtain the vacuum gauges, remove the petrol tank, and arrange a remote supply (i.e. connect the fuel tank, placed on a nearby bench, to the carburettors, using a length of tubing).
 - Remove the engine rubber hose from the fuel manifolds, and attach the vacuum gauge hoses. The vacuum gauges can now be attached, one hose to each of the four pipes, so that the vacuum on all four cylinders can all be read on the corresponding gauges. With the engine running at idle speed, close down the vacuum gauge intake valve until the gauge needle fluctuates less than 2 mm (3/16 inch) in 10 s.
 - The normal manifold vacuum gauge reading is 18-24 cm Hg (7.5-9.5 mm Hg) for each cylinder. If any gauge reads less than 2 cm Hg (5/8 inch Hg) repeat the pilot air screw adjustment, and make sure that the carburettor hose clamps and sparking plug are secure.
 - Balance the carburettors by adjusting the throttle valve adjusting screws at 900-1200 rpm (See Chapter, Section 6. All the



2.6 Spines on mixture screws feed air to jets in carburettor



2.7 Carburettor covers (floats) slip on all carburettors

carburettors should be adjusted to within 2 mm Hg (2.8 in. Hg) of each other.

5 Open the throttle fairly rapidly and allow it to snap shut several times, while watching to see if the vacuum gauge reading remains the same. Repeat any carburettors whose reading have changed.

6 The vacuum gauges can now be removed. Repeat the mixture routine (steps 1 to 4) on the adjuster. Repeat any carburettor by the pilot screw and adjust the idle speed to about 850 – 1200 rpm.

9 Carburettor settings

1 Some of the carburettor settings, such as the sizes of the needle jets, main jets, and needle positions are pre-determined by the manufacturer. Under normal riding conditions it is unlikely that these settings will require modification. If a change appears necessary, it is often because of an engine fault, or an alteration to the exhaust system (eg a retro-fitted pipe conversion system).

2 As an approximate guide to the carburettor settings, the pilot jet controls the engine speed up to $\frac{1}{2}$ throttle. The main jet (or jets) controls the engine speed from $\frac{1}{2}$ to $\frac{3}{4}$ throttle and the position of the needle in the side from $\frac{1}{2}$ to $\frac{3}{4}$ throttle. The size of the main jet is responsible for engine speed at the full phase of $\frac{3}{4}$ to full throttle. These are only guide lines; there is no clearly defined demarcation line due to a certain amount of overlap between.

3 Watch the engine closely towards a rich mixture so that a too weak fuel will cause the engine to cough and burn the exhaust valves. Reference to Chapter 3 will show how the condition of the sparking plug can be interpreted with some experience as a reliable guide to carburettor mixture settings.

9 Air cleaner location, removal and maintenance

1 A removable air cleaner element is mounted inside the air cleaner housing to prevent the ingress of abrasive dust. The element may be removed for inspection and cleaning.

2 To gain access to the element, lift the (dashed) to expose the top of the air cleaner chamber. Unscrew the paper gaskets and lift this away. The element can now be pulled out for examination.

3 Clean the element with petrol or a cleaning solvent and then blow it dry with compressed air from inside. Do not use any cleaner that will not completely evaporate.

4 Inspect the element and also the sponge gaskets for signs of wear or damage, and replace the element if either are damaged. The sponge gaskets can be great help on if they are loose and in good condition. Be careful, when handling the element, not to clog the pores.

5 The sponge should be spun on one of these elements in approximately 3000 miles or 12 months, whichever the sooner. Furthermore, it is best to clean around three or four times due to wear in very dusty conditions (should be replaced).

6 Lower on the machine below the air cleaner panel, adjusting the permanently weak mixture that would otherwise cause severe engine damage.

10 Engine and gearbox lubrication

1 As previously described at the beginning of the Chapter the lubrication system is of the wet sump type, with the oil being forced from the pump to portions of the gearbox bearings, the main engine bearings, and the cam box bearings, all oil eventually draining back to the sump. The system incorporates a gear driven oil pump, an oil filter, a safety bypass valve, and an oil pressure switch. Oil vapours created in the crankcase are vented through a breather to the air cleaner box, where they are recirculated in the crankcase, providing an oil-tight system.

2 The oil pump is of the involute type, being gear driven off the crankshaft. An oil seal is fitted to the intake side of the pump, which serves to prevent the pump mechanism from impurities in the oil which might cause damage.

3 An oil filter unit is housed in the bottom of the pump, in an oil filter canister containing a paper element. As the oil filter unit becomes clogged with impurities, its ability to function correctly is reduced, and it becomes an integral part of the system. The oil flow, a bypass valve opens and routes the oil flow around the filter. This results in unfiltered oil being pumped throughout the engine, a condition which is avoided if the filter element is changed at regular intervals.

4 The oil pressure switch which is situated inside the contact breaker housing serves to indicate when the oil pressure has dropped (due to an oil pump malfunction, leakage in an oil passage, or a loss of contact). The switch is not intended to be used as an indication of the correct oil level.

5 As previously mentioned an oil breather is incorporated into the system. It is mounted in the top of the crankcase and is essential for an engine of this size with so many moving parts. It serves to minimize crankcase pressure variations due to piston and crankshaft movement, and also helps lower the oil

temperature, by venting the crankcase. The breather tube carries the crankcase vapours to the air cleaner housing where they become mixed with the air drawn into the carburettor. If the breather hose or the ports inside the breather become blocked, pressure may build-up to such a level in the crankcase that oil leaks will occur. If the oil level is too high in the sump, this may result in oil entering cavities enough to cause the air cleaner to become oil saturated. This will lead to poor combustion, fouling/spalling the cones.

3 Excessive oil consumption as indicated by a blue smoke emitting from the exhaust pipe, coupled with a poor performance and fouling of the spark plugs, is caused by either an excessive oil build-up in the oil breather chamber or by oil getting past the piston rings. First check the oil breather chamber and air cleaner for oil build-up. If this is the fault, check the gaskets from the oil filter separator in the oil breather chamber in the lower half of the crankcase. A leakage here will prevent oil flowing back into the crankcase, resulting in oil build-up in the breather chamber and air cleaner tube.

4 Be sure to check the oil level in the pump before starting the engine. If the oil level is not each between the two marks adjacent to the sight window at the bottom of the stub case, remedy with the correct amount of oil of the recommended viscosity.




10.7 Top of between upper (A) and lower (B) stubs

11 Lubrication system: checking the oil pressure

1 The efficiency of the lubrication system is dependent on the oil pump delivering oil at the correct pressure. This can be checked by fitting an oil pressure gauge to the right-hand end of pressure plug, which is located immediately below the contact breaker housing. Note that the correct threaded adaptor must be obtained or fabricated for this purpose. The bare course of action is to drain the correct recommended pressure gauge and adaptor, part numbers 5-4061-104 and 5-1901-483 respectively.

2 Remove the oil plug and fit the adaptor and gauge into position. The correct pressure at 4000 rpm, 90°C (184°F) should be 2.0–2.5 kg/cm² (28–35 psi). If the oil pressure is significantly below this figure, and no obvious oil leakage is apparent, the oil pump should be removed for examination. Do not attempt to drive the machine by used with low oil pressure, as plain bearing engines in particular rely on oil pressure as much as vacuum for effective lubrication.

3 It is likely that the oil pressure will be slightly above the specified pressure, but if it proves to be extremely high, it is likely to be due to the oil pressure relief valve being jammed or damaged. The valve component is fitted to the inside of the pump. Refer to Section 12 of this chapter.



10.3 Filtered air is washed in outside cover (see text)

12 Oil pump: removal, examination and reassembly

1 It is possible to remove the oil pump for examination after the stub case, stub assembly, and pump have been removed, having of course drained the pump beforehand. Refer to the relevant Sections of Chapter 1 for details. Examination of the pressure relief valve and inward of the oil filter element should be undertaken before reassembling these components. The oil pump can be removed from the underside of the crankcase after releasing the mounting bolts.

2 The oil pump end cover is retained by three screws. These should be removed, and the shaft on the end of the oil pump spindle detached, to permit the cover to be lifted away. The inner and outer rotors can be shaken-out of the pump-body, the drive pin displaced, and the pump spindle withdrawn.

3 Wash all the pump components with petrol and allow them to dry before carrying out an examination. Before partially reassembling the pump for various measurements to be carried out, check the timing/for leakage or friction, wrapping an old inside gasket.

4 Reassemble the pump rotors and measure the clearance between the outer rotor and the pump body, using a feeler gauge. If the measurement exceeds the service limit of 0.30 mm (0.012 in) the rotor or the body must be removed, whichever is worn. Measure the clearance between the outer rotor and the inner rotor, using a feeler gauge. If the clearance exceeds 0.30 mm (0.012 in) the rotor must be removed as it is. It should be noted that one face of both the inner and the outer rotor is a push marked. The push marks should face away from the main pump casing during measurements and on re-assembly. With the pump rotors located in the pump body lay a straight edge across the mating surfaces of the pump body. Again with a feeler gauge measure the clearance between the outer rotor and the straight edge. If the clearance exceeds 0.125 mm (0.005 in) the rotor should be replaced as a set.

5 Examine the rotors and the pump-body for signs of scoring, chipping or other surface damage which will cause it metallic particles find their way into the oil pump assembly. Removal of the affected parts is the only remedy under these circumstances, bearing in mind that the rotors must always be replaced as a matched pair.

6 Reassemble the pump components by reversing the disassembling procedure. The component parts must be marked with a blue or white ink or damage to the pump will result. Replace the rotors and lubricate them thoroughly before refitting the cover.

7. Check that the pump turns smoothly, then lift it to the casting. Before lifting the pump, remove and examine the pressure relief valve (as described in Section 18). Be sure onto the large O-ring which must be fitted to the oil pump below the pump lifterhead.

12.04 Pressure relief valve: dismantling, examination and reassembly

1. If problems with the lubrication system have been experienced, it is advisable to check the operation of the pressure relief valve, which the pump is mounted. The valve can be withdrawn from the inside of the pump, using a spanner on the hexagonal body.

2. Remove the pivot internal circlip from the top of the valve body to release the internal parts. On some early models, a spring-loaded ball-type valve may used, whereas on later models, a small plunger replaces the ball. The location and method of checking, however, remains the same for both types.

3. Examine the plunger (or ball) for signs of wear or scoring, removing it, if necessary. The face of the valve body should also be free from scoring; if the valve appears badly worn, the complete assembly should be renewed, unless the spring if it has a free length of less than 18.1 mm (0.71 in).



12.24 Remove circlip and examine the plunger and plate



12.1 Oil pump can be removed with engine in position



12.25 Strain out the water and moss screens for examination



12.26 Measure the clearance between rotor and pump body



12.28 Dipose the driving pin to allow ...



12.2a ... the driving gear and shaft to be withdrawn



12.2b Note the bearing pin and corresponding nut



12.2b Use new gasket, note locating clevis



12.2c Filter screen can be removed to permit cleaning



12.3 Pressure relief valve is removed from pump

14 Oil filter, removing the element

- 1 The oil filter is contained within a semi-enclosed chamber within the manifold. Access to the element is made by unscrewing the filter cover centre bolt which will bring with it the cover and pad (the element). Before removing the cover place a makeshift barrier to the engine to catch the engine oil contained in the filter element.
- 2 When removing the filter element it is vital to rotate the filter cover 270° ring at the same time. This will obviate the possibility of any oil leaks. Do not over-tighten the centre bolt on replacement.
- 3 The filter by-pass valve, comprising a plunger and spring, is situated in the base of the filter cover centre bolt. It is recommended that the by-pass valve be checked for free movement during every filter change. The spring and plunger are retained by a pin across the centre bolt. Knocking the pin out will allow the spring/plunger to be removed for cleaning.
- 4 Run over the engine without the filter element in place for the period between the recommended oil changes or oil filter changes.




Fig. 3.2 Oil pump and oil filter

- | | | | |
|----------------------------|-------------------------|--------------------|-----------------------------|
| 1 Oil pump assembly | 11 Screw - 2 off | 21 O-ring - 2 off | 31 Oil filter primer |
| 2 Oil pump gear | 12 Cover pin | 22 O-ring - 2 off | 32 Washer |
| 3 Roller pin - 2 off | 13 Cover pin - 2 off | 23 Oil pump gasket | 33 Oil filter spring |
| 4 Oil pump shaft | 14 Bush | 24 Oil pump cover | 34 Oil filter cover |
| 5 Oil pump roller cover | 15 Roller - 2 off | 25 Bush - 7/8 off | 35 Oil filter cover |
| 6 Oil pump roller assembly | 16 Roller vial assembly | 26 Oil pump plug | 36 Oil filter bolt assembly |
| 7 Oil pump gasket | 17 Roller | 27 Washer | 37 Valve spring |
| 8 Oil pump cover | 18 Roller | 28 O-ring | 38 Spring roller |
| 9 Washer | 19 Spring | 29 Plug | 39 O-ring |
| 10 Cover | 20 Roller | 30 O-Ring | 40 Spring pin |



14.1 Oil filter is removed by screw tool.



15 Oil pressure warning switch

1. An oil pressure warning switch is incorporated in the lubrication system to give warning of impending disaster in the event of oil pressure failure. The switch is located inside the contact breaker housing and normally gives very little warning in the event that the oil warning light does not come on when the ignition is first switched on. It is imperative that the fault is located and rectified before the machine is ridden.

2. Remove the contact breaker cover, and disconnect the pressure switch lead. With the ignition switched on, earth the lead from the warning lamp against the metalcase. If the warning lamp comes on, the switch should be replaced. If, however, the warning lamp still does not work, attention should be turned to the bulb/switching.

3. The switch may be unscrewed from the casing after the contact breaker base plate has been removed, noting that it will be necessary to re-time the ignition after reassembly. Note that the terminal which screws onto the top of the switch should be positioned away from the contact breaker to avoid any possibility of it arcing across. This problem actually occurred when the machine used for the photographs in this manual was being maintained.

If the light comes on suddenly whilst riding, stop the machine immediately, and investigate the cause, noting the above comments. Oil is poured into the machine with the warning lamp on.

15.1 Oil pressure switch is mounted inside contact breaker housing.

16 Fault diagnosis: fuel system and lubrication

Symptom	Cause	Remedy
Engine gradually loses and stops	Fuel starvation	Check vent hole in filter cap. Sediment in filter bowl or fuel stumbles. Obstructions and leaks.
Engine runs badly. Black smoke from exhausts.	Carburettor flooding	Diagnose and check carburettor. Check for punctured float or sticking float needle.
Engine lacks response and overheats	Weak mixture Air cleaner disconnected or hole split Modified choke—too open carburettor.	Check for partial block in carburettor Reconnect or remove foam. Replace with original design.
Oil pressure warning light comes on	Lubrication system failure Short circuit in warning lamp system	Stop engine immediately. Trace and rectify fault before re-starting. Check and rectify source of short lead test.
Engine suddenly gets noisy	Failure to change engine oil when recommended.	Drain off oil and refill with new oil of correct grade. Remove oil filter element.

Chapter 3 Ignition system

Contents

General description	1	Ignition timing (checking and setting)	7
Ignition coils (checking)	2	Automatic timing unit (examination)	18
Contact breaker adjustments	3	Spark plug (checking and resetting the gaps)	18
Contact breaker points (using dial indicator)	4	Ignition switch (maintenance)	50
Contact breaker points (removal and replacement)	5	Fault diagnosis (ignition system)	11
Condensers (removal and replacement)	6		

Specifications

Sparkling plugs (1)

Size	14 mm
Reach	19 mm (1.25)
Type (Normal and)	NGK BR8S or NGK W44ES Champion BR
Low speed use and testing (L)	NGK BR8S
High speed use and testing (H)	NGK BR8S
Advantages	Mitsubishi AS1 or AS061 (high speed)
Excludes and	0.7 - 0.8 mm (0.028 - 0.031 in)
Recommended by manufacturer	

Condenser

Capacity	0.24 ± 0.02 microfarad
----------	------------------------

Ignition coils (1)

Number	2
Type	CD000-14, CD003-01
Make	Trico/Genes
Primary winding resistance	0.8 ohms approx.
Secondary winding resistance	20.0k ohms approx.

Contact breaker

Gap	0.3 - 0.4 mm
Swirl angle (degress)	180° - 190°
Swirl angle (percentage)	81 - 84%
Ignition timing	18° BTDC ± 1.00 deg to 30° BTDC ± 0.00 deg
Range	Mechanical, by Automatic Timing Unit (ATU)
Advance method	

1 General description

The spark necessary to ignite the petrol vapour in the combustion chamber is supplied by a battery and two ignition coils (one coil serves cylinders).

There are two sets of contact breaker points, two camshafts, four sparking plugs and an automatic ignition advance mechanism, the breaker cam, which is incorporated in the advance mechanism, opens each set of points once in 180° of crankshaft rotation, giving a spark to occur in two of the

cylinders. The other set of points fires 180° later, so that in every 180° of crankshaft rotation each plug is fired once. One wire spark occurs during the time when there is no combustible material in the chamber.

Each set of points has one fixed and one movable contact, the latter of which protrudes the face of the cam opposite them. The two camshafts are driven in parallel, one with each set of contact points, and these function as electrical storage reservoirs, while also preventing arcing across the points. The camshafts serve to absorb surplus current that flows to contact through the system when there is an over-advance situation, and

feeds the current back to the ignition coils. They also help internally the spark. When the points are closed, the current flows straight through them to earth. When they open, there is now an open circuit. It isn't for the convenience, this current may arc across the points causing them to flume and pit. With the condenser back there quickly, they discharge the current back through the primary windings and eventually to the sparking plug. The time the points get badly burnt, it is advisable to renew them, and the condenser also.

Each of the two coils has one high voltage sparking plug leads, and as in the case of points, one coil serves cylinders 1 and 4, and the other cylinders 2 and 3.

The coils convert the low tension voltage into a high tension voltage sufficient to provide a spark strong enough to jump the sparking plug air gap. If at any time a very weak or erratic spark occurs at the plug, and the rest of the ignition system is known to be in good condition, it is time to renew an ignition coil. Although coils normally have a long life they can sometimes be faulty especially if the better case has been damaged.

The automatic advance mechanism serves to advance the ignition timing as the engine speed rises. The mechanism is made up of two spring loaded weights which, under the action of centrifugal force caused by the rotation of the crankshaft, fly apart and cause the contact points to open earlier. If the mechanism does not operate smoothly, the timing will not advance smoothly, or it may stick in one position. This will result in poor running in any but that one position. Sometimes the springs are prone to stretching, which can cause the timing to advance too soon. It is best to check the automatic advance mechanism, by turning out a static timing lead on the ignition followed by a dynamic lead. It is always best to check the motion of the weights by hand, using 2000 r/min and to clean and lubricate the unit at the same time.

The ignition system is operated by a key switch, mounted on a dash panel between the speedometer and the tachometer. There are three positions on the switch, OFF, ON, and PARK, in the OFF position all the circuits are turned off and the key can be removed from the switch. In the ON position the motorcycle can be started and all the lights and accessories can be used. The key cannot be removed from the switch when it is in this position.

In the PARK position, only the tail light stays on, and the key can be removed from the switch. The overriding of the battery that operates the ignition system is taken care of by an automatic that is mounted on the left hand side of the main shaft. This supplies current which is applied by a rectifier, mounted on a panel alongside the voltage regulator, on the right hand side of the machine, below the fuel tank.



2.1 Ignition coils are mounted on top beneath-panel tank

3 Ignition coils checking

- 1 The ignition coils are tested with designed to give long life, and are mounted on the frame tubes in the upper cradle behind the steering stem. The most accurate test of an ignition coil is with a three primary coil and condenser tester instrument.
- 2 Connect the coil to the tester when the unit is switched on, and open out the adjusting screw on the tester to 0.5 mm (0.024 inch). The spark at this point should bridge the gap continuously if the spark points to break down or to intermediate, the coil is faulty and should be renewed.
- 3 In the absence of a coil tester, the winding may be checked for broken or external shortings using a multimeter, noting that test will use rubber insulation breakdown which may give no picture under high voltage.
- 4 The primary winding resistance can be measured by connecting one of the wires across to the red/white lead, and the other to the green or black lead. Resistance should be in the region of 4 ohms. Secondary resistance involves the connection of one probe to each of the high tension leads. In this case the resistance should be approximately 28 k ohms. Always check for any conductivity between the coil leads and the red/white lead, if the insulation here is not perfect, or if the primary and secondary resistance readings are noticeably different from those specified, then the coil should be renewed.

3 Contact breaker adjustments

- 1 To gain access to the contact breaker it is necessary to remove the cover-plate screws and the cover on the right-hand side of the crankcase.
- 2 Rotate the engine by slowly turning it over with the kick-starter until one set of points is fully open. Examine the faces of the contacts for pitting and burning. If badly pitted or burnt they should be renewed as described in Section 4 of this Chapter.
- 3 Adjustment is carried out by adjusting the gap within the range 0.2 to 0.4 mm (0.008 - 0.016 inch) when the points are fully open by moving the base contact with a screwdriver at the dotted point. Retighten the top covers after adjustment with the feeler gauge and recheck the gap then repeat the same operation for the other set of points. Do not forget to double check after you have tightened the setting screws, in case the settings have moved.
- 4 Before reattaching the cover and plates, press a slight amount of grease on the cam and a few drops of oil on the felt seal. Do not use lubricate for fear of oil getting on the points, and causing poor electrical contact.



3.3 Use feeler gauge to check contact breaker gap




Fig. 8.5 Ignition system - component parts

- | | | |
|---------------------------------|---|--|
| 1 Ignition coil, outer cylinder | 12 Nut - 2 off | 23 Plain washer - 2 off |
| 2 Ignition coil, inner cylinder | 13 Regulator | 24 Lockring lock |
| 3 Nut - 4 off | 14 Bolt - 2 off | 25 Contact assembly |
| 4 Revolver | 15 Assembly timing unit (if fit) | 26 Contact breaker wiring |
| 5 Spring washer - 2 off | 16 Magnet | 27 Screw - 2 off |
| 6 Nut | 17 Special bolt | 28 Suppressor cap - 4 off |
| 7 Starter solenoid | 18 Contact breaker assembly | 29 Dust seal - 4 off (alternative part) |
| 8 End cap | 19 Contact breaker coil, inner cylinder | 30 Suppressor cap - 4 off (alternative part) |
| 9 Insulator/lead | 20 Contact breaker coil, outer cylinder | |
| 10 Rubber sleeve | 21 Screw - 4 off | 31 Dust seal - 4 off (alternative part) |
| 11 Rubber mounting block | 22 Spring washer - 2 off | |



Fig. 3.4 Distributor cap with distributor with one or two steps of adjustment




Fig. 3.5 Contact breaker assembly

- | | |
|---|-------------------------------------|
| 1 Contact breaker base plate spacer - 2 off | 10 Contact breaker terminal - 2 off |
| 2 Distributor - 2 off | 11 Distributor - 2 off |
| 3 Moving contact - 2 off | 12 Plate washer - 2 off |
| 4 Nut - 2 off | 13 Insulating washer - 2 off |
| 5 Spring washer - 2 off | 14 Condenser terminal - 2 off |
| 6 Plate washer - 2 off | 15 Condenser - 2 off |
| 7 Insulating washer - 2 off | 16 Contact breaker base plate |
| 8 Leaf spring - 2 off | |
| 9 Insulating washer - 2 off | |

4 Contact breaker adjustment - using dwell meter

1. The contact breaker gap may be set by using a dwell meter. These are available, usually in the form of a combined lead meter or ignition analyzer, from most main distributors. Before fitting the contact breaker to this method ensures that the contact breaker provides the performance which is normally

expected when the gap is set correctly, but which often does not occur in practice. Most dwell meters have a range of settings for engines of varying numbers of cylinders, and may be calibrated in degrees of crankshaft rotation or in percentage. The table below shows the various cylinder number settings, and the corresponding readings:

Setting	Reading
1 cylinder	180.0 - 185.0° (37.0 - 34.0%)
2 cylinder	90.0 - 93.0° (23.0 - 27.0%)
3 cylinder	60.0 - 66.0° (17.0 - 18.0%)
4 cylinder	45.0 - 49.0° (14.0 - 13.0%)

2. Set the dwell meter in the appropriate position, then connect the positive (+) probe to the contact breaker terminal, and the negative (-) probe to the condenser. With the engine running at less than 1000 rpm, check that the reading is within the limits given. If this is not the case, loosen the four contact breaker securing screws just enough to permit movement, then adjust the gap until the reading is within the specified tolerance. Tighten the securing screws, then check that the setting has not altered. The two screws should be tightened on the remaining set of contact breaker points.

5 Contact breaker points removal and replacement

1. If the contact points are badly burnt or worn, they should be removed. Undo the two screws that hold the base of the fixed contact of each set of points, and remove the wire leading to the condenser, which will allow the points to be lifted off. Removal of the circlip on the end of the plate pin will permit the moving contact point to be detached. Note the arrangement of the insulating washers.
2. The points should be dressed with an oil stone or fine emery cloth to remove deposits due to arcing. Keep them absolutely square throughout the dressing operation, otherwise this will make regular contact on replacement, and rapidly burn away, if silicon carbide is used. It should be checked by a flat strip of steel, if it is necessary to remove a substantial amount of material before the base can be refitted, the points should be replaced.
3. Restore the contacts by carrying the dismantling procedure, making quite certain that the insulating washers are fitted in the correct form, in order for the ignition system to function as set. The moving contact and the low tension lead must be perfectly insulated from the base plate and fixed contact. It is advantageous to apply a very light smear of grease to the distal pin, prior to replacement of the moving contact.
4. Check, and if necessary, re-adjust the contact breaker points when they are in the fully open position.

6 Condensers removal and replacement

1. There are several condensers contained in the ignition system, each one wired in parallel with a set of points. If a fault develops in a condenser, ignition failure is likely to occur.
2. In the engine room difficult to work, an existing screw, it is possible that a condenser is at fault. To check, separate the contact points by hand when the ignition is switched on. If a spark occurs across the points as they are separated by hand and this has a faint or hazy appearance, the condenser connected to that set of points can be regarded as unserviceable.
3. Test the condenser on a coil and condenser tester unit or alternatively fit a new replacement. In view of the small size involved it is preferable to fit a new condenser, and observe the effect on engine performance as a result of the substitution.
4. Check that the screws that hold the condensers to the contact breaker plate are tight, and also form a good earth-connection.



Spark plug maintenance: Checking plug gap with feeler gauges



Altering the plug gap. Note use of correct tool



Spark plug conditions: A brown, tan or grey firing end is indicative of correct engine running conditions and the selection of the appropriate heat rating plug



White deposits have accumulated from excessive amounts of oil in the combustion chamber or through the use of low quality oil. Remove deposits or a hot spot may form



Black sooty deposits indicate an over-rich fuel/air mixture, or a malfunctioning ignition system. If no improvement is obtained, try one grade hotter plug



Wet, oily carbon deposits form an electrical leakage path along the insulator nose, resulting in a misfire. The cause may be a badly worn engine or a malfunctioning ignition system



A blistered white insulator or melted electrode indicates over-advanced ignition timing or a malfunctioning cooling system. If correction does not prove effective, try a colder grade plug



A worn spark plug not only wastes fuel but also overloads the whole ignition system because the increased gap requires higher voltage to initiate the spark. This condition can also affect air pollution



3.1 Contact fingers are mounted on contact breaker plate



3.4 A. Contact breaker pivot screws. B. Pivot contact screws. C. Base plate screws. D. Contact breaker terminals.

7 Ignition timing checking and setting

1. In order to check the ignition timing accurately it is necessary to remove the contact breaker cover, and check the points gap first. Using a feeler gauge, set the gap within the range of 0.3–0.4 mm (0.012–0.016 in) wherever an oil passage is fully open.
2. Rotate the engine with a spanner on the timing shaft bolt, until the 'F' mark on the timing advance for the set of points is adjusted slightly to the left of the timing mark, located just above the timing advance.
3. Make up a timing light to light light bulbs and two pieces of wire, one wire to the base of the bulb and one wire to the side of the bulb. Fit cassette clips to the other ends of the wire, and connect one wire to the make-up point spring, and the other to earth (an engine cooling fan or the frame will do) by means of the cassette clips. Turn on the ignition switch, rotate the engine backwards a few degrees past the point of alignment, and then rotate forward again until the 'F' mark is aligned with the timing mark. The light should flash as the two come together. If it does, the timing is correct. Check in a similar fashion the other set of points.
4. If the mounting plate for the points has to be moved, loosen the two screws on the point adjusting plate and use a screwdriver to move the plate to the position desired, so that the points just begin to open as the timing mark comes into line. If the points adjusting plate will not move far enough for any set of points, loosen the contact breaker base plate by undoing the three crosshead screws, enough to rotate the baseplate to the required position. Secure the screws and retighten the timing before going on to the other set of points. **Note:** Do not leave the ignition switched on for long, just enough to set the timing, otherwise the points will burn.
5. If the light will not come on, there could be a bad connection, the points gap may need attention again, or the points may need cleaning thoroughly.
6. It can be remembered that optimum performance depends on the accuracy with which the ignition timing is set. Even a small error can cause a marked reduction in performance and in an extreme case, engine damage due to overheating. The contact breaker gap must be checked and if necessary re-adjusted **BEFORE** carrying out ignition timing checking or setting. When ignition timing adjustment is made it is essential that the automatic timing returns to the standard (closed) position.

8 Automatic timing unit examination

1. The automatic timing mechanism rarely requires attention, although it is advisable to examine it periodically, when the contact breaker is requiring attention. It is rotated by a small belt and runs under the same oil as the integral camshaft breaker arm and can be pulled off the end of the camshaft when the contact breaker plate is removed.
2. The unit comprises a spring loaded balance weights, which move outward against the spring tension as centrifugal force increases. The balance weights must move freely on their pivots and be well lubed. The tension springs must also be in good condition. Keep the points lubricated and make sure the balance weights move easily without binding. Most problems arise as a result of contamination, within the engine, which causes the unit to not set balance weight movement to be restricted.
3. The automatic timing unit mechanism is fixed in relation to the camshaft by means of a dowel. In consequence the mechanism cannot be replaced in anything other than the correct position. This ensures accuracy of ignition timing to within close limits, although a check should always be made when assembly of the contact breaker is complete.
4. The correct functioning of the auto-advance unit can be checked when the engine is running by the use of a strobeoscopic light. If a strobe light is available, connect it to the ignition circuit as directed by the manufacturer of the light. With the engine running, direct the beam of light at the face timing mark of the camshaft, through the aperture in the base plate. At 1000–1200 rpm the timing mark and the 'F' mark on the auto-advance unit should be precisely aligned. When the engine is running at 2000 rpm or above, the timing mark should align with two parallel lines which are marked on the automatic timing unit slightly in advance of the 'F' mark. The above test will, of course, be on the auto ignition timing/advance system.

9 Sparking plugs: checking and setting the gap

1. Four NGK BR8S, 90 104553 or Champion 104 sparking plugs are fitted as standard to the Kawasaki 250E series. Under certain operating conditions, a change from these plug grades may be required, but generally the type recommended above will be found to give the best results. If the plugs persistently

system failed, it may be necessary to substitute a grade of sparking plug which operates at a higher temperature, such as NGK B7ES. Commonly, uncooled high-speed use may result in the standard sparking plug becoming fouled, in which case NGK B7ES or equivalent may be used.

2 The sparking plug electrode gaps should be checked in accordance with the intervals specified in the Routine Maintenance Section, or in the event of ignition problems. Note that if the sparking plugs in 1 and 4 or 3 and 2 cylinders appear to malfunction simultaneously, the relevant coil should be checked (see Section 2 of this Chapter).

To test the gap, bend the outer electrode pin to bring it closer to, or further away from the central electrode pin (a 0.7 mm B7ES 10 basic gauge can be used). Please bend the central electrode at the insulator still point, causing engine damage if the particles fall into the cylinder while the engine is running.

3 With some insulation, the condition of the sparking plug electrodes and insulator can be used as a reliable guide to engine operating conditions. See the accompanying diagram.

4 Always carry a spare pair of sparking plugs of the recommended grade. In the rare event of plug failure, they will enable the engine to be restarted.

5 Because of over-tightening the sparking plugs, otherwise there is a risk of stripping the threads from the aluminium alloy cylinder heads. The plugs should be sufficiently tight to seat firmly on their copper seating surfaces, and no more. Use a spanner while in a good fit to prevent the spanner from slipping and damaging the insulator.

6 If the threads in the cylinder head strip as a result of over-tightening the sparking plugs, it is possible to repair the head by the use of a helical thread insert. This is a cheap and convenient method of replacing the threads; most motorcycle dealers operate a service of this nature at an economic price.

7 Make sure the plug insulating caps are a good fit and have

their rubber caps. This should also be kept clean to prevent fouling. These caps contain the suppressors that eliminate backfire and TV interference.

30 Ignition switch - maintenance

1 In the event that the ignition switch malfunctions, it may be checked by using a multimeter set on resistance, or alternatively a simple battery/bulb test arrangement, such as that described in Section 7, may be used.

2 Remove the headlamp unit, trace and separate the connector leads from the ignition switch, and test the continuity between the various leads, using the table below as a guide.

Ignition switch ON	Result
Chast - White to Brown	Continuity
Chast - Blue to Blue	Continuity
White to Blue	Isolation
Brown to Blue	
White to Blue	
Brown to Blue	
Ignition switch OFF	Result
Chast - White to Blue	Continuity
White to Brown	Isolation
White to Blue	
Brown to Blue	

3 If any of the results are not as shown above, the switch must be regarded as defective. It may be possible to restore the contacts by using a proprietary switch cleaning fluid, but if this fails, a new switch will be required.



8.1 Accurate timing will be retained by centre bolt



8.2 Check the action of springs, weights and cam

15 Fault diagnosis Ignition system

Symptom	Cause	Remedy
Engine will not start	Faulty ignition switch Starter motor not working Open circuit in wiring Completely discharged battery	Operate switch several times to see contacts are dirty. If lights are, function, switch may need removal. Discharged battery. Use trickle until battery is recharged. Check whether fuse is loose. Eliminate fault before re-switching-on again. If lights do not work, remove battery and recharge.
Engine misfires	Faulty condenser in ignition circuit Faulty sparking plug Fuel spark due to generator failure and discharged battery	Remove condenser and so test. Remove plug and have original cleaned. Check output from generator. Remove and recharge battery.
Engine ticks power and overheats	Stalled ignition timing	Check timing and also contact breaker gap. Check whether auto-advance unit has jammed.
Engine 'flutes' when under load, rattles from engine	No ignition	Check grade of shop fitted, use recommended grades only.

Chapter 4 Frame and forks

Contents

General description	1	Carriage stand disassembly	18
Front fork legs removal and replacement	2	Drop stand disassembly	13
Fork adjuster and steering head bearings removal and replacement	3	Adjusters and nut to fork adjuster disassembly	12
Steering head bearings disassembly and reassembly	4	Oilseal removal and replacement	13
Front fork legs disassembling, reassembly and inspection	5	Speedometer and tachometer leads removal and replacement	14
Steering head/axis maintenance	6	Speedometer and tachometer drives location and disassembly	15
Frame disassembly and reassembly	7	Cleaning the machine	16
Swinging arm fork removal and installation	8	Inspection of frame and forks	17
Rear suspension units disassembly	9		

Specifications

Frame

Type

Front forks

Type

Damping capacity

Damping grade

Damping level

Fork spring free length

Rear suspension units

Type

Swinging arm

Type

Pinion stem diameter

Wear limit

Wear inner diameter

Wear limit

Pinion shaft thread

Wear limit

Tubular double cradle

Hydraulically damped telescopic

180 - 191 mm leg, dry

1.5kg

180 mm (18 - 19) mm free top of suspension

454 - 4 mm nominal (17.5 in)

456 - 7 mm wear limit (17.9 in)

Coil spring, hydraulically damped

Welded tubular steel

21 - 875 - 22 - 002 mm (8 - 885 - 8 - 885 in)

21 - 860 mm (8 - 884 in)

22 - 045 - 22 - 048 mm (8 - 886 - 8 - 870 in)

22 - 04 mm (8 - 878 in)

less than 0-1 mm (0 - 0.04 mm)

less than 0-2 mm (0 - 0.08 in)

1 General description

1 The frame of the Kawasaki 250S is of the full cradle type, in which the engine is supported by duplex tubes at the base of the cradles.

2 A top tube runs from the steering head to a position at the rear of the petrol tank; the frame is attached to this rear end-point with provision for fitting the multipoint. Look for the attachment of the subframe, the pillion footrests, rear brake pedal, carriage stand and prop-stand on this frame.

3 The front forks are hydraulically damped, consisting of two telescopic shock absorber assemblies, each of which comprises an inner tube, an outer tube, a spring and a cylinder, piston and valve. The whole fork assembly is attached to the frame by the steering head stem and is mounted on two bearing assemblies contained in the steering head housing.

4 The damping action of the fork is accomplished by the flow resistance of the fluid oil flowing between the inner and outer tubes. The method of removal, disassembling and reassembly of the complete fork assembly is described in the following text.

2 Fork fork legs removal and replacement

- 1 The lower fork legs may be removed from the machine without disturbing the fork yokes, avoiding the complication of removing the handbar components and headlamp assembly. Start by supporting the machine securely on its centre stand. Place a steel wooden block or similar, underneath the castorose to raise the front wheel clear of the ground.
- 2 Disconnect the speedometer cable at the adjuster by releasing the gland nut which retains it to the speedometer drive cable. Separate the two nuts which secure each wheel speed pump. Then slacken the adjuster spindle steering nuts. The clamp between the steering components, and the adjuster fitted close to the forks, have that item in a fixed of the fork yoke being displaced if the lever should be accidentally squeezed while the adjuster is loosened. To prevent this occurring, a small chip of plastic or similar should be inserted between the brake pads.
- 3 If the fork by which carries the brake caliper is to be removed, the caliper must be detached. This latter unit is maintained by two mounting bolts which pass through lugs on the lower leg. Remove the caliper and release the hydraulic hose guides, then fit the upper pipe from the fork legs. Do not allow it to hang from its hydraulic hose. Remove the six foot midguard mounting bolts, and fit the midguard again. Place this in a safe place where the fork will not get scratched or damaged.
- 4 The fork legs are each retained by a clamp bolt in the lower fork yoke, and a similar clamp arrangement on the upper one. Remove the relevant clamp bolts. The complete fork right can now be pulled downwards and disengaged from the yokes, leaving the yokes and headlamp assembly in position.
- 5 The fork legs can be refitted in a similar manner, releasing the attachment to and to as it is slid into position. If it proves difficult to fit the machines through the yokes, the clamp bolts may be removed and a screwdriver blade used to open the holes in the yokes slightly.
- 6 The top nuts should be just flush with the top of the upper yoke before retightening the clamp bolts. Remember to refill the fork legs if they have been drained. An empty gal of motor oil (see can be used) to top up the legs with 5-8. 1 litre (200 square oil. The correct level is 225 mm (11 in) 18 in from the top of the strainer.

3 Fork yokes and steering head bearings removal and replacement

- 1 The fork yokes and steering head assembly can be removed with or without the fork legs in position. Start by following steps 1 to 3 inclusive in Section 2 of this Chapter. Undo the nut and disconnect the petrol feed pipe, then disconnect and remove the petrol tank, placing it somewhere where it will not get damaged. Remove the headlamp, oil, and disconnect the various leads and connectors, pulling the cables clear of the headlamp shell. Remove the headlamp shell and indicator lamps, then disconnect the speedometer and tachometer drive cables, pulling these clear of the fork assembly.
- 2 Release the instrument panel mounting nuts, taking care not to lose the mounting subunit. The complete assembly can now be lifted away from the top fork yoke and placed in one side. Disconnect the front brake cable leads, then releasing the three way hydraulic union from the lower fork yoke.
- 3 Slacken the top handbar clamp bolts and remove the clamp nut. Lift the handbars up and back far enough to clear the upper fork yoke, positioning them so that there is no risk of the hydraulic fluid in the reservoir spilling out. Detach the upper fork yoke clamp bolts and the steering head clamp bolt, and remove the chromate plated steering head cap bolt. The upper yoke can now be lowered upwards, using a hook matter, and slid away from the fork.

- 4 Arrange any remaining cables, leads, etc. so that they do not foul the lower yoke. Clean the seal lip on the in which the steering head/balls can be placed safely. Place this on the lower yoke and when no released, the lower cone balls will drop free, and some provision must be made to catch them. As a precaution place a large piece of rag below the headstock to catch any dropped balls. Slacken the locking, using a C spanner, and lower the steering head/caster and lower yoke assembly clear of the frame. Note that there are 22 balls in the lower cone and 19 in the upper one, all being of the same size, namely $\frac{1}{2}$ in diameter.
- 5 Before reassembly, examine and clean the bearing races, then slide the 22 lower cone balls into position using high-viscosity palm grease. Reassemble the fork unit, following the dismantling sequence in reverse. Note that the steering head should be tightened just sufficiently to remove 'free play'. Do not attempt to tighten the head yoke. It is surprisingly easy to inadvertently apply a loading of several tons to the head bearings, which will quickly break up as a result. When set correctly, there should be no discernible play in the forks when they are shaken. The fork assembly should, however, move easily and without any sign of resistance from fork to fork.

4 Steering head bearings examination and restoration

- 1 Before commencing reassembly of the fork, examine the steering head races. The ball bearing marks of the repetitive top and cone bearings should be polished and free from indentations, cracks or pitting. If signs of wear are evident, the caps and cones must be removed by order to the straight line steering as my motorcycle to be consistently good, the steering head bearings must be absolutely perfect. Even the smallest amount of wear on the caps and cones may cause steering wobble at high speeds and judder during heavy front wheel braking. The caps and cones are an interference fit on their respective seatings and can be tapped into position with a suitable die.
- 2 Ball bearings are relatively cheap. If the originals are marked or discoloured they must be replaced. To hold the steel balls in place during assembly of the fork yokes, pack the bearings with grease. The upper and lower cones contain 19 and 22 $\frac{1}{2}$ in steel balls respectively. Although a conical cap with radius when the balls have been fitted, an oil seal must fit on cone ball to be inserted, so the gap is intended to prevent the balls from sliding against each other and wearing quickly.



2 To release the speedometer drive cable of the gearbox



2.26 Remove the brake clamps and remove the front wheel



2.27 Release the mudguard mounting bolts



2.28 Release the lower yoke pinion bolt ...



2.29 ... and lower yoke pinion bolt ...



2.30 ... then pull fork legs clear of yokes



2.31 A. Check top nut, B. Push bolt, C. Adjusting ring

5. Front fork legs: dismantling, renovation and reassembly

1 Having removed the fork legs as described in Section 3, they may be dismantled for further examination. Always deal with one leg at a time, and on an access interchange components from one leg to the other as the various moving parts will have lubed in during use, and should remain lubed. Commence by draining the oil, either by way of the drain plug in the lower leg or by removing the ball and breather in the top. Pumping the oil will assist in the draining operation.

2 Before the oil is removed, first check the main seal assembly, using your part set on a clean surface as it is removed. Remove the dustproof plate top bolt and withdraw the upper and spring seat, followed by the fork spring. It will be necessary to prevent the damper assembly from turning with the allen screw in the base of the lower leg is dismantled. This will be particularly necessary if the forks are being stripped for the first time since their total assembly, in the absence of the Kawasaki holding bolt (part number 50001 - 143) a little ingenuity must be applied. It was found that a piece of wire cut steel with the end ground to a taper could be used as an improvised holding tool (see photograph), but it may be found preferable if an excessive amount of stress loading had been used.

3 Having managed to remove the retaining bolt, the dustproof may be pulled out of the lower leg. Strike the damper out out of the damper, then remove the shim in the lower end of the damper and shake out the remaining damper components. The plates may be removed from the damper rod after releasing the shim which retains it.

4 The parts most liable to wear over an extended period of service are the internal surfaces of the lower leg and the outer surfaces of the fork crown tubes. If there is excessive play between these two parts they must be replaced as a complete unit. Check the fork tube for scoring over the length which enters the oil seal (but scoring here will damage the oil seal and lead to fuel leakage).

5 It is advisable to retire the oil seals when the forks are dismantled even if they appear to be in good condition. This will save a drip-down of the forks at a later date if oil leakage occurs. The oil seal in the top of each lower fork leg is retained by an internal O ring which can be gripped out of position with a small screwdriver. Check that the dust exciter rubbers are not split or worn where they bear on the fork tube. A worn exciter will allow the ingress of dust and water which will damage the oil seal and eventually cause wear of the fork tube.

6 It is not generally possible to straighten forks which have been badly damaged in an accident, particularly when the crown legs are not available. It is always best to fit on the side

of safety and fit new ones, especially since there is no easy means to check whether the forks have been over stressed or metal fatigued. Fork excitors instead can be checked, after removal from the lower leg, by rolling them on a steel flat surface. Any misalignment will be immediately obvious.

7 The fork springs will take a permanent set after considerable usage and will need renewal if the fork action becomes spongy. The service life for the total free length of each spring is 454.7 mm (17.9 in), always reuse them as a matched pair.

8 Fork damping is governed by the viscosity of the oil in the fork legs, normally SAE 15W150, and by the action of the damper assembly. Each fork leg holds 180 - 184 cc of damping fluid.

6. Steering head lock - maintenance

1 A security lock is mounted on the headstem, enabling the owner to immobilise the machine by locking the steering in any position. The lock consists of a key-operated plunger which engages in a slot in the steering head. A small return spring disengages the lock mechanism when the key is released.

2 Maintenance is confined to keeping the lock lightly lubricated, using light machine oil or one of the multipurpose spray lubricants. In the event that the lock malfunctions, it will be necessary to remove the lock after unscrewing the cover plate, and to fit a replacement unit.

7. Frame examination and renovation

1 The frame is unlikely to require attention unless accident damage has occurred. In some cases, removal of the frame is the only satisfactory remedy if the frame is badly out of alignment. Only a few frame variations have the legs and mainstrut necessary for operating the frame to the required standard of accuracy, and even then there is no easy means of assessing to what extent the frame may have been over-stressed.

2 After the machine has covered a considerable mileage, it is advisable to examine the frame closely for signs of cracking or splitting at the welded joints. Rust corrosion can also cause weakness at these joints. Minor damage can be repaired by welding or bracing, depending on the extent and nature of the damage.

3 Remember that a frame which is out of alignment will cause handling problems, and may even promote 'lured accidents'. If misalignment is suspected, as a result of an accident, it will be necessary to strip the machine completely so that the frame can be checked, and if necessary renewed.



Fig. 5 Remove fork top bolt and spring seat.



Fig. 6 ... then withdraw the fork spring



5.24 Tapered damper can be used in both damper assembly ...



5.25 ... while Allen screw in base of leg is tightened.



5.26 Pull station and damper out of lower leg.



5.27 Allow seal with fit off the end of damper leg.




5.28 Damper assembly is reinserted in lower leg.



5.29 Examine the mating parts for signs of wear.

Fig. 4.1 Front fork



- | | | | | | |
|----|---------------------------|----|-------------------------|----|----------------------------|
| 1 | Front fork assembly | 14 | Spring washer - 2 off | 27 | Nut - 2 off |
| 2 | Fork cap bush - 2 off | 15 | Bush - 2 off | 28 | Fork cap gasket - 2 off |
| 3 | O-ring - 2 off | 16 | Bush - 4 off | 29 | Washer - 2 off |
| 4 | Bush - 2 off | 17 | Spring seat - 2 off | 30 | Washer - 2 off |
| 5 | Spring washer - 2 off | 18 | Fork crown - 1 off | 31 | Oil seal - 2 off |
| 6 | Steering yoke - Top | 19 | Fork crown - 8 off | 32 | Fork cap gasket - 2 off |
| 7 | Bush | 20 | Washer - 2 off | 33 | Lower fork cap - 2 off |
| 8 | Bush - 5 off | 21 | Guide washer - 2 off | 34 | Damper fork gasket - 2 off |
| 9 | Fork lower washer - 2 off | 22 | Washer - 2 off | 35 | Fork |
| 10 | Steering stem tube | 23 | Fork spring - 2 off | 36 | Fork cap gasket - 2 off |
| 11 | Washer | 24 | Fork lower tube - 2 off | 37 | Damper bush - 2 off |
| 12 | Oil seal | 25 | Fork damper - 2 off | 38 | Damper bush gasket - 2 off |
| 13 | Steering yoke - lower | 26 | Pinion - 2 off | | |



5.5a Pries out and inspects the rollers. If worn or damaged



5.5b Dam roller must be in good condition to prevent squeaking



5.6 Refill fork legs with the correct quantity of oil



5.7 Steering knuckle is reassembled to hub/shock

5 Realigning arm forks: removal and reinstallation

1 The swinging arm fork is supported on two tapered bushes which pivot on an inner sleeve. The assembly is retained by a long pin shaft which passes through lugs on the frame and through the centre of the sleeve. A grease nipple is fitted to enable grease to be pumped into the bearing surfaces.

1.1 Wear in the swinging arm bushes is characterised by a tendency for the toe of the machine to twitch when it takes a turn through a series of bends. This can be checked by placing the machine on the centre stand, and jacking the swinging arm lower side in wide. Any discernible free play will necessitate the removal of the swinging arm for further examination.

1.2 Commence by detaching the sleeve from each side of the machine, after loosening the clamp nut and mounting nuts on each unit. Bench the rear brake switch operating spring, then release the brake adjusting nut. The brake operating rod can now be disassembled from the operating lever. Pull out the spring pin from the longer arm mounting stud, then remove the securing nut and disengage the longer arm. Release the oblique stud mounting nuts and lift the guard away.

1.3 Remove the split pin which retains the rear wheel spindle nut, then slacken the nut. Release and mark off the chain tensioner drawbolt, and swing them through 90° degrees. The wheel can now be pushed forwards as far as possible, and the front drive chain disengaged from the rear wheel sprocket.


2 Loosen the bolt which retains each of the stops at the end of the forks. Remove the stops, then pull the wheel backwards until it clears the frame. Lift it clear and place it in one side to await reassembly.


3 Remove the lower suspension mounting bolt from each side of the machine, and push the axle rear of the swinging arm. Release the pivot studs and pull the pivot shaft out, supporting the swinging arm. The swinging arm can now be drawn rearwards, noting that the caps on each end of the green tube will probably drop clear. Disengage the fork from the other chain, and place it on a bench to await further dismantling.

4 Cleanse the pivot sleeves and retain the sleeve and the tapered bushes to remove all trace of grease. Examine the sleeve and both bearing surfaces for signs of wear or scoring. If damaged or worn, or if better the limits given in the Specifications Section, replace the components as necessary. The two tapered bushes may be drawn out using a suitable bar or drill. When fitting new bushes, ensure that they are tapped squarely into the swinging arm bore, and that they seat correctly. Clean off any corrosion on the inner sleeve if this is to be re-used.

5 If an assembly there appears to be excessive axial play in the swinging arm, it is possible to correct this by giving appropriate adjustments of shims under the anchor, unless the unit has been installed, use a grease gun to force grease into the assembly. Continue greasing until it oozes at each end, wiping off the excess.

Fig. 4.3 Frame assembly





6.2a Remove spring pin and nut to release brake linkage pin



6.2b Detach chain guard



8.4 Release Chain, wheel spindle nut and drum/brake assembly



8.5a Remove the rear wheel, and detach suspension units



8.5b Block and secure the front drive shaft...



8.5c ... withdraw the front shaft...



8.5d ... and disengage the trailing arm



8.6 Clean and examine the lower control and bushes



8.7a Grease all components during assembly



8.7b Do not forget to coil and separate reinstallation



8.7c Shocks should be kept well lubricated via the grease nipple

9 Rear suspension units examination

1. Rear suspension units of the 2 way adjustable type with hydraulic damping are fitted to the 2000. The units can be adjusted to give 3 different settings. A lock spacer in the middle is used to adjust the units by means of any holes.
2. There is no means of draining or tapping up the units as they are permanently sealed. In the interests of good road holding, both units should be replaced if either seems to leak or loses its damping action.

10 Centre stand examination

1. The centre stand is attached to the machine by two bolts on the bottom of the frame. It is returned by a centre spring. The links and spring should be checked for tightness and tension respectively. A weak spring can cause the centre stand to protrusion-actuate and unseat the rider.

11 Prop stand examination

1. The prop stand is secured to a plate on the frame with a bolt and nut, and is returned by a tension spring. Make sure the bolt is tight and the spring is not over-stretched otherwise an accident can occur if the stand drops during coming.

12 Footrests and rear brake pedal examination

1. The footrests are of the universal type and are retained by a clamp pin secured by a split pin. The advantage of this type of footrest is that if the machine should fall over the footrest will not be broken/damaged.
2. The rear brake pedal is held in position by a stud-anchored nut; the pedal return spring must be detached to remove the brake lever.

13 Dualnut, removal and replacement

1. The dualnut is attached to the frame by two clamp pins that are located with split pins, on the right-hand side of the frame. To remove the seat, loosen the spring (see 20) each on



8.8 Rear suspension units can be adjusted for preload as shown

the left-hand side, and press the seat up with the stay provided. Withdraw the two split pins from the steering plate pins, and remove the plate pins. The seat mountings and dampers cannot be left in place as the seat is lifted off.

2 If the fuel tank is removed (because it is new, it is possible in most cases to find a specialist firm that recovers fuel tanks for an economical price, usually considerably cheaper than having to buy a new replacement). The usual charge is about 50% the cost of a new replacement, depending on the extent of the damage.



14.1 Instrument dials are each retained by a single screw, from top-to-bottom (seat on side)

14 Speedometer and tachometer heads: removal and replacement

1 The speedometer and tachometer are both mounted together on a single panel on top of the front forks. They are mounted on studs with rubber bushes and secured with nuts. The heads are enclosed in light alloy shrouds secured to the instruments by a single crosshead screw. The shrouds have to be removed first, to enable the instruments to be released.

2 When the shrouds are detached the drive cables can be unscrewed. The rubber-mounted bulb holders can be pulled out with the bulbs. Check for broken bulbs while they are out. The four bolts in the dash panel are also a push fit and can be

checked at the same time.

3 The speedometer and tachometer heads cannot be repaired by the private owner, and if a defect occurs, a new instrument has to be fitted. Remember that a speedometer in constant working order is required by law on a machine in the EEC area from other countries.

4 Speedometer and tachometer cables are only supplied as a complete assembly. Make sure the cables are routed correctly through the straps provided on the top fork yokes, brake levers, pipes, and the frame.

15 Speedometer and tachometer drives: location and installation

1 The speedometer is driven from a gear inside the front wheel hub assembly. The gear is driven internally by a horizontal splined hornshaft. The hornshaft engages with the stars in the wheel hub, on the left-hand side. As the wheel rotation is pre-greased with grease on assembly, it should last the life of the machine, or until new parts are fitted. The spiral pinion (that drives off the internal gear) is retained in the speedometer gearbox housing by a grub screw, which should always be secured tightly.

2 The tachometer drive runs off the camshaft in the cylinder and connects directly into the cylinder head cover in the same position. The cable is retained by a screwed ferrule, in the same manner as the speedometer cable.

16 Cleaning the machine

1 After removing of the surface dirt with warm water and a rag or sponge, use a cleaning compound such as 'Gardol' or 'Jax' for the oily parts. Apply the cleaner with a brush when the parts are clogged, so that it has an opportunity to soak into the filth or oily grease.

Rinse off by washing down liberally, taking care that water does not enter into the carburettors, air cleaner or electric, if desired, a petrol such as Mineral Antisol can be applied to the oily parts to give them a full lather. Application of a wax polish to the chrome parts and a good chrome cleaner to the chrome parts will also give a good finish. Always wipe down the machine if used in the wet, and make sure the chain is well oiled. Check that the control cables are kept well oiled (this will only take 15 minutes, if you clean each week rather than all year). There is also less chance of water getting into the cables, if they are well lubricated.

12 Fork diagnosis: frame and forks

Symptom	Cause	Remedy
Machine veers to left or right with loads off handbars	Wheels out of alignment Forks twisted Frame bent	Check wheels and cables. Sprig and repair. Sprig and repair or renew.
Machine wanders out at low speeds	Steering head bearings not adjusted correctly or worn	Check adjustment and renew the bearings, if worn.
Machine tends to wander	Worn packing and bearings	Check and renew bearings. (Check adjustment and renew.
Forks/judder when front brake is applied	Steering head bearings slack Forks rub on sliding surfaces	Tighten forks. Check adjustment, renew all worn parts.
Forks bottom	Spout chafed	Repair with correct viscosity oil.
Fork action stiff	Fork legs out of alignment Bent shafts, or twisted tubes	Tighten and renew or slacken clamp bolts, then wheel spindle and top bolts. Polish forks several times, and tighten from bottom upwards.
Machine tends to pitch back	Defective rear suspension units, or ineffective fork damping	Check damping action. (Check the grade and quantity of oil in the fork tubes.

Chapter 5 Wheels, brakes and tyres

Contents

General description	1	and assembly	10	
Front wheel examination and renovation	2	Rear sprocket assembly: examination, renovation	and replacement	11
Front wheel/tilt linkage: examination and renovation	3	Rear axle assembly: examination and renovation	12	
Removing and replacing the brake disc	4	Rear brake assembly: adjusting	13	
Master cylinder: examination and renovation	5	Rear drive chain: examination and lubrication	15	
Front wheel/bearings: examination and replacement	7	Tyre: removal and replacement	18	
Front wheel: assembly and replacement	8	Tyre: correct fit/fitting	18	
Rear wheel assembly: examination and renovation	8	Wheel spacers	19	
Rear wheel/bearings: examination and replacement	9			
Rear brake assembly: examination, renovation				

Specifications

Tyres

Front	3.25H – 19 (3.45H)
Rear	4.00H – 19 (3.45H)

Tyre pressures

	Safe	Filler or high speed
Front	2.0 kg/cm ² (28 psi)	2.5 kg/cm ² (34 psi)
Rear	2.0 kg/cm ² (28 psi)	2.5 kg/cm ² (34 psi)

Brakes

Front	345 mm hydraulic disc brake
Rear	190 x 40 mm single-leading shoe drum brake

1 General description

The 2000 models have a 19 inch diameter front wheel and an 18 inch diameter rear wheel. The front tyre is of the ribbed road pattern, the rear tyre has a block road pattern. All models employ steel rims in conjunction with cast aluminium hubs. The front brake is of the hydraulic disc type, the rear brake is the internal expanding drum type.

2 Front wheel: examination and renovation

Place the machine on its centre stand so that the front wheel is clear of the ground. Spin the wheel by hand and check the rim for alignment. Visual inspection can be completed by sighting the spokes in the affected area. Any flats in the wheel rim will be evident at the same time. In this latter case it will be necessary to have the wheel rebuilt with a new rim. The machine should not be run with a deformed wheel, since this will have every adverse effect on handling.

2 Check for loose or broken spokes. Tightening the spokes is a good guide to the correct tension; a loose spoke will always produce a different sound and should be tightened by turning

the nipple in an anti-clockwise direction. Always check for rim run by spinning the wheel again. If the spokes have to be tightened by an excessive amount, it is advisable to remove the tyre and tube as detailed in Section 18 of this Chapter. This will enable the protruding ends of the spokes to be ground off, thus preventing them from chafing the inner tube and causing punctures.

3 Front wheel/tilt linkage: examination and renovation

1 Check the front brake master cylinder, hose and caliper unit for signs of fluid leakage. Pay particular attention to the condition of the synthetic rubber hose, which should be replaced without question if there are signs of cracking, splitting or other exterior damage.

2 Check the level of hydraulic fluid by removing the cap on the brake fluid reservoir and filling out the dipstick and discharge plug. This is one of the maintenance tasks which should never be neglected. Make certain that the handlebars are in the neutral position when removing the reservoir cap, because if the fluid level is high, the fluid will spill over the reservoir tube. If the level is particularly low, the fluid delivery

leakage will be allowed when content with the air pad may necessitate the bleeding of the system at a later date. A level mark is given on the inside of the reservoir cylinder. If the level is below the mark, brake fluid of the correct grade must be added. **NEVER USE ENGINE OIL** or anything other than the recommended fluid. Other fluids have undesirable characteristics and will quickly destroy the seals.

2 The brake pads should be inspected for wear. Each pad is treated with a scuffed line, indicating the maximum wear limit. If worn beyond this point, both brake pads must be renewed as a set. The brake pads can be checked while they are still in position in the caliper and the front wheel is still in situ. If the front brake is operated, the extent of wear can be easily seen.

3 The brake pads can be removed from the caliper after the front wheel has been taken off. Commence by removing the retaining screw and backplate on the inside pad. The pad will push out of position. Very gently apply the front brake lever, which will separate the caliper piston and so push the outer pad from position. Do not pump the brake when carrying out this operation or there is a danger of the piston being pushed out of the cylinder. It will be noted that the outer pad (piston pad) has a steel shim on the rear face. The shim is fitted to prevent the disc brake assembly squeaking during operation, and is located by a small clip on the brake pad.

When fitting new pads, it will probably be found that the recessed side of the pads will follow the lesser disc face (looking between) the pads will follow the lesser disc face (looking between). To ensure this, press hard on the outer caliper pad and at the same time slightly loosen the brake bleed valve. The pad will move towards slowly and then stop, at which point the bleed valve must be tightened immediately. It will be found that a small amount of fluid will have been drawn from the bleed valve. Wipe up the fluid immediately and then check the level in the master cylinder.

4 If brake action becomes spongy, or if any part of the hydraulic system is damaged (such as when the hose is ruptured) it is necessary to bleed the system in order to remove all traces of air. The following procedure should be followed:

1 Attach a tube to the bleed valve at the top of the caliper unit. After removing the dust cap, it is preferable to use a transparent plastic tube, so that the presence of air bubbles is easily noticeable.

2 The top end of the tube should rest in a small bottle so that it is submerged in hydraulic fluid. This is essential to prevent air being drawn back into the system. In consequence, the end of the tube must remain submerged at all times.

3 Check that the reservoir on the foundation is full of fluid and replace the cap to keep the fluid clean.

4 If sponge brake action necessitates the bleeding operation, depress and release the brake lever several times to equalise pressure, to allow the pressure in the system to build up. Then open the bleed valve by unscrewing it (one complete turn will build sufficient pressure in the line). This is a lever-action operation. Repeat the lever falls until it reaches the foundation when close the bleed valve. If parts of the system have been repaired, the bleed valve should be opened from the beginning and the brake lever worked until fluid issues from the bleed tube. Note that it may be necessary to top up the reservoir during this operation. If it empties, air will enter the system and the whole operation will have to be repeated.

50 Repeat operation 4 until bubbles disappear from the bleed tube. Close the bleed valve fully, remove the bleed tube and replace the dust cap.

11 Check the level in the reservoir and top up if necessary. Pour the fluid which has drained into the bottle at the end of the bleed tube because this contains air bubbles which will re-introduce air into the system. The fluid must stand for 24 hours before it can be re-used.

12 Refit the dustcap and dustcap plate and tighten the reservoir cap securely.

13 Do not spill fluid on the axle area. It is a very effective paint stripper! Also, the plastic plates in the speedometer and tachometer heads will be badly affected if fluid gets on them.



3.3 Maximum wear limit is denoted by scuffed line



3.4 Release the retaining screw and backplate




3.4b Bleed-off device for dustcap and withdraw...



2.46. ... knowing the inner of mixing and



2.48. Breath tube must be in position before cover is attached



4. Rebuilding and replacing the brake disc

1 It is unlikely that the disc will require attention until a considerable mileage has been covered, unless premature scoring of the disc has taken place thereby reducing braking efficiency. To remove the disc, first detach the front wheel as described in Chapter 5, Section 2.1 and 2. The disc is bolted to the front wheel on the left hand side by four bolts, which are secured in pairs by a common bolt/washer. Remove the bolt/washer and remove the bolts to free the disc.

2 The brake disc (as it is checked for wear and for warped surface the front wheel is still in the machine. Using a micrometer measure the thickness of the disc at the point of greatest wear. If the measurement is much less than the recommended spindle limit of 8 mm (0.315 in) the disc should be resurfaced. Check the warpage of the disc by setting up a suitable pointer close to the outer periphery of the disc and spinning the front wheel slowly. If the total warpage is more than 0.15 mm (0.012 in) the disc should be resurfaced. A resurfaced disc, apart from reducing the braking efficiency, is likely to cause juddering during braking and will also cause the brake to bind when it is hot in use.

5. Master cylinder - examination and restoration

1 The master cylinder is unlikely to give trouble unless the machine has been stored for a lengthy period or until a considerable mileage has been covered. The usual signs of trouble are leakage of hydraulic fluid and a gradual fall in the fluid

reservoir content.

2 To gain full access to the master cylinder, commence the dismantling operation by attaching a bleed tube to the caliper until/over the top. Open the bleed nipple one complete turn, then operate the front brake lever until all fluid is pumped out of the reservoir. Close the bleed nipple, detach the tube and store the fluid in a clean container for subsequent use.

3 Detach the hose and also the stop lamp switch. Remove the handlebar lower plastic cover and the lever fork.

4 Access is now available to the piston and the cylinder and it is possible to remove the piston assembly, together with all the returned seals. Take note of the way in which the seals are arranged because they must be replaced in the same order. Failure to observe this necessarily will result in brake failure.

5 Clean the master cylinder and piston with clean hydraulic fluid or acetone. Do not acetone use either alcohol or other solvents such as petrol. If any signs of wear or damage are evident, resurfacing is necessary. It is not practicable to resurface either the piston or the cylinder bore.

6 Reak the new seals in hydraulic fluid for about 10 minutes prior to fitting, then reassemble the parts in the **EXACT THE SAME ORDER**, using the remains of the dismantling procedure. Lubricate with hydraulic fluid and make sure the feather edges of the various seals are not damaged.

7 Refill the resurfaced master cylinder and in the handlebar, and reinsert the handlebar lower fork, stop lamp etc. Refill the reservoir with hydraulic fluid and bleed the entire system by following the procedure described in Section 1.4 of this Chapter.

8 Check that the brake is working correctly before taking the machine on the road, to restore pressure and align the pads with the disc surface.




Fig. 5.2 Front brake master cylinder

- 1 Front brake master cylinder assembly
- 2 Oil reservoir cap
- 3 Master cylinder plug
- 4 O-ring
- 5 Lever ball
- 6 Front brake lever
- 7 Nut
- 8 Master cylinder body
- 9 Piston washer - 2 off
- 10 Seal - 2 off
- 11 Repair kit
- 12 Return spring
- 13 Piston cap
- 14 Piston
- 15 O-ring
- 16 Gland
- 17 Seal cover
- 18 Gland
- 19 Seal washer
- 20 Seal nut
- 21 Lever adjustment screw
- 22 O-ring/washer - 2 off
- 23 Cylinder brake hose
- 24 Seal - 3 off
- 25 Seal cover
- 26 Ball
- 27 Seal
- 28 Spring/washer - 2 off
- 29 Washer - 2 off
- 30 Speedometer and instrument cable clamp - 2 off
- 31 Three-way joint
- 32 Front brake switch
- 33 Bridge plate
- 34 Caliper brake hose
- 35 Pinion
- 36 Brake hose pinion



5.1 Brake disc is retained by four bolts and double nut washers

6 Front wheel bearings: examination and replacement

1 Access is available to the front wheel bearings when the suspension and front wheel spindle are removed. The bearings are of the ball journal type and are non-adjustable. There are two linings and two oil seals, the rear bearings are inspected by a distance collar in the centre of the hub.

2 First remove the speedometer cable by undoing the locked nut. Remove the front wheel spindle, and pull off the speedometer drive gearbox. Remove the brake disc after releasing the four retaining bolts. Take off the collar and wheel cap, and stir out the left-hand bearing, using a double diameter drift from the right-hand side.

When the bearing is removed, the distance collar can be taken out. Working from inside the hub, use the same drift to replace the right-hand bearing. Remove the oil seal, take out the retaining ring, and from the left-hand side use the drift to tap evenly around the inner race of the right-hand bearing and knock it out.

3 Remove all the old grease from the hub and bearings, wash the bearings in petrol, and dry them thoroughly. Check the bearings for roughness by spinning them whilst holding the inner ball with one hand and rotating the outer ball with the other. If there is the slightest sign of roughness remove them.

4 Before driving the bearings back into the hub, pack the hub with new grease and also grease the bearings. Use the same double diameter drift to press them into position. Refit any oil seals or dust covers which have been displaced.



5.2a Remove the wheel spindle and speedometer gearbox...



5.3 Examine hydraulic hoses and distributor hose for signs of leakage

7 Front wheel re-assembly and replacement

1 Refit the speedometer gearbox, and fit the wheel cap or boot which is retained by two bolts.

2 Place the location bolts diagonally across where the front wheel is fitted back into position. First tighten the front spindle clamp bolt and then the nut/bolt for each hub leg, so that there will be a gap at the rear after tightening. Spin the wheel to make sure it revolves freely, and check that the brake operates correctly from the front wheel while raising the speedometer cable, so that the tongue of the speedometer drive will locate correctly.

8 Rear wheel assembly: examination and removal

1 Place the machine on the centre stand so that the rear wheel is raised clear of the ground. Check the drive/lock alignment, damage to the rim or broken spokes by following the procedure relating to the rear wheel described in Section 2 of this Chapter.

2 To remove the rear wheel, refer to Chapter 4, Section 8.2 and 4.

3 Remove the wheel spindle and take out the brake plate.

Take the coupling assembly from the coast drive rubbers, and remove the rubbers. The rear wheel spindle can be withdrawn for inspection by removing the six nuts and the three locknuts.



5.2b ...and remove spacer and hub-cover



6.21 The nut can be tightened clockwise



6.22 Wheel bearing is retightened correctly




Fig. 6.2 Front hub assembly

- 1 Axle guide collar - 2 off
- 2 Sprocket/chain pinion assembly
- 3 Nut pin
- 4 Front washer - 1 off
- 5 Sprocket/chain drive shaft
- 6 Sprocket/chain drive Assembly
- 7 Sprocket/chain gear
- 8 Oil seal
- 9 Sprocket/chain gear drive slip
- 10 Front hub assembly
- 11 Ball bearing - 2 off
- 12 Bearing spacer
- 13 Chain
- 14 Oil seal
- 15 Dust cover
- 16 Front washer - 2 off
- 17 Screw - 2 off
- 18 Bolt - 4 off
- 19 Locking plate - 2 off
- 20 Dust cover
- 21 Spindle collar
- 22 Front wheel spindle



7.1a Hold driving flange in wheel center...



7.1b ... which engage in speedometer gearbox



7.1c Hub steel is retained by two screws



8.1 Rear wheel drive is retained as described in Chapter 4



8.2a Remove to the backstop...



8.2b ... and catch drive/shock nut

5 Rear wheel bearings: examination and replacement

1 The rear wheel bearings are a drive fit into the hub. They are separated by a spacer and a distance collar. There are two bearings in the hub and one in the centre of the rear final drive sprocket boss.

2 Remove the distance collar from the coast drive hub, take out the wheel spindle collar, and then the oil seal. Tapping evenly around the inner race from the inside of the coupling, knock out the bearing.

3 To remove the two bearings from the wheel hub, use a double diameter drift again and tapping evenly around the inner race from the sprocket side knock out the bearing on the front plate side.

4 Remove the large diameter collar, and tapping on the inner race from the brake plate side, knock out the bearing on the sprocket side.

5 Remove all the old grease from the bearings and hub. Wash the bearings in petrol and dry them thoroughly. Check the bearing for roughness by spinning them while holding the inner race with one hand, and rotating the outer race with the other hand. If there is the slightest sign of roughness remove them.

6 Before fitting the bearings back into the hub and sprocket cones, pack the hub with new grease and also grease the bearings. Use the same double diameter drift to place them into position. Refit any oil seals or dust covers which have been displaced, renewing them if damaged or worn.




Fig. 5.4. Rear hub assembly

- 1 Split pin
- 2 Camshaft/hub
- 3 Spacer
- 4 Sprocket
- 5 Rear chain
- 6 Coast drive hub assembly
- 7 Nut - 8 off
- 8 Lock washer - 2 off
- 9 Oil seal
- 10 Ball bearing
- 11 Coupling cone
- 12 Nut - 8 off
- 13 Rear brake assembly
- 14 Ball bearing
- 15 Spring
- 16 Shock absorber rod ends
- 17 Bearing spacer
- 18 Ball bearing
- 19 Circlip
- 20 Rear brake panel
- 21 Brake shoe - 2 off
- 22 Brake shoe spring - 2 off
- 23 Camshaft
- 24 Cam dust shield
- 25 Brake shoe ball joint
- 26 Cam lever
- 27 Pin
- 28 Spring collar
- 29 Rear wheel spindle



8.2a Remove roller roller. It will fit position.



8.2b ... and withdraw roller piece from bearing.



8.2c Oil seal and bearing may turn for removal.



8.2d If large diameter socket makes removal difficult.



8.4a Detail full bearing and ...



8.4b ... inner hub bearing can be treated similarly.



Tyre removal: Deflate inner tube and insert lever in close proximity to tyre valve



Use two levers to work bead over the edge of rim



When first bead is clear, remove tyre as shown



Tyre fitting: Inflate inner tube and insert in tyre



Lay tyre on rim and feed valve through hole in rim



Work first bead over rim, using lever in final section



Use similar technique for second bead, finish at tyre valve position



Push valve and tube up into tyre when fitting final section, to avoid trapping

10 Rear brake assembly: examination, renovation and assembly

- The rear brake is of the internal expanding variety. Access to the brake shoes is obtained by first removing the rear wheel, and taking off the brake plate to which the shoes are attached.
- Use a punch to mark the original position of the brake arm and the brake operating lever. Remove the plate lock and lever. Remove the drum seal, and the brake shoes, by pulling them up evenly and removing them, along with the brake cam.
- Take off the rear brake shoe return springs. Inspect the brake drum for a scored or warped condition. If the drum is scored or warped slightly, it is possible to have it turned down on a lathe by a specialist machine tool if the scoring is too deep or the average roughness is over replacement is necessary.
- Inspect the brake shoes for excessive wear on wear, or for oil or grease on the linings. If the impregnation is too bad the shoes will have to be replaced with new ones.

The standard measurement for the brake linings is as follows:

Standard thickness	Service limit
4.00 - 5.00mm 37-73 - 37-72mm	2.5mm 35-38mm

- Inspect the brake return springs for a worn, pitted or collapsed condition, and replace them as necessary. The brake return spring has length specifications as follows:

Standard length	Service limit
80.0 - 87.0mm 72-80 - 74-82mm	80.0mm 72-73mm

- Inspect the brake cam and brake plate for signs of wear or damage, and replace if necessary. It cannot be maintained that wear on these parts is critical if full braking efficiency is to be maintained.
- Assemble it in the reverse order of dismantling. Use new lubing tabs and split pins wherever possible, also smear slight amount of grease on the brake cam and pivot pins during assembly, taking care not to get any grease on the brake linings.

11 Rear sprocket assembly: examination, renovation and replacement

- The rear wheel sprocket is held to the wheel by six nuts and three locknuts. To remove the sprocket, bend back the locknuts and undo the nuts. The sprocket needs to be removed only if the teeth are worn, broken or chipped. It is a good policy to change both sprockets at the same time, after the chain, otherwise new rapid wear will develop.
- It is not advisable to size the rear wheel sprocket size or the gearbox sprocket size. The ratios selected by the manufacturer are the ones that give optimum performance with the existing engine power output.

12 Rear curb drive examination and renovation

- The curb drive assembly is contained in the left hand side of the wheel hub. It takes the form of six triangular rubber pads (interlocking slots). These engage with ones on the coupling which is located to the rear sprocket. The rollers engage with slots on the hub and the rubber assembly flexes to shock absorber which permits the sprocket to move within certain limits. This cushioning absorbs any roughness in the transmission which would otherwise cause an impression of harshness.

- The usual sign that shock absorber rubbers are worn is excessive movement in the operation, or rubber dust appearing in between the sprocket and hub. The rubbers should then be taken out and replaced.

13 Rear brake assembly: adjusting

- If the adjustment of the rear brake is correct, the brake pedal will have a travel of 20 mm to 30 mm (0.8 to 1.2 inch). Adjustment is carried out at the end of the operating rod by an adjusting nut.
- It may be necessary to change the height of the stop lamp switch if the pedal travel has been altered in any marked extent. Raise the switch for the stop lamp to operate earlier by turning the adjustment nut clockwise.

14 Front drive-chain examination and lubrication

- As the front drive chain is fully exposed on all models it requires lubrication and adjustment at regular intervals. To adjust the chain, take out the split pin from the rear wheel sprocket and loosen the sprocket nut. Loosely turn the torque arm bolt, and leave the bolt in position, slacken the chain adjuster locknuts and turn the adjuster (inwards to tighten the chain, or outwards to slacken the chain).
- Chain tension is correct if there is 20 to 40 mm (about 1 1/2 inch) slack measured at the centre of the bottom run of the chain between the two sprockets.
- Do not run the chain too tight to try to compensate for wear, or it will absorb a surprising amount of engine power. Also it can damage the gearbox and rear wheel bearings.
- All models are equipped with endless chains, having 'O' rings at the end of each pin to retain the grease used during assembly. It is not possible to remove the chain for full lubrication in 1 1/2 litre or 1 1/2 quart as with normal chains. Lubrication is therefore restricted to frequent cleaning and lubrication with special chain lubricant.
- Chain wear can be assessed by stretching the chain fast by means of the chain adjuster, and measuring a 20-link section. The measurement should be made between 2 1/2 pin centres. This length should normally be 117.5 mm (4 5/8 in). It works to 120 mm (4 3/4 in) or more, the chain must be renewed.
- Removal of the rear chain for several consecutive days the national of the rear wheel and coupling arm assemblies, as described in Chapter 5, Section 5. Once the coupling arm has been removed the chain may be lifted off the gearbox sprocket. When fitting a new chain, ensure that the gearbox and rear wheel sprockets are in good condition.



Fig. 13 Adjust rear brake by way of the adjuster nut

18 Year, manual and experience

1. An hour later it took the test and went to complete the

preparation and maintenance a further year, but it

was a year later that the engine was the engine, and the

engine was the engine, and the engine was the engine

2. To avoid the risk of engine failure, the engine was

and when the test was completed, the test was the test

3. Once a test was done, the test was the test, and the

4. Once the test was done, the test was the test, and the

5. Once the test was done, the test was the test, and the

18.4 Check valve on high speed and low speed



18.5 Pressure indicator valve (pressure gauge) with



18.1 Keep engine temperature during engine adjustment



around the wall of the tyre on both sides, which should be an equal distance from the wheel rim at all points. If the tyre is unevenly inflated on the rim, by loosening the wheel when the tyre is at the recommended pressure, it is probable that one of the beads has not pulled round of the centre wall.

14. Always use the force at the recommended pressure and never under- or over-inflate. The correct pressure for SUVs can be given in the Specifications Section of this Chapter.

15. Tyre replacement is aided by cleaning the axle nuts, particularly in the vicinity of the beads, with a liberal coating of french chalk. Wiping up liquid can also be used to good effect, but this has the disadvantage of causing the inner surface of the wheel rim to rust.

16. Never replace the inner tube and tyre without the rim type in position. If this precaution is overlooked there is a good chance of the ends of the spoke nipples chafing the inner tube and causing a snag or puncture.

17. Never fit a tyre that has a damaged bead or sidewall. Apart from legal aspects, there is a very great risk of a blowout, which can have very serious consequences on a two-wheeled

vehicle.

18. Tyre valves rarely give trouble, but it is always advisable to check whether the valve (nut) is leaking before removing the tyre. Do not forget to fit the dust cap, which forms an effective extra seal.

19. Valve valves and bearings

1. Inspect the valves in the inner tubes from time to time making sure that the seal and spring are making an effective seal. There are tyre valve tools available for clearing damaged threads in the valve body, and incorporating thread clearing for the outside thread of the body. A key is also incorporated for tightening the valve lock.

2. The valve lock prevents dirt and foreign matter from entering the valve, and also forms an effective second seal so that in the event of the tyre valve sitting, air will not be lost.

3. Note that when a dust cap is fitted for the first time to a standard wheel, the wheel may have to be rebalanced.

17 Fault diagnosis

Symptom	Cause	Remedy
Handlebars wobble at low speed	Buckle or fit to wheel rim, most probably from wheel Tyre not straight on rim	Check the alignment by spinning wheel. Correct by tensioning spokes or re-bulding on new rim. Check tyre alignment.
Machine lacks power and accelerates poorly	Rear brake binding	Warn brake drum/pedal/line system. Re-adjust brake.
Rear brake grabs when applied gently	Ends of brake shoes un-chamfered Blighted brake drum	Sharpen with file. Lightly skim in lathe (specialist attention required).
Rear brake feels spongy	Air in hydraulic system	Bleed brake.
Brake pull-off sluggish	Brake cam binding in housing Weak brake shoe springs Blinking pistons in brake caliper	Free and grease. Renew if springs have not become stretched. Overhaul caliper unit.
Handlebar wobble	Worn or badly adjusted final drive chain Flexed or badly worn spokes Worn or deteriorating rear drive system	Adjust or renew, as necessary. Renew as a pair. Renew system.

Chapter 6 Electrical system

Contents

General description	1	Stop and lamp light, replacing the bulbs	12
Crankshaft alternator (checking the output)	2	Flashing indicator entry and lamps	
Alternator (checking the armature and field coils)	3	Location and replacement	13
Voltage regulator (location and replacement)	4	Spares and accessories (replacing the bulbs)	14
Voltage regulator operating principle and testing	5	Fuse location and adjustment	15
Battery (examination and maintenance)	6	Wiper motor location and adjustment	
Battery (charging procedure)	7	Wiper motor switches, ignition and lighting switches	
Fuses, location and removal	8	Wiper motor and replacement	16
Starter motor, removal, examination and replacement	9	Stop lamp switches, adjustment and replacement	17
Starter solenoid switch, function and location	10	Engine oil pressure switch, removal and replacement	18
Headlamp (replacing bulbs and adjusting beam light)	11	Fast diagnostic electrical system	19

Specifications

Battery

Make
Type
Voltage
Capacity
Term

Name
Volts	12
Capacity	60 Ah
Polarity	Negative

Alternator

Make
Model
Type

Wipac Densu
400100
3-phase

Starter motor

Make
Type

Mitsuba
5AM-1040

Headlamp

UK and Europe
USA

12V-45/45W bulb (low)
12V-55/55W sealed beam

Bulbs

Stop/lamp
All stop/lamp
Indicator
Non-parking lamp

L6 12V 52/54, L6 12V 62/74
12V 54W
12V 21W (UK); 12V 12W (EU)
12V 55W (USA)

Horn

12V 2.5 amp
-------------	-------

1 General description

The Kawasaki 2500 models are equipped with a 12 volt negative 10 earth electrical system. The system comprises a crankshaft-mounted or belt-driven current generator of the 3-phase type, the output of which is governed by an electronic voltage regulator to match the electrical demand. A voltage regulator is incorporated in the circuit to convert the current to its direct current so it can be used to charge the battery.

2 Crankshaft alternator (checking the output)

1. The alternator generates the current required by the machine's electrical circuits; the output is three phase alternating current (AC). The output is changed to direct current (DC) by the rectifier, the voltage being controlled by the voltage regulator. The alternator consists of a rotor and stator. Permanent magnets supply the magnetic field of the rotor, so that no slip rings or brushes are necessary. This makes the rotor practically maintenance free. The stator consists of three

sets of coils wound on laminated steel cores. The coils are connected in a Y pattern, so that there is always a smooth, ample supply of current available.

2 To check the output of the alternator, the battery and wiper/brush lead must first be tested so that they are known to be good. If the battery shows less than the required 12 volts it should be fully charged.

3 Remove the left hand side panel, and disconnect the brown and green leads from the regulator. Connect the two leads together, ensuring that they cannot short against the frame by wrapping them with insulating tape. Untighten the nut and disconnect the negative (-) battery lead. Obtain a 0-50 amp ammeter, and connect the negative (-) terminal of the ammeter to the negative (-) battery lead, and the positive (+) terminal to the battery positive terminal (+). This, in effect, means that the changing current must pass through the alternator.

4 To prevent damage to the ammeter, make up a bypass lead with a short (about 6 in) of each end, and connect this to a bridge between the ammeter terminals. Obtain a 0-20 volt dc voltmeter, and connect the positive (+) terminal to the positive (+) battery terminal, and the negative (-) terminal to the negative (-) battery terminal.

5 Use the voltmeter to start the engine (use the electric starter, as this will overcome the resistance). Set the heading on main beam, and switch it on. Disconnect one end of the bypass lead, and note the readings of the two meters at 4000 rpm. These should be in the region of 15 volts and 2 amps. If the readings differ greatly from these figures, it is likely that the alternator is defective. This can be confirmed by taking structure and field coil resistance measurements as described in Section 8.

3 Alternator - checking the armature and field coils

1 If the alternator is suspect, the armature and field coil resistances should be checked, using a multimeter set in the ohms, or ohms, setting.

2 Disconnect the 4-pin alternator output lead connector, and measure the resistance between each pair of the three yellow leads, a total of three readings. These must be between 2.4 - 2.8 ohms. If greatly different from this, remove the unit and take it to a Kawasaki Service Agent for verification and repair. Similar action should be taken if a measurement between each of the yellow leads is low, and zero, shows anything other than perfect insulation.



3.2a Stator and field coil winding are housed in outer cover

3 Disconnect the green lead from the alternate field coil, and test the resistance between it and earth. The reading must be between 2.1 and 2.4 ohms, a lower reading indicating a short circuit, and a higher reading denoting an open circuit.

4 Diode rectifier location and replacement

1 The silicon rectifier fitted to the electrical system converts the ac current produced by the alternator to dc so that it can be used to charge the battery.

2 The rectifier is mounted on the underside of the battery cover, and is retained by a single mounting nut.

3 The rectifier is a component that cannot be repaired, and if found faulty it has to be replaced with a new unit. Damage to the unit can be caused by running the machine without a battery or if the battery leads are accidentally swapped.

4 The six-diode arrangement (two diodes for each of the alternator's three output phases) is used to convert ac current into dc current for battery charging, ignition, lighting, and horn circuits. The diodes in the rectifier can only conduct current from negative to positive, and therefore they convert ac to dc. If the rectifier or diodes become faulty they will conduct current either in both directions, or not at all, and therefore lead eventually to a discharge problem.

5 The rectifier can be tested with an ohmmeter. First disconnect the white rectifier plug from the connector panel, and the white lead going to the battery. With the meter set on the R x 10 and R x 100 range, check the resistance between the white rectifier lead and each of the yellow leads, the yellow leads and the white lead, the black lead and each of the yellow leads, and the each yellow and black lead. This involves a total of twelve measurements. The resistance should be low in one direction, and about ten times as great in the other direction. If the readings are the same in either direction for any pair of wires, the rectifier is faulty and should be replaced. The lower reading should be within the 2 ohm range, regardless of the type of meter used.

6 **Note** When removing or installing the rectifier, do not loosen or try to tighten the main assembly nut of the rectifier, as this is part of the assembly and should not be disturbed. If disturbed, damage can be caused to the white rectifier assembly and under it causes. When fitting a new replacement take great care not to disturb the coating over the sockets, which may cause or lead to a battery warning condition.



3.2b Rear to top view of rectifier assembly and nut



8.2 Battery unit is retained to underside of battery tray

8 Voltage regulator : operating principle and testing

1 The voltage regulator fitted to the 2000 model is of the electro-mechanical type. Its function is to handle the power output from the three phase generator, and to limit the voltage to 15-16 volts. It is constructed to control each of the three phases of the alternator output.

2 Two systems which would indicate the possibility of a faulty regulator are repeated battery discharging or failure recharging. A battery recharged is indicated by the need to top up the electrolyte more frequently than is normal, and also by blowing bulbs in the lighting system when running at high rpm.

3 Discharging of the battery more excessively than is normal is indicated by a battery that when checked each day, but goes dead quickly after being fully charged.

4 If symptoms of malfunctioning, the regulator operator may be checked using a voltmeter or multimeter set to 20v dc. Before the headlight unit, and separate the right connector block, then holding the engine at 2000 rpm and switching the beam on the alternator. Ensure that all the lights are on switched off.

5 Carry out the following in the battery, positive to positive (+) to (+), and negative to negative (-) to (-). Start the engine, and gradually bring the speed up to 1800 rpm, at which point the meter should indicate 14-15 volts, without backing the throttle off at any point, gradually bring the engine speed up to 3000 rpm. Do not account for the speed drop slightly, and then slow again, as this will affect the reading. The speed must be increased smoothly from 3000, and the two readings noted. If the throttle is released instantaneously after the first reading, go back to 1800 rpm and start the test again. At the second reading point of 3000 rpm, the voltage indicated should still be 14-15 volts, unless the regulator is defective.

6 If the regulator is suspect, it is recommended that the machine be taken to a Kawasaki Service Agent, or any attempt to test or adjust the unit will invalidate the warranty. An authorized Agent will have the equipment and skill necessary to test the unit and effect a repair or adjustment.

8 Battery: examination and maintenance

1 The Kawasaki 2000 models are equipped with a 12 volt 12 amp hour battery. The battery is retained by a rubber strap in a compartment beneath the dashboard. The battery has a translucent plastic case, making a quick visual check of the electrolyte level possible, the two lines marking the upper and lower levels.

2 The level of the electrolyte in the battery should never be allowed to fall below the lower level water mark. If it does, it must be topped up with distilled water to the upper level, after the correct fill with sulphuric acid of a specific gravity of 1.260 to 1.280. Also make sure the vent caps is loose through the paper channel provided to ensure that it discharges heat of the frame parts.

3 It is not possible to repair a cracked battery case because the acid that is already established in the cracks will prevent the formation of an effective seal. A cracked battery should be removed at once because apart from a deterioration in efficiency there will be a considerable amount of hydrogen if extended continuous use.

4 The battery should be checked every month, and topped up when necessary to the upper electrolyte level. When the machine is left up for any length of time, it is always advisable to remove the battery and give it a recharge charge every four or six weeks, using a battery charger. Once a battery has been put into service filled with acid it must be kept in use, otherwise the electrolyte will sulphate and render it useless.

7 Battery: charging procedure

1 The normal charging rate for batteries of up to 18 amp hour capacity is 1/10 to 2/10 amp. It is permissible to charge at a more rapid rate in an emergency but the duration of the life of the battery, and should be limited. Always remove the vent caps when recharging the battery, otherwise the gas created while the battery when charging takes place will explode and burst the case with disastrous consequences.

8 Fuses: location and removal

1 The electrical system is protected by two 10 amp and one 20 amp fuses, located in a plastic case fitted beneath the right hand side panel. The fuses are located to prevent damage to the electrical components in the event of an over-load or short circuit.

2 If the fuse blows it should not be reinserted until the cause of the short is found. This will involve checking the electrical circuit to correct the fault. If this rule is not observed, the fuse will almost certainly blow again.

3 When a fuse blows and no spare is available a 100 watt lamp, already in the case, can be used as a spare before replacing it in the fuse holder. This spare lamp will remain lit until extinguished by cooling the battery wires under the fuse. Replace the damaged fuse in the carriage immediately to restore full circuit protection. When a spare short circuit is eliminated first.

4 Always cover the spare fuses of the correct ratings.



8.3 A Fusebox ready for greater protection. (A) Regulator unit.



8.4 Separate connector block to isolate lighting circuit



8.1 Battery is housed in compartment between the stator and



8.1 Fuse box is mounted between right-hand side panel

3 Starter motor: removal, examination and replacement

1 An electric starter motor, operated from a small push-button on the right-hand side of the fanhousing, provides an alternative and more convenient method of starting the engine, without having to use the kickstart. The starter motor is mounted within a compartment at the rear of the cylinder block, covered by a rectangular aluminium plated cover. Current is supplied from the battery via a heavy duty electrical switch and a cable capable of carrying the very high current demanded by the starter motor on the initial start-up.

2 The starter motor drives a free wheel type clutch, which is incorporated in the secondary shaft assembly. Maintenance of the clutch assembly is covered in Chapter 7, Section 21. The clutch assembly starts the motor (this is disconnected from the primary transmission immediately the engine starts). It operates on the centrifugal principle, spring loaded, which takes up the drive until the centrifugal force of the rotating engine overcomes their resistance and the drive is automatically disconnected.

3 To remove the starter motor from the engine unit, first disconnect the positive lead from the battery, then the starter motor cable from the solenoid switch. Remove two bolts in the aluminium plated cover (use the starter motor housing and lift away the cover, complete with gasket). The starter motor is secured to the combustion fan bolts which pass through the left hand end of the motor casing. When these bolts are withdrawn, the motor can be tilted out of position and lifted out of its compartment, with the heavy duty cable still attached. Once the starter motor has been removed, the starter motor cable may be detached.

4 The parts of the starter motor most likely to require attention are the brushes. The end cover is retained by two long screws which pass through the top cast on both end plates. If the screws are withdrawn, the end cover can be lifted away and the brush-gear exposed.

5 Lift up the spring clips which bear on the end of each brush and remove the brushes from their holders. Each brush should have a length of 10.5 - 13.8 mm (0.41 - 0.51 in). The minimum allowable brush length is 9 mm (0.354 in). If the brush is shorter it must be replaced.

6 Before the brushes are replaced, make sure that the commutator is clean. The commutator is the copper segments to which the brushes bear. Clean the commutator with a strip of glass paper. Never use emery cloth or 'wet or dry' paper as the small abrasive fragments may embed themselves in the soft brass of the commutator and cause excessive wear of the brushes. Polish off the commutator with moist polish to give a smooth surface and finally wipe the segments over with a chlorinated spirit soaked rag to remove a greasy film surface. Check that the ring is evenly, within the tolerance the equipment of the commutator, are uniform. The standard groove depth is 0.5 - 0.8 mm (0.02 - 0.03 in), but if the average groove depth is less than 0.2 mm (0.008 in) the structure should be renewed or returned to a Kawasaki dealer for re-cutting.

7 Replace the brushes in their holders and check that they slide quite freely. Make sure the brushes are replaced in their original positions because they will have worn to the profile of the commutator. Replace and tighten the end cover, then replace the starter motor and cable in the housing, tighten down and remake the electrical connection to the solenoid switch. Check that the starter motor functions correctly before replacing the compartment cover and sealing gasket.




Fig. 8.1 Barber motor - component parts

- | | | |
|-------------------------|--------------------------|-----------------------|
| 1 Barber motor cover | 20 O-ring | 31 Nut - 2 off |
| 2 Barber motor gasket | 21 O-ring | 32 Allen-bolt - 3 off |
| 3 Nut - 2 off | 22 O-ring | 33 Nut |
| 4 Barber motor assembly | 23 O-ring | 34 Flange nut |
| 5 O-ring | 24 Barber motor cable | 35 Motor |
| 6 Shim - as required | 25 Rubber liner | 36 Motor seal/lock |
| 7 Motor washer | 26 Nut - 2 off | 37 Allen-bolt - 3 off |
| 8 Carbon brush - 2 off | 27 Spring washer - 4 off | 38 Washer - 2 off |
| 9 Brush spring - 2 off | 28 Screw - 2 off | |



6.3 Starter motor lowered by new mounting bolts



6.4 Disposed spring to release/breaker from holder



6.6 Check and clean the commutator surface



6.7 It is easier to measure the cable prior to installation

10 Starter solenoid: switch, function and location

1 The starter motor switch is designed to work on the electro-magnetic principle. When the starter motor button is depressed, current from the battery passes through windings in the switch solenoid and generates an electro-magnetic force which causes a set of contact points to close, immediately the points close, the starter motor is engaged and a very heavy current is drawn from the battery.

2 This arrangement is used for at least two reasons. Firstly, the starter motor current is drawn only when the button is depressed and is cut off again when pressure on the button is released. This ensures minimum drainage on the battery. Secondly, if the battery is in a fair state of charge, there will not be sufficient current to cause the solenoid contacts to close, in consequence, it is not possible to place an excessive drain on the battery which, in some circumstances, can cause the plates to overheat and shed their coating. If the starter will not operate, first suspect a discharged battery. This can be checked by using the horn or switching on the lights. If this check shows the battery to be in good shape, suspect the starter solenoid which should come into action with a pronounced click. It is located behind the left-hand side panel and can be identified by the heavy duty starter cable connected to it. It is not possible to effect a satisfactory repair if the solenoid malfunctions; it must be

replaced.

11 Headlamps: replacing bulbs and adjusting beam height

1 In order to gain access to the headlamp bulbs remove the rim, this is retained by two screws behind the rim. The rim can now be pulled off with the reflector unit complete and the pilot bulb removed.

2 Disconnect the headlamp bulb adaptor from the sealed beam unit and remove the lens retaining ring. The main bulb can now be removed.

3 The adjust headlight beam height, slanting the two turn signal mounting nuts inside the headlamp shell, lower the mounting bolts underneath the lamp and adjust the vertical aim of the unit to the required position.

4 Adjust the horizontal (left to right) aim of the light by turning the small cross-hatched screw situated directly in front of the rim. Screwing the screw towards the right steers the beam to the right and screwing out moves the beam to the left. On European models the headlamp lens and bulb is of the pre-focus type, on USA models the headlamp lens and bulb are a sealed unit, and the adjust unit has to be replaced in the event of light failure. For the beam-height adjust the machine on a level surface 20 feet from a wall so that the centre of the light spot is the same distance as that from the centre of the headlamp to the ground.



Fig. 6.12. Reconnect the bulb to the vehicle wiring harness.



Fig. 6.13. Re-attach the headlight to the car body.



Fig. 6.14. The bulb must be electrically earthed through the metal bracket.



Fig. 6.15. UK vehicles have both earths. UK vehicles also require a fuse.



Fig. 6.16. The bulb must connect to the earth adjustment.

Fig. 6.17. Stop and start lamp, replacing the bulb.

1. The LED lamp fitted to the 2020 models has a double filament bulb. One lights the rear lamp and the other indicates when the brakes are applied. The brake light is operated by either the foot or the hand lamp switch. The foot brake switch is an auxiliary pressure switch, installed in the foot operation brake line. It operates when foot brake pressure is applied. The rear brake switch is operated by the rear brake pedal. The stop lamp is activated by either its own filament or the auxiliary filament.

2. Remove the two long screws that retain the rear lamp lens. The bulb can be removed by pulling it out at the same time working in an anti-clockwise direction. Replace the bulb by reversing the procedure. The bulb has to be mounted in order the red lamp or brake light filament faces out. After the bulb is replaced, make sure the mounting gaskets is in good condition and rechecked.



12.13 Indicator and relay wiring harness is easily accessed by the battery



12.15 Check indicator headlights for incorrect wiring

12 Replacing indicator relay and fuses – location and inspection

- 1 The fusing indicator relay is fitted in the same electrical panel as the engine stopper and wipers, unless the alternator on the right-hand side of the engine. It is mounted in either the engine compartment or the boot (see Chapter 12).
- 2 The fuses indicator relays are fitted to the left and right of the indicator on 'winker' through arms that extend each side across the battery frame (see also above text). To inspect and replace the fuses, type bulbs, these are single filament with a rating of 12 volt 15 watt. Make sure the rubber gaskets on the base of the lens are in good condition and resealed, when replacing the lens.
- 3 See Specifications.

14 Replenishing and restoring – replacing the bulbs

- 1 The bulbs that fit the headlights and dash panel are of the small filament type, single 12 volts, 35 watt.
- 2 The correct replacement bulbs are available from the nearest motor factor. The bulbs are marked with the bulb of the panel and relay rating (see Chapter 12).

16 Horn location and adjustment

- 1 The horns is adjustable by means of the screw screws located at the base of the horn, situated at the top of the horn frame (see Fig. 12.16). To adjust the volume, turn the screw about half a turn either way until the desired tone is achieved.
- 2 It is necessary to determine the tone to stop the horn. The correct way to test horn volume (H.V.) after any fine tune has been set is to use a sound meter (H.V.) after any fine tune has been set. It need be measured, ideally for the horn's volume right for measuring air-pollution contributing.

18 Headlights, indicators, parking and lighting switches – maintenance and replacement

- 1 The headlight switches are made up of two halves that snap together with great compliance forces. They are adjusted

underneath the steering assemblies. The switches seldom give any trouble, and it is not necessary to take them apart as the unit fits in so neat that adjustment and cover fitting themselves, with a little care and attention. The switch tends to be better with a little oil on the contact points. This is applied simply with the spray as fitted into some connections.

2 The main ignition switch is located in the centre of the dash panel and is accessed by depressing the ring and moving the handle of the switch. The main panel can often be removed. Take all the main light and headlight and together with the fuel tank pump and ignition the vehicle, leave away and the mounting unit. The ignition switch can now be removed by removing the nuts.

3 When replacing the ignition switch, the vertical slot of the headlight switches body indicates into slot but the left side has separate one plate in the green wire, and the right side has right side integrated the red-green wire.

19 Stop lamp switches – adjustment and replacement

- 1 The rear brake stop lamp switch is located in a bracket above the rear brake pedal and is operated by an integral linkage mechanism. The stop lamp switch is of the variable inductive type and is set to an interval.
- 2 If the stop lamp stop lamp is not in operation, check the two terminals across the switch body, when the adjustment is correct replace the bulb and test. If the stop lamp is early in operation, check the solenoid across the body is related to the bracket.
- 2 As a guide the lights should come on when the rear brake pedal has been depressed about 3 cm (1 in).
- 3 The bracket frame under stop switch, operates the same bulb to give off light at the rear brake pedal. The bulb will give adjustment of the stop lamp is not possible, it is the only switch can be replaced. The complete switch can be removed after the body's system has been opened from the stop very front's plate attached underneath the dashboard. When a stop lamp's pressure switch is installed it will be necessary to add and bleed the hydraulic brake system as described in Chapter 11, Section 3.




Fig. 8.2 Speedometer and tachometer assembly

- 1 Speedometer assembly
- 2 Tachometer
- 3 Lock nut
- 4 Instrument-temp cover
- 5 Washer
- 6 Gasket - 4 oil
- 7 Rubber - 4 oil
- 8 Wash washer - 4 oil

- 9 Spring washer - 4 oil
- 10 Nut - 4 oil
- 11 Spacer assembly
- 12 Nut - 10 oil
- 13 Cover
- 14 Spring washer - 5 oil
- 15 Gasket - 5 oil
- 16 Lock nut

- 17 Tachometer cover
- 18 Nut - 2 oil
- 19 Spring washer - 2 oil
- 20 Wash washer - 2 oil
- 21 Gasket - 4 oil
- 22 Ignition switch
- 23 Key set
- 24 Ignition switch holder



12.2 Russian helmet and single Russian eye



12.3a Russian helmet, chest, and Russian eye on side



12.2b It may prove necessary to follow commander's eye to get clearance



12.3b Both helmet and a guide to the instrument panel



15.7 From the instrument panel, placing face assembly



15.1a Russian stations are compared on either side ...



18.16 ... of the ventilator.



18.17 Switch body is adjustable by way of nut and lockwasher.

78 Engine oil pressure switch: removing and replacement


7 The oil pressure switch is mounted inside the contact breaker housing. The oil pressure switch serves to indicate when the oil pressure has dropped due to pump failure, blockage in an oilway or too little oil available to the oil pump. It is not however intended to be used as an indicator of correct oil level. If the oil pressure lamp located in the dash panel comes on and stays on when the oil is hot and the machine is being rapidly accelerated, the fault is probably the switch, this can sometimes be corrected by raising the engine up past 3000 rpm for a second or two but if this does not put the light out, disconnect the three wires from the oil pressure sensor and remove the switch. When installing a new switch coat the thread with a sealer to form an airtight seal. **MAKESURE IT IS THE SWITCH AT FAULT BEFORE USING THE MACHINE. A GENUINE LUBRICATION PROBLEM WILL CAUSE SEVERE ENGINE DAMAGE.**



18.18 Oil pressure switch is located inside contact breaker housing.

1B Fault diagnosis: electrical system

Symptom	Cause	Remedy
Complete electrical failure	Blown fuse Weak/battery	Check wiring for loose connections before fitting a new fuse. Check battery connections for signs of corrosion.
Constant blowing of fuses	Wiresafe or poor earth connections	Check bulb holders, check earth cable connections
Dim lights, horn and starter do not work	Discharged battery	Recharge battery with a battery charger. Check generator for output.
Starter motor sluggish or will not work	Worn brushes	Remove starter motor and replace with new brushes.
Flashing lights will not flash	Faulty relay unit Bad earth.	Check connections Replace with a new relay unit. Check flasher lamp bulb holders for good earth.



Right Headlight Switch Connection

Color	Headlight Switch	Starter Switch	Engine Stop Switch
OFF	ON	ON	OFF
ON	OFF	OFF	ON

Ignition Switch Connections


Color	Battery	Ignition	Tail 1	Tail 2
OFF	ON	ON	Blue	Red
ON	OFF	OFF	Brown	Blue

Left Headlight Switch Connections

Color	Peering Switch	Starter Lockout Switch	Turn Signal Switch	Horn Button
ON	ON	ON	Green	Black
OFF	OFF	OFF	Blue	Black

Wiring diagram Z650 model (UK)

Other model except European model (286-0)



Wiring diagram KZ650 model (USA)

Metric conversion tables

Inches	Decimals	Millimeters	Millimeters to Inches		Inches to Millimeters	
			mm	Inches	Inches	mm
1/64	0.015625	0.3969	0.25	0.009843	0.004	0.10254
1/32	0.03125	0.7927	0.50	0.019685	0.008	0.20508
3/64	0.046875	1.1885	0.75	0.029528	0.012	0.30762
1/16	0.0625	1.5843	1.00	0.039370	0.016	0.41016
5/64	0.078125	1.9801	1.25	0.049213	0.020	0.51270
3/32	0.09375	2.3759	1.50	0.059056	0.024	0.61524
7/64	0.109375	2.7717	1.75	0.068898	0.028	0.71778
1/8	0.125	3.1675	2.00	0.078741	0.032	0.82032
9/64	0.140625	3.5633	2.25	0.088584	0.036	0.92286
5/32	0.15625	3.9591	2.50	0.098426	0.040	1.02540
11/64	0.171875	4.3549	2.75	0.108269	0.044	1.12794
3/16	0.1875	4.7507	3.00	0.118111	0.048	1.23048
13/64	0.203125	5.1465	3.25	0.127954	0.052	1.33302
7/32	0.21875	5.5423	3.50	0.137797	0.056	1.43556
15/64	0.234375	5.9381	3.75	0.147639	0.060	1.53810
1/4	0.25	6.3539	4.00	0.157482	0.064	1.64064
5/16	0.3125	7.9250	4.50	0.177225	0.072	1.82880
3/8	0.375	9.5161	5.00	0.196968	0.080	2.03700
7/8	0.875	22.2263	7.50	0.296711	0.120	3.04800
1 1/8	1.125	28.7375	10.00	0.393701	0.160	4.06400
1 1/4	1.25	31.75	12.50	0.491291	0.200	5.08000
1 3/8	1.375	34.7613	15.00	0.588882	0.240	6.09600
1 1/2	1.5	38.125	17.50	0.686473	0.280	7.11200
1 5/8	1.625	41.1458	20.00	0.784064	0.320	8.12800
1 3/4	1.75	44.1475	22.50	0.881655	0.360	9.14400
1 7/8	1.875	47.1492	25.00	0.979246	0.400	10.16000
2	2.0	50.8	27.50	1.076837	0.440	11.17600
2 1/8	2.125	53.975	30.00	1.174428	0.480	12.19200
2 1/4	2.25	57.15	32.50	1.272019	0.520	13.20800
2 3/8	2.375	60.325	35.00	1.369610	0.560	14.22400
2 1/2	2.5	63.5	37.50	1.467201	0.600	15.24000
2 5/8	2.625	66.675	40.00	1.564792	0.640	16.25600
2 3/4	2.75	69.85	42.50	1.662383	0.680	17.27200
2 7/8	2.875	73.025	45.00	1.760000	0.720	18.28800
3	3.0	76.2	47.50	1.857600	0.760	19.30400
3 1/8	3.125	79.375	50.00	1.955191	0.800	20.32000
3 1/4	3.25	82.55	52.50	2.052782	0.840	21.33600
3 3/8	3.375	85.725	55.00	2.150373	0.880	22.35200
3 1/2	3.5	88.9	57.50	2.247964	0.920	23.36800
3 5/8	3.625	92.075	60.00	2.345555	0.960	24.38400
3 3/4	3.75	95.25	62.50	2.443146	1.000	25.40000
3 7/8	3.875	98.425	65.00	2.540737	1.040	26.41600
4	4.0	101.6	67.50	2.638328	1.080	27.43200
4 1/8	4.125	104.775	70.00	2.735919	1.120	28.44800
4 1/4	4.25	107.95	72.50	2.833510	1.160	29.46400
4 3/8	4.375	111.125	75.00	2.931101	1.200	30.48000
4 1/2	4.5	114.3	77.50	3.028692	1.240	31.49600
4 5/8	4.625	117.475	80.00	3.126283	1.280	32.51200
4 3/4	4.75	120.65	82.50	3.223874	1.320	33.52800
4 7/8	4.875	123.825	85.00	3.321465	1.360	34.54400
5	5.0	127.0	87.50	3.419056	1.400	35.56000
5 1/8	5.125	130.175	90.00	3.516647	1.440	36.57600
5 1/4	5.25	133.35	92.50	3.614238	1.480	37.59200
5 3/8	5.375	136.525	95.00	3.711829	1.520	38.60800
5 1/2	5.5	139.7	97.50	3.809420	1.560	39.62400
5 5/8	5.625	142.875	100.00	3.907011	1.600	40.64000
5 3/4	5.75	146.05	102.50	4.004602	1.640	41.65600
5 7/8	5.875	149.225	105.00	4.102193	1.680	42.67200
6	6.0	152.4	107.50	4.199784	1.720	43.68800
6 1/8	6.125	155.575	110.00	4.297375	1.760	44.70400
6 1/4	6.25	158.75	112.50	4.394966	1.800	45.72000
6 3/8	6.375	161.925	115.00	4.492557	1.840	46.73600
6 1/2	6.5	165.1	117.50	4.590148	1.880	47.75200
6 5/8	6.625	168.275	120.00	4.687739	1.920	48.76800
6 3/4	6.75	171.45	122.50	4.785330	1.960	49.78400
6 7/8	6.875	174.625	125.00	4.882921	2.000	50.80000
7	7.0	177.8	127.50	4.980512	2.040	51.81600
7 1/8	7.125	180.975	130.00	5.078103	2.080	52.83200
7 1/4	7.25	184.15	132.50	5.175694	2.120	53.84800
7 3/8	7.375	187.325	135.00	5.273285	2.160	54.86400
7 1/2	7.5	190.5	137.50	5.370876	2.200	55.88000
7 5/8	7.625	193.675	140.00	5.468467	2.240	56.89600
7 3/4	7.75	196.85	142.50	5.566058	2.280	57.91200
7 7/8	7.875	199.925	145.00	5.663649	2.320	58.92800
8	8.0	203.2	147.50	5.761240	2.360	59.94400
8 1/8	8.125	206.375	150.00	5.858831	2.400	60.96000
8 1/4	8.25	209.55	152.50	5.956422	2.440	61.97600
8 3/8	8.375	212.725	155.00	6.054013	2.480	62.99200
8 1/2	8.5	215.9	157.50	6.151604	2.520	64.00800
8 5/8	8.625	219.075	160.00	6.249195	2.560	65.02400
8 3/4	8.75	222.25	162.50	6.346786	2.600	66.04000
8 7/8	8.875	225.425	165.00	6.444377	2.640	67.05600
9	9.0	228.6	167.50	6.541968	2.680	68.07200
9 1/8	9.125	231.775	170.00	6.639559	2.720	69.08800
9 1/4	9.25	234.95	172.50	6.737150	2.760	70.10400
9 3/8	9.375	238.125	175.00	6.834741	2.800	71.12000
9 1/2	9.5	241.3	177.50	6.932332	2.840	72.13600
9 5/8	9.625	244.475	180.00	7.029923	2.880	73.15200
9 3/4	9.75	247.65	182.50	7.127514	2.920	74.16800
9 7/8	9.875	250.825	185.00	7.225105	2.960	75.18400
10	10.0	254.0	187.50	7.322696	3.000	76.20000
10 1/8	10.125	257.175	190.00	7.420287	3.040	77.21600
10 1/4	10.25	260.35	192.50	7.517878	3.080	78.23200
10 3/8	10.375	263.525	195.00	7.615469	3.120	79.24800
10 1/2	10.5	266.7	197.50	7.713060	3.160	80.26400
10 5/8	10.625	269.875	200.00	7.810651	3.200	81.28000
10 3/4	10.75	273.05	202.50	7.908242	3.240	82.29600
10 7/8	10.875	276.225	205.00	8.005833	3.280	83.31200
11	11.0	279.4	207.50	8.103424	3.320	84.32800
11 1/8	11.125	282.575	210.00	8.201015	3.360	85.34400
11 1/4	11.25	285.75	212.50	8.298606	3.400	86.36000
11 3/8	11.375	288.925	215.00	8.396197	3.440	87.37600
11 1/2	11.5	292.1	217.50	8.493788	3.480	88.39200
11 5/8	11.625	295.275	220.00	8.591379	3.520	89.40800
11 3/4	11.75	298.45	222.50	8.688970	3.560	90.42400
11 7/8	11.875	301.625	225.00	8.786561	3.600	91.44000
12	12.0	304.8	227.50	8.884152	3.640	92.45600
12 1/8	12.125	307.975	230.00	8.981743	3.680	93.47200
12 1/4	12.25	311.15	232.50	9.079334	3.720	94.48800
12 3/8	12.375	314.325	235.00	9.176925	3.760	95.50400
12 1/2	12.5	317.5	237.50	9.274516	3.800	96.52000
12 5/8	12.625	320.675	240.00	9.372107	3.840	97.53600
12 3/4	12.75	323.85	242.50	9.469698	3.880	98.55200
12 7/8	12.875	327.025	245.00	9.567289	3.920	99.56800
13	13.0	330.2	247.50	9.664880	3.960	100.58400
13 1/8	13.125	333.375	250.00	9.762471	4.000	101.60000
13 1/4	13.25	336.55	252.50	9.860062	4.040	102.61600
13 3/8	13.375	339.725	255.00	9.957653	4.080	103.63200
13 1/2	13.5	342.9	257.50	10.055244	4.120	104.64800
13 5/8	13.625	346.075	260.00	10.152835	4.160	105.66400
13 3/4	13.75	349.25	262.50	10.250426	4.200	106.68000
13 7/8	13.875	352.425	265.00	10.348017	4.240	107.69600
14	14.0	355.6	267.50	10.445608	4.280	108.71200
14 1/8	14.125	358.775	270.00	10.543199	4.320	109.72800
14 1/4	14.25	361.95	272.50	10.640790	4.360	110.74400
14 3/8	14.375	365.125	275.00	10.738381	4.400	111.76000
14 1/2	14.5	368.3	277.50	10.835972	4.440	112.77600
14 5/8	14.625	371.475	280.00	10.933563	4.480	113.79200
14 3/4	14.75	374.65	282.50	11.031154	4.520	114.80800
14 7/8	14.875	377.825	285.00	11.128745	4.560	115.82400
15	15.0	381.0	287.50	11.226336	4.600	116.84000
15 1/8	15.125	384.175	290.00	11.323927	4.640	117.85600
15 1/4	15.25	387.35	292.50	11.421518	4.680	118.87200
15 3/8	15.375	390.525	295.00	11.519109	4.720	119.88800
15 1/2	15.5	393.7	297.50	11.616700	4.760	120.90400
15 5/8	15.625	396.875	300.00	11.714291	4.800	121.92000
15 3/4	15.75	399.95	302.50	11.811882	4.840	122.93600
15 7/8	15.875	403.125	305.00	11.909473	4.880	123.95200
16	16.0	406.4	307.50	12.007064	4.920	124.96800
16 1/8	16.125	409.575	310.00	12.104655	4.960	125.98400
16 1/4	16.25	412.75	312.50	12.202246	5.000	126.99600
16 3/8	16.375	415.925	315.00	12.299837	5.040	128.00800
16 1/2	16.5	419.1	317.50	12.397428	5.080	129.02400
16 5/8	16.625	422.275	320.00	12.495019	5.120	130.04000
16 3/4	16.75	425.45	322.50	12.592610	5.160	131.05600
16 7/8	16.875	428.625	325.00	12.690201	5.200	132.07200
17	17.0	431.8	327.50	12.787792	5.240	133.08800
17 1/8	17.125	434.975	3			

1 Imperial gallon = 8 Imp pints = 1.25 US gallons = 277.42 cu in = 4.54 litres

1 US gallon = 4 US quarts = 0.83 Imp gallon = 231 cu in = 3.78 litres

1 Liter = 0.21 Imp gallon = 0.88 US gallon = 61.02 cu in = 1000 cc

Miles to Kilometres

1	1.61
2	3.22
3	4.83
4	6.44
5	8.05
6	9.66
7	11.27
8	12.88
9	14.49
10	16.10
20	32.19
30	48.28
40	64.37
50	80.47
60	96.56
70	112.65
80	128.75
90	144.84
100	160.93

Kilometres to Miles

1	0.62
2	1.24
3	1.86
4	2.49
5	3.11
6	3.73
7	4.35
8	4.97
9	5.59
10	6.21
20	12.42
30	18.64
40	24.85
50	31.07
60	37.29
70	43.50
80	49.71
90	55.92
100	62.14

kg/lb to kg/lb

1	0.454
2	0.908
3	1.362
4	1.816
5	2.270
6	2.724
7	3.178
8	3.632
9	4.086
10	4.540
20	9.080
30	13.620
40	18.160
50	22.700
60	27.240
70	31.780
80	36.320
90	40.860
100	45.400

kg/lb to lb/kg

1	2.205
2	4.409
3	6.613
4	8.817
5	11.021
6	13.225
7	15.429
8	17.633
9	19.837
10	22.041
20	44.082
30	66.123
40	88.164
50	110.205
60	132.246
70	154.287
80	176.328
90	198.369
100	220.410

kg/m² to kg/m²

1	0.07
2	0.14
3	0.21
4	0.28
5	0.35
6	0.42
7	0.49
8	0.56
9	0.63
10	0.70
20	1.41
30	2.11

kg/m² to lb/ft²

1	14.22
2	28.45
3	42.67
4	56.89
5	71.12
6	85.34
7	99.56
8	113.79
9	128.00
10	142.23
20	284.47
30	426.70

Index

A

Adjustment/assembly 2

Adjust this Manual 3

Adjustments—

Control/selector 11

Deflection 72

Clutch 11

Contact breaker 10, 80

Final drive chain 8, 110

Final engine/gearbox assembly 88

Revolving beam height 118

Seat 120

Swivel plate adjustments 15

Base bracket 110

Valve clearance 12

Air cleaner 70

Aspirator 118

Automatic timing unit 84

B

Battery charging/operation 118

Balancing drive shafts 112

Beefing—

Engine 28

Man 28

Beaming head 88

Wheel—

Front 104

Rear 104

Beeding the hydraulic system 100

Brakes—

Front disc 100, 102

Jack 102

Main cylinder 102

Pusher—rear table 87

Rear drum 100

Bulk—replacement—

Filter 120

Hydraulic 118

Specifications and sealometer 120

Strap and roll 118

Burrs—

Score parts 7

Tools 68

C

Carburetors

Adjustment 70

Disassembly and assembly 68

Idle diagnosis 78

Idle height adjustment 70

Removal 60

Settings 72

Specifications 64

Synchronization 70

Control selector 11, 38

Clutch—

Clutch 11, 80

Lubrication 10

Speedometer and tachometer 88

Tools—80, 85, 87

Clayton containers—

1 Engine, clutch and gearbox 17

2 Fuel system and accessories 64

3 Ignition system 78

4 Frame and forks 87

5 Wheels, brakes and tires 100

6 Electrical system 112

Clutch—

Charging system 110–114

Clutch 80

Contact breaker points 10, 80

Clutch 81

Engine/gearbox oil level 81

Control 84

Hydraulic fluid level 8

Ignition timing 10, 84

Legal 10

Oil pressure 74

Rally 18

Spark plug—gap setting 104

Tire pressure 8, 15

Wax clearance 12

Wheel spacers 12

Control valve 87

Clearing—

Air intake element 12

Contact breaker 10

Final drive shaft 8

The machine 88

Clutch—

Adjustment 11

Clutch 11, 80

Clutch 80

Examination and renovation 40

Multi-diagnosis 80

Removal 23

Rebuilding 81

Slip 84

Specifications 10

Clutch—

Control/selector 38

Final drive 110

Cells—

Ignition 80

Control 80

Contact/point 28

Contact breaker 80

Consoles/forks—

Rebuilding 28

Setting 68

Control/selector 37–40

Cush drive—rear wheel 110

Cylinder block 23–30

Cylinder head 22, 38

D

Decarbonizing 20

Decorations—general—

Electrical system 112

Engine, clutch and gearbox 17

Frame and forks 87

Fuel system 64

- Ignition system 78
 - Lubrication 88
 - Wheels, brakes and tyres 100
- Dimensions and weights 8**
- Front axle - fork wheel 112
 - Subframe - removal 81
- E**
- Electrical system-**
- Alarm 112
 - Battery 115
 - Fault diagnosis 124
 - Flashing indicators 120
 - Fuse location 118
 - Headlamp 118
 - Horn 120
 - Lamps 118, 119
 - On-board power 122
 - Signal receiver 114
 - Specifications 112
 - Starter motor 118
 - Switches - handlebar 120
 - Switch - power 118
 - Voltage regulator 118
 - Wiring diagrams 120-122
- Engine-**
- Camshaft - tappets and drive mechanism 38
 - Clutch removal 23
 - Connecting rod 29
 - Camshaft bearing adjustment 31
 - Crankshaft 31-48
 - Crankcase bottom-
 - Drumming 25
 - Loosening 49
 - Cylinder block 22, 33
 - Cylinder head 22, 29
 - Decomposing 22
 - Disassembly - general 22
 - Inspection and reassembly - general 23
 - Fault diagnosis 45
 - Final assembly and adjustment 52
 - Gudgeon pin 23, 52
 - Lubrication system 65, 72
 - Oil pump-
 - Removal 24
 - Refitting 48
 - Oil seals 22
 - Pistons and rings 22-23
 - Reassembly 45
 - Refitting to frame 68
 - Removal from frame 20
 - Specifications 17, 18
 - Starting and running a subunit 63
 - Tappets 38
 - Valve - correct settings 19
 - Valve grinding 24
- F**
- Fault diagnosis-**
- Clutch 62
 - Electrical system 124
 - Engine 63
 - Frame and forks 82
 - Fuel system 78
 - Gearbox 62
 - Ignition system 64
 - Lubrication system 78
 - Wheels, brakes and tyres 112
- Flare-**
- Air 72
 - Oil 78
- Final drive chain 8**
- Forks 87**
- Frame and forks-**
- Centre stand 87
 - Subframe - removal 81
 - Fault diagnosis 88
 - Fork shaft 87
 - Fork tubes 87
 - Fork examination and reassembly 82
 - Fork fork legs-
 - Disassembly, reassembly and reassembly 82
 - Removal and replacement 82
 - Prop-rod 87
 - Rear brake pedal 87
 - Rear suspension units 87
 - Shock absorber and forkometer heads and drive 88
 - Steering head bearing 88
 - Steering head nut 88
 - Steering arm fork 88
- Front wheel 120, 124**
- Fuel system-**
- Carburettor-
 - Adjustment 72
 - Disassembly and reassembly 68
 - Fuel level height 72
 - Settings 72
 - Synchronisation 72
 - Air filter 72
 - Fault diagnosis 78
 - Petrol tank 65
 - Petrol tap 65
- Fuse location 118**
- G**
- Gearbox-**
- Components - examination and reassembly 41
 - Disassembly - general 22
 - Fault diagnosis 63
 - Lubrication 72
 - Refitting gear cluster 48
 - Removal 22
 - Selector mechanism-
 - Removal 24
 - Refitting 42
 - Specifications 18
 - Generator (alternator) 112
 - Gudgeon pin 23, 52
- H**
- Handlebar switches 120**
- Headlamp beam height adjustment 118**
- Head lockers 120**
- Hydraulic brake system bleeding 100**
- I**
- Ignition system-**
- ATU 84
 - Coils-checking 80
 - Contacts 82
 - Contact breaker - adjustment 80, 82
 - Charging system 80
 - Fault diagnosis 88
 - Spark plug-
 - Checking and setting gap 84, 85
 - Colour charts
 - Operating conditions 82
 - Specifications 78
 - Switch 85
 - Timing 84
- J**
- Knock-**
- Mechanism 41
 - Return spring 22, 31

- L**
- Latches 78
 - Legal obligations 10, 98, 112
 - Lighting and ignition switch 120
 - Lubrication systems 88, 78
 - Insulation—
 - Cables 10
 - Checking oil pressure 14
 - Start pilot steam 8
 - Wheel bearings 104, 107
 - Lubricants — recommended 14
- M**
- Maintenance, adjustment and capacities 18
 - Master cylinder 108
 - Maintenance — section 8 — 14
 - Metric conversion tables 117, 119
- N**
- No filter 18
 - Oil pressure warning lamp 78, 123
 - Oil pump 24, 88
 - Oil seals 10
 - Oilering —
 - Spoke caps 8
 - Tires 12
- O**
- Quick glass maintenance adjustments 18
- P**
- Pedal — rear brake 87
 - Panel work 84
 - Panel cap 84
 - Piston and rings 21, 23
 - Prop stand 97
- R**
- Rear brake pedal 87
 - Rear shaft—
 - Coil spring and lubrication 8
 - Insulation 110
 - Rear suspension units 87
 - Rear wheel 108
 - Rear wheel—
 - Cushion 110
 - Spocket 118
 - Refrigerant unit 114
 - Recommended lubricants 14
 - Rings and pistons 21, 23
 - Routine maintenance 14
- S**
- Seals check 10
 - Selector mechanism—
 - Removal 24
 - Refitting 22
- Sealing plug:**
- Checking and setting cap 84, 85
 - Close steam operating conditions 88
- Specifications: head and drive 98**
- Switch/lighting—**
- Brake 113
 - Clutch 88
 - Electrical system 112
 - Engine 11, 18
 - Frame and forks 87
 - Rear system 84
 - Seatbox 18
 - Ignition 78
 - Lubrication 84
 - Wheels, brakes and tires 118
- Starters motor 118**
- Electricity requirements 10, 98, 112
 - Electric/light assembly 88
 - Suspension unit — rear 87
 - Swaging arm fork 82
- Switches—**
- Brake/light — examination and replacement 120
 - Lighting and ignition 120
 - Oil pressure warning 78, 123
 - Starter motor — voltage 118
 - Stoplamp 120
- T**
- Tachometer: head and drive 98
- Tires—**
- Condition 88
 - Electric unit 114
 - Storage regulator 115
- Tires 18**
- Final wrench settings 19
- Tires—**
- Pressures 8, 14, 100
 - Removal and replacement (see Instructional 108)
 - Tires and dust caps 108
- V**
- Varnish—
 - Clearance 12
 - Coating 24
 - Cables 10
 - Spokes 14
 - Voltage regulator 115
- W**
- Weights and dimensions
 - Wheels—
 - Balancing from wheel 112
 - Bearings 104, 107
 - Frame 100, 104
 - Rear 108
 - Spoke conditions 11
 - Swaging diagrams 124, 126
 - Swaging conditions 18