



YFM50S

SERVICE MANUAL

LIT-11616-17-13

5YF-28197-10

EBS00001

YFM50S
SERVICE MANUAL
©2003 by Yamaha Motor Corporation, U.S.A.
First Edition, April 2003
All rights reserved.
Any reproduction or unauthorized use
without the written permission of
Yamaha Motor Corporation, U.S.A.
is expressly prohibited.
Printed in U.S.A.
LIT-11616-17-13

NOTICE

This manual was produced by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual, so it is assumed that anyone who uses this book to perform maintenance and repairs on Yamaha machine has a basic understanding of the mechanical ideas and the procedures of machine repair. Repairs attempted by anyone without this knowledge are likely to render the machine unsafe and unfit for use.

Yamaha Motor Company, Ltd. is continually striving to improve all its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

NOTE:

Designs and specifications are subject to change without notice.

IMPORTANT INFORMATION

Particularly important information is distinguished in this manual by the following notations.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



Failure to follow WARNING instructions could result in severe injury or death to the machine operator, a bystander or a person checking or repairing the machine.

CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the machine.

NOTE:

A NOTE provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

MANUAL ORGANIZATION

This manual consists of chapters for the main categories of subjects. (See “symbols”)

1st title ①: This is the title of the chapter with its symbol in the upper right corner of each page.

2nd title ②: This title indicates the section of the chapter and only appears on the first page of each section. It is located in the upper left corner of the page.

3rd title ③: This title indicates a sub-section that is followed by step-by-step procedures accompanied by corresponding illustrations.

EXPLODED DIAGRAMS

To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.

1. An easy-to-see exploded diagram ④ is provided for removal and disassembly jobs.
2. Numbers ⑤ are given in the order of the jobs in the exploded diagram. A number that is enclosed by a circle indicates a disassembly step.
3. An explanation of jobs and notes is presented in an easy-to-read way by the use of symbol marks ⑥. The meanings of the symbol marks are given on the next page.
4. A job instruction chart ⑦ accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
5. For jobs requiring more information, the step-by-step format supplements ⑧ are given in addition to the exploded diagram and the job instruction chart.

②
①

CLUTCH
ENG

CLUTCH
ENG

Order	Job/Part	Qty	Remarks
Removing the clutch			
	Engine oil		Remove the parts in the order listed. Drain.
	C.D.I. magneto cover		Refer to "CHANGING THE ENGINE OIL" in chapter 3.
1	Clutch cover	1	Refer to "REMOVING THE CLUTCH" and "INSTALLING THE CLUTCH".
2	Clutch cover gasket	1	
3	Dowel pin	2	
4	Push plate	1	
5	Circlip	1	
6	Pressure plate	1	
7	Push rod	1	
8	Friction plate 1 (with black color marking)	4	Refer to "INSTALLING THE CLUTCH".

CLUTCH
ENG

CLUTCH
ENG

REMOVING THE CLUTCH

1. Remove:

- clutch cover

NOTE:
Loosen each screw 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the screws are fully loosened, remove them.

2. Loosen:

- clutch boss nut ①

NOTE:
While holding the clutch boss ② with the clutch holder ③, loosen the clutch boss nut.

Clutch holder
P/N. 90890-04100

REMOVING THE PRIMARY DRIVE GEAR

1. Loosen:

- primary drive gear nut ①

NOTE:
Place an aluminum plate ② between the teeth of the primary driven gear/clutch housing ③ and primary drive gear ④.

CHECKING THE FRICTION PLATES

The following procedure applies to all of the friction plates.

1. Check:

- friction plate

Damage/wear → Replace the friction plates as a set.
























2. Measure:

- friction plate thickness

Out of specification → Replace the friction plates as a set.

NOTE:
Measure the friction plate at four places.

Friction plate thickness
2.92 - 3.08 mm (0.115 - 0.121 in)
◁Limit>: 2.90 mm (0.114 in)

① GEN INFO 	② SPEC 	
③ CHK ADJ 	④ ENG 	
⑤ CARB 	⑥ DRIV 	
⑦ CHAS 	⑧ ELEC 	
⑨ TRBL SHTG ?	⑩ 	
⑪ 	⑫ 	
⑬ 	⑭ 	
⑮ 	⑯ 	⑰ 
⑱ 	⑲ 	⑳ 
㉑ 	㉒ 	㉓ 
㉔ 	㉕ New	

EBS00005

SYMBOLS

The following symbols are not relevant to every machine.

Symbols ① to ⑨ indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic checks and adjustments
- ④ Engine
- ⑤ Carburetor
- ⑥ Drive train
- ⑦ Chassis
- ⑧ Electrical
- ⑨ Troubleshooting

Symbols ⑩ to ⑰ indicate the following.

- ⑩ Serviceable with engine mounted
- ⑪ Filling fluid
- ⑫ Lubricant
- ⑬ Special tool
- ⑭ Torque
- ⑮ Wear limit, clearance
- ⑯ Engine speed
- ⑰ Electrical data (Ω , V, A)










Symbols ⑱ to ㉓ in the exploded diagrams indicate the types of lubricants and lubrication points.

- ⑱ Apply engine oil
- ⑲ Apply gear oil
- ⑳ Apply molybdenum disulfide oil
- ㉑ Apply wheel bearing grease
- ㉒ Apply lithium-soap-based grease
- ㉓ Apply molybdenum disulfide grease

Symbols ㉔ to ㉕ in the exploded diagrams indicate where to apply a locking agent ㉔ and when to install a new part ㉕.

- ㉔ Apply the locking agent (LOCTITE®)
- ㉕ Replace

TABLE OF CONTENTS

GENERAL INFORMATION	
	GEN INFO 1
SPECIFICATIONS	
	SPEC 2
PERIODIC CHECKS AND ADJUSTMENTS	
	CHK ADJ 3
ENGINE	
	ENG 4
CARBURETOR	
	CARB 5
DRIVE TRAIN	
	DRIV 6
CHASSIS	
	CHAS 7
ELECTRICAL	
	ELEC 8
TROUBLESHOOTING	
	TRBL SHTG 9

CONTENTS

CHAPTER 1 GENERAL INFORMATION

MACHINE IDENTIFICATION	1-1
VEHICLE IDENTIFICATION NUMBER	1-1
MODEL LABEL.....	1-1
IMPORTANT INFORMATION	1-2
PREPARATION FOR REMOVAL AND DISASSEMBLY.....	1-2
REPLACEMENT PARTS.....	1-2
GASKETS, OIL SEALS AND O-RINGS	1-2
LOCK WASHERS/PLATES AND COTTER PINS	1-3
BEARINGS AND OIL SEALS	1-3
CIRCLIPS	1-3
CHECKING THE CONNECTIONS.....	1-4
SPECIAL TOOLS	1-5

CHAPTER 2 SPECIFICATIONS

GENERAL SPECIFICATIONS	2-1
ENGINE SPECIFICATIONS	2-4
CHASSIS SPECIFICATIONS	2-11
ELECTRICAL SPECIFICATIONS	2-12
TIGHTENING TORQUES	2-14
ENGINE TIGHTENING TORQUES.....	2-14
CHASSIS TIGHTENING TORQUES.....	2-15
HOW TO USE THE CONVERSION TABLE	2-17
GENERAL TIGHTENING TORQUE SPECIFICATIONS	2-17
LUBRICATION POINTS AND LUBRICANT TYPES	2-18
ENGINE.....	2-18

OIL FLOW DIAGRAMS	2-20
CABLE ROUTING	2-22

CHAPTER 3

PERIODIC CHECKS AND ADJUSTMENTS

INTRODUCTION	3-1
PERIODIC MAINTENANCE/LUBRICATION	3-1
SEAT, FENDERS AND FUEL TANK	3-2
SEAT AND FRONT PANEL	3-2
FRONT FENDER	3-3
REAR FENDER AND FOOTREST BOARDS	3-4
FUEL TANK.....	3-6
ENGINE	3-7
ADJUSTING THE TIMING CHAIN TENSIONER	3-7
ADJUSTING THE VALVE CLEARANCE	3-8
ADJUSTING THE ENGINE IDLING SPEED	3-10
ADJUSTING THE THROTTLE LEVER FREE PLAY	3-11
ADJUSTING THE SPEED LIMITER.....	3-12
CHECKING THE SPARK PLUG	3-13
CHECKING THE IGNITION TIMING.....	3-14
MEASURING THE COMPRESSION PRESSURE.....	3-15
CHECKING THE ENGINE OIL LEVEL.....	3-17
CHANGING THE ENGINE OIL	3-18
CLEANING THE AIR FILTER ELEMENT.....	3-19
CLEANING THE SPARK ARRESTER	3-20
CHASSIS	3-22
CHECKING THE FRONT AND REAR BRAKE SHOES.....	3-22
ADJUSTING THE FRONT BRAKE	3-22
ADJUSTING THE REAR BRAKE.....	3-23
CHECKING THE FINAL GEAR OIL LEVEL.....	3-24
CHANGING THE FINAL GEAR OIL.....	3-24
CHECKING THE SWINGARM DUST BOOT	3-25
CHECKING THE STEERING SYSTEM	3-26
ADJUSTING THE TOE-IN.....	3-27
CHECKING THE FRONT AND REAR SHOCK ABSORBERS	3-28
CHECKING THE TIRES.....	3-29
CHECKING THE WHEELS	3-31
CHECKING AND LUBRICATING THE CABLES	3-32
LUBRICATING THE LEVERS, STEERING SHAFT AND STEERING KNUCKLES	3-32

ELECTRICAL SYSTEM	3-33
CHECKING AND CHARGING THE BATTERY	3-33
CHECKING THE FUSE.....	3-37

CHAPTER 4

ENGINE

ENGINE	4-1
EXHAUST PIPE/MUFFLER, BREATHER HOSE AND LEADS	4-1
ENGINE MOUNTING BOLTS	4-2
REMOVING THE ENGINE	4-4
INSTALLING THE ENGINE.....	4-4
CYLINDER HEAD	4-5
REMOVING THE CYLINDER HEAD.....	4-7
CHECKING THE CAMSHAFT SPROCKET	4-8
CHECKING THE TAPPET COVERS AND CAMSHAFT SPROCKET COVER.....	4-8
CHECKING THE TIMING CHAIN GUIDES	4-8
CHECKING THE TIMING CHAIN TENSIONER ASSEMBLY	4-8
CHECKING THE CYLINDER HEAD	4-9
INSTALLING THE CYLINDER HEAD	4-10
CAMSHAFT, ROCKER ARMS AND VALVES	4-12
REMOVING THE ROCKER ARMS AND CAMSHAFT.....	4-14
REMOVING THE VALVES AND VALVE SPRINGS	4-14
CHECKING THE CAMSHAFT.....	4-15
CHECKING THE ROCKER ARMS AND ROCKER ARM SHAFTS	4-15
CHECKING THE VALVES AND VALVE SPRINGS	4-17
INSTALLING THE VALVES AND VALVE SPRINGS	4-21
INSTALLING THE CAMSHAFT AND ROCKER ARMS	4-22
CYLINDER AND PISTON	4-23
REMOVING THE PISTON	4-24
CHECKING THE CYLINDER AND PISTON	4-24
CHECKING THE PISTON RINGS.....	4-26
CHECKING THE PISTON PIN	4-27
INSTALLING THE PISTON	4-28
INSTALLING THE CYLINDER	4-29
C.D.I. MAGNETO	4-30
REMOVING THE C.D.I. MAGNETO ROTOR	4-31
CHECKING THE PICKUP COIL/STATOR ASSEMBLY.....	4-31
INSTALLING THE C.D.I. MAGNETO ROTOR	4-32
INSTALLING THE SHIFT LEVER	4-32

CLUTCH	4-33
REMOVING THE CLUTCH	4-35
REMOVING THE PRIMARY DRIVE GEAR	4-35
CHECKING THE FRICTION PLATES.....	4-35
CHECKING THE CLUTCH PLATES	4-36
CHECKING THE CLUTCH SPRINGS.....	4-36
CHECKING THE CLUTCH HOUSING	4-36
CHECKING THE CLUTCH BOSS.....	4-37
CHECKING THE PRESSURE PLATE	4-37
CHECKING THE CLUTCH BALLS.....	4-37
CHECKING THE PRIMARY DRIVE GEARS	4-37
INSTALLING THE PRIMARY DRIVE GEAR.....	4-38
INSTALLING THE CLUTCH.....	4-38
STARTER CLUTCH AND OIL PUMP	4-42
CHECKING THE STARTER CLUTCH	4-44
CHECKING THE OIL PUMP	4-45
SHIFT SHAFT	4-47
CHECKING THE SHIFT SHAFT	4-48
CHECKING THE STOPPER LEVER	4-48
INSTALLING THE STOPPER LEVER	4-48
INSTALLING THE SHIFT SHAFT	4-48
CRANKCASE	4-49
CRANKCASE BEARINGS.....	4-50
SEPARATING THE CRANKCASE	4-51
CHECKING THE TIMING CHAIN.....	4-51
CHECKING THE BEARINGS AND OIL SEALS.....	4-52
CHECKING THE CRANKCASE	4-52
INSTALLING THE BEARINGS.....	4-52
ASSEMBLING THE CRANKCASE.....	4-53
CRANKSHAFT	4-54
CHECKING THE CRANKSHAFT	4-55
INSTALLING THE CRANKSHAFT	4-55
TRANSMISSION	4-56
REMOVING THE TRANSMISSION	4-57
CHECKING THE SHIFT FORK	4-57
CHECKING THE SHIFT DRUM	4-58
CHECKING THE TRANSMISSION	4-58
INSTALLING THE TRANSMISSION	4-59
MIDDLE GEAR	4-60
REMOVING THE MIDDLE DRIVEN SHAFT	4-61
CHECKING THE PINION GEARS	4-62
SELECTING MIDDLE DRIVEN GEAR SHIMS	4-63
INSTALLING THE MIDDLE DRIVEN SHAFT	4-64
MEASURING THE MIDDLE GEAR BACKLASH.....	4-66

CHAPTER 5 CARBURETOR

CARBURETOR	5-1
DISASSEMBLING THE CARBURETOR.....	5-4
CHECKING THE CARBURETOR.....	5-4
ASSEMBLING THE CARBURETOR.....	5-6
INSTALLING THE CARBURETOR.....	5-6
MEASURING AND ADJUSTING THE FUEL LEVEL.....	5-7

CHAPTER 6 DRIVE TRAIN

TROUBLESHOOTING	6-1
CHECKING NOISES.....	6-2
TROUBLESHOOTING CHART.....	6-4
REAR AXLE/FINAL DRIVE ASSEMBLY AND DRIVE SHAFT	6-5
REAR AXLE/FINAL DRIVE ASSEMBLY.....	6-7
REMOVING THE NUTS.....	6-8
REMOVING THE REAR AXLE/FINAL DRIVE ASSEMBLY.....	6-8
DISASSEMBLING THE REAR AXLE HOUSING.....	6-9
DISASSEMBLING THE FINAL GEAR CASE.....	6-9
CHECKING THE REAR AXLE.....	6-10
CHECKING THE DRIVE SHAFT.....	6-10
CHECKING THE REAR AXLE HOUSING AND FINAL DRIVE ASSEMBLY.....	6-10
ASSEMBLING THE FINAL GEAR CASE.....	6-11
ASSEMBLING THE REAR AXLE HOUSING.....	6-11
INSTALLING THE REAR AXLE/FINAL DRIVE ASSEMBLY.....	6-12
INSTALLING THE NUTS.....	6-13

CHAPTER 7 CHASSIS

FRONT AND REAR WHEELS	7-1
FRONT WHEELS.....	7-1
REAR WHEELS.....	7-2
CHECKING THE WHEELS.....	7-3
CHECKING THE FRONT WHEEL HUBS.....	7-3
CHECKING THE REAR WHEEL HUBS.....	7-4
INSTALLING THE WHEEL HUBS.....	7-4
INSTALLING THE WHEELS.....	7-5

FRONT AND REAR BRAKES	7-6
FRONT BRAKE	7-6
REAR BRAKE	7-7
REMOVING THE BRAKES	7-9
CHECKING THE BRAKE SHOE PLATES	7-9
CHECKING THE BRAKE SHOES.....	7-9
CHECKING THE BRAKE DRUMS	7-10
INSTALLING THE FRONT BRAKES	7-11
INSTALLING THE REAR BRAKE	7-12
STEERING SYSTEM	7-14
HANDLEBAR.....	7-14
REMOVING THE HANDLEBAR GRIPS.....	7-16
REMOVING THE REAR BRAKE SWITCH	7-16
CHECKING THE HANDLEBAR	7-16
INSTALLING THE HANDLEBAR	7-17
INSTALLING THE HANDLEBAR GRIPS	7-17
INSTALLING THE REAR BRAKE LEVER	7-18
INSTALLING THE FRONT BRAKE LEVER ASSEMBLY.....	7-18
STEERING STEM	7-19
REMOVING THE STEERING STEM	7-20
CHECKING THE STEERING STEM	7-20
INSTALLING THE STEERING STEM	7-20
INSTALLING THE LOCK WASHER.....	7-20
TIE-RODS AND STEERING KNUCKLES	7-21
REMOVING THE TIE-RODS.....	7-22
CHECKING THE TIE-RODS	7-22
CHECKING THE STEERING KNUCKLES.....	7-22
INSTALLING THE TIE-RODS	7-23
FRONT SHOCK ABSORBER ASSEMBLIES AND FRONT SWINGARM ...	7-24
REMOVING THE FRONT SWINGARM	7-25
CHECKING THE FRONT SWINGARM	7-25
CHECKING THE FRONT SHOCK ABSORBER ASSEMBLIES	7-25
REAR SHOCK ABSORBER AND REAR SWINGARM	7-26
REMOVING THE REAR SWINGARM.....	7-27
CHECKING THE REAR SHOCK ABSORBER.....	7-27
CHECKING THE REAR SWINGARM	7-28
CHECKING THE DUST BOOT	7-28
INSTALLING THE LOCK WASHER.....	7-28


CHAPTER 8 ELECTRICAL

ELECTRICAL COMPONENTS	8-1
CHECKING SWITCH CONTINUITY	8-2
CHECKING THE SWITCHES	8-3
CHECKING THE BULBS AND BULB SOCKETS	8-4
TYPES OF BULBS	8-4
CHECKING THE CONDITION OF THE BULBS	8-4
CHECKING THE CONDITION OF THE BULB SOCKETS	8-6
IGNITION SYSTEM	8-7
CIRCUIT DIAGRAM	8-7
TROUBLESHOOTING	8-8
ELECTRIC STARTING SYSTEM	8-12
CIRCUIT DIAGRAM	8-12
STARTING CIRCUIT OPERATION.....	8-13
TROUBLESHOOTING	8-14
STARTER MOTOR	8-18
CHECKING THE STARTER MOTOR	8-19
ASSEMBLING THE STARTER MOTOR.....	8-20
CHARGING SYSTEM	8-21
CIRCUIT DIAGRAM	8-21
TROUBLESHOOTING	8-22
SIGNAL SYSTEM	8-24
CIRCUIT DIAGRAM	8-24
TROUBLESHOOTING	8-25
CHECKING THE SIGNALING SYSTEM	8-26

CHAPTER 9 TROUBLESHOOTING

STARTING FAILURE/HARD STARTING	9-1
FUEL SYSTEM.....	9-1
ELECTRICAL SYSTEM.....	9-1
COMPRESSION SYSTEM.....	9-2

POOR IDLE SPEED PERFORMANCE	9-2
POOR IDLE SPEED PERFORMANCE.....	9-2
POOR MEDIUM AND HIGH-SPEED PERFORMANCE	9-2
POOR MEDIUM AND HIGH-SPEED PERFORMANCE	9-2
FAULTY DRIVE TRAIN	9-3
FAULTY GEAR SHIFTING	9-4
HARD SHIFTING.....	9-4
SHIFT LEVER DOES NOT MOVE	9-4
JUMPS OUT GEAR.....	9-4
CLUTCH SLIPPING/Dragging	9-4
CLUTCH SLIPPING	9-4
CLUTCH DRAGGING	9-4
OVERHEATING	9-4
OVERHEATING	9-4
FAULTY BRAKE	9-5
POOR BRAKING EFFECT	9-5
SHOCK ABSORBER MALFUNCTION	9-5
MALFUNCTION.....	9-5
UNSTABLE HANDLING	9-5
UNSTABLE HANDLING	9-5




EBS00009

GENERAL INFORMATION MACHINE IDENTIFICATION

EBS00010

VEHICLE IDENTIFICATION NUMBER

The vehicle identification number ① is stamped into the left side of the frame.



EBS00011

MODEL LABEL

The model label ① is affixed to the frame. This information will be needed to order spare parts.

EBS00013

IMPORTANT INFORMATION PREPARATION FOR REMOVAL AND DISASSEMBLY

1. Before removal and disassembly remove all dirt, mud, dust and foreign material.
2. Use only the proper tools and cleaning equipment.
Refer to "SPECIAL TOOLS".
3. When disassembling always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.
4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.

1

EBS00014


REPLACEMENT PARTS

1. Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.

EBS00015

GASKETS, OIL SEALS AND O-RINGS


1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. During reassembly properly oil all mating parts and bearings, and lubricate the oil seal lips with grease.



EBS00016

LOCK WASHERS/PLATES AND COTTER PINS

After removal, replace all lock washers/plates ① and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.



EBS00017


BEARINGS AND OIL SEALS

Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, lubricate the oil seal lips with a light coat of lithium-soap-based grease. Oil bearings liberally when installing, if appropriate.


① Oil seal

CAUTION:

Do not spin the bearing with compressed air because this will damage the bearing surfaces.



① Bearing




EBS00018

CIRCLIPS

Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip ①, make sure the sharp-edged corner ② is positioned opposite the thrust ③ that the circlip receives.

④ Shaft



EBS00019

CHECKING THE CONNECTIONS

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

1. Disconnect:


- lead
- coupler
- connector

2. Check:

- lead
- coupler
- connector

Moisture → Dry with an air blower.

Rust/stains → Connect and disconnect several times.



3. Check:

- all connections

Loose connection → Connect properly.

NOTE: _____


If the pin ① on the terminal is flattened, bend it up.

4. Connect:

- lead
- coupler
- connector

NOTE: _____

Make sure all connections are tight.



5. Check:

- continuity (with the pocket tester)




Pocket tester

P/N. YU-03112-C, 90890-03112

NOTE: _____

- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps (1) to (3).
- As a quick remedy, use a contact revitalizer available at most part stores.



EBS00021

SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools; this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools may differ by shape and part number from country to country. In such a case, two types are provided.







When placing an order, refer to the list provided below to avoid any mistakes.









For US and CDN









P/N. YM-, YU-, YS-, YK-, ACC-

Except for US and CDN





P/N. 90890-

Tool No.	Tool name/Function	Illustration
Bolt 90890-01085 Weight 90890-01084 Set YU-01083-A	Slide hammer bolt (M8)/weight/set These tools are used to remove the rocker arm shaft.	
90890-01189 YM-01189	Flywheel puller This tool is needed to remove the rotor.	
90890-01304 YU-01304	Piston pin puller set This tool is used to remove the piston pin.	
90890-01311 YM-08035	Tappet adjusting tool (3 mm) This tool is necessary for adjusting the valve clearance.	
90890-01312 YM-01312-A	Fuel level gauge This gauge is used to measure the fuel level in the float chamber.	
90890-01388	Damper rod holder (27 mm) This tool is needed to loosen and tighten the middle driven pinion gear bearing retainer.	

Tool No.	Tool name/Function	Illustration	
90890-01422 YM-37132	<p>Axle nut wrench (36 mm)</p> <p>This tool is needed to loosen or tighten the rear axle nut.</p>		
90890-01430 YM-38404	<p>Ring nut wrench</p> <p>This tool is needed to loosen and tighten the final gear case bearing retainer.</p>		
90890-01467 YM-01467	<p>Gear lash measurement tool</p> <p>This tool is used to measure the middle gear backlash.</p>		
90890-01701 YS-01880-A	<p>Sheave holder</p> <p>This tool is needed to hold the rotor when removing or installing the rotor nut.</p>		
<p>Gauge 90890-03081 YU-33223 Adapter 90890-04082</p>	<p>Compression gauge Adapter</p> <p>These tools are needed to measure engine compression.</p>		
90890-03112 YU-03112-C	<p>Pocket tester</p> <p>This instrument is needed for checking the electrical system.</p>		
90890-03113	<p>Engine tachometer</p> <p>This tool is needed for observing engine rpm.</p>		
90890-03141 YM-33277-A	<p>Timing light</p> <p>This tool is necessary for checking ignition timing.</p>		

Tool No.	Tool name/Function	Illustration
Compressor 90890-04019 YM-04019 Attachment 90890-04108 YM-04108	Valve spring compressor Valve spring compressor attachment This tool is needed to remove and install the valve assemblies.	
Holder 90890-04062 YM-04062 Attachment 90890-04096	Universal joint holder Universal joint holder attachment This tool is needed when removing or installing the universal joint yoke nut.	
90890-04097 YM-04097	Valve guide remover (5 mm) This tool is needed to remove and install the valve guide.	
90890-04098 YM-04098	Valve guide installer (5 mm) This tool is needed to install the valve guide.	
90890-04099	Valve guide reamer (5 mm) This tool is needed to rebore the new valve guide.	
90890-04100	Clutch holder This tool is needed to hold the clutch boss when removing or installing the clutch boss nut.	
90890-04129 YM-04129	Pinion gear fix clamp This tool is used to hold the drive axle/middle drive pinion gear assembly.	
90890-06754	Ignition checker This instrument is necessary for checking the ignition system components.	



Tool No.	Tool name/Function	Illustration
Bond 90890-85505 Sealant ACC-11001-05-01	Yamaha bond No. 1215 Sealant (Quick Gasket®) This sealant (bond) is used on crankcase mating surfaces, etc.	
YM-01363	27-mm hexagon wrench This tool is needed to loosen and tighten the middle driven pinion gear bearing retainer.	
YM-34487	Dynamic spark tester This instrument is necessary for checking the ignition system components.	
YU-8036-B	Inductive self-powered tachometer This tool is needed for observing engine rpm.	



EBS01001

SPECIFICATIONS

GENERAL SPECIFICATIONS

Item	Standard
Model code	5YF1
Dimensions	
Overall length	1,537 mm (60.5 in)
Overall width	825 mm (32.5 in)
Overall height	915 mm (36.0 in)
Seat height	618 mm (24.3 in)
Wheelbase	1,030 mm (40.6 in)
Minimum ground clearance	70 mm (2.76 in)
Minimum turning radius	2,300 mm (90.6 in)
Basic weight	
With oil and full fuel tank	115 kg (253 lb)
Engine	
Engine type	Air-cooled 4-stroke, SOHC
Cylinder arrangement	Forward-inclined single cylinder
Displacement	49 cm ³
Bore × stroke	39.0 × 41.4 mm (1.54 × 1.63 in)
Compression ratio	10.0 : 1
Standard compression pressure (at sea level)	1,200 kPa (12.0 kg/cm ² , 170.6 psi) at 1,000 r/min
Starting system	Electric starter
Lubrication system	Wet sump
Oil type or grade	
Engine oil	API service SE, SF, SG type or higher
Final gear oil	SAE 80API "GL-4" Hypoid gear oil
Oil capacity	
Engine oil	
Periodic oil change	0.80 L (0.70 Imp qt, 0.85 US qt)
Total amount	0.95 L (0.84 Imp qt, 1.00 US qt)
Final gear case oil	
Total amount	0.12 L (0.11 Imp qt, 0.13 US qt)
Air filter	Wet type element










Item	Standard
Fuel Type Fuel tank capacity Fuel reserve amount	Unleaded gasoline only 6.8 L (1.50 Imp gal, 1.80 US gal) 0.9 L (0.20 Imp gal, 0.24 US gal)
Carburetor Type/quantity Manufacturer	VM16SH/1 MIKUNI
Spark plug Type/manufacturer Spark plug gap	CR7HS/NGK 0.6 ~ 0.7 mm (0.024 ~ 0.028 in)
Clutch type	Wet, multiple-disc automatic
Transmission Primary reduction system Primary reduction ratio Secondary reduction system Secondary reduction ratio Operation Gear ratio 1st gear	Spur gear 65/20 (3.250) Shaft drive 19/18 × 34/10 (3.588) Left hand operation 38/14 (2.714)
Chassis Frame type Caster angle Camber angle Kingpin angle Trail Tread (STD) front rear Toe-in	Steel tube frame 1.0° 2.0° 10° 3.4 mm (0.13 in) 630 mm (24.80 in) 665 mm (26.18 in) 0 ~ 10 mm (0 ~ 0.39 in)
Tire Type Size front rear Manufacturer front rear Type front rear	Tubeless AT16 × 7-7 AT16 × 8-7 DUNLOP DUNLOP KT145 KT145
Tire pressure (cold tire) Maximum load* Off-road riding front rear *Load in total weight of rider accessories	40 kg (88 lb) 17 ~ 23 kPa (0.17 ~ 0.23 kgf/cm ² , 2.5 ~ 3.3 psi) 17 ~ 23 kPa (0.17 ~ 0.23 kgf/cm ² , 2.5 ~ 3.3 psi)





EBS01002

ENGINE SPECIFICATIONS

Item	Standard	Limit
<p>Cylinder head Warp limit *</p> 	<p>----</p>	<p>0.05 mm (0.002 in)</p>
<p>Cylinder Bore size Taper limit Maximum out-of-round</p>	<p>39.000 ~ 39.005 mm (1.5354 ~ 1.5356 in) ---- ----</p>	<p>39.105 mm (1.5396 in) 0.05 mm (0.002 in) 0.01 mm (0.0004 in)</p>
<p>Camshaft Drive method Cam dimensions</p>  <p>Intake "A" "B"</p> <p>Exhaust "A" "B"</p> <p>Camshaft runout limit</p> 	<p>Chain drive (Left)</p> <p>25.300 ~ 25.310 mm (0.9961 ~ 0.9965 in) 20.994 ~ 21.094 mm (0.8265 ~ 0.8305 in) 25.301 ~ 25.311 mm (0.9961 ~ 0.9965 in) 21.021 ~ 21.121 mm (0.8276 ~ 0.8315 in) ----</p>	<p>----</p> <p>25.200 mm (0.9921 in) 20.894 mm (0.8226 in) 25.201 mm (0.9922 in) 20.921 mm (0.8237 in) 0.03 mm (0.0012 in)</p>
<p>Timing chain Timing chain type/No. of links Timing chain adjustment method</p>	<p>Bush chain/82 Manual</p>	<p>---- ----</p>

Item		Standard	Limit
Rocker arm/rocker arm shaft			
Rocker arm inside diameter		10.000 ~ 10.015 mm (0.3937 ~ 0.3943 in)	----
Rocker arm shaft outside diameter		9.981 ~ 9.991 mm (0.3930 ~ 0.3933 in)	----
Rocker-arm-to-rocker-arm-shaft clearance		0.009 ~ 0.034 mm (0.0004 ~ 0.0013 in)	0.08 mm (0.0031 in)
Valve, valve seat, valve guide			
Valve clearance (cold)	IN	0.05 ~ 0.10 mm (0.002 ~ 0.004 in)	----
	EX	0.075 ~ 0.125 mm (0.003 ~ 0.005 in)	----
Valve dimensions			
			
Head Diameter	Face Width	Seat Width	Margin Thickness
"A" head diameter	IN	19.9 ~ 20.1 mm (0.7835 ~ 0.7913 in)	----
	EX	16.7 ~ 16.9 mm (0.6575 ~ 0.6654 in)	----
"B" face width	IN	1.10 ~ 2.30 mm (0.0433 ~ 0.0906 in)	----
	EX	1.30 ~ 2.40 mm (0.0512 ~ 0.0945 in)	----
"C" seat width	IN	0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in)	1.6 mm (0.0630 in)
	EX	0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in)	1.6 mm (0.0630 in)
"D" margin thickness	IN	0.5 ~ 0.9 mm (0.0197 ~ 0.0354 in)	1.6 mm (0.0630 in)
	EX	0.6 ~ 1.0 mm (0.0236 ~ 0.0394 in)	1.6 mm (0.0630 in)
Stem outside diameter	IN	4.975 ~ 4.990 mm (0.1959 ~ 0.1965 in)	4.950 mm (0.1949 in)
	EX	4.960 ~ 4.975 mm (0.1953 ~ 0.1959 in)	4.953 mm (0.1950 in)
Guide inside diameter	IN	5.000 ~ 5.012 mm (0.1969 ~ 0.1973 in)	5.030 mm (0.1980 in)
	EX	5.000 ~ 5.012 mm (0.1969 ~ 0.1973 in)	5.030 mm (0.1980 in)





Item		Standard	Limit
Stem-to-guide clearance	IN	0.010 ~ 0.037 mm (0.0004 ~ 0.0015 in)	0.08 mm (0.0031 in)
	EX	0.025 ~ 0.052 mm (0.0010 ~ 0.0020 in)	0.10 mm (0.0039 in)
Stem runout limit		----	0.02 mm (0.0008 in)
	IN	0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in)	1.6 mm (0.0630 in)
	EX	0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in)	1.6 mm (0.0630 in)
Valve spring			
Free length	IN	32.00 mm (1.26 in)	30.40 mm (1.20 in)
	EX	32.00 mm (1.26 in)	30.40 mm (1.20 in)
Compressed pressure (installed)	IN	136 ~ 158 N at 24.6 mm (13.87 ~ 16.11 kg, 30.57 ~ 35.52 lb at 0.97 in)	----
	EX	136 ~ 158 N at 24.6 mm (13.87 ~ 16.11 kg, 30.57 ~ 35.52 lb at 0.97 in)	----
Tilt limit *	IN		2.5°/1.4 mm (2.5°/0.06 in)
	EX		2.5°/1.4 mm (2.5°/0.06 in)
	IN		
	EX		
Direction of winding (top view)	IN	Clockwise	----
	EX	Clockwise	----



Item	Standard	Limit
Piston		
Piston to cylinder clearance	0.025 ~ 0.045 mm (0.0010 ~ 0.0018 in)	0.15 mm (0.0059 in)
Piston size "D"	38.960 ~ 38.975 mm (1.5339 ~ 1.5344 in)	----
Measuring point "H"	5.0 mm (0.20 in)	----
Oversize	2nd 4th	----

Piston off-set	0.5 mm (0.02 in)	----
Piston off-set direction	Intake side	----
Piston pin bore inside diameter	13.002 ~ 13.013 mm (0.5119 ~ 0.5123 in)	13.043 mm (0.5135 in)
Piston pin outside diameter	12.996 ~ 13.000 mm (0.5117 ~ 0.5118 in)	12.976 mm (0.5109 in)
Piston rings		
Top ring		
Type	Barrel	----
Dimensions (B × T)	1.0 × 1.7 mm (0.0394 × 0.0669 in)	----
End gap (installed)	0.08 ~ 0.20 mm (0.0031 ~ 0.0079 in)	0.45 mm (0.0177 in)
Side clearance (installed)	0.030 ~ 0.065 mm (0.0012 ~ 0.0026 in)	0.12 mm (0.0047 in)
2nd ring		
Type	Taper	----
Dimensions (B × T)	1.0 × 1.7 mm (0.0394 × 0.0669 in)	----
End gap (installed)	0.05 ~ 0.20 mm (0.0020 ~ 0.0079 in)	0.55 mm (0.0217 in)
Side clearance	0.020 ~ 0.055 mm (0.0008 ~ 0.0022 in)	0.12 mm (0.0047 in)



Item	Standard	Limit
<p>Oil ring</p>  <p>Dimensions (B × T)</p> <p>End gap (installed)</p>	<p>2.0 × 2.0 mm (0.0787 × 0.0787 in)</p> <p>0.20 ~ 0.70 mm (0.0079 ~ 0.0276 in)</p>	<p>----</p> <p>----</p>
<p>Crankshaft</p>  <p>Crank width "A"</p> <p>Runout limit C1</p> <p>C2</p> <p>Big end side clearance "D"</p> <p>Big end radial clearance "E"</p> <p>Small end free play "F"</p>	<p>40.20 ~ 40.25 mm (1.5827 ~ 1.5846 in)</p> <p>----</p> <p>----</p> <p>0.10 ~ 0.40 mm (0.0039 ~ 0.0157 in)</p> <p>0.004 ~ 0.019 mm (0.0002 ~ 0.0007 in)</p> <p>0.80 ~ 1.00 mm (0.0315 ~ 0.0394 in)</p>	<p>----</p> <p>0.05 mm (0.0020 in)</p> <p>0.04 mm (0.0016 in)</p> <p>0.50 mm (0.0197 in)</p> <p>----</p> <p>1.50 mm (0.0591 in)</p>
<p>Clutch</p> <p>Friction plate 1 (with black color marking)</p> <p>Thickness</p> <p>Quantity</p> <p>Friction plate 2</p> <p>Thickness</p> <p>Quantity</p>	<p>2.92 ~ 3.08 mm (0.115 ~ 0.121 in)</p> <p>4</p> <p>2.92 ~ 3.08 mm (0.115 ~ 0.121 in)</p> <p>1</p>	<p>2.90 mm (0.114 in)</p> <p>----</p> <p>2.90 mm (0.114 in)</p> <p>----</p>




Item	Standard	Limit
Clutch plate 1		
Thickness	1.4 mm (0.055 in)	----
Quantity	1	----
Maximum warpage	----	0.06 mm (0.002 in)
Clutch plate 2		
Thickness	1.2 ~ 1.6 mm (0.047 ~ 0.063 in)	----
Quantity	3	----
Maximum warpage	----	0.06 mm (0.002 in)
Clutch spring		
Free length	31.9 mm (1.26 in)	30.3 mm (1.19 in)
Quantity	8	----
Automatic centrifugal clutch		
Clutch-in revolution	2,300 ~ 2,500 r/min	----
Clutch-stall revolution	3,000 ~ 3,200 r/min	----
Transmission		
Main axle deflection limit	----	0.08 mm (0.0031 in)
Drive axle deflection limit	----	0.08 mm (0.0031 in)
Shifter		
Shifter type	Shift drum and guide bar	----
Carburetors		
I. D. mark	5YF1 00	----
Main jet (M.J)	#72.5	----
Air jet (A.J)	1.2	----
Jet needle (J.N)	3PZ13-2	----
Needle jet (N.J)	D-8M	----
Cutaway (C.A)	3	----
Pilot outlet (P.O)	0.7	----
Pilot jet (P.J)	#15	----
Valve seat size (V.S)	1.2	----
Fuel level (F.L)	4.0 ~ 5.0 mm (0.16 ~ 0.20 in)	----
	Below the float chamber mating surface	
Engine idle speed	1,750 ~ 1,850 r/min	----
Intake vacuum	30 kPa (225 mmHg, 8.9 inHg)	----



Item	Standard	Limit
Oil pump		
Oil pump type	Trochoid	----
Inner-rotor-to-outer-rotor-tip clearance	0.05 ~ 0.07 mm (0.002 ~ 0.003 in)	0.15 mm (0.006 in)
Outer-rotor-to-oil-pump-housing clearance	0.013 ~ 0.036 mm (0.0005 ~ 0.0014 in)	0.106 mm (0.0042 in)
Oil-pump-housing-to-inner-rotor-and-outer-rotor clearance	0.06 ~ 0.10 mm (0.0024 ~ 0.0039 in)	0.17 mm (0.0067 in)
Shaft drive		
Middle gear backlash	0.17 ~ 0.31 mm (0.007 ~ 0.012 in)	----
Final gear backlash	0.17 ~ 0.31 mm (0.007 ~ 0.012 in)	----

Lubrication chart



EBS01003

CHASSIS SPECIFICATIONS

Item	Standard	Limit
Front suspension		
Shock absorber travel	60 mm (2.36 in)	----
Optional spring	No	----
Rear suspension		
Shock absorber travel	58 mm (2.28 in)	----
Optional spring	No	----
Front wheel		
Type	Panel wheel	----
Rim size	7 × 5.5 AT	----
Rim material	Steel	----
Rim runout limit	radial	2.0 mm (0.08 in)
	lateral	2.0 mm (0.08 in)
Rear wheel		
Type	Panel wheel	----
Rim size	7 × 6.5 AT	----
Rim material	Steel	----
Rim runout limit	radial	2.0 mm (0.08 in)
	lateral	2.0 mm (0.08 in)
Front drum brake		
Type	Leading, trailing	----
Brake drum inside diameter	110.0 mm (4.33 in)	110.5 mm (4.35 mm)
Lining thickness	4.0 mm (0.16 in)	2.0 mm (0.08 in)
Shoe spring free length	54.0 mm (2.13 in)	----
Rear drum brake		
Type	Leading, trailing	----
Brake drum inside diameter	130.0 mm (5.12 in)	130.5 mm (5.14 in)
Lining thickness	4.0 mm (0.16 in)	2.0 mm (0.08 in)
Shoe spring free length	36.5 mm (1.44 in)	----
Brake lever and brake pedal		
Brake lever free play (pivot)	front	10 ~ 12 mm (0.39 ~ 0.47 in)
	rear	7 ~ 10 mm (0.28 ~ 0.39 in)
Throttle lever free play		1.5 ~ 5.0 mm (0.06 ~ 0.20 in)



EBS01004

ELECTRICAL SPECIFICATIONS

Item	Standard	Limit
Voltage	12 V	----
Ignition system		
Ignition timing (B.T.D.C.)	10°/1,700 r/min	----
Advanced timing (B.T.D.C.)	30°/5,000 r/min	----
Advancer type	Electrical (analogue)	----
C.D.I.		
Magneto model/manufacturer	F2FM/YAMAHA	----
Pickup coil resistance/color	264 ~ 396 Ω at 20 °C (68 °F)/ White/Red—White/Blue	----
Source coil resistance/color	304 ~ 456 Ω at 20 °C (68 °F)/ Black/Red—Green/White	----
C.D.I. unit model/manufacturer	5YF/YAMAHA	----
Ignition coil		
Model/manufacturer	2JN/YAMAHA	----
Minimum spark gap	6 mm (0.24 in)	----
Primary winding resistance	0.18 ~ 0.28 Ω at 20 °C (68 °F)	----
Secondary winding resistance	6.32 ~ 9.48 kΩ at 20 °C (68 °F)	----
Spark plug cap		
Type	Resin	----
Resistance	10 kΩ	----
Charging system		
Type	A.C. magneto	----
Model/manufacturer	F2FM/YAMAHA	----
Nominal output	14 V 45 W at 5,000 r/min	----
Charging coil resistance/color	0.72 ~ 1.08 Ω at 20 °C (68 °F)/ White—Black	----
Lighting coil resistance	0.32 ~ 0.48 Ω at 20 °C (68 °F)/ Yellow/Red—Black	----
Rectifier/regulator		
Regulator type	Semi conductor-short circuit	----
No-load regulated voltage (DC)	14.0 ~ 15.0 V	----
No-load regulated voltage (AC)	13.0 ~ 14.0 V	----
Model/manufacturer	SH704-12/SHINDENGEN	----
Capacity (DC)	5 A	----
Capacity (AC)	8 A	----
Withstand voltage	200 V	----









Item	Standard	Limit
Electric starter system		
Type	Constant mesh	----
Starter motor		
Model/manufacture	ADB4A5/DENSO	----
Output	0.2 kW	----
Armature coil resistance	0.029 ~ 0.035 Ω at 20 °C (68 °F)	----
Brush overall length	6.0 mm (0.24 in)	3.5 mm (0.14 in)
Spring force	3.24 ~ 4.22 N (330 ~ 430 gf, 11.66 ~ 15.19 oz)	----
Commutator diameter	16.5 mm (0.65 in)	15.5 mm (0.61 in)
Mica undercut	1 mm (0.04 in)	----
Starter relay		
Model/manufacture	MS5E-661/JIDECO	----
Amperage rating	100 A	----
Coil winding resistance	4.18 ~ 4.62 Ω at 20 °C (68 °F)	----
Starting circuit cut-off relay		
Model/manufacture	ACA12115-3/MATSUSHITA	----
Coil resistance	72 ~ 88 Ω at 20 °C (68 °F)	----
Diode	Yes	----
Circuit breakers		
Type	Fuse	----
Amperage for individual circuit		
Main fuse	5 A \times 1	----
Reserve	5 A \times 1	----



EBS01005

TIGHTENING TORQUES

ENGINE TIGHTENING TORQUES

Part to be tightened	Part name	Thread size	Q'ty	Tightening torque			Remarks
				Nm	m · kg	ft · lb	
Cylinder head (exhaust pipe)	Stud bolt	M6	2	7	0.7	5.1	
Intake and exhaust tappet cover	—	M45	2	18	1.8	13	
Camshaft sprocket cover	Screw	M6	2	7	0.7	5.1	
Cylinder head	Nut	M6	4	12	1.2	8.7	
	Bolt	M6	2	10	1.0	7.2	
Spark plug	—	M10	1	13	1.3	9.4	
C.D.I. magneto rotor	Nut	M10	1	40	4.0	29	
Valve adjuster	Nut	M5	2	7	0.7	5.1	
Camshaft sprocket	Bolt	M8	1	20	2.0	14	
Timing chain tensioner	—	M18	1	18	1.8	13	
Timing chain tension adjuster locknut	Nut	M6	1	7	0.7	5.1	
Oil pump	Screw	M6	2	7	0.7	5.1	
Engine oil drain bolt	Bolt	M12	1	20	2.0	14	
Intake manifold	Screw	M6	2	7	0.7	5.1	
Carburetor	Screw	M6	2	7	0.7	5.1	
Exhaust pipe	Nut	M6	2	10	1.0	7.2	
Muffler	Bolt	M8	2	25	2.5	18	
Spark arrester	Screw	M6	2	8	0.8	5.8	
Muffler purging bolt	Bolt	M6	1	10	1.0	7.2	
Crankcase	Screw	M6	9	7	0.7	5.1	
Crankcase (cylinder head)	Stud bolt	M6	4	10	1.0	7.2	
Main axle bearing retainer	Screw	M6	2	8	0.8	5.8	
Drive axle/middle drive pinion gear assembly plate	Bolt	M6	3	10	1.0	7.2	
Clutch cover	Screw	M6	3	7	0.7	5.1	
C.D.I. magneto cover	Screw	M6	9	7	0.7	5.1	
Starter clutch	Screw	M6	3	10	1.0	7.2	Stake 
Primary drive gear	Nut	M12	1	50	5.0	36	
Clutch boss	Nut	M14	1	60	6.0	43	
Push plate	Screw	M6	4	8	0.8	5.8	
Middle driven shaft bearing retainer	—	M42	1	60	6.0	43	Stake 
Universal joint yoke	Nut	M12	1	90	9.0	65	Stake 
Middle driven shaft bearing housing	Bolt	M6	3	10	1.0	7.2	
Shift drum retainer	Screw	M6	2	8	0.8	5.8	
Shift shaft spring stopper	Bolt	M8	1	25	2.5	18	
Shift drum stopper lever	Bolt	M6	1	10	1.0	7.2	
Shift lever	Bolt	M6	1	10	1.0	7.2	
Stator assembly	Screw	M6	2	7	0.7	5.1	
Starter motor	Bolt	M6	2	10	1.0	7.2	

TIGHTENING TORQUES

SPEC



Part to be tightened	Part name	Thread size	Q'ty	Tightening torque			Remarks
				Nm	m · kg	ft · lb	
Neutral switch	—	M10	1	20	2.0	14	
Spark arrester tailpipe	Screw	M6	2	8	0.8	5.8	
Purging bolt	Bolt	M6	1	10	1.0	7.2	

EBS01006




CHASSIS TIGHTENING TORQUES

Part to be tightened	Thread size	Tightening torque			Remarks
		Nm	m · kg	ft · lb	
Engine and frame	M8	33	3.3	24	
Rear swingarm and frame	M12	85	8.5	61	
Rear swingarm and swingarm guard	M8	23	2.3	17	
Rear shock absorber and frame	M10	45	4.5	32	
Rear shock absorber and rear axle housing	M10	45	4.5	32	
Front swingarm and frame	M12	60	6.0	43	
Front shock absorber and frame	M10	45	4.5	32	
Front shock absorber and front swingarm	M12	45	4.5	32	
Steering knuckle and front swingarm	M10	30	3.0	22	
Steering knuckle and tie-rod ball joint	M10	40	4.0	29	
Steering stem and tie-rod ball joint	M10	40	4.0	29	
Tie-rod locknut	M10	15	1.5	11	
Steering stem and frame	M10	35	3.5	25	
Steering stem bushing and frame	M8	23	2.3	17	
Handlebar holder and steering stem	M8	20	2.0	14	
Throttle lever and housing	M8	8	0.8	5.8	
Front wheel and brake drum	M8	28	2.8	20	
Front axle and brake drum	M14	70	7.0	50	
Front brake camshaft and camshaft lever	M6	9	0.9	6.5	
Rear brake camshaft and camshaft lever	M6	9	0.9	6.5	
Rear axle and nut	M28				See NOTE.
Rear wheel and wheel hub	M8	28	2.8	20	
Rear axle and wheel hub	M12	70	7.0	50	
Rear brake drum boss and brake drum	M8	21	2.1	15	
Rear axle housing and rear swingarm	M10	40	4.0	29	
Footrest board bracket and frame	M12	85	8.5	61	
Front bumper and frame	M8	23	2.3	17	
Front bumper and dummy headlight	M6	7	0.7	5.1	
Front bumper and front fender	M6	7	0.7	5.1	
Front fender and frame	M6	7	0.7	5.1	
Front fender stay and frame	M6	7	0.7	5.1	
Footrest board and bracket	M6	7	0.7	5.1	
Rear fender and frame	M6	7	0.7	5.1	
Rear swingarm and final gear case	M8	20	2.0	14	
Final gear case and rear axle housing	M6	20	2.0	14	

TIGHTENING TORQUES

SPEC



Part to be tightened	Thread size	Tightening torque			Remarks
		Nm	m · kg	ft · lb	
Final gear oil drain plug	M14	23	2.3	17	
Final gear case bearing retainer	M55	80	8.0	58	
Final drive pinion gear and bearing	M20	12	1.2	8.7	
Rear axle housing bearing retainer	M58	110	11.0	80	

NOTE:

1. Before tightening the nuts, apply locking agent (LOCTITE®) to rear axle threads.
2. Tighten the inside nut to 110 Nm (11.0 m · kg, 80 ft · lb).
3. Tighten the outside nut to 130 Nm (13.0 m · kg, 94 ft · lb) while holding the inside nut.
4. Loosen the inside nut to 160 Nm (16.0 m · kg, 115 ft · lb) while holding the outside nut.

HOW TO USE THE CONVERSION TABLE/ GENERAL TIGHTENING TORQUE SPECIFICATIONS



EBS00022

HOW TO USE THE CONVERSION TABLE

All specification data in this manual are listed in SI and METRIC UNITS.

Use this table to convert METRIC unit data to IMPERIAL unit data.

Ex.

METRIC		MULTIPLIER	=	IMPERIAL
** mm	×	0.03937	=	** in
2 mm	×	0.03937	=	0.08 in


CONVERSION TABLE

METRIC TO IMPERIAL			
	Metric unit	Multiplier	Imperial unit
Torque	m · kg	7.233	ft · lb
	m · kg	86.794	in · lb
	cm · kg	0.0723	ft · lb
	cm · kg	0.8679	in · lb
Weight	kg	2.205	lb
	g	0.03527	oz
Speed	km/h	0.6214	mph
Distance	km	0.6214	mi
	m	3.281	ft
	m	1.094	yd
	cm	0.3937	in
	mm	0.03937	in
Volume/ Capacity	cc (cm ³)	0.03527	oz (Imp liq.)
	cc (cm ³)	0.06102	cu · in
	lt (liter)	0.8799	qt (Imp liq.)
	lt (liter)	0.2199	gal (Imp liq.)
Misc.	kg/mm	55.997	lb/in
	kg/cm ²	14.2234	psi (lb/in ²)
	Centigrade (°C)	9/5+32	Fahrenheit (°F)

EBS00023

GENERAL TIGHTENING TORQUE SPECIFICATIONS

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided for each chapter of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross pattern and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.



A: Distance between flats

B: Outside thread diameter

A (nut)	B (bolt)	General tightening torques		
		Nm	m · kg	ft · lb
10 mm	6 mm	6	0.6	4.3
12 mm	8 mm	15	1.5	11
14 mm	10 mm	30	3.0	22
17 mm	12 mm	55	5.5	40
19 mm	14 mm	85	8.5	61
22 mm	16 mm	130	13.0	94



EBS00024

LUBRICATION POINTS AND LUBRICANT TYPES

ENGINE

Lubrication points	Lubricant
Oil seal lips	
Bearings	
O-rings	
Tappet cover thread	
Crankshaft pin	
Connecting rod (bearing)	
Crankshaft, oil seal	
Piston, piston ring	
Piston pin	
Valve stem	
Valve stem end	
Rocker arm	
Rocker arm shaft	
Camshaft lobe	
Camshaft sprocket	
Timing chain tensioner	
Intake side timing chain guide	
Oil pump assembly	
Starter idle gear shaft	
Starter wheel gear	
Primary driven gear, spacer	
Clutch push rod, oil seal	
Drive axle, 1st wheel gear	
Drive axle dog splines	
Drive axle dog shift fork groove	
Middle drive/driven pinion gear	
Shift drum	
Shift fork guide bar, O-ring	
Shift shaft	
Shift shaft washer	
Middle driven pinion gear, universal joint yoke, drive shaft, coupling gear, final drive pinion gear splines	
Final drive pinion gear, ring gear	
Crankcase mating surface	Sealant (Quick Gasket®) Yamaha Bond No.1215

LUBRICATION POINTS AND LUBRICANT TYPES

SPEC


Lubrication points	Lubricant
Final gear case and rear axle housing mating surface	Sealant (Quick Gasket®) Yamaha Bond No.1215



EBS00026


OIL FLOW DIAGRAMS

- ① Camshaft
- ② Crankshaft
- ③ Main axle
- ④ Drive axle





- ① Oil pump
- ② Oil strainer






EBS00028


CABLE ROUTING

- | | | |
|----------------------------------|---------------------------------------|------------------------------|
| ① Rear brake cable | ⑩ Wire harness | ⑱ Left front brake cable |
| ② Throttle cable | ⑪ Negative battery lead | ⑲ Engine stop switch (frame) |
| ③ Fuel tank breather hose | ⑫ Rectifier/regulator | |
| ④ Carburetor air vent hose | ⑬ Engine stop switch lead (frame end) | |
| ⑤ Final gear case breather hose | ⑭ Battery breather hose | |
| ⑥ Crankcase breather hose | ⑮ Starter motor lead | |
| ⑦ Starter relay | ⑯ Fuel overflow hose | |
| ⑧ Starting circuit cut-off relay | ⑰ Right front brake cable | |
| ⑨ Positive battery lead | | |






- A** Route the rear brake cable to the right of the steering stem.
- B** Pass the carburetor air vent hose through the hole on the left side of the steering stem bracket and then insert the hose between the bracket and frame. Make sure that there is no slack or bends in the hose. Do not route the hose over the throttle cable.
- C** Route the final gear case breather hose and crankcase breather hose to the right of the ignition coil.
- D** Align the white tape of the wire harness with the bracket.
- E** 200 mm (7.87 in)
- F** To starter motor
- G** Fasten the engine stop switch lead (frame end) to the frame with a plastic band.
- H** Pass the final gear case breather hose through the hose guide.
- I** Pass the battery breather hose through the hole.






- J** Fasten the carburetor air vent hose with a plastic band. Be sure to not pinch the hose. Install the plastic band with the buckle facing backward and the end inward.
- K** Route the cables under the frame.
- L** 45°






- ① Rear brake cable
- ② Wire harness
- ③ Ignition coil
- ④ Handlebar switch lead
- ⑤ Rear brake switch lead
- ⑥ Neutral indicator light lead
- ⑦ Main switch
- ⑧ C.D.I. unit
- ⑨ Fuel hose
- ⑩ Crankcase breather hose
- ⑪ Final gear case breather hose
- ⑫ Fuel tank breather hose
- ⑬ Throttle cable
- ⑭ Front brake cables






- A** 80 mm (3.15 in)
- B** Fasten the rear brake cable, wire harness, crankcase breather hose, and final gear case breather hose with a plastic band. Be sure to not pinch the hoses.
- C** Route the final gear case breather hose and crankcase breather hose over the wire harness. Fasten the hoses with a plastic band. Be sure to not pinch the hoses. Pass the ends of the hoses between the frame and bracket.
- D** Fasten the rear brake cable and wire harness near the ignition coil with a plastic locking tie.
- E** Do not fasten the main switch lead.
- F** Fasten the crankcase breather hose and final gear case breather hose with a plastic band.
- G** Face the coupler release tabs backward.
- H** Forward






- ① Rear brake switch
- ② Rear brake cable
- ③ Left front brake cable
- ④ Right front brake cable
- ⑤ Throttle cable
- ⑥ Fuel tank breather hose
- ⑦ Negative battery lead
- ⑧ Main fuse
- ⑨ Positive battery lead
- ⑩ Handlebar switch






- A** Fasten the negative battery lead with the plastic holder.
- B** To starter motor
- C** Pass the leads through the hole.
- D** To wire harness
- E** To starter relay
- F** Fasten the handlebar switch lead and rear brake switch lead with a plastic band.
- G** Connect the negative battery lead to the battery so that the lead is routed to the side of the battery.
- H** Connect the positive battery lead to the battery so that the lead contacts the battery case.





- ① Throttle cable
- ② Fuel tank breather hose
- ③ Rear brake cable
- ④ Handlebar switch lead
- ⑤ Rear brake switch lead
- ⑥ Air filter joint
- ⑦ Neutral indicator light lead
- ⑧ Right front brake cable
- ⑨ Left front brake cable

- Ⓐ Route the front brake cables to the left of the steering stem. Route the left front brake cable to the right of the air filter joint. Route the right front brake cable to the left of the air filter joint.



EBS00029

PERIODIC CHECKS AND ADJUSTMENTS

INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable machine operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to machines already in service as well as to new machines that are being prepared for sale. All service technicians should be familiar with this entire chapter.

EBS00030

PERIODIC MAINTENANCE/LUBRICATION

ITEM	ROUTINE	INITIAL			EVERY	
		1 month	3 months	6 months	6 months	1 year
Valves*	<ul style="list-style-type: none"> • Check valve clearance. • Adjust if necessary. 	○		○	○	○
Cam chain*	<ul style="list-style-type: none"> • Check chain tension. • Adjust if necessary. 	○		○	○	○
Spark plug	<ul style="list-style-type: none"> • Check condition. • Adjust gap and clean. • Replace if necessary. 	○	○	○	○	○
Air filter element	<ul style="list-style-type: none"> • Clean. • Replace if necessary. 	Every 20 ~ 40 hours (more often in wet or dusty areas)				
Carburetor*	<ul style="list-style-type: none"> • Check idle speed/choke lever operation. • Adjust if necessary. 		○	○	○	○
Crankcase breather system*	<ul style="list-style-type: none"> • Check breather hose for cracks or damage. • Replace if necessary. 			○	○	○
Exhaust system*	<ul style="list-style-type: none"> • Check for leakage. • Tighten if necessary. • Replace gasket if necessary. 			○	○	○
Spark arrester	<ul style="list-style-type: none"> • Clean. 			○	○	○
Fuel line*	<ul style="list-style-type: none"> • Check fuel hose for cracks or damage. • Replace if necessary. 			○	○	○
Engine oil	<ul style="list-style-type: none"> • Replace (warm engine before draining). 	○		○	○	○
Final gear oil	<ul style="list-style-type: none"> • Check oil level/oil leakage. • Replace every 12 months. 	○				○
Brakes*	<ul style="list-style-type: none"> • Check operation. • Adjust if necessary. 	○	○	○	○	○
Wheels*	<ul style="list-style-type: none"> • Check balance/damage/runout. • Replace if necessary. 	○		○	○	○
Wheel bearings*	<ul style="list-style-type: none"> • Check bearing assemblies for looseness/damage. • Replace if damaged. 	○		○	○	○
Steering system*	<ul style="list-style-type: none"> • Check operation. • Repair if damaged. • Check toe-in. • Adjust if necessary. 	○	○	○	○	○
Knuckle shafts/steering shaft*	<ul style="list-style-type: none"> • Lubricate every 6 months with Lithium-soap-based grease. 			○	○	○
Fittings and fasteners*	<ul style="list-style-type: none"> • Check all chassis fittings and fasteners. • Correct if necessary. 	○	○	○	○	○
Battery*	<ul style="list-style-type: none"> • Check specific gravity. • Check breather hose for correct routing. • Correct if necessary. 	○	○	○	○	○

* Since these items require special tools, data and technical skills, have a Yamaha dealer perform the service.

EBS00032




Indicates a potential hazard that could result in serious injury or death.

EBS00033

SEAT, FENDERS AND FUEL TANK


SEAT AND FRONT PANEL



Order	Job/Part	Q'ty	Remarks
	Removing the seat and front panel		Remove the parts in the order listed.
1	Seat	1	NOTE: _____ Pull back the seat lock lever, than pull up on the rear of the seat.
2	Front panel	1	
3	Fuel tank breather hose	1	
4	Handlebar cover	1	NOTE: _____ When installing the handlebar cover, pass the fuel tank breather hose through the hole in the handlebar cover.
5	Neutral indicator light connectors	2	Disconnect. For installation, reverse the removal procedure.

EBS00037


FRONT FENDER




Order	Job/Part	Q'ty	Remarks
	Removing the front fender		
	Seat and front panel		Remove the parts in the order listed. Refer to "SEAT AND FRONT PANEL".
1	Fuel tank top panel	1	
2	Air cleaner joint clamp screw	1	Loosen.
3	Main switch	1	
4	Front fender	1	
			For installation, reverse the removal procedure.

EBS00039

REAR FENDER AND FOOTREST BOARDS




Order	Job/Part	Q'ty	Remarks
	Removing the rear fender and footrest boards		Remove the parts in the order listed.
	Seat		Refer to "SEAT AND FRONT PANEL".
	Front fender		Refer to "FRONT FENDER".
1	Battery band	1	
2	Main fuse	1	
3	Negative battery lead	1	Disconnect. CAUTION: _____ First disconnect the negative lead, then disconnect the positive lead. _____
4	Positive battery lead	1	Disconnect.
5	Battery breather hose	1	Disconnect.



Order	Job/Part	Q'ty	Remarks
6	Battery	1	For installation, reverse the removal procedure.
7	Footrest board	2	
8	Rear fender	1	

EBS00042

FUEL TANK




Order	Job/Part	Q'ty	Remarks
1	Removing the fuel tank Seat and front panel Front fender Fuel hose	1	Remove the parts in the order listed. Refer to "SEAT AND FRONT PANEL". Refer to "FRONT FENDER". Disconnect. NOTE: _____ Before disconnecting the fuel hose, turn the fuel cock to "OFF". _____
2	Fuel tank	1	For installation, reverse the removal procedure.

EBS00057


CHECKING THE SPARK PLUG

1. Remove:
 - spark plug
2. Check:
 - spark plug type
 Incorrect → Change.

**Standard spark plug
CR7HS/NGK**




3. Check:
 - electrode ①
Wear/damage → Replace.
 - insulator ②
Abnormal color → Replace.
Normal color is a medium-to-light tan color.
4. Clean:
 - spark plug
(with a spark plug cleaner or wire brush)



5. Measure:
 - spark plug gap ③
Use a wire gauge or thickness gauge.
Out of specification → Regap.



Spark plug gap
0.6 ~ 0.7 mm (0.024 ~ 0.028 in)

6. Tighten:
 - spark plug  **13 Nm (1.3 m · kg, 9.4 ft · lb)**

NOTE:

Before installing a spark plug, clean the gasket surface and plug surface.

EBS00061

MEASURING THE COMPRESSION PRESSURE


NOTE: _____

Insufficient compression pressure will result in a loss of performance.

1. Measure:
 - valve clearance
Out of specification → Adjust.
Refer to “ADJUSTING THE VALVE CLEARANCE”.
2. Start the engine, warm it up for several minutes, and then turn it off.
3. Disconnect:
 - spark plug cap
4. Remove:
 - spark plug

CAUTION: _____

Before removing a spark plug, use compressed air to blow away any dirt accumulated in the spark plug well to prevent it from falling into the cylinder.



5. Attach:
 - adapter
 - compression gauge ①




Compression gauge
P/N. YU-33223, 90890-03081
Adapter
P/N. 90890-04082

6. Measure:
 - compression pressure
Out of specification → Refer to steps (c) and (d).



Compression pressure (at sea level)


Minimum
1,040 kPa
(10.4 kg/cm², 147.9 psi)
Standard
1,200 kPa
(12.0 kg/cm², 170.6 psi)
Maximum
1,340 kPa
(13.4 kg/cm², 190.5 psi)




EBS00068

CHANGING THE ENGINE OIL

1. Start the engine, warm it up for several minutes, and then turn it off.
2. Place a container under the engine oil drain bolt.
3. Remove:
 - dipstick ①
 - engine oil drain bolt ② (along with the gasket)
4. Drain:
 - engine oil (completely from the crankcase)
5. Check:
 - engine oil drain bolt gasket
Damage → Replace.



6. Install:
 - engine oil drain bolt ① (along with the gasket)

 **20 Nm (2.0 m · kg, 1.4 ft · lb)**

7. Fill:
 - crankcase (with the specified amount of the recommended engine oil)



Quantity
Total amount
0.95 L (0.84 Imp qt, 1.00 US qt)
Periodic oil change
0.80 L (0.70 Imp qt, 0.85 US qt)

8. Install:
 - dipstick
9. Start the engine, warm it up for several minutes, and then turn it off.
10. Check:
 - engine (for engine oil leaks)
11. Check:
 - engine oil level
Refer to “CHECKING THE ENGINE OIL LEVEL”.

- b. Squeeze the excess solvent out of the element and let it dry.

CAUTION: _____

Do not twist or wring out the element. This could damage the foam material.

- c. Apply engine oil to the element.
d. Squeeze out the excess oil.

NOTE: _____

The element should be wet but not dripping.




7. Install:
- air filter element
 - air filter element guide
8. Connect:
- rubber band
9. Install:
- air filter cover

NOTE: _____

Make sure its sealing surface matches the sealing surface of the case so there is no air leak.

10. Install:
- front panel
- Refer to "SEAT, FENDERS AND FUEL TANK".



CLEANING THE SPARK ARRESTER

1. Clean:
- spark arrester





⚠ WARNING _____

- **Select a well-ventilated area free of combustible materials.**
- **Always let the exhaust system cool before performing this operation.**
- **Do not start the engine when removing the tailpipe from muffler.**

- a. Remove the screws ①.
b. Remove the tailpipe ② by pulling it out of the muffler.

CLEANING THE SPARK ARRESTER



- c. Tap the tailpipe lightly with a soft-face hammer or suitable tool, then use a wire brush to remove any carbon deposits from the spark arrester portion of the tailpipe and the inner contact surfaces of the muffler.
- d. Insert the tailpipe into the muffler and align the screw holes.
- e. Insert the screw and tighten it.



Screw
8 Nm (0.8 m · kg, 5.8 ft · lb)

- f. Remove the purging bolt ③.
- g. Start the engine and rev it up approximately twenty times while momentarily creating exhaust system back pressure by blocking the end of the muffler with a shop towel.
- h. Stop the engine and allow the exhaust pipe to cool.
- i. Install the purging bolt ③ and tighten it.



Bolt
10 Nm (1.0 m · kg, 7.2 ft · lb)



EBS00084



ADJUSTING THE REAR BRAKE

NOTE: _____


Before adjusting the rear brake, the rear brake linings should be checked.

CAUTION: _____

Proper lever free play is essential to avoid excessive brake drag.



1. Place the machine on a level surface.
2. Measure:
 - rear brake lever free play Ⓐ
 Out of specification → Adjust.

	Rear brake lever free play 7 ~ 10 mm (0.28 ~ 0.39 in)
---	--

3. Adjust:
 - brake lever free play



First step:

- a. Loosen the locknut ① and fully turn in the adjuster ② (lever side).
- b. Turn the adjuster ③ in or out until the specified rear brake lever free play is obtained (drum side).
- c. Tighten the locknut.

NOTE: _____

If the free play cannot be adjusted here, adjust if at the lever side of the cable.

Second step:


- a. Loosen the locknut ①.
- b. Turn the adjuster ② in or out until the specified rear brake lever free play is obtained (lever side).
- c. Tighten the locknut.

⚠ WARNING _____

After this adjustment is performed. block the rear of the machine off the ground, and spin the rear wheels to ensure there is no brake drag. If any brake drag is noticed, perform the above steps again.



CHECKING THE FINAL GEAR OIL LEVEL/ CHANGING THE FINAL GEAR OIL



EBS00101

CHECKING THE FINAL GEAR OIL LEVEL

1. Place the machine on a level surface.
2. Remove:
 - dipstick ①
3. Check:
 - final gear oil levelOil level should be between the maximum ① and minimum ② marks.
Oil level low → Add oil to the proper level.




Recommended oil
SAE80 API "GL-4" Hypoid gear oil

CAUTION:

Take care not allow foreign material to enter the final gear case.

4. Install:
 - dipstick



EBS00102

CHANGING THE FINAL GEAR OIL

1. Place the machine on a level surface.
2. Place a receptacle under the final gear case.
3. Remove:
 - dipstick ①
 - final gear oil drain plug ②
4. Drain:
 - final gear oil
5. Install:
 - final gear oil drain plug

23 Nm (2.3 m · kg, 17 ft · lb)

NOTE:

Check the gasket (drain plug). If it is damaged, replace it with a new one.

6. Fill:
- final gear case




Total amount
0.12 L (0.11 Imp qt, 0.13 US qt)
Recommended oil
SAE80 API "GL-4" Hypoid gear
oil

CAUTION:

Take care not to allow foreign material to enter the final gear case.



7. Check:
- final gear oil level
Refer to "CHECKING THE FINAL GEAR OIL LEVEL".
8. Install:
- dipstick



EBS00105

CHECKING THE SWINGARM DUST BOOT



1. Remove:
- C.D.I. magneto cover
Refer to "C.D.I. MAGNETO" in chapter 4.
2. Check:
- dust boot ①
Damage → Replace.
Refer to "REAR SHOCK ABSORBER AND REAR SWINGARM" in chapter 7.
3. Install:
- C.D.I. magneto cover
Refer to "C.D.I. MAGNETO" in chapter 4.



EBS00107

CHECKING THE STEERING SYSTEM

1. Place the machine on a level surface.
2. Check:
 - steering shaft bushings and bearings
Move the handlebar up and down, and/or back and forth.
Excessive play → Replace the steering shaft bushings and or bearings.
Refer to “STEERING SYSTEM” in chapter 7.
3. Check:
 - tie-rod ends
Turn the handlebar to the left and/or right until it stops completely, then slightly move the handlebar from left to right.
Tie-rod end has any vertical play → Replace the tie-rod end(s).
Refer to “STEERING SYSTEM” in chapter 7.
4. Raise the front end of the machine so that there is no weight on the front wheels.



5. Check:
 - knuckles and/or wheel bearings
Move the wheels laterally back and forth.
Excessive free play → Replace the following parts.
- 1) Wheel bearings
 - 2) Bushings ①
 - 3) Thrust covers ②
 - 4) Knuckle shafts ③
 - 5) Spacers ④
 - 6) Cotter pins ⑤
- Refer to “FRONT AND REAR WHEELS” and “STEERING SYSTEM” in chapter 7.

EBS00108

ADJUSTING THE TOE-IN



1. Place the machine on a level surface.
2. Measure:
 - toe-in
 Out of specification → Adjust.

Toe-in
0 ~ 10 mm (0 ~ 0.39 in)



NOTE:

Before measuring the toe-in, make sure that the tire pressure is correct.



- a. Mark both front tire tread centers.
- b. Raise the front end of the machine so that there is no weight on the front tires.
- c. Face the handlebar straight ahead.
- d. Measure the width **A** between the marks.
- e. Rotate the front tires 180° until the marks are exactly opposite one another.
- f. Measure the width **B** between the marks.
- g. Calculate the toe-in using the formula given below.

Toe-in = B - A

- h. If the toe-in is incorrect, adjust it.

C Forward



3. Adjust:
 - toe-in

WARNING

- Be sure that both tie-rods are turned the same amount. If not, the machine will drift right or left even though the handlebar is positioned straight. This may lead to mis-handling and an accident.
- After setting the toe-in to specification, run the machine slowly for some distance with both hands lightly holding the handlebar and check that the handlebar responds correctly. If not, turn either the right or left tie-rod within the toe-in specification.

EBS00114

CHECKING THE TIRES

WARNING

This model is equipped with low pressure tires. It is important that they be inflated correctly and maintained at the proper pressures.

- **TIRE CHARACTERISTICS**

1) Tire characteristics influence the handling of ATVs. The tires listed below have been approved by Yamaha Motor Co., Ltd. for this model. If other tire combinations are used, they can adversely affect your machine's handling characteristics and are therefore not recommended.

	Manufacturer	Size	Type
Front	DUNLOP	AT16× 7-7	KT145
Rear	DUNLOP	AT16× 8-7	KT145

- **TIRE PRESSURE**

1) Recommended tire pressure

Front 20 kPa (0.20 kgf/cm², 2.9 psi)

Rear 20 kPa (0.20 kgf/cm², 2.9 psi)

2) Tire pressure below the minimum specification could cause the tire to dislodge from the rim under severe riding conditions.

The following are minimums:

Front 17 kPa (0.17 kgf/cm², 2.5 psi)

Rear 17 kPa (0.17 kgf/cm², 2.5 psi)

3) Use no more than

Front 250 kPa (2.5 kgf/cm², 36 psi)

Rear 250 kPa (2.5 kgf/cm², 36 psi)

when seating the tire beads. Higher pressures may cause the tire to burst.


Inflate the tires slowly and carefully.

Fast inflation could cause the tire to burst.

- **MAXIMUM LOADING LIMIT**

Vehicle load limits: 40 kg (88 lb)

*Total weight of the cargo, trailer hitch vertical load, rider, and accessories.



1. Measure:
 - tire pressure
 - Out of specification → Adjust.

NOTE:


- The low-pressure tire gauge ① is included as standard equipment.
- If dust or the like is stuck to this gauge, it will not provide the correct readings. Therefore, take two measurements of the tire's pressure and use the second reading.

Cold tire pressure	Front	Rear
Standard	20 kPa (0.20 kgf/cm ² , 2.9 psi)	20 kPa (0.20 kgf/cm ² , 2.9 psi)
Minimum	17 kPa (0.17 kgf/cm ² , 2.5 psi)	17 kPa (0.17 kgf/cm ² , 2.5 psi)
Maximum	23 kPa (0.23 kgf/cm ² , 3.3 psi)	23 kPa (0.23 kgf/cm ² , 3.3 psi)

⚠ WARNING

Uneven or improper tire pressure may adversely affect the handling of this machine and may cause loss of control.

- Maintain proper tire pressures.
- Set tire pressures when the tires are cold.
- Tire pressures must be equal in both front tires and equal in both rear tires.




2. Check:
 - tire surfacesWear/damage → Replace.



Tire wear limit ^a
Front and rear: 3 mm (0.12 in)

⚠ WARNING

It is dangerous to ride with a worn-out tire. When tire wear is out of specification, replace the tire immediately.



EBS00116

CHECKING THE WHEELS

1. Check:
 - wheel ①Damage/bends → Replace.

NOTE:

Always balance the wheel when a tire or wheel has been changed or replaced.

⚠ WARNING

- Never attempt even small repairs to the wheel.
- Ride conservatively after installing a tire to allow it to seat itself properly on the rim.

EBS00117

CHECKING AND LUBRICATING THE CABLES

 **WARNING**

A damaged cable sheath may cause corrosion and interfere with the cable movement. An unsafe condition may result so replace a damaged cable as soon as possible.

1. Check:
 - cable sheath
Damage → Replace.
2. Check:
 - cable operation
Unsmooth operation → Lubricate or replace.

	Recommended lubricant Lithium-soap-base grease
---	--

NOTE:

Hold the cable end up and apply several drops of lubricant to the cable.

EBS00118

LUBRICATING THE LEVERS, STEERING SHAFT AND STEERING KNUCKLES

Lubricate the pivoting point and metal-to-metal moving parts of the levers, steering shaft and steering knuckles.

	Recommended lubricant Lithium-soap-base grease
---	--



EBS00119

ELECTRICAL SYSTEM

CHECKING AND CHARGING THE BATTERY

⚠ WARNING

Batteries generate explosive hydrogen gas and contain electrolyte which is made of poisonous and highly caustic sulfuric acid. Therefore, always follow these preventive measures:

- Wear protective eye gear when handling or working near batteries.
- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks or open flames (e.g., welding equipment, lighted cigarettes).
- **DO NOT SMOKE** when charging or handling batteries.
- **KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.**
- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.

FIRST AID IN CASE OF BODILY CONTACT: EXTERNAL

- **Skin** — Wash with water.
- **Eyes** — Flush with water for 15 minutes and get immediate medical attention.

INTERNAL

- Drink large quantities of water or milk followed with milk of magnesia, beaten egg or vegetable oil. Get immediate medical attention.

1. Remove:

- seat
- battery band


Refer to "SEAT, FENDERS AND FUEL TANK".

2. Disconnect:


- battery leads (from the battery terminals)
- battery breather hose

CAUTION:

First, disconnect the negative battery lead ①, and then the positive lead ②.



CHECKING AND CHARGING THE BATTERY



3. Remove:

- battery

4. Check:


- electrolyte level

The electrolyte level should be between the minimum level mark (a) and the maximum level mark (b).

Below the minimum level mark → Add distilled water to the proper level.

CAUTION:

Add only distilled water. Tap water contains minerals which are harmful to the battery.




5. Check:

- specific gravity

Less than 1.280 → Recharge the battery.



Specific gravity
1.280 at 20 °C (68 °F)



6. Charge:

- battery



Battery charging amperage and time
7 amps/10 hrs

WARNING

Do not quick charge a battery.

CAUTION:

- Loosen the battery sealing caps.
- Make sure the battery breather hose and battery vent are free of obstructions.
- To ensure maximum performance, always charge a new battery before using it.




- Do not use a high-rate battery charger. They force a high-amperage current into the battery quickly and can cause battery overheating and battery plate damage.
 - If it is impossible to regulate the charging current on the battery charger, be careful not to overcharge the battery.
 - When charging a battery, be sure to remove it from the machine. (If charging has to be done with the battery mounted on the machine, disconnect the negative lead from the battery terminal.)
 - To reduce the chance of sparks, do not plug in the battery charger until the battery charger leads are connected to the battery.
 - Before removing the battery charger lead clips from the battery terminals, be sure to turn off the battery charger.
 - Make sure the battery charger lead clips are in full contact with the battery terminal and that they are not shorted. A corroded battery charger lead clip may generate heat in the contact area and a weak clip spring may cause sparks.
 - If the battery becomes hot to the touch at any time during the charging process, disconnect the battery charger and let the battery cool before reconnecting it. Hot batteries can explode!
-

NOTE: _____

Replace the battery whenever:

- battery voltage does not rise to specification or bubbles fail to rise during charging,
 - sulfation of one or more battery cells occurs (as indicated by the battery plates turning white or material accumulating in the bottom of the battery cell),
 - specific gravity readings after a long, slow charge indicate that one battery cell's charge is lower than the rest,
 - warpage or buckling of the battery plates or insulators is evident.
-




7. Check:
 - battery breather hose and battery vent
Obstruction → Clean.
Damage → Replace.
8. Install:
 - battery
9. Connect:
 - battery breather hose ①

CAUTION: _____

When checking the battery, make sure the battery breather hose is properly installed and routed correctly. If the battery breather hose is positioned so as to allow electrolyte or hydrogen gas from the battery to contact the frame, the machine and its finish may be damaged.

NOTE: _____

Refer to “CABLE ROUTING” in chapter 2.



10. Check:
 - battery terminals
Dirt → Clean with a wire brush.
Loose connection → Connect properly.
11. Connect:
 - battery leads
(to the battery terminals)


CAUTION: _____

First, connect the positive battery lead ①, and then the negative battery lead ②.

12. Lubricate:
 - battery terminals

	Recommended lubricant Dielectric grease
---	--

13. Install:
 - battery band
 - seat
Refer to “SEAT, FENDERS AND FUEL TANK”.



EBS00121


CHECKING THE FUSE

CAUTION: _____

To avoid a short circuit, always set the main switch to “OFF” when checking or replacing a fuse.

1. Remove:

- seat
Refer to “SEAT, FENDERS AND FUEL TANK”.
- fuse holder ①



2. Check:

- fuse



- a. Connect the pocket tester to the fuse and check the continuity.

NOTE: _____

Set the pocket tester selector to “Ω × 1”.



Pocket tester
P/N. YU-03112-C, 90890-03112

- b. If the pocket tester indicates “∞”, replace the fuse.



3. Replace:

- blown fuse



- a. Set the main switch to “OFF”.
- b. Install a new fuse of the correct amperage.
- c. Set on the switches to verify if the electrical circuit is operational.

d. If the fuse immediately blows again, check the electrical circuit.

Items	Amperage rating	Q'ty
Main	5 A	1
Reserve	5 A	1

⚠ WARNING

Never use a fuse with an amperage rating other than that specified. Improvising or using a fuse with the wrong amperage rating may cause extensive damage to the electrical system, cause the ignition systems to malfunction and could possibly cause a fire.



4. Install:

- seat
Refer to "SEAT, FENDERS AND FUEL TANK".




EBS00198

ENGINE

ENGINE

EXHAUST PIPE/MUFFLER, BREATHER HOSE AND LEADS




4

Order	Job/Part	Q'ty	Remarks
	Removing the exhaust pipe/muffler, breather hose and leads		Remove the parts in the order listed.
	Rear fender		Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3.
1	Exhaust pipe/muffler	1	
2	Exhaust pipe gasket	1	
3	Spark plug lead	1	
4	C.D.I. magneto coupler	2	
5	Crankcase breather hose	1	
			For installation, reverse the removal procedure.




EBS00205


ENGINE MOUNTING BOLTS



Order	Job/Part	Q'ty	Remarks
	Removing the engine mounting bolts		Remove the parts in the order listed.
	Carburetor		Refer to "CARBURETOR" in chapter 5.
	Starter motor		Refer to "ELECTRIC STARTING SYSTEM" in chapter 8.
	C.D.I. magneto cover		Refer to "C.D.I. MAGNETO".
1	Metal clamp	2	<p>CAUTION: _____</p> <p>Install all of the bolts/nuts and then tighten them to full torque specifications.</p> <p>_____</p> <p>Refer to "INSTALLING THE ENGINE".</p>
2	Lower engine mounting nut/bolt	1/1	



Order	Job/Part	Q'ty	Remarks
3	Upper engine mounting nut/bolt	1/1	Refer to "INSTALLING THE ENGINE".
4	Engine assembly	1	
5	Dust boot	1	Refer to "REMOVING THE ENGINE" and "INSTALLING THE ENGINE". For installation, reverse the removal procedure.




REMOVING THE ENGINE

1. Remove:
 - metal clamps

NOTE:

After removing the metal clamps, slide the dust boot ① towards the swingarm.




EBS00207

INSTALLING THE ENGINE

1. Install:
 - dust boot ①

NOTE:

Before mounting the engine assembly, install the dust boot onto the middle driven gear bearing housing.




2. Install:
 - upper engine mounting bolt/nut ①
 - lower engine mounting bolt/nut ②


NOTE:

Do not fully tighten the bolts and nuts.

3. Tighten:
 - upper engine mounting nut ①

 **33 Nm (3.3 m · kg, 24 ft · lb)**


- lower engine mounting nut ②

 **33 Nm (3.3 m · kg, 24 ft · lb)**




EBS00218


CYLINDER HEAD



Order	Job/Part	Q'ty	Remarks
	Removing the cylinder head		Remove the parts in the order listed.
	Carburetor assembly		Refer to "CARBURETOR" in chapter 5.
	Exhaust pipe/muffler		Refer to "ENGINE".
	C.D.I. magneto cover		Refer to "C.D.I. MAGNETO".
1	Spark plug lead	1	
2	Spark plug	1	
3	Camshaft sprocket cover	1	
4	Intake tappet cover	1	
5	Exhaust tappet cover	1	
6	Timing chain tension adjuster	1	
7	Timing chain tensioner assembly	1	Refer to "REMOVING THE CYLINDER HEAD" and "INSTALLING THE CYLINDER HEAD".
8	Camshaft sprocket	1	
9	Cylinder head	1	
10	Intake side timing chain guide	1	




Order	Job/Part	Q'ty	Remarks
11	Exhaust side timing chain guide	1	For installation, reverse the removal procedure.
12	Cylinder head gasket	1	
13	Dowel pin	2	



4. Remove:
- bolts
 - nuts
 - cylinder head ①

NOTE:

Working in a crisscross pattern, loosen each nut 1/4 of a turn.




EBS00224


CHECKING THE CAMSHAFT SPROCKET

1. Check:
- camshaft sprocket
Wear/damage → Replace the camshaft sprocket and timing chain as a set.

- ① 1/4 of a tooth
- ② Correct
- ③ Roller
- ④ Sprocket

**CHECKING THE TAPPET COVERS AND CAMSHAFT SPROCKET COVER**


1. Check:
- tappet covers ①
 - camshaft sprocket cover ②
 - O-rings
Cracks/damage → Replace.



EBS00226

CHECKING THE TIMING CHAIN GUIDES

1. Check:
- intake side timing chain guide ①
 - exhaust side timing chain guide ②
Wear/damage → Replace.




EBS00228

CHECKING THE TIMING CHAIN TENSIONER ASSEMBLY

1. Check:
- chain tensioner assembly
Wear/damage → Replace.



- i. If the marks are aligned, temporarily tighten the camshaft sprocket bolt. If the marks are not aligned, change the meshing position of the camshaft sprocket and timing chain.



- 3. Install:
 - timing chain tensioner assembly

18 Nm (1.8 m · kg, 13 ft · lb)

- timing chain tension adjuster

NOTE: _____

- Align the timing chain tensioner rod groove ① with the timing chain tensioner straight plug projection ②.
- The flat surface ③ of the timing chain tensioner rod should face towards the adjuster threaded hole ④.

⚠ WARNING _____

Always use a new gasket.


- 4. Adjust:
 - timing chain tensioner
 Refer to “ADJUSTING THE TIMING CHAIN TENSIONER” in chapter 3.

- 5. Tighten:
 - camshaft sprocket bolt ①

20 Nm (2.0 m · kg, 14 ft · lb)

NOTE: _____

- Use the sheave holder ② to hold the rotor.
- Do not allow the sheave holder to touch the projection on the rotor.




Sheave holder
P/N. YS-01880-A, 90890-01701

- 6. Check:
 - camshaft sprocket alignment mark
 - rotor “T” mark
 Out of alignment → Adjust.




EBS00235


CAMSHAFT, ROCKER ARMS AND VALVES



Order	Job/Part	Q'ty	Remarks
	Removing the camshaft, rocker arms and valves		Remove the parts in the order listed.
	Cylinder head		Refer to "CYLINDER HEAD".
1	Intake manifold	1	
2	Rocker arm shaft	2	Refer to "REMOVING THE ROCKER ARMS AND CAMSHAFT" and "INSTALLING THE CAMSHAFT AND ROCKER ARMS".
3	Rocker arm	2	
4	Adjuster	2	
5	Camshaft	1	
6	Valve cotter	4	Refer to "REMOVING THE VALVES AND VALVE SPRINGS" and "INSTALLING THE VALVES AND VALVE SPRINGS".
7	Valve spring retainer	2	
8	Valve spring	2	
9	Intake valve	1	
10	Exhaust valve	1	
11	Valve stem seal	2	
12	Valve spring seat	2	



Order	Job/Part	Q'ty	Remarks
13	Valve guide	2	For installation, reverse the removal procedure.





2. Remove:
 - valve cotters

NOTE:

Attach a valve spring compressor ① and attachment ② between the valve spring retainer and the cylinder head to remove the valve cotters.



Valve spring compressor
 P/N. YM-04019, 90890-04019
Valve spring compressor attachment
 P/N. YM-04108, 90890-04108



EBS00223

CHECKING THE CAMSHAFT

1. Check:
 - cam lobes
 Pitting/scratches/blue discoloration → Replace.
2. Measure:
 - cam lobe dimensions ① and ②
 Out of specification → Replace.



Camshaft lobe limit
Intake
 ① 25.200 mm (0.9921 in)
 ② 20.894 mm (0.8226 in)
Exhaust
 ① 25.201 mm (0.9922 in)
 ② 20.921 mm (0.8237 in)

EBS00239

CHECKING THE ROCKER ARMS AND ROCKER ARM SHAFTS

The following procedure applies to all of the rocker arms and rocker arm shafts.

1. Check:
 - rocker arm
 Damage/wear → Replace.



2. Check:

- rocker arm shaft

Blue discoloration/excessive wear/pitting/scratches → Replace or check the lubrication system.

3. Check:


- camshaft lobe

Excessive wear → Replace the camshaft.

4. Measure:

- rocker arm inside diameter Ⓐ

Out of specification → Replace.




Rocker arm inside diameter
10.000 ~ 10.015 mm
(0.3937 ~ 0.3943 in)

5. Measure:

- rocker arm shaft outside diameter Ⓐ

Out of specification → Replace.



Rocker arm shaft outside diameter
9.981 ~ 9.991 mm
(0.3930 ~ 0.3933 in)

6. Calculate:

- rocker-arm-to-rocker-arm-shaft clearance


NOTE:

Calculate the clearance by subtracting the rocker arm shaft outside diameter from the rocker arm inside diameter.

Above 0.08 mm (0.0031 in) → Replace the defective part(s).



Rocker-arm-to-rocker-arm-shaft clearance
0.009 ~ 0.034 mm
(0.0004 ~ 0.0013 in)
<Limit>: 0.08 mm (0.0031 in)




EBS00240

CHECKING THE VALVES AND VALVE SPRINGS

1. Measure:
 - stem-to-guide clearance

$$\text{Stem-to-guide clearance} = \text{valve guide inside diameter (a)} - \text{valve stem diameter (b)}$$

Out of specification → Replace the valve guide.



Stem-to-guide clearance

Intake

0.010 ~ 0.037 mm
(0.0004 ~ 0.0015 in)
<Limit>: 0.08 mm (0.0031 in)

Exhaust


0.025 ~ 0.052 mm
(0.0010 ~ 0.0020 in)
<Limit>: 0.10 mm (0.0039 in)

2. Replace:
 - valve guide




NOTE:


To ease guide removal, installation and to maintain correct fit, heat the cylinder head to 100 °C (212 °F) in an oven.



- a. Remove the valve guide using a valve guide remover ①.
- b. Install the new valve guide using a valve guide remover ① and valve guide installer ②.
- c. After installing the valve guide, bore the valve guide using a valve guide reamer ③ to obtain proper stem-to-guide clearance.



Valve guide remover (5 mm)
P/N. YM-04097, 90890-04097
Valve guide installer (5 mm)
P/N. YM-04098, 90890-04098
Valve guide reamer (5 mm)
P/N. 90890-04099




NOTE:

After replacing the valve guide reface the valve seat.





3. Check:
 - valve face
Pitting/wear → Grind the face.
 - valve stem end
Mushroom shape or diameter larger than the body of the stem → Replace.
4. Measure:
 - margin thickness [Ⓐ]
Out of specification → Replace.

**Margin thickness****Intake**

0.5 ~ 0.9 mm

(0.0197 ~ 0.0354 in)


<Limit>: 1.6 mm (0.0630 in)

Exhaust

0.6 ~ 1.0 mm

(0.0236 ~ 0.0394 in)

<Limit>: 1.6 mm (0.0630 in)



5. Measure:
 - runout (valve stem)
Out of specification → Replace.


**Runout limit**

0.02 mm (0.0008 in)


NOTE:

- When installing a new valve always replace the guide.
- If the valve is removed or replaced always replace the oil seal.

6. Eliminate:
 - carbon deposits
(from the valve face and valve seat)
7. Check:
 - valve seats
Pitting/wear → Reface the valve seat.



302-024



- b. Apply molybdenum disulfide oil to the valve stem.
- c. Install the valve into the cylinder head.
- d. Turn the valve until the valve face and valve seat are evenly polished, then clean off all of the compound.

NOTE: _____


For best lapping results, lightly tap the valve seat while rotating the valve back and forth between your hands.

- e. Apply a fine lapping compound to the valve face and repeat the above steps.

NOTE: _____

After every lapping operation be sure to clean off all of the compound from the valve face and valve seat.

- f. Apply Mechanic's blueing dye (Dykem) to the valve face.
- g. Install the valve into the cylinder head.
- h. Press the valve through the valve guide and onto the valve seat to make a clear pattern.
- i. Measure the valve seat width again. If the valve seat width is out of specification, reface and relap the valve seat.




302-005

10. Measure:

- valve spring free length (a)
Out of specification → Replace.



Valve spring free length
32 mm (1.26 in)
<Limit>: 30.4 mm (1.20 in)




302-006

11. Measure:

- compressed spring force (a)
Out of specification → Replace.
- (b) Installed length



Compressed spring force
136 ~ 158 N at 24.6 mm
(13.87 ~ 16.11 kg,
30.57 ~ 35.52 lb at 0.97 in)



302 028

12. Measure:


- spring tilt ①
- Out of specification → Replace.



Spring tilt limit

Inner

2.5°/1.4 mm (2.5°/0.06 in)



11172001

EBS00241

INSTALLING THE VALVES AND VALVE SPRINGS

1. Apply:
 - molybdenum disulfide oil
(onto the valve stem and valve stem seal)
2. Install:
 - valve spring seats
 - valve stem seals **New**
 - valves
 - valve springs
 - valve spring retainers

NOTE: _____

Install the valve springs with the larger pitch ① facing upwards.


② Smaller pitch

3. Install:

- valve cotters

NOTE: _____

Install the valve cotters while compressing the valve spring with the valve spring compressor ① and attachment ②.




Valve spring compressor

P/N. YM-04019, 90890-04019

Valve spring compressor attachment



P/N. YM-04108, 90890-04108



4. To secure the valve cotters onto the valve stem, lightly tap the valve tip with a piece of wood.

CAUTION: _____

Hitting the valve tip with excessive force could damage the valve.



EBS00243

**INSTALLING THE CAMSHAFT AND
ROCKER ARMS**

1. Install:
 - camshaft ①

NOTE: _____

Install the camshaft groove ② facing down.

2. Apply:
 - engine oil
(onto the rocker arm shafts)
3. Install:
 - rocker arms ①
 - rocker arm shafts


NOTE: _____

Use a slide hammer bolt ② to install the rocker arm shaft.



EBS00245

CYLINDER AND PISTON





Order	Job/Part	Q'ty	Remarks
	Removing the cylinder and piston		Remove the parts in the order listed.
	Cylinder head		Refer to "CYLINDER HEAD".
1	Cylinder	1	Refer to "INSTALLING THE CYLINDER".
2	Cylinder gasket	1	
3	Dowel pin	2	
4	Piston pin clip	2	
5	Piston pin	1	Refer to "REMOVING THE PISTON" and "INSTALLING THE PISTON".
6	Piston	1	
7	Piston ring set	1	
			For installation, reverse the removal procedure.

Cylinder bore "C"	39.000 ~ 39.005 mm (1.5354 ~ 1.5356 in)
Taper limit "T"	0.05 mm (0.002 in)
Out-of-round "R"	0.01 mm (0.0004 in)

"C" = maximum of D ₁ ~ D ₂
"T" = maximum of D ₁ or D ₂ – maximum of D ₅ or D ₆
"R" = maximum of D ₁ , D ₃ or D ₅ – minimum of D ₂ , D ₄ or D ₆


- b. If out of specification, rebore or replace the cylinder, and replace the piston and piston rings as a set.
- c. Measure piston skirt diameter "P" with the micrometer.
- Ⓐ 5 mm (0.20 in) from the bottom edge of the piston



	Piston size "P"
Standard	38.960 ~ 38.975 mm (1.5339 ~ 1.5344 in)


- d. If out of specification, replace the piston and piston rings as a set.
- e. Calculate the piston-to-cylinder clearance with the following formula.

Piston-to-cylinder clearance = Cylinder bore "C" – Piston skirt diameter "P"

	Piston-to-cylinder clearance 0.025 ~ 0.045 mm (0.0010 ~ 0.0018 in) <Limit>: 0.15 mm (0.0059 in)
---	--

- f. If out of specification, rebore or replace the cylinder, and replace the piston and piston rings as a set.





EBS00250

CHECKING THE PISTON RINGS

1. Measure:

- piston ring side clearance

Out of specification → Replace the piston and piston rings as a set.

NOTE:

Before measuring the piston ring side clearance, eliminate any carbon deposits from the piston ring grooves and piston rings.

**Piston ring side clearance****Top ring**

0.030 ~ 0.065 mm

(0.0012 ~ 0.0026 in)


<Limit>: 0.12 mm (0.0047 in)

2nd ring

0.020 ~ 0.055 mm

(0.0008 ~ 0.0022 in)

<Limit>: 0.12 mm (0.0047 in)



307-027

2. Install:

- piston ring
(into the cylinder)

NOTE:

Level the piston ring into the cylinder with the piston crown.

3. Measure:

- piston ring end gap

Out of specification → Replace the piston ring.

NOTE:

The oil ring expander spacer's end gap cannot be measured. If the oil ring rail's gap is excessive, replace all three piston rings.

**Piston ring end gap****Top ring**

0.08 ~ 0.20 mm

(0.0031 ~ 0.0079 in)

<Limit>: 0.45 mm (0.0177 in)

2nd ring

0.05 ~ 0.20 mm

(0.0020 ~ 0.0079 in)

<Limit>: 0.55 mm (0.0217 in)

Oil ring

0.20 ~ 0.70 mm

(0.0079 ~ 0.0276 in)




EBS00251

CHECKING THE PISTON PIN

1. Check:

- piston pin

Blue discoloration/grooves → Replace the piston pin and then check the lubrication system.




2. Measure:

- piston pin outside diameter (a)

Out of specification → Replace the piston pin.



Piston pin outside diameter
12.996 ~ 13.000 mm
(0.5117 ~ 0.5118 in)
<Limit>: 12.976 mm (0.5109 in)



3. Measure:

- piston pin bore diameter (b)

Out of specification → Replace the piston.



Piston pin bore diameter
13.002 ~ 13.013 mm
(0.5119 ~ 0.5123 in)
<Limit>: 13.043 mm (0.5135 in)

4. Calculate:




- piston-pin-to-piston-pin-bore clearance

Out of specification → Replace the piston pin and piston as a set.

Piston-pin-to-piston-pin-bore clearance =
Piston pin bore diameter (b) –
Piston pin outside diameter (a)



Piston-pin-to-piston clearance
0.002 ~ 0.017 mm
(0.00008 ~ 0.00067 in)
<Limit>: 0.067 mm (0.00264 in)



EBS00252

INSTALLING THE PISTON

1. Install:
 - piston rings
(onto the piston)

NOTE:

- Be sure to install the piston rings so that the manufacturer's marks or numbers are located on the upper side of the rings.
- Lubricate the piston and piston rings liberally with engine oil.

2. Position:

- top ring
- 2nd ring
- oil ring

Offset the piston ring end gaps as shown.

- Ⓐ Top ring end
- Ⓑ Upper oil ring rail end
- Ⓒ Expander end
- Ⓓ Lower oil ring rail end
- Ⓔ 2nd ring end
- Ⓕ 20 mm (0.79 in)

3. Install:

- piston ①
- piston pin ②
- piston pin clips ③ **New**

NOTE:


- Apply engine oil onto the piston pin, piston rings and piston.
- Be sure that the arrow mark Ⓐ on the piston points to the exhaust side of the engine.
- Before installing the piston pin clips, cover the crankcase with a clean rag to prevent the piston pin clips from falling into the crankcase.

4. Lubricate:

- piston
- piston rings
- cylinder

NOTE:

Apply a liberal coating of engine oil.



EBS00253

INSTALLING THE CYLINDER

1. Install:
 - cylinder

NOTE: _____

Install the cylinder with one hand while compressing the piston rings with the other hand.


CAUTION: _____

- Be careful not to damage the timing chain damper during installation.
- Pass the timing chain through the timing chain cavity.




EBS00256

C.D.I. MAGNETO



Order	Job/Part	Q'ty	Remarks
	Removing the C.D.I. magneto		Remove the parts in the order listed.
	Rear fender		Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3.
1	Shift lever	1	Refer to "INSTALLING THE SHIFT LEVER".
2	C.D.I. magneto cover	1	
3	C.D.I. magneto cover gasket	1	
4	Dowel pin	2	
5	C.D.I. magneto rotor	1	Refer to "REMOVING THE C.D.I. MAGNETO ROTOR" and "INSTALLING THE C.D.I. MAGNETO ROTOR".
6	Woodruff key	1	
7	Pickup coil/stator assembly	1	
8	Neutral switch	1	
			For installation, reverse the removal procedure.



EBS00259


REMOVING THE C.D.I. MAGNETO ROTOR

1. Remove:

- C.D.I. magneto rotor nut
- washer

NOTE:

- While holding the C.D.I. magneto rotor ① with the sheave holder ②, loosen the rotor nut.
- Do not allow the sheave holder to touch the projection on the rotor.


**Sheave holder****P/N. YS-01880-A, 90890-01701**

2. Remove:

- C.D.I. magneto rotor ①
- woodruff key

NOTE:

Use the flywheel puller ②.

**Flywheel puller****P/N. YM-01189, 90890-01189**

EBS00262

CHECKING THE PICKUP COIL/STATOR ASSEMBLY

1. Check:

- pickup coil/stator assembly
Damage → Replace.




EBS00268

INSTALLING THE C.D.I. MAGNETO ROTOR

1. Install:
 - woodruff key
 - C.D.I. magneto rotor

NOTE: _____

- Before installing the rotor, clean the outside of the crankshaft and the inside of the rotor.
- After installing the rotor, check that the rotor rotates smoothly. If not, reinstall the key and rotor.



2. Tighten:
 - C.D.I. magneto rotor nut


	40 Nm (4.0 m · kg, 29 ft · lb)
--	---------------------------------------

NOTE: _____

- While holding the C.D.I. magneto rotor ① with the sheave holder ②, tighten the C.D.I. magneto rotor nut.
- Do not allow the sheave holder to touch the projection on the rotor.



Sheave holder P/N. YS-01880-A, 90890-01701
--

**INSTALLING THE SHIFT LEVER**

1. Install:
 - shift lever


NOTE: _____

Temporarily install the left footrest board, and then install the shift lever and align it with the mark ① on the left footrest board.




EBS00291


CLUTCH



Order	Job/Part	Q'ty	Remarks
	Removing the clutch		
	Engine oil		Remove the parts in the order listed. Drain. Refer to "CHANGING THE ENGINE OIL" in chapter 3.
	C.D.I. magneto cover		Refer to "C.D.I. MAGNETO".
1	Clutch cover	1	Refer to "REMOVING THE CLUTCH" and "INSTALLING THE CLUTCH".
2	Clutch cover gasket	1	
3	Dowel pin	2	
4	Push plate	1	
5	Circlip	1	
6	Pressure plate	1	
7	Push rod	1	
8	Friction plate 1 (with black color marking)	4	Refer to "INSTALLING THE CLUTCH".



Order	Job/Part	Q'ty	Remarks
9	Clutch plate 1	1	Refer to "INSTALLING THE CLUTCH".
10	Clutch plate 2	3	
11	Friction plate 2	1	
12	Thrust weight plate	1	
13	Clutch ball	12	
14	Thrust plate	1	
15	Clutch boss	1	
16	Clutch boss one-way cam	1	
17	Primary driven gear/clutch housing	1	
18	Spacer	1	
19	Primary drive gear	1	



EBS00297

REMOVING THE CLUTCH

1. Remove:
 - clutch cover


NOTE:

Loosen each screw 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the screws are fully loosened, remove them.


2. Loosen:
 - clutch boss nut ①

NOTE:

While holding the clutch boss ② with the clutch holder ③, loosen the clutch boss nut.



Clutch holder
P/N. 90890-04100




EBS00298

REMOVING THE PRIMARY DRIVE GEAR

1. Loosen:
 - primary drive gear nut ①

NOTE:

Place an aluminum plate ② between the teeth of the primary driven gear/clutch housing ③ and primary drive gear ④.



EBS00300

CHECKING THE FRICTION PLATES

The following procedure applies to all of the friction plates.


1. Check:
 - friction plate
Damage/wear → Replace the friction plates as a set.
2. Measure:
 - friction plate thickness
Out of specification → Replace the friction plates as a set.

NOTE:

Measure the friction plate at four places.



Friction plate thickness
2.92 ~ 3.08 mm (0.115 ~ 0.121 in)
<Limit>: 2.90 mm (0.114 in)



EBS00301


CHECKING THE CLUTCH PLATES

The following procedure applies to all of the clutch plates.

1. Check:
 - clutch plate
Damage → Replace the clutch plates as a set.
2. Measure:
 - clutch plate warpage
(with a surface plate and thickness gauge ①)
Out of specification → Replace the clutch plates as a set.



Clutch plate warpage limit
0.06 mm (0.002 in)



EBS00302


CHECKING THE CLUTCH SPRINGS

The following procedure applies to all of the clutch springs.

1. Check:
 - clutch spring
Damage → Replace the clutch springs as a set.
2. Measure:
 - clutch spring free length ②
Out of specification → Replace the clutch springs as a set.



Clutch spring free length
31.9 mm (1.26 in)
<Limit>: 30.3 mm (1.19 in)




EBS00303

CHECKING THE CLUTCH HOUSING

1. Check:
 - clutch housing dogs
Damage/pitting/wear → Deburr the clutch housing dogs or replace the clutch housing.
 - clutch housing bearing
Damage/pitting/wear → Replace.

NOTE:

Pitting on the clutch housing dogs will cause erratic clutch operation.



EBS00304

CHECKING THE CLUTCH BOSS


1. Check:

- clutch boss splines
- clutch boss cam groove
- clutch boss one-way cam

Damage/pitting/wear → Replace the clutch boss and clutch boss one-way cam as a set.

NOTE:

Pitting on the clutch boss splines will cause erratic clutch operation.



EBS00305

CHECKING THE PRESSURE PLATE

1. Check:

- pressure plate


Cracks/damage → Replace.

CHECKING THE CLUTCH BALLS

1. Check:

- clutch ball

Pitting/damage/wear → Replace the clutch balls as a set.



EBS00307


CHECKING THE PRIMARY DRIVE GEARS

1. Check:

- primary drive gear ①
- primary driven gear ②

Damage/wear → Replace the primary drive gear and clutch housing as a set.

Excessive noise during operation → Replace the primary drive gear and clutch housing as a set.



EBS00310

INSTALLING THE PRIMARY DRIVE GEAR

1. Tighten:

- primary drive gear nut ①

50 Nm (5.0 m · kg, 36 ft · lb)


NOTE: _____

Place an aluminum plate ② between the teeth of the primary driven gear/clutch housing ③ and primary drive gear ④.



Sheave holder

P/N. YS-01880-A, 90890-01701




INSTALLING THE CLUTCH

1. Install:

- clutch balls

NOTE: _____

Install the clutch balls ① on the primary driven gear/clutch housing as shown.




2. Install:

- thrust weight plate
- clutch boss one-way cam
- clutch boss

NOTE: _____


Align section ① of the clutch boss one-way cam with section ② of the clutch boss and then install the primary driven gear/clutch housing.



5. Install:
- clutch housing ①

NOTE:


Make sure that the primary driven gear teeth and primary drive gear teeth mesh correctly.




6. Install:
- clutch boss one-way cam ①
 - clutch boss ②

NOTE:

Align section (a) of the clutch boss one-way cam with section (b) of the clutch boss and then install the primary driven gear/clutch housing.



7. Tighten:
- clutch boss nut ①


 60 Nm (6.0 m · kg, 43 ft · lb)

NOTE:

While holding the clutch boss ② with the clutch holder ③, tighten the clutch boss nut.





Clutch holder
P/N. 90890-04100



8. Install:
- clutch balls

NOTE:

Install the clutch balls on the primary driven gear/clutch housing as shown.



9. Install:

- thrust weight plate ①
- friction plate 2 ②
- clutch plates 2 ③
- friction plates 1 ④
- clutch plate 1 ⑤
- pressure plate ⑥

Ⓐ silver section

NOTE:

Install the clutch plates and friction plates alternately on the clutch boss, starting and ending with a friction plate.

CAUTION:

- The friction plate 2 ② must be placed between the thrust weight plate and the third clutch plate 2.
- The clutch plate 1 ⑤ must be placed between the first and second friction plate 1.

10. Install:

- clutch cover

7 Nm (0.7 m · kg, 5.1 ft · lb)


NOTE:

Tighten the screws in stage, using a crisscross pattern.



EBS00315


STARTER CLUTCH AND OIL PUMP




Order	Job/Part	Q'ty	Remarks
	Removing the starter clutch and oil pump		Remove the parts in the order listed.
	Clutch assembly		Refer to "CLUTCH".
1	Starter idle gear assembly	1	
2	Starter wheel gear	1	
3	Starter clutch assembly	1	
4	Spacer	1	
5	Oil pump drive gear	1	
6	Oil pump driven gear	1	
7	Oil pump assembly	1	
8	Oil pump gasket	1	
9	Oil strainer	1	
			For installation, reverse the removal procedure.




EBS00316



Order	Job/Part	Q'ty	Remarks
	Disassembling the oil pump		Remove the parts in the order listed.
①	Oil pump housing cover	1	
②	Oil pump shaft	1	
③	Inner rotor	1	
④	Outer rotor	1	
⑤	Oil pump housing	1	
			For assembly, reverse the disassembly procedure.




4. Check:
 - starter idle gear teeth ①
 - starter wheel gear teeth ②
 Burrs/clips/roughness/wear → Replace.
5. Check:
 - starter wheel gear contacting surface ①
 Damage/pitting/wear → Replace.




EBS00330

CHECKING THE OIL PUMP

1. Check:
 - oil pump drive gear ①
 - oil pump driven gear ②
 - oil pump housing ③
 - oil pump housing cover ④
 Cracks/wear/damage → Replace.
2. Clean:
 - oil strainer ①
 Damage → Replace.





3. Measure:

- inner-rotor-to-outer-rotor-tip clearance (a)
- outer-rotor-to-oil-pump-housing clearance (b)
- oil-pump-housing-to-inner-rotor-and-outer-rotor clearance (c)

Out of specification → Replace the oil pump.

- ① Inner rotor
- ② Outer rotor
- ③ Oil pump housing



Inner-rotor-to-outer-rotor-tip clearance

0.05 ~ 0.07 mm
(0.002 ~ 0.003 in)

<Limit>: 0.15 mm (0.006 in)

Outer-rotor-to-oil-pump-housing clearance


0.013 ~ 0.036 mm
(0.0005 ~ 0.0014 in)

<Limit>: 0.106 mm (0.0042 in)

Oil-pump-housing-to-inner-rotor-and-outer-rotor clearance

0.06 ~ 0.10 mm
(0.0024 ~ 0.0039 in)

<Limit>: 0.17 mm (0.0067 in)




4. Check:

- oil pump operation


Rough movement → Repeat steps #1 and #3 or replace the defective parts.



SHIFT SHAFT




Order	Job/Part	Q'ty	Remarks
	Removing the shift shaft		
	Clutch assembly		Remove the parts in the order listed. Refer to "CLUTCH".
1	Shift shaft	1	
2	Stopper lever	1	
3	Dowel pin	5	
			For installation, reverse the removal procedure.



EBS01018

CHECKING THE SHIFT SHAFT


1. Check:
 - shift shaft ①
Bends/damage/wear → Replace.
 - shift shaft spring ②
Damage/wear → Replace.



EBS01019

CHECKING THE STOPPER LEVER


1. Check:
 - stopper lever ①
Bends/damage → Replace.
 - stopper lever spring ②
Roller turns roughly → Replace the stopper lever.

**INSTALLING THE STOPPER LEVER**

1. Install:
 - stopper lever ①

NOTE:

Hook the hooked end of the stopper lever spring onto the stopper lever and catch the straight end of the stopper lever spring onto the crankcase.

**INSTALLING THE SHIFT SHAFT**

1. Install:
 - shift shaft ①


NOTE:

- Install the end of the shift shaft spring onto the shift shaft spring stopper ②.
- Make sure that the arm section of the shift shaft contacts the dowel pins on the shift drum ③.



EBS00319

CRANKCASE




Order	Job/Part	Q'ty	Remarks
	Removing the timing chain and separating the crankcase		Remove the parts in the order listed.
	Engine		Refer to "ENGINE".
	Cylinder head		Refer to "CYLINDER HEAD".
	Cylinder and piston		Refer to "CYLINDER AND PISTON".
	C.D.I. magneto		Refer to "C.D.I. MAGNETO".
	Clutch		Refer to "CLUTCH".
	Starter clutch and oil pump		Refer to "STARTER CLUTCH AND OIL PUMP".
	Shift shaft		Refer to "SHIFT SHAFT".
1	Timing chain	1	Refer to "SEPARATING THE CRANKCASE" and "ASSEMBLING THE CRANKCASE".
2	Shift drum retainer	1	
3	Right crankcase	1	
4	Dowel pin	2	
5	Left crankcase	1	
			For installation, reverse the removal procedure.




EBS00321

CRANKCASE BEARINGS



Order	Job/Part	Q'ty	Remarks
	Removing the crankcase bearings		Remove the parts in the order listed.
	Crankshaft		Refer to "CRANKSHAFT".
	Transmission		Refer to "TRANSMISSION".
	Middle driven pinion gear		Refer to "MIDDLE GEAR".
1	Bearing retainer	1	
2	Bearing	6	Refer to "INSTALLING THE BEARINGS". For installation, reverse the removal procedure.



EBS00339


CHECKING THE BEARINGS AND OIL SEALS

1. Check:
 - bearings
Clean and lubricate, then rotate the inner race with a finger.
Roughness → Replace.
2. Check:
 - oil seals
Damage/wear → Replace.

EBS00338

CHECKING THE CRANKCASE

1. Thoroughly wash the case halves in a mild solvent.
2. Clean all the gasket mating surfaces and crankcase mating surfaces thoroughly.
3. Check:
 - crankcase
Cracks/damage → Replace.
 - oil delivery passages
Clogged → Blow out with compressed air.




INSTALLING THE BEARINGS

1. Install:
 - left main axle bearing ①

NOTE:

Press the left main axle bearing into the left crankcase ②, as shown in the illustration.

- ① 34.0 ~ 34.5 mm (1.34 ~ 1.36 in)
- ② Crankcase mating surface



EBS00341

ASSEMBLING THE CRANKCASE

1. Apply:
 - sealant (Quick Gasket®) or Yamaha bond No. 1215 ①
(to the mating surfaces of both case halves)




Sealant (Quick Gasket®)
P/N. ACC-11001-05-01
Yamaha bond No. 1215
P/N. 90890-85505

2. Install:
 - dowel pin
3. Fit the right crankcase onto the left case.
Tap lightly on the case with a soft hammer.

CAUTION:

Before installing and torquing the crankcase holding screws, be sure to check whether the transmission is functioning properly by manually rotating the shift drum in both directions.



4. Install:
 - gaskets ① **New**
 - crankcase screws
5. Tighten:
 - crankcase screws

7 Nm (0.7 m · kg, 5.1 ft · lb)

- ② Screw: $\ell = 45$ mm
- ③ Screw: $\ell = 60$ mm
- ④ Screw: $\ell = 75$ mm

NOTE:


Tighten the screws in stages, using a criss-cross pattern.

6. Apply:
 - 4-stroke engine oil
(to the crankshaft pin, bearing and oil delivery hole)
7. Check:
 - crankshaft and transmission operation
Unsmooth operation → Repair.




EBS00326

CRANKSHAFT



Order	Job/Part	Q'ty	Remarks
	Removing the crankshaft		
	Crankcase		Remove the parts in the order listed. Separate. Refer to "CRANKCASE".
1	Crankshaft	1	Refer to "INSTALLING THE CRANKSHAFT". For installation, reverse the removal procedure.



EBS00361

CHECKING THE CRANKSHAFT

1. Measure:

- crank width Ⓐ

Out of specification → Replace the crankshaft.



Crank width
40.20 ~ 40.25 mm
(1.5827 ~ 1.5846 in)

2. Measure:

- side clearance Ⓓ

Out of specification → Replace the crankshaft.



Big end side clearance
0.10 ~ 0.40 mm
(0.0039 ~ 0.0157 in)
<Limit>: 0.50 mm (0.0197 in)

3. Measure:

- runout Ⓒ

Out of specification → Replace the crankshaft.



Runout limit
C1: 0.05 mm (0.0020 in)
C2: 0.04 mm (0.0016 in)

4. Measure:

- small end free play Ⓕ

Out of specification → Replace the big end bearing, crankshaft pin, connecting rod and/or side washer as a set.



Small end free play
Standard
0.80 ~ 1.00 mm
(0.0315 ~ 0.0394 in)
<Limit>: 1.50 mm (0.0591 in)

EBS00362

INSTALLING THE CRANKSHAFT

1. Install:

- crankshaft


CAUTION:

Apply engine oil to each bearing to protect the crankshaft against scratches and to make installation easier.




EBS00345

TRANSMISSION



Order	Job/Part	Q'ty	Remarks
	Removing the transmission		
	Crankcase		Remove the parts in the order listed. Separate. Refer to "CRANKCASE".
1	Main axle/1st pinion gear	1	Refer to "REMOVING THE TRANSMISSION" and "INSTALLING THE TRANSMISSION".
2	Shift fork guide bar	1	
3	Shift fork	1	
4	Drive axle/middle drive pinion gear assembly	1	
5	Shift drum	1	
6	1st wheel gear	1	
7	Drive axle dog gear	1	
8	Middle drive gear shim	1	
			For installation, reverse the removal procedure.




REMOVING THE TRANSMISSION

1. Remove:

- shift fork guide bar ①
- shift fork ②
- drive axle/middle drive pinion gear assembly ③
- shift drum ④

NOTE:

Remove the shift fork guide bar, shift fork, drive axle/middle drive gear assembly, and shift drum from the crankcase together.




EBS00350

CHECKING THE SHIFT FORK

1. Check:

- shift fork cam follower ①
- shift fork pawl ②

Bends/damage/scoring/wear → Replace the shift fork.



11520401


2. Check:

- shift fork guide bar

Roll the shift fork guide bar on a flat surface.
Bends → Replace.

⚠ WARNING

Do not attempt to straighten a bent shift fork guide bar.




11520101

3. Check:

- shift fork movement

(along the shift fork guide bar)


Rough movement → Replace the shift fork and shift fork guide bar as a set.



EBS01103

CHECKING THE SHIFT DRUM

1. Check:
 - shift drum grooves
Damage/scratches/wear → Replace the shift drum assembly.
 - shift drum segment ①
Damage/wear → Replace the shift drum assembly.



I1650702


EBS00354

CHECKING THE TRANSMISSION

1. Measure:
 - main axle runout
(with a centering device and dial gauge ①)
Out of specification → Replace the main axle.




**Main axle runout limit
0.08 mm (0.0031 in)**



2. Measure:
 - drive axle runout
(with a centering device and dial gauge ①)
Out of specification → Replace the drive axle.




**Drive axle runout limit
0.08 mm (0.0031 in)**



I1650401

3. Check:
 - transmission gears
Blue discoloration/pitting/wear → Replace the defective gear(s).
 - transmission gear dogs
Cracks/damage/rounded edges → Replace the defective gear(s).
4. Check:
 - transmission gear engagement
(each pinion gear to its respective wheel gear)
Incorrect → Reassemble the transmission axle assemblies.
5. Check:
 - transmission gear movement
Rough movement → Replace the defective part(s).
6. Check:
 - circlips
Bends/damage/looseness → Replace.




EBS00357

INSTALLING THE TRANSMISSION**1. Install:**

- shift drum ①
- drive axle/middle drive pinion gear assembly ②
- shift fork ③
- shift fork guide bar ④

NOTE:

- The embossed marks on the shift fork should face towards the left of the engine.
- Be sure to install the forked section ① of the drive axle/middle drive gear assembly around the shift fork guide bar when installing the transmission.

**2. Check:**

- transmission
Rough movement → Repair.


NOTE:

- Oil each gear and bearing thoroughly.
- Before assembling the crankcase, be sure that the transmission is in neutral and that the gears turn freely.






EBS00363

MIDDLE GEAR



Order	Job/Part	Q'ty	Remarks
	Removing the middle gear		Remove the parts in the order listed.
	Crankcase		Separate. Refer to "CRANKCASE".
	Drive axle/middle drive pinion gear assembly		Refer to "TRANSMISSION".
1	Middle drive gear shim	1	
2	Middle driven gear shim		Refer to "SELECTING MIDDLE DRIVEN GEAR SHIMS".
3	Bearing	4	
4	Universal joint	1	
5	Universal joint yoke	2	Refer to "REMOVING THE MIDDLE DRIVEN SHAFT" and "INSTALLING THE MIDDLE DRIVEN SHAFT".
6	Middle driven shaft (with driven pinion gear)	1	
7	Bearing retainer	1	
8	Bearing housing	1	
			For installation, reverse the removal procedure.



EBS00366

REMOVING THE MIDDLE DRIVEN SHAFT

1. Remove:

- universal joint



- Remove the circlips.
- Place the universal joint in a press.
- With a suitable diameter pipe ① beneath the yoke ②, press the bearings ③ into the pipe as shown.

NOTE: _____

It may be necessary to lightly tap the yoke with a punch.

- Repeat the steps for the opposite bearing.
- Remove the yoke.

NOTE: _____

It may be necessary to lightly tap the yoke with a punch.



2. Remove:



- nut ①
- washer
- universal joint yoke (front side)

NOTE: _____

Use the universal joint holder ② and attachment ③ to hold the universal joint yoke.



Universal joint holder
P/N. YM-04062, 90890-04062
Universal joint holder attachment
P/N. 90890-04096



3. Install:
- universal joint



- Install the yoke into the universal joint.
- Apply wheel bearing grease to the bearings.
- Install the bearing ① onto the yoke.

CAUTION: _____

Check each bearing. The needles can easily fall out of their races. Slide the yoke back and forth on the bearings; the yoke will not go all the way onto a bearing if a needle is out of place.


- Press each bearing into the universal joint using a suitable socket.

NOTE: _____

The bearing must be inserted far enough into the universal joint so that the circlip can be installed.

- Install the circlips into the groove of each yoke.







EBS00376

MEASURING THE MIDDLE GEAR BACKLASH

1. Measure:
 - middle gear lash


	<p>Middle gear lash 0.17 ~ 0.31 mm (0.007 ~ 0.012 in)</p>
---	--




- a. Temporarily install the drive axle/middle drive pinion gear assembly and middle driven pinion gear.
- b. Attach the pinion gear fix clamp ① to the drive axle/middle drive pinion gear assembly.

	<p>Pinion gear fix clamp P/N. YM-04129, 90890-04129</p>
---	--

NOTE: _____
Tighten the bolt on one corner of the pinion gear fix clamp as shown to secure the pinion gear fix clamp.



- c. Attach the gear lash measurement tool ② and dial gauge ③.

	<p>Gear lash measurement tool P/N. YM-01467, 90890-01467</p>
---	---

- ② 25.2 mm (0.99 in)
- d. Measure the gear lash while rotating the middle driven shaft back and forth.

NOTE: _____
Measure the gear lash at 4 positions. Rotate the middle driven gear 90° each time.

- e. If the gear lash is incorrect, adjust the gear lash by middle driven gear shim(s).






EBS00141

CARBURETOR


CARBURETOR




Order	Job/Part	Q'ty	Remarks
	Removing the carburetor		Remove the parts in the order listed.
1	Fuel overflow hose	1	Refer to "INSTALLING THE CARBURETOR". For installation, reverse the removal procedure.
2	Carburetor air vent hose	1	
3	Fuel hose	1	
4	Carburetor assembly	1	
5	Carburetor top cover	1	
6	Throttle cable	1	
7	Spring	1	
8	Piston valve	1	
9	Jet needle set	1	




EBS00144




Order	Job/Part	Q'ty	Remarks
	Disassembling the carburetor		Remove the parts in the order listed. NOTE: _____ Before disassembling the carburetor, make sure to note the number of times the pilot screw is turned out from the seated position to its set position. _____
①	Throttle stop screw	1	
②	Float chamber	1	
③	Pilot jet	1	
④	Main jet	1	
⑤	Needle jet	1	
⑥	Float pin	1	




Order	Job/Part	Q'ty	Remarks
⑦	Float	1	Refer to "ASSEMBLING THE CARBURETOR".
⑧	Needle valve	1	For assembly, reverse the disassembly procedure.



4. Check:
- piston valve ①
Scratches/wear/damage → Replace.



5. Check:
- carburetor top cover ①
 - spring ②
Cracks/damage → Replace.



6. Check:
- jet needle ①
 - main jet ②
 - needle jet ③
 - pilot jet ④
 - throttle stop screw ⑤
Bends/wear/damage → Replace.
Blockage → Blow out the jets with compressed air.

7. Check:
- piston valve movement
Sticks → Replace the piston valve.
Insert the piston valve into the carburetor body, and check for free movement.

8. Check:
- choke valve movement
Sticks → Replace.




EBS00150

ASSEMBLING THE CARBURETOR**NOTE:** _____

Before assembling the carburetor, make sure to turn out the pilot air screw the same number of times, as noted before disassembly, from the seated position to the set position.

CAUTION: _____


- Before reassembling, wash all of the parts in a clean petroleum based solvent.
- Always use a new gasket.

**INSTALLING THE CARBURETOR**

1. Install:
 - jet needle set
 - piston valve
 - spring
 - throttle cable

NOTE: _____

Align the slit ① of the throttle valve with the tab ② of the carburetor body.



EBS00154

MEASURING AND ADJUSTING THE FUEL LEVEL

1. Measure:

- fuel level ①

Out of specification → Adjust.


	<p>Fuel level (below the float chamber mating surface) 4.0 ~ 5.0 mm (0.16 ~ 0.20 in)</p>
--	---



- Stand the machine on a level surface.
- Install the fuel level gauge ① onto the fuel drain pipe ②.

	<p>Fuel level gauge P/N. YM-01312-A, 90890-01312</p>
--	---

- Loosen the fuel drain screw ③.
- Hold the fuel level gauge vertically next to the line on the float chamber.
- Measure the fuel level.



2. Adjust:

- fuel level



- Remove the carburetor assembly.
- Check the needle valve seat and needle valve.
- If either is worn, replace them as a set.
- If both are fine, adjust the float level by slightly bending the float tang ①.
- Install the carburetor assembly.
- Measure the fuel level again.
- Repeat steps (a) to (f) until the fuel level is within specification.





EBS00155

DRIVE TRAIN

TROUBLESHOOTING

The following conditions may indicate damaged shaft drive components:

Symptoms	Possible Causes
<ol style="list-style-type: none"> 1. A pronounced hesitation or “jerky” movement during acceleration deceleration or sustained speed. (This must not be confused with engine surging or transmission characteristics.) 2. A “rolling rumble” noticeable at low speed; a high-pitched whine; a “clunk” from a shaft drive component or area. 3. A locked-up condition of the shaft drive train mechanism, no power transmitted from the engine to the rear wheels. 	<ol style="list-style-type: none"> A. Bearing damage. B. Improper gear lash. C. Gear tooth damage. D. Broken drive shaft. E. Broken gear teeth. F. Seizure due to lack of lubrication. G. Small foreign objects lodged between the moving parts.

NOTE:

Areas A, B, and C above may be extremely difficult to diagnose. The symptoms are quite subtle and difficult to distinguish from normal machine operating noise. If there is reason to believe these components are damaged, remove the components and check them.



EBS00156

CHECKING NOISES

1. Investigate any unusual noises.



- a. A “rolling rumble” noise during coasting, acceleration, or deceleration. The noise increases with rear wheel speed, but it does not increase with higher engine or transmission speeds.

Diagnosis: Possible wheel bearing damage.

- b. A “whining” noise that varies with acceleration and deceleration.

Diagnosis: Possible incorrect reassembly, too-little gear lash.

CAUTION:

Too little gear lash is extremely destructive to the gear teeth. If a test ride following reassembly indicates this condition, stop riding immediately to minimize gear damage.

- c. A slight “thunk” evident at low speed operation. This noise must be distinguished from normal machine operation.

Diagnosis: Possible broken gear teeth.

⚠ WARNING

Stop riding immediately if broken gear teeth are suspected. This condition could result in the shaft drive assembly locking up, causing loss of control of the machine and possible injury to the rider.



2. Check:

- drained oil

Drained oil shows large amounts of metal particles → Check the bearing for seizure.

NOTE:


A small amount of metal particles in the oil is normal.




EBS00157

TROUBLESHOOTING CHART

When basic condition "a" and "b" exist, check the following points:




REAR AXLE/FINAL DRIVE ASSEMBLY AND DRIVE SHAFT





EBS00178

REAR AXLE/FINAL DRIVE ASSEMBLY AND DRIVE SHAFT



Order	Job/Part	Q'ty	Remarks
	Removing the rear axle/final drive assembly and drive shaft		Remove the parts in the order listed.
	Rear wheels		Refer to "FRONT AND REAR WHEELS" in chapter 7.
	Brake drum cover		Refer to "FRONT AND REAR BRAKES" in chapter 7.
	Final gear oil		Drain. Refer to "CHANGING THE FINAL GEAR OIL" in chapter 3.
1	Nut	1	Refer to "REMOVING THE NUTS" and "INSTALLING THE NUTS".
2	Nut	1	
3	Final gear case breather hose	1	
4	Bolt/nut	1/1	
5	Swingarm guard	1	


REAR AXLE/FINAL DRIVE ASSEMBLY AND DRIVE SHAFT




Order	Job/Part	Q'ty	Remarks
6	Rear axle/final drive assembly	1	Refer to "REMOVING THE REAR AXLE/FINAL DRIVE ASSEMBLY" and "INSTALLING THE REAR AXLE/FINAL DRIVE ASSEMBLY". For installation, reverse the removal procedure.
7	Drive shaft	1	
8	Coupling gear	1	

EBS00179

REAR AXLE/FINAL DRIVE ASSEMBLY



Order	Job/Part	Q'ty	Remarks
	Disassembling the rear axle/final drive assembly		Remove the parts in the order listed.
1	Rear axle housing	1	Refer to "DISASSEMBLING THE REAR AXLE HOUSING" and "ASSEMBLING THE REAR AXLE HOUSING".
2	Rear axle housing bearing retainer	1	
3	Spacer	1	Refer to "DISASSEMBLING THE FINAL GEAR CASE" and "ASSEMBLING THE FINAL GEAR CASE".
4	Final gear case bearing retainer	1	
5	Spacer	1	
6	Final drive pinion gear	1	
7	Rear axle (with final drive ring gear)	1	
8	Final gear case	1	For assembly, reverse the disassembly procedure.



REMOVING THE NUTS

1. Place the machine on a level surface.
2. Loosen:
 - nuts ①


NOTE:

- Apply the rear brake lever so that the rear axle does not turn, when loosening the nuts.
- Use an axle nut wrench (36 mm).



Axle nut wrench (36 mm)
P/N. YM-37132, 90890-01422

3. Elevate the rear wheels by placing the suitable stand under the frame.
4. Remove:
 - rear wheels
 - wheel hubs
 - nuts
5. Remove:
 - rear brake assembly
 Refer to "FRONT AND REAR BRAKES" in chapter 7.





REMOVING THE REAR AXLE/FINAL DRIVE ASSEMBLY

1. Remove:
 - rear axle/final drive assembly ①

NOTE:

Remove the rear axle/final drive assembly as an assembly after removing each bolt and nut.





EBS00181

DISASSEMBLING THE REAR AXLE HOUSING

1. Remove:
 - rear axle housing bearing retainer

NOTE: _____

Use a ring nut wrench ①.

**Ring nut wrench**
P/N. YM-38404, 90890-01430


EBS00181

DISASSEMBLING THE FINAL GEAR CASE

1. Remove:
 - rear axle
(with final drive ring gear)

CAUTION: _____

Never directly tap the axle end with a hammer, since this will result in damage to the axle thread and spline.




2. Remove:
 - final gear case bearing retainer

NOTE: _____

Use a ring nut wrench ①.

**Ring nut wrench**
P/N. YM-38404, 90890-01430

3. Remove:
 - final drive pinion gear assembly
With a soft hammer, lightly tap on the final drive pinion gear end.



EBS00190

CHECKING THE REAR AXLE


1. Check:
 - rear axle runout ①
 Out of specification → Replace.

⚠ WARNING

Do not attempt to straighten a bent axle.




**Rear axle runout limit
1.5 mm (0.06 in)**



EBS00191

CHECKING THE DRIVE SHAFT




1. Check:
 - drive shaft splines ①
 - coupling gear splines ②
 Wear/damage → Replace.



EBS00192

CHECKING THE REAR AXLE HOUSING AND FINAL DRIVE ASSEMBLY

1. Check:
 - final gear case ①
 - rear axle housing ②
 Cracks/damage → Replace.
2. Check:
 - gear teeth
 Pitting/galling/wear → Replace the drive pinion gear and ring gear as a set.
 - oil seals
 - O-rings
 Damage → Replace.
3. Check:
 - bearings
 Damage → Replace.



EBS00195

ASSEMBLING THE FINAL GEAR CASE

1. Install:
 - final drive pinion gear assembly
 - spacer ①
 - bearing
 - final gear case bearing retainer

80 Nm (8.0 m · kg, 58 ft · lb)

Use a ring nut wrench ②.

CAUTION: _____

Always use a new bearing.



Ring nut wrench
P/N. YM-38404, 90890-01430



2. Install:
 - oil seal ①
 - dust seal ②

NOTE: _____

Install the oil seal and dust seal as shown.

Ⓐ 6 ~ 6.5 mm (0.24 ~ 0.26 in)

Ⓑ 1 ~ 2 mm (0.04 ~ 0.08 in)



EBS00195

ASSEMBLING THE REAR AXLE HOUSING

1. Install:
 - rear axle housing bearing retainer

110 Nm (11.0 m · kg, 80 ft · lb)

Use a bearing retainer wrench ①.

CAUTION: _____

Always use a new bearing.



Ring nut wrench
P/N. YM-38404, 90890-01430


2. Install:
 - bearing ①

NOTE: _____

Install the bearing as shown.

Ⓐ 0.5 mm (0.02 in)


Ⓑ rear axle housing bearing retainer



EBS00196

INSTALLING THE REAR AXLE/FINAL DRIVE ASSEMBLY

1. Lubricate:
 - drive shaft
 - coupling gear
 - O-ring
 - oil seal
 - bearing




	Lithium-soap-based grease
--	----------------------------------

2. Install:
 - drive shaft
 - coupling gear (to the universal joint)
3. Install:
 - rear axle/final drive assembly




- a. Apply sealant (Quick Gasket®) or Yamaha bond No. 1215 to the mating surfaces of the swingarm and the final gear case.



	Sealant (Quick Gasket®) P/N. ACC-11001-05-01 Yamaha bond No. 1215 P/N. 90890-85505
--	---

- b. Temporarily install the rear axle/final drive assembly ① on the swingarm ②. The bolts and nuts should be temporarily tightened.
- c. Check that the rear axle rotates smoothly.
- d. Tighten the bolts and nuts.

- ① Rear axle/final drive assembly
- ② Swingarm
- ③ Bolt (× 4)
- ④ Nut (× 3)
- ⑤ Bolt (× 6)



	Bolt ③ 20 Nm (2.0 m · kg, 14 ft · lb)
	Nut ④ 40 Nm (4.0 m · kg, 29 ft · lb)
	Bolt ⑤ 20 Nm (2.0 m · kg, 14 ft · lb) LOCTITE®






EBS00378

CHASSIS

FRONT AND REAR WHEELS

FRONT WHEELS




Order	Job/Part	Q'ty	Remarks
	Removing the front wheels		Remove the parts in the order listed. Place the machine on a level surface. ⚠ WARNING _____ Securely support the machine so there is no danger of it falling over. _____ The following procedure applies to both of the front wheels. Refer to "INSTALLING THE WHEEL HUBS". Refer to "INSTALLING THE WHEELS". For installation, reverse the removal procedure.
1	Cotter pin	1	
2	Axle nut	1	
3	Front wheel	1	
4	Front brake drum	1	



EBS00379

REAR WHEELS



Order	Job/Part	Q'ty	Remarks
	Removing the rear wheels		Remove the parts in the order listed. Place the machine on a level surface. ⚠ WARNING _____ Securely support the machine so there is no danger of it falling over. _____ The following procedure applies to both of the rear wheels.
1	Cotter pin	1	Refer to "INSTALLING THE WHEEL HUBS".
2	Axle nut	1	
3	Rear wheel	1	
4	Rear wheel hub	1	
			For installation, reverse the removal procedure.




⚠ WARNING

Eye protection is recommended when using striking tools.

- c. To install the wheel bearings, reverse the above sequence. Use a socket that matches outside diameter of bearing outer race to drive in bearing.

CAUTION:

Do not strike the center race or balls of the bearing. Contact should be made only with the outer race.




EBS00384

CHECKING THE REAR WHEEL HUBS

The following procedure applies to both of the rear wheel hubs.

1. Check:
 - rear wheel hub ①
Cracks/damage → Replace.
 - wheel hub splines ②
Wear/damage → Replace.



EBS00390



INSTALLING THE WHEEL HUBS

The following procedure applies to both of the front and rear wheel hubs.

1. Install:
 - axle nut ① **70 Nm (7.0 m · kg, 50 ft · lb)**
 - cotter pin ② **New**

NOTE:

Do not loosen the axle nut after torquing it. If the axle nut groove is not aligned with the cotter pin hole, align the groove with the hole by tightening the axle nut.



EBS00391

INSTALLING THE WHEELS

The following procedure applies to both of the front and rear wheels.

1. Install:
 - wheel

NOTE:


The arrow mark ① on the tire must point in the direction of rotation **a** of the wheel.

A Front wheel

B Rear wheel

2. Tighten:

- nuts


 **28 Nm (2.8 m · kg, 20 ft · lb)**



EBS00437

FRONT AND REAR BRAKES


FRONT BRAKE




Order	Job/Part	Q'ty	Remarks
	Removing the front brakes		
	Front wheels		Remove the parts in the order listed. Refer to "FRONT AND REAR WHEELS". The following procedure applies to both of the front brakes.
1	Brake shoe	2	Refer to "INSTALLING THE FRONT BRAKES". Refer to "REMOVING THE BRAKES" and "INSTALLING THE FRONT BRAKES". For installation, reverse the removal procedure.
2	Front brake cable (drum side)	1	
3	Brake shoe plate	1	
4	Brake camshaft lever	1	
5	Brake shoe wear indicator	1	
6	Brake camshaft	1	
7	Left front brake cable (lever side)	1	
8	Right front brake cable (lever side)	1	
9	Front brake lever	1	



REAR BRAKE



Order	Job/Part	Q'ty	Remarks
	Removing the rear brake		Remove the parts in the order listed. Refer to "FRONT AND REAR WHEELS".
1	Brake drum cover	1	Refer to "REAR AXLE/FINAL DRIVE ASSEMBLY AND DRIVE SHAFT" in chapter 6.
2	Nut	1	
3	Nut	1	
4	Lock washer	2	Refer to "INSTALLING THE REAR BRAKE".
5	Brake drum	1	
6	Brake drum boss	1	
7	Brake shoe	2	
8	Rear brake cable (drum side)	1	Refer to "REMOVING THE BRAKES" and "INSTALLING THE REAR BRAKE".
9	Brake camshaft lever	1	
10	Brake shoe wear indicator	1	
11	Brake camshaft	1	



Order	Job/Part	Q'ty	Remarks
12	Rear brake cable (lever side)	1	For installation, reverse the removal procedure.
13	Rear brake switch	1	
14	Rear brake lever	1	

**REMOVING THE BRAKES**

The following procedure applies to each brake.

1. Remove:
 - brake camshaft lever
 - brake shoe wear indicator
 - brake camshaft

NOTE: _____


When removing the brake camshaft lever, mark the position on the brake camshaft lever where it is aligned with the punch mark in the brake camshaft.

EBS00439

CHECKING THE BRAKE SHOE PLATES

The following procedure applies to each brake.

1. Check:
 - brake shoe plate
 - pivot pin
 - brake camshaft
 - Bends/cracks/damage → Replace.
 - dust seal
 - Wear/damage → Replace.



EBS00440


CHECKING THE BRAKE SHOES

The following procedure applies to each brake.

1. Check:
 - brake shoes ①
 - brake shoe springs ②
 - Cracks/damage → Replace as a set.


NOTE: _____

When replacing the brake shoes, replace the brake shoe springs at the same time.



2. Check:
 - brake shoe lining surface
Glazed areas → Remove.
Use coarse sandpaper.

NOTE: _____
After using sandpaper, wipe off the polished particles with a cloth.




3. Measure:
 - brake shoe lining thickness @
Out of specification → Replace.
- ① Measuring points

NOTE: _____
Replace the brake shoes as a set if either is found to be worn to the wear limit.



Brake lining thickness
4.0 mm (0.16 in)
<Limit>: 2.0 mm (0.08 in)



EBS00441

CHECKING THE BRAKE DRUMS


The following procedure applies to each brake.

1. Measure:
 - brake drum inside diameter @
Out of specification → Replace.



Rear brake drum inside diameter
Front: 110.0 mm (4.33 in)
<Limit>: 110.5 mm (4.35 in)
Rear: 130.0 mm (5.12 in)
<Limit>: 130.5 mm (5.14 in)

- Ⓐ Front brake drum
- Ⓑ Rear brake drum



2. Check:
- brake drum inner surface
- Oil/scratches → Remove.

Oil	Use a rag soaked in lacquer thinner or solvent.
Scratches	Use an emery cloth (light and even polishing).

- A** Front brake drum
B Rear brake drum

EBS00442

INSTALLING THE FRONT BRAKES

The following procedure applies to both of the front brakes.

Reverse the “Removal” procedure.



Note the following points.

1. Lubricate:
- brake camshaft
 - pivot pin

	Lithium-soap-based grease
--	----------------------------------

CAUTION:

During installation, lightly grease the brake camshaft and the pivot pin. Wipe off the excess grease.




2. Install:
- brake camshaft ①
 - brake shoe wear indicator ②
 - brake camshaft lever

9 Nm (0.9 m · kg, 6.5 ft · lb)

NOTE:

- Install the brake camshaft so its punch mark (a) is positioned as shown.
- Align the projection on the brake shoe wear indicator with the notch in the brake camshaft.
- Align the punch mark in the brake camshaft with the mark on the brake camshaft lever.

- A** Left side
B Right side



3. Install:
- brake shoe plate ①

NOTE: _____
When installing the brake shoe plate, align the groove ① of the brake shoe plate with the projection ② of the steering knuckle.

4. Install:
- front brake cable (drum side)
 - brake shoes

NOTE: _____
Check that the brake shoes are properly positioned.

5. Check:
- brake camshaft operation
Unsmooth operation → Repair.
6. Adjust:
- front brake
Refer to “ADJUSTING THE FRONT BRAKE” in chapter 3.

EBS00442

INSTALLING THE REAR BRAKE

Reverse the “Removal” procedure.
Note the following points.


1. Lubricate:
- brake camshaft
 - pivot pin




Lithium-soap-based grease

CAUTION: _____

During installation, lightly grease the brake camshaft and the pivot pin. Wipe off the excess grease.



2. Install:
- brake camshaft ①
 - brake shoe wear indicator plate ②
 - brake camshaft lever

 **9 Nm (0.9 m · kg, 6.5 ft · lb)**

NOTE: _____


- Install the brake camshaft so its punch mark ① is positioned as shown.
- Align the projection on the brake shoe wear indicator with the notch in the brake camshaft.
- Align the punch mark in the brake camshaft with the mark on the brake camshaft lever.

3. Install:

- rear brake cable (drum side)
- brake shoes

NOTE: _____

Check that the brake shoes are properly positioned.



4. Install:

- brake drum boss
- brake drum
- lock washers ① **New**

NOTE: _____

Bend the tabs of each lock washer along a flat side of each nut.

5. Check:

- brake camshaft operation
Unsmooth operation → Repair.

6. Adjust:


- rear brake
Refer to “ADJUSTING THE REAR BRAKE” in chapter 3.




EBS00444

STEERING SYSTEM


HANDLEBAR



Order	Job/Part	Q'ty	Remarks
	Removing the handlebar		Remove the parts in the order listed.
	Handlebar cover		Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3.
1	Handlebar grip	2	Refer to "REMOVING THE HANDLEBAR GRIPS" and "INSTALLING THE HANDLEBAR GRIPS".
2	Front brake cable	2	Refer to "INSTALLING THE FRONT BRAKE LEVER ASSEMBLY".
3	Front brake lever assembly	1	
4	Handlebar switch	1	
5	Rear brake cable	1	
6	Rear brake switch	1	
7	Rear brake lever	1	
8	Plastic band	1	



Order	Job/Part	Q'ty	Remarks
9	Upper handlebar holder	2	Refer to "INSTALLING THE HANDLE-BAR".
10	Handlebar	1	
11	Lower handlebar holder	1	
			For installation, reverse the removal procedure.




EBS00447

REMOVING THE HANDLEBAR GRIPS

1. Remove:
 - handlebar grips ①

NOTE:

Blow compressed air between the handlebar and handlebar grip, and gradually push the grip off the handlebar.




EBS00445

REMOVING THE REAR BRAKE SWITCH

1. Remove:
 - rear brake switch ①

NOTE:

Push the fastener when removing the rear brake switch out of the rear brake lever holder.



EBS00448


CHECKING THE HANDLEBAR

1. Check:
 - handlebar ①

Bends/cracks/damage → Replace.

⚠ WARNING

Do not attempt to straighten a bent handlebar as this may dangerously weaken the handlebar.



EBS00449


INSTALLING THE HANDLEBAR

1. Install:
 - lower handlebar holder
 - handlebar
 - upper handlebar holders

20 Nm (2.0 m · kg, 14 ft · lb)

NOTE:

- Install the handlebar within 15° from the horizontal line shown in the illustration.
- The upper handlebar holders should be installed with the punched mark ① forward ②.



CAUTION:

First tighten the bolt ③ on the front side of the handlebar holder, and then tighten the bolt ④ on the rear side.





EBS00450

INSTALLING THE HANDLEBAR GRIPS

1. Install:
 - handlebar grips

NOTE:

- Before installing the handlebar grips, temporarily install the rear brake lever and front brake lever assembly on the handlebar.
- Before applying the adhesive, wipe off grease or oil on the handlebar surface with a lacquer thinner.



EBS00451

INSTALLING THE REAR BRAKE LEVER

1. Install:
 - rear brake lever ①
 - handlebar switch ②

NOTE:

- Install the rear brake lever within 10° from the horizontal line shown in the illustration.
- After installing the rear brake lever, make sure the rear brake lever ①, handlebar switch ②, and handlebar grip ③ are in the positions shown in the illustration.

2. Adjust:

- rear brake
Refer to “ADJUSTING THE REAR BRAKE” in chapter 3.

EBS00452

INSTALLING THE FRONT BRAKE LEVER ASSEMBLY

1. Install:
 - front brake lever assembly ①

NOTE:

- Install the front brake lever assembly within 10° from the horizontal line shown in the illustration.
- After installing the front brake lever assembly, make sure that the clearance ① between the front brake lever assembly ① and handlebar grip ② is 9 mm (0.35 in).


2. Adjust:

- front brake
Refer to “ADJUSTING THE FRONT BRAKE” in chapter 3.




EBS00454

STEERING STEM



Order	Job/Part	Q'ty	Remarks
	Removing the steering stem		Remove the parts in the order listed.
	Front fender		Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3.
	Handlebar		Refer to "HANDLEBAR".
1	Lock washer	1	Refer to "INSTALLING THE LOCK WASHER".
2	Steering stem bushing	2	
3	Spacer	2	
4	Oil seal	2	
5	Steering stem	1	Refer to "REMOVING THE STEERING STEM" and "INSTALLING THE STEERING STEM".
			For installation, reverse the removal procedure.




EBS00455

REMOVING THE STEERING STEM

1. Remove:
 - steering stem

NOTE:

When loosening each tie-rod end nut ①, hold the tie-rod ball joint with a 14-mm wrench ②.




EBS00456

CHECKING THE STEERING STEM


1. Check:
 - steering stem
 - Bends → Replace.

⚠ WARNING

Do not attempt to straighten a bent stem; this may dangerously weaken the stem.



2. Check:
 - steering stem bushings ①
 - Wear/damage → Replace.



INSTALLING THE STEERING STEM

1. Tighten:
 - steering stem nut ①


35 Nm (3.5 m · kg, 25 ft · lb)

- tie-rod end nut ②

40 Nm (4.0 m · kg, 29 ft · lb)

NOTE:

When tightening each tie-rod end nut ②, hold the tie-rod ball joint with a 14-mm wrench ③.



EBS00459

INSTALLING THE LOCK WASHER

1. Install:
 - lock washer ① **New**


NOTE:

Bend a lock washer tab along a flat side of each bolt.




EBS00460

TIE-RODS AND STEERING KNUCKLES



Order	Job/Part	Q'ty	Remarks
	Removing the tie-rods and steering knuckles		Remove the parts in the order listed.
	Front brakes		Refer to "FRONT AND REAR BRAKES". The following procedure applies to both of the tie-rods and steering knuckles.
1	Tie-rod	1	Refer to "REMOVING THE TIE-RODS" and "INSTALLING THE TIE-RODS".
2	Steering knuckle	1	
3	Thrust cover	2	
4	Spacer	1	
5	Bushing	2	
			For installation, reverse the removal procedure.



EBS00461


REMOVING THE TIE-RODS

The following procedure applies to both of the tie-rods.

1. Remove:
 - tie-rod ①

NOTE:

When removing the tie-rod, hold each tie-rod ball joint with a 14-mm wrench ② and then loosen the tie-rod end nut.




EBS00462

CHECKING THE TIE-RODS

The following procedure applies to both of the tie-rods.

1. Check:
 - tie-rod free play and movement
 - Free play → Replace the tie-rod end.
 - Turns roughly → Replace the tie-rod end.
2. Check:
 - tie-rod
 - Bends/damage → Replace.





EBS00464

CHECKING THE STEERING KNUCKLES

The following procedure applies to both of the steering knuckles.

1. Check:
 - steering knuckle
 - Damage/pitting → Replace.




EBS00465

INSTALLING THE TIE-RODS

The following procedure applies to both of the tie-rods.

1. Install:

- tie-rod

 **15 Nm (1.5 m · kg, 11 ft · lb)**

NOTE:

- The tie-rod side which must be installed on the inside has grooves ①.
- When installing the tie-rod, hold each tie-rod ball joint with a 14-mm wrench ② and then tighten the tie-rod end nut.


2. Adjust:

- toe-in





Refer to “ADJUSTING THE TOE-IN” in chapter 3.

EBS00468

FRONT SHOCK ABSORBER ASSEMBLIES AND FRONT SWINGARM



Order	Job/Part	Q'ty	Remarks
	Removing the front shock absorber assemblies and front swingarm		Remove the parts in the order listed.
1	Steering knuckles	2	Refer to "STEERING SYSTEM".
1	Front shock absorber	2	
2	Front swingarm	1	Refer to "REMOVING THE FRONT SWINGARM". For installation, reverse the removal procedure.



EBS00469

REMOVING THE FRONT SWINGARM

1. Check:

- front swingarm free play



- a. Check the front swingarm side play [A] by moving it from side to side.

If side play is noticeable, check the bushings.

- b. Check the front swingarm vertical movement [B] by moving it up and down.

If the vertical movement is tight or rough, or if there is binding, check the bushings.



2. Remove:

- front swingarm

EBS00470

CHECKING THE FRONT SWINGARM

1. Check:

- front swingarm ①
Bends/damage → Replace.

2. Check:

- bushings ②
Wear/damage → Replace.

EBS00471

CHECKING THE FRONT SHOCK ABSORBER ASSEMBLIES

1. Check:

- shock absorber rod
Bends/damage → Replace the shock absorber assembly.

- shock absorber assembly
Oil leaks → Replace the shock absorber assembly.


- spring
Fatigue → Replace the shock absorber assembly.

Move the spring up and down.




EBS00476

REAR SHOCK ABSORBER AND REAR SWINGARM




Order	Job/Part	Q'ty	Remarks
	Removing the rear shock absorber and swingarm		Remove the parts in the order listed.
	C.D.I. magneto cover		Refer to "C.D.I. MAGNETO" in chapter 4.
	Rear axle/final drive assembly		Refer to "REAR AXLE/FINAL DRIVE ASSEMBLY AND DRIVE SHAFT" in chapter 6.
1	Rear shock absorber	1	
2	Pivot shaft	1	
3	Lock washer	1	Refer to "INSTALLING THE LOCK WASHER".
4	Rear swingarm	1	Refer to "REMOVING THE REAR SWINGARM".
5	Metal clamp	2	
6	Dust boot	1	
			For installation, reverse the removal procedure.



EBS00479

CHECKING THE REAR SWINGARM


1. Check:
 - rear swingarm
Bends/cracks/damage → Replace.
2. Check:
 - bushings
Wear/damage → Replace.



EBS00481

CHECKING THE DUST BOOT

1. Check:
 - dust boot ①
Damage → Replace.




INSTALLING THE LOCK WASHER

1. Install:
 - lock washer ① **New**

NOTE:

Insert the small tab of the lock washer in the groove on the swingarm, and then bend the other lock washer tab along a flat side of the pivot shaft head.







EBS00500

ELECTRICAL

ELECTRICAL COMPONENTS

- | | | |
|------------------------------|----------------------------------|-----------------|
| ① Main switch | ⑧ Rectifier/regulator | ⑮ Ignition coil |
| ② Neutral indicator light | ⑨ Diode | ⑯ C.D.I. unit |
| ③ Rear brake switch | ⑩ Starting circuit cut-off relay | ⑰ Wire harness |
| ④ Handlebar switch | ⑪ Starter relay | |
| ⑤ Battery | ⑫ Neutral switch | |
| ⑥ Main fuse | ⑬ Pickup coil/stator assembly | |
| ⑦ Engine stop switch (frame) | ⑭ Starter motor | |





EBS01028

CHECKING SWITCH CONTINUITY

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

CAUTION:

Never insert the tester probes into the coupler terminal slots ①. Always insert the probes from the opposite end of the coupler, taking care not to loosen or damage the leads.



Pocket tester
P/N. YU-03112-C, 90890-03112

NOTE:

- Before checking for continuity, set the pocket tester to "0" and to the "Ω × 1" range.
- When checking for continuity, switch back and forth between the switch positions a few times.

The terminal connections for switches (e.g., main switch, engine stop switch) are shown in an illustration similar to the one on the left.

The switch positions ① are shown in the far left column and the switch lead colors ② are shown in the top row in the switch illustration.


NOTE:

"○—○" indicates a continuity of electricity between switch terminals (i.e., a closed circuit at the respective switch position).

The example illustration on the left shows that:

There is continuity between black and black/white when the switch is set to "OFF".

There is continuity between red and brown when the switch is set to "ON".



EBS01029


CHECKING THE SWITCHES

Check each switch for damage or wear, proper connections, and also for continuity between the terminals. Refer to "CHECKING SWITCH CONTINUITY".

Damage/wear → Repair or replace.


Improperly connected → Properly connect.

Incorrect continuity reading → Replace the switch.



- ① Main switch
- ② Start switch
- ③ Engine stop switch (handlebar)

- ④ Rear brake switch
- ⑤ Neutral switch
- ⑥ Engine stop switch (frame)



EBS01030



CHECKING THE BULBS AND BULB SOCKETS

Check each bulb and bulb socket for damage or wear, proper connections, and also for continuity between the terminals.

Damage/wear → Repair or replace the bulb, bulb socket or both.

Improperly connected → Properly connect.

No continuity → Repair or replace the bulb, bulb socket or both.



TYPES OF BULBS


The bulbs used on this machine are shown in the illustration on the left.

- Bulbs (a) and (b) are used for the headlights and usually use a bulb holder that must be detached before removing the bulb. The majority of these types of bulbs can be removed from their respective socket by turning them counterclockwise.
- Bulbs (c) is used for turn signal and tail/brake lights and can be removed from the socket by pushing and turning the bulb counterclockwise.
- Bulbs (d) and (e) are used for meter and indicator lights and can be removed from their respective socket by carefully pulling them out.

CHECKING THE CONDITION OF THE BULBS

The following procedure applies to all of the bulbs.

1. Remove:
 - bulb



EBS01045

TROUBLESHOOTING

The ignition system fails to operate (no spark or intermittent spark).

Check:

1. spark plug
2. ignition spark gap
3. spark plug cap resistance
4. ignition coil resistance
5. main switch
6. engine stop switches
7. pickup coil resistance
8. source coil resistance
9. wiring connections (of the entire ignition system)

NOTE:

- Before troubleshooting, remove the following part(s):
 1. seat
 2. front fender
 3. fuel tank
- Troubleshoot with the following special tool(s).

Dynamic spark tester
P/N. YM-34487

Ignition checker
P/N. 90890-06754

Pocket tester
P/N. YU-03112-C, 90890-03112

EBS01032

1. Spark plug

- Check the condition of the spark plug.
- Check the spark plug type.
- Measure the spark plug gap.
Refer to “CHECKING THE SPARK PLUG” in chapter 3.

Standard spark plug
CR7HS (NGK)
Spark plug gap
0.6 ~ 0.7 mm (0.024 ~ 0.028 in)

- Is the spark plug in good condition, is it of the correct type, and is its gap within specification?




YES



NO


Re-gap or replace the spark plug.



EBS01034

2. Ignition spark gap

- Disconnect the spark plug cap from the spark plug.
- Connect the ignition dynamic spark tester ① as shown.
- ② Spark plug cap
- ③ Spark plug
- Set the main switch to "ON".
- Measure the ignition spark gap ④.
- Crank the engine by pushing the starter switch and gradually increase the spark gap until a misfire occurs.



**Minimum ignition spark gap
6 mm (0.24 in)**

- Is there a spark and is the spark gap within specification?

NO


YES

The ignition system is OK.

EBS01036

3. Spark plug cap resistance

- Remove the spark plug cap from the spark plug lead.
- Connect the pocket tester ("Ω × 1k" range) to the spark plug cap as shown.



- Measure the spark plug cap resistance.




**Spark plug cap resistance
10 kΩ at 20 °C (68 °F)**

- Is the spark plug cap OK?

YES

NO

Replace the spark plug cap.




EBS01038

4. Ignition coil resistance

- Disconnect the ignition coil connectors from the ignition coil terminals.
- Connect the pocket tester ($\Omega \times 1$) to the ignition coil as shown.

Positive tester probe → orange terminal
Negative tester probe → ignition coil base




- Measure the primary coil resistance.



Primary coil resistance
 0.18 ~ 0.28 Ω at 20 °C (68 °F)

- Connect the pocket tester ($\Omega \times 1k$) to the ignition coil as shown.

Positive tester probe → orange terminal
Negative tester probe → spark plug lead



- Measure the secondary coil resistance.



Secondary coil resistance
 6.32 ~ 9.48 k Ω at 20 °C (68 °F)

- Is the ignition coil OK?

↓ YES

↓ NO

Replace the ignition coil.

EBS01041

5. Main switch

- Check the main switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?

↓ YES

↓ NO

Replace the main switch.

EBS01042


6. Engine stop switches

- Check the engine stop switches for continuity. Refer to "CHECKING THE SWITCHES".
- Are the engine stop switches OK?

↓ YES

↓ NO

Replace the handle-bar switch or engine stop switch (frame).



EBS01040

7. Pickup coil resistance


- Disconnect the C.D.I. magneto coupler from the wire harness.
- Connect the pocket tester ($\Omega \times 100$) to the pickup coil terminal as shown.

Positive tester probe → white/red terminal ①
Negative tester probe → white/blue terminal ②

• Measure the pickup coil resistance.

Pickup coil resistance
 264 ~ 396 Ω at 20 °C (68 °F)
 (between white/red and white/blue)

• Is the pickup coil OK?



EBS01099


8. Source coil resistance

- Disconnect the C.D.I. magneto coupler from the wire harness.
- Connect the pocket tester ($\Omega \times 100$) to the source coil terminal.

Positive tester probe → black/red terminal ①
Negative tester probe → green/white terminal ②

• Measure the source coil resistance.

Source coil resistance
 304 ~ 456 Ω at 20 °C (68 °F)
 (black/red and green/white)



EBS01047

9. Wiring


- Check the entire ignition system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the ignition system's wiring properly connected and without defects?

YES ↓

NO ↓

Replace the C.D.I. unit.


Properly connect or repair the ignition system's wiring.





EBS00506

ELECTRIC STARTING SYSTEM

CIRCUIT DIAGRAM



- ② Neutral switch
- ③ Main switch
- ⑤ Main fuse
- ⑥ Positive battery lead
- ⑦ Battery
- ⑧ Negative battery lead
- ⑨ Starter relay
- ⑩ Starter motor
- ⑪ Starting circuit cut-off relay
- ⑮ Diode
- ⑯ Rear brake switch
- ⑰ Start switch



EBS00507


STARTING CIRCUIT OPERATION

The starting circuit on this model consists of the starter motor, starter relay, starting circuit cut-off relay, rear brake switch and neutral switch. If the main switch is on and the engine stop switch is in the RUN position, the starter motor can be operated only if:

- The transmission is in neutral (the neutral switch is closed).
- or**
- You pull in the rear brake lever (the rear brake switch is ON).

- ① Main fuse
- ② Battery
- ③ Starter relay
- ④ Starter motor
- ⑤ Starting circuit cut-off relay
- ⑥ Diode
- ⑦ Rear brake switch
- ⑧ Start switch
- ⑨ Neutral switch

- Ⓐ TO MAIN SWITCH
- Ⓑ FROM MAIN SWITCH



EBS01050

TROUBLESHOOTING

The starter motor fails to turn.

Check:

1. main fuse
2. battery
3. starter motor
4. starting circuit cut-off relay
5. starter relay
6. main switch
7. neutral switch
8. rear brake switch
9. start switch
10. diode
11. wiring connections
(of the entire starting system)

NOTE:

- Before troubleshooting, remove the following part(s):
 1. seat
 2. front fender
 3. rear fender
 4. C.D.I. magneto cover
- Troubleshoot with the following special tool(s).



Pocket tester
P/N. YU-03112-C, 90890-03112

EBS01043

1. Main fuse

- Check the main fuse for continuity. Refer to "CHECKING THE FUSE" in chapter 3.
- Is the main fuse OK?



Replace the fuse.

EBS01044


2. Battery

- Check the condition of the battery. Refer to "CHECKING AND CHARGING THE BATTERY" in chapter 3.



Specific gravity
1.280 at 20 °C (68 °F)

- Is the battery OK?




- Refill battery fluid.
- Clean the battery terminals.
- Recharge or replace the battery.

EBS01051

3. Starter motor

- Connect the positive battery terminal ① and starter motor lead ② with a jumper lead ③.




⚠ WARNING

- A wire that is used as a jumper lead must have at least the same capacity or more as that of the battery lead, otherwise the jumper lead may burn.
- This check is likely to produce sparks, therefore make sure nothing flammable is in the vicinity.

- Does the starter motor turn?



Repair or replace the starter motor.



EBS01053

4. Starting circuit cut-off relay

First step:


- Disconnect the starting circuit cut-off relay coupler from the wire harness.
- Connect the pocket tester ($\Omega \times 1$) and battery (12 V) to the starting circuit cut-off relay coupler as shown.

Positive battery terminal → red/white ①

Negative battery terminal → black/yellow ②

Positive tester probe → red/white ①

Negative tester probe → blue/white ③




- Does the starting circuit cut-off relay have continuity between red/white and blue/white?

Second step:

- Connect the pocket tester ($\Omega \times 1$) to the starting circuit cut-off relay coupler as shown.
- Measure the starting circuit cut-off relay for continuity as follows.

Positive tester probe → sky blue ④	Continuity
Negative tester probe → black/yellow ⑤	

Positive tester probe → black/yellow ⑤	No continuity
Negative tester probe → sky blue ④	




NOTE:

When you switch the tester's positive and negative probes, the readings in the above chart will be reversed.

- Are the testing readings correct?



Replace the starting circuit cut-off relay.



EBS01054

5. Starter relay

- Disconnect the starter relay coupler from the coupler.
- Connect the pocket tester ($\Omega \times 1$) and battery (12 V) to the starter relay coupler as shown.

Positive battery terminal → blue/white ①
Negative battery terminal → red/white ②

Positive tester probe → red ③
Negative tester probe → black ④

- Does the starter relay have continuity between red and black?

YES ↓ NO ↓

Replace the starter relay.

EBS01041

6. Main switch

- Check the main switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?

YES ↓ NO ↓

Replace the main switch.

EBS01046

7. Neutral switch

- Check the neutral switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the neutral switch OK?

YES ↓ NO ↓

Replace the neutral switch.

8. Rear brake switch

- Check the rear brake switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the rear brake switch OK?

YES ↓ NO ↓

Replace the rear brake switch.


EBS01057

9. Start switch

- Check the start switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the start switch OK?

YES ↓ NO ↓

Replace the handle-bar switch.



EBS01060

10. Diode

- Remove the diode from the coupler.
- Connect the pocket tester ($\Omega \times 1$) to the diode terminals as shown.
- Check the diode for continuity as follows.

Positive tester probe → green/yellow ① Negative tester probe → black/yellow ②	Continuity
Positive tester probe → black/yellow ② Negative tester probe → green/yellow ①	No continuity

NOTE: _____
 When you switch the tester's positive and negative probes, the readings in the above chart will be reversed.

- Are the testing readings correct?

↓ YES

↓ NO

Replace the diode.

EBS01059


11. Wiring

- Check the entire starting system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the starting system's wiring properly connected and without defects?

↓ YES ↓ NO


The starting system circuit is OK.

Properly connect or repair the starting system's wiring.







EBS01061

STARTER MOTOR



Order	Job/Part	Q'ty	Remarks
	Removing the starter motor		Remove the parts in the order listed.
1	Starter motor lead	1	
2	Ground lead	1	
3	Starter motor	1	
			For installation, reverse the removal procedure.
	Disassembling the starter motor		Remove the parts in the order listed.
①	Yoke	1	Refer to "ASSEMBLING THE STARTER MOTOR".
②	Armature coil	1	
③	Brush	1	
④	Bracket	1	
			For assembly, reverse the disassembly procedure.



EBS01064

CHECKING THE STARTER MOTOR

1. Check:
 - commutator
Dirt → Clean with 600-grit sandpaper.
2. Measure:
 - commutator diameter Ⓐ
Out of specification → Replace the starter motor.



Commutator wear limit
15.5 mm (0.61 in)

3. Measure:
 - mica undercut Ⓐ
Out of specification → Scrape the mica to the proper measurement with a hacksaw blade that has been grounded to fit the commutator.



Mica undercut
1 mm (0.04 in)

NOTE:

The mica of the commutator must be undercut to ensure proper operation of the commutator.

4. Measure:
 - armature assembly resistances (commutator and insulation)
Out of specification → Replace the starter motor.



- a. Measure the armature assembly resistances with the pocket tester.





Pocket tester
P/N. YU-03112-C, 90890-03112



Armature coil
Commutator resistance ①
0.029 ~ 0.035 Ω at 20 °C (68 °F)
Insulation resistance ②
Above 1 MΩ at 20 °C (68 °F)

- b. If any resistance is out of specification, replace the starter motor.





5. Measure:

- brush length ①

Out of specification → Replace the brushes as a set.



Brush length wear limit
3.5 mm (0.14 in)

6. Measure:

- brush spring force

Out of specification → Replace the brush springs as a set.



Brush spring force
3.24 ~ 4.22 N
(320 ~ 430 gf, 11.66 ~ 15.19 oz)

7. Check:


- gear teeth

Damage/wear → Replace the gear.

8. Check:

- bearing
- oil seal
- O-rings

Damage/wear → Replace the defective part(s).



EBS00515


ASSEMBLING THE STARTER MOTOR

1. Install:

- bracket
- brush
- armature coil
- yoke


NOTE:


Align the projection ① on the yoke with the slot ② on the bracket.



EBS00516

**CHARGING SYSTEM
CIRCUIT DIAGRAM**





EBS01065

TROUBLESHOOTING


The battery is not being charged.

Check:

1. main fuse
2. battery
3. charging voltage
4. charging coil resistance
5. wiring connections
(of the entire charging system)

NOTE:

- Before troubleshooting, remove the following part(s):
 1. seat
 2. rear fender
- Troubleshoot with the following special tool(s).



Inductive self-powered tachometer

- P/N. YU-8036-B**
- Engine tachometer**
- P/N. 90890-03113**
- Pocket tester**
- P/N. YU-03112-C, 90890-03112**

EBS01043

1. Main fuse

- Check the main fuse for continuity. Refer to “CHECKING THE FUSE” in chapter 3.
- Is the main fuse OK?



YES



NO

Replace the fuse.

EBS01044

2. Battery

- Check the condition of the battery. Refer to “CHECKING AND CHARGING THE BATTERY” in chapter 3.



Specific gravity
1.280 at 20 °C (68 °F)

- Is the battery OK?




YES



NO

- Refill battery fluid.
- Clean the battery terminals.
- Recharge or replace the battery.




EBS01066

3. Charging voltage

- Connect the engine tachometer to the spark plug lead.
- Connect the pocket tester (DC 20 V) to the battery as shown.

Positive tester probe → positive battery terminal
Negative tester probe → negative battery terminal



- Start the engine and let it run at approximately 5,000 r/min.
- Measure the charging voltage.



Charging voltage
 14 V at 5,000 r/min

NOTE: _____
 Make sure the battery is fully charged.

- Is the charging voltage within specification?




The charging circuit is OK.

EBS01100

4. Charging coil resistance

- Disconnect the C.D.I. magneto coupler from the wire harness.
- Connect the pocket tester ($\Omega \times 1$) to the charging coils.


Positive tester probe → white terminal ①
Negative tester probe → black terminal ②



- Measure the charging coil resistance.



Charging coil resistance
 0.72 ~ 1.08 Ω at 20 °C (68 °F)
 (between white and black)




Replace the rectifier/regulator.

Replace the pickup coil/stator assembly.

EBS01059


5. Wiring

- Check the entire charging system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the charging system's wiring properly connected and without defects?




The charging system circuit is OK.


Properly connect or repair the charging system's wiring.



EBS00521

**SIGNAL SYSTEM
CIRCUIT DIAGRAM**





EBS01073

TROUBLESHOOTING

If the neutral indicator light fails to come on.

Check:

1. main fuse
2. battery
3. main switch
4. wiring connections
(of the entire signaling system)

NOTE:

- Before troubleshooting, remove the following part(s):
 1. seat
 2. front fender
 3. C.D.I. magneto cover
- Troubleshoot with the following special tool(s).



Pocket tester
P/N. YU-03112-C, 90890-03112

EBS01043

1. Main fuse

- Check the main fuse for continuity. Refer to "CHECKING THE FUSE" in chapter 3.
- Is the main fuse OK?

↓ YES

↓ NO

Replace the fuse.

EBS01044

2. Battery

- Check the condition of the battery. Refer to "CHECKING AND CHARGING THE BATTERY" in chapter 3.



Specific gravity
1.280 at 20 °C (68 °F)

- Is the battery OK?

↓ YES

↓ NO

- Refill battery fluid.
- Clean the battery terminals.
- Recharge or replace the battery.

EBS01041

3. Main switch

- Check the main switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?

↓ YES

↓ NO

Replace the main switch.

EBS01074

4. Wiring


- Check the entire signal system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the signaling system's wiring properly connected and without defects?

↓ YES

↓ NO

Check the condition of each of the signaling system's circuits. Refer to "CHECKING THE SIGNALING SYSTEM".

Properly connect or repair the signaling system's wiring.



EBS01075

CHECKING THE SIGNALING SYSTEM

EBS01077

1. The neutral indicator light fails to come on.

1. Neutral indicator light bulb and socket

- Check the neutral indicator light bulb and socket for continuity. Refer to "CHECKING THE BULBS AND BULB SOCKETS".
- Are the neutral indicator light bulb and socket OK?

↓ YES

↓ NO

Replace the neutral indicator light bulb, socket or both.

2. Neutral switch

- Check the neutral switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the neutral switch OK?

↓ YES


↓ NO

Replace the neutral switch.

3. Voltage

- Connect the pocket tester (DC 20 V) to the neutral indicator light connectors (wire harness side) as shown.

Positive tester probe → brown ①
Negative tester probe → sky blue ②



- Set the main switch to "ON".
- Measure the voltage (DC 12 V).
- Is the voltage within specification?

↓ YES

↓ NO

This circuit is OK.

The wiring circuit from the main switch to the neutral indicator light connectors is faulty and must be repaired.

TROUBLESHOOTING**NOTE:**

The following troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to troubleshooting. Refer to the relative procedure in this manual for check, adjustment and replacement of parts.

STARTING FAILURE/HARD STARTING**FUEL SYSTEM****Fuel tank**

- Empty
- Clogged fuel filter
- Clogged fuel strainer
- Clogged fuel breather hose
- Deteriorated or contaminated fuel

Fuel cock

- Clogged fuel hose

Carburetor

- Deteriorated or contaminated fuel
- Clogged pilot jet
- Clogged pilot air passage
- Sucked-in air
- Deformed float
- Worn needle valve
- Improperly sealed valve seat
- Improperly adjusted fuel level
- Improperly set pilot jet

Air filter

- Clogged air filter element

ELECTRICAL SYSTEM**Spark plug**

- Improper plug gap
- Worn electrodes
- Wire between terminals broken
- Improper heat range
- Faulty spark plug cap

Ignition coil

- Broken or shorted primary/secondary
- Faulty spark plug lead
- Broken body

C.D.I. system

- Faulty C.D.I. unit
- Faulty pickup coil
- Faulty source coil
- Broken woodruff key

Switches and wiring

- Faulty main switch
- Faulty engine stop switch
- Broken or shorted wiring
- Faulty neutral switch
- Faulty start switch

Starter motor

- Faulty starter motor
- Faulty starter relay
- Faulty starter circuit cut-off relay

Battery

- Faulty battery

COMPRESSION SYSTEM

Cylinder and cylinder head

- Loose spark plug
- Loose cylinder head or cylinder
- Broken cylinder head gasket
- Broken cylinder gasket
- Worn, damaged or seized cylinder

Valve, camshaft and crankshaft

- Improperly sealed valve
- Improperly contacted valve and valve seat
- Improper valve timing
- Broken valve spring
- Seized camshaft
- Seized crankshaft

Piston and piston rings

- Improperly installed piston ring
- Worn, fatigued or broken piston ring
- Seized piston ring
- Seized or damaged piston

Crankcase and crankshaft

- Improperly seated crankcase
- Seized crankshaft

Valve train

- Improperly adjusted valve clearance
- Improperly adjusted valve timing

EBS00538

POOR IDLE SPEED PERFORMANCE

POOR IDLE SPEED PERFORMANCE

Carburetor

- Loose pilot jet
- Clogged pilot jet
- Clogged pilot air jet
- Improperly adjusted idle speed (throttle stop screw)
- Improper throttle cable play
- Flooded carburetor

Electrical system

- Faulty battery
- Faulty spark plug
- Faulty C.D.I. unit
- Faulty pickup coil
- Faulty source coil
- Faulty ignition coil

Valve train

- Improperly adjusted valve clearance

Air filter

- Clogged air filter element

EBS00539

POOR MEDIUM AND HIGH-SPEED PERFORMANCE

POOR MEDIUM AND HIGH-SPEED PERFORMANCE

Refer to “STARTING FAILURE/HARD STARTING” and “POOR IDLE SPEED PERFORMANCE—Valve train”.

Carburetor

- Improper jet needle clip position
- Improperly adjusted fuel level
- Clogged or loose main jet
- Deteriorated or contaminated fuel

Air filter

- Clogged air filter element

EBS00540

FAULTY DRIVE TRAIN

The following conditions may indicate damaged shaft drive components:

Symptoms	Possible Causes
<ol style="list-style-type: none"> 1. A pronounced hesitation or “jerky” movement during acceleration, deceleration, or sustained speed. (This must not be confused with engine surging or transmission characteristics.) 2. A “rolling rumble” noticeable at low speed; a high-pitched whine; a “clunk” from a shaft drive component or area. 3. A locked-up condition of the shaft drive mechanism, no power transmitted from the engine to the rear wheels. 	<ol style="list-style-type: none"> A. Bearing damage. B. Improper gear lash. C. Gear tooth damage. D. Broken drive shaft. E. Broken gear teeth. F. Seizure due to lack of lubrication. G. Small foreign objects lodged between the moving parts.

NOTE:

Areas A, B, and C above may be extremely difficult to diagnose. The symptoms are quite subtle and difficult to distinguish from normal machine operating noise. If there is reason to believe these components are damaged, remove the components and check them.

EBS00541

FAULTY GEAR SHIFTING

HARD SHIFTING

Refer to “CLUTCH SLIPPING/DRAGGING—CLUTCH DRAGGING”.

SHIFT LEVER DOES NOT MOVE

Shift shaft

- Bent shift shaft

Shift cam, shift forks

- Groove jammed with impurities
- Seized shift fork
- Bent shift fork guide bar

Transmission

- Seized transmission gear
- Jammed impurities
- Incorrectly assembled transmission

JUMPS OUT GEAR

Shift shaft

- Improperly adjusted shift shaft position
- Improperly returned stopper lever

Shift forks

- Worn shift fork

Shift drum

- Improper thrust play
- Worn shift drum groove

Transmission

- Worn gear dog

EBS00545

CLUTCH SLIPPING/DRAGGING

CLUTCH SLIPPING

Clutch

- Loose clutch spring
- Fatigued clutch spring
- Worn friction plate
- Worn clutch plate
- Incorrectly assembled clutch

Engine oil

- Low oil level
- Improper quality (low viscosity)
- Deterioration

CLUTCH DRAGGING

Clutch

- Warped pressure plate
- Unevenly tensioned clutch springs
- Loose clutch boss nut
- Bent clutch plate
- Swollen friction plate
- Broken clutch boss

Engine oil

- High oil level
- Improper quality (high viscosity)
- Deterioration

EBS00546

OVERHEATING

OVERHEATING

Ignition system

- Improper spark plug gap
- Improper spark plug heat range
- Faulty C.D.I. unit

Fuel system

- Improper carburetor main jet (improper setting)
- Improper fuel level
- Clogged air filter element

Compression system

- Heavy carbon build-up

Engine oil

- Improper oil level
- Improper oil viscosity
- Inferior oil quality

Brake

- Brake drag

EBS00549

FAULTY BRAKE

POOR BRAKING EFFECT

Front and rear drum brake

- Worn brake shoe lining
- Worn brake drum
- Oily or greasy brake shoe lining
- Oily or greasy brake drum
- Improperly adjusted brake lever free play
- Improper brake cam lever position
- Improper brake shoe position
- Fatigued/damaged return spring
- Broken brake cable

EBS00551

SHOCK ABSORBER MALFUNCTION

MALFUNCTION

- Bent or damaged damper rod
- Damaged oil seal lip
- Fatigued shock absorber spring

EBS00552

UNSTABLE HANDLING

UNSTABLE HANDLING

Handlebar

- Improperly installed or bent

Steering

- Incorrect toe-in
- Bent steering stem
- Improperly installed steering stem
- Damaged bearing or bearing race
- Bent tie rods
- Deformed steering knuckles

Tires

- Uneven tire pressures on both sides
- Incorrect tire pressure
- Uneven tire wear

Wheels

- Deformed wheel
- Loose bearing
- Bent or loose wheel axle
- Excessive wheel runout

Frame

- Bent
- Damaged frame


Swingarm

- Worn bearing or bushing
- Bent or damaged



PRINTED IN U.S.A.

YFM50S WIRING DIAGRAM



- ① C.D.I. magneto
- ② Neutral switch
- ③ Main switch
- ④ Rectifier/regulator
- ⑤ Main fuse
- ⑥ Positive battery lead
- ⑦ Battery
- ⑧ Negative battery lead
- ⑨ Starter relay
- ⑩ Starter motor
- ⑪ Starting circuit cut-off relay
- ⑫ C.D.I. unit
- ⑬ Ignition coil
- ⑭ Spark plug
- ⑮ Diode
- ⑯ Rear brake switch
- ⑰ Engine stop switch (frame)
- ⑱ Handlebar switch
- ⑲ Start switch
- ⑳ Engine stop switch (handlebar)
- ㉑ Neutral indicator light

- COLOR CODE**
- B Black
 - Br Brown
 - O Orange
 - R Red
 - Sb Sky blue
 - W White
 - Y Yellow
 - B/R Black/Red
 - B/W Black/White
 - B/Y Black/Yellow
 - G/W Green/White
 - G/Y Green/Yellow
 - L/W Blue/White
 - R/W Red/White
 - W/L White/Blue
 - W/R White/Red
 - Y/R Yellow/Red