| | | |
|---|---|---|
| **Last Modified:** 03-12-2013 | 6.4 F | **Doc ID:** NM1000000004IHI |
| **Model Year:** 2013 | **Model:** RAV4 | **Prod Date Range:** [12/2012 - ] |
| **Title:** SEAT: SEAT HEATER SYSTEM: SEAT HEATER CONTROL; 2013 MY RAV4 [12/2012 - ] | | |

# SEAT HEATER CONTROL

## 1. FUNCTION OF MAIN COMPONENTS

(a) The main components have the following functions:

| COMPONENT | FUNCTION |
|---|---|
| Seat Heater Assembly | The seat heater is sewn into the internal surfaces of the seat cushion and the seat back. It warms up the seat surfaces using the heat caused by electrical resistance. |
| Seat Heater Switch Assembly | By operating this switch, the seat heater system is turned HI or LO. |

## 2. FUNCTION

(a) Seat Heater System

(1) The seat heater system is operated by pressing the seat heater switch assembly. The temperature can be adjusted between 2 stages by pressing the HI switch or LO switch of the seat heater switch assembly.