| | | |
|---|---|---|
| **Last Modified:** 03-12-2013 | 6.4 F | **Doc ID:** NM1000000005G0Y |
| **Model Year:** 2013 | **Model:** RAV4 | **Prod Date Range:** [12/2012 - ] |
| **Title:** WINDOW / GLASS: WINDSHIELD / WINDOW GLASS SYSTEM: WINDSHIELD DEICER CONTROL; 2013 MY RAV4 [12/2012 - ] | | |

# WINDSHIELD DEICER CONTROL

### 1. FUNCTION OF MAIN COMPONENTS

| COMPONENT | FUNCTION |
|---|---|
| Windshield Deicer Switch | Operates the windshield deicer system. |
| Windshield Deicer Wire | Applies electrical current to a windshield deicer wire in the windshield glass to generate heat and remove ice from the windshield glass. |

### 2. SYSTEM COTNROL

(a) The windshield deicer system is activated when the ignition switch is turned to ON and the windshield deicer switch is pushed. The windshield deicer switch keeps the front wiper deicer on for approximately 15 minutes.