| | | |
|---|---|---|
| **Last Modified:** 03-12-2013 | 6.4 F | **Doc ID:** NM1000000005IHR |
| **Model Year:** 2013 | **Model:** RAV4 | **Prod Date Range:** [12/2012 - ] |
| **Title:** LIGHTING (EXT): LIGHTING SYSTEM: DAYTIME RUNNING LIGHT; 2013 MY RAV4 [12/2012 - ] | | |

# DAYTIME RUNNING LIGHT

### 1. FUNCTION OF MAIN COMPONENTS

| COMPONENT | | FUNCTION |
|---|---|---|
| Main Body ECU (Multiplex Network Body ECU) | | The main body ECU receives various signals and illuminates the high beam headlight via daytime running light module. |
| Headlight Dimmer Switch Assembly | Light Control Switch | The light control switch outputs a light control signal and transmits it to the main body ECU. |
| ECM | | The ECM outputs an engine speed signal and transmits it to the main body ECU. |

### 2. SYSTEM CONTROL

(a) The daytime running light system is enabled when the conditions given below are met:

| | |
|---|---|
| Condition | Ignition switch is ON. |
| | Light control switch is in off*1 or DRL*2 or AUTO*3 position (when taillight is not being controlled by the automatic light control system). |
| | Engine is running. |
| | Parking brake is off. |

*1: Except models for U.S.A.
*2: Models for U.S.A.
*3: Models with automatic light control system