| | | |
|---|---|---|
| **Last Modified:** 03-12-2013 | 6.4 F | **Doc ID:** NM1000000005IHO |
| **Model Year:** 2013 | **Model:** RAV4 | **Prod Date Range:** [12/2012 - ] |
| **Title:** LIGHTING (INT): LIGHTING SYSTEM: GENERAL; 2013 MY RAV4 [12/2012 - ] | | |

# GENERAL

## 1. OUTLINE

(a) Interior Light

(1) Each kind of light is used to enhance convenience and comfort.

(b) Illuminated Entry System

(1) An illuminated entry system is used, which turns on in response to the opening and closing of each door, to enhance usability at night and produce a pleasing cabin space.

(2) The illuminated entry system is controlled by the main body ECU (multiplex network body ECU).

## 2. SPECIFICATION

(a) Interior Light

| LIGHT | SPECIFICATION |
|---|---|
| Map Light Assembly (Front Room Light) | 12 V, 5 W |
| No. 1 Room Light Assembly (Rear Room Light) | 12 V, 8 W |
| No. 2 Room Light Assembly | 12 V, 5 W |
| Vanity Light Assembly | 12 V, 8 W |
| Ignition Switch Illumination*1 | LED |
| Engine Switch Illumination*2 | LED |
| Cup Holder Illumination*3 | LED |

*1: Models without smart key system
*2: Models with smart key system
*3: Models with cup holder illumination

## 3. PRECAUTION

(a) Ignition Switch Expressions

(1) The type of ignition switch used on this model differs depending on the specifications of the vehicle. The expressions listed in the table below are used in this section.

| EXPRESSION | IGNITION SWITCH (POSITION) | ENGINE SWITCH (CONDITION) |
|---|---|---|
| Ignition Switch off | LOCK | Off (Lock) |
| Ignition Switch ACC | ACC | On (ACC) |
| Ignition Switch ON | ON | On (IG) |
| Engine Start | START | On (Start) |