| | | |
|---|---|---|
| **Last Modified:** 03-12-2013 | 6.4 F | **Doc ID:** NM1000000004IDN |
| **Model Year:** 2013 | **Model:** RAV4 | **Prod Date Range:** [12/2012 - ] |
| **Title:** AUDIO / VIDEO: AUDIO AND VISUAL SYSTEM: BLUETOOTH HANDS-FREE CONTROL; 2013 MY RAV4 [12/2012 - ] | | |

# BLUETOOTH HANDS-FREE CONTROL

## 1. FUNCTION

(a) The Bluetooth hands-free system has the following functions:

| FUNCTION | | | OUTLINE | *1 | *2 |
|---|---|---|---|---|---|
| Calling with a Bluetooth Phone | By Dialing | | The user can call by inputting a telephone number. | ○ | ○ |
| | By Phonebook | | The user can call by using the phonebook data that has been transferred from the user's cellular phone. The user can register up to 1000 numbers in the phonebook. | ○ | ○ |
| | By Call History*3 | Dialed Number | The user can call by selecting a previously dialed number. | ○ | ○ |
| | | Received Call | The user can call by selecting the telephone number of a received call. | ○ | ○ |
| | | Missed Call | The user can call by selecting the telephone number of a missed call. | ○ | ○ |
| | | All Call History | The user can call by selecting the telephone number from all call history. However, the user can use the last 5 numbers while driving. | ○ | ○ |
| | By Speed Dial*3 | | The user can call by using registered telephone numbers selected from the phonebook, dialed numbers or received calls. | ○ | ○ |
| | By Voice Recognition*3 | Dialing by Name | The user can call by giving a name registered in the phonebook. | - | ○*4 |
| | | Dialing by Phone Number | The user can call by giving a desired number. | - | ○*4 |
| Receiving a Call Using a Bluetooth Phone | | | When a call is received, the receive screen is displayed with a sound. | ○ | ○ |
| Talking on a Bluetooth Phone | | | While the user is talking on the phone, the talking screen is displayed. | ○ | ○ |
| | Speed Dial Registration | | The user can register a desired telephone number from the phonebook, dialed numbers or received calls. Up to 5 (*1), 18 (*2) speed dial numbers can be registered. | ○ | ○ |
| | Editing Speed Dial | | The user can edit the speed dial. | ○ | - |

| | | | | |
|---|---|---|---|---|
| Changing Bluetooth Phone Settings | Deleting Speed Dial | The user can delete the speed dials individually or all at once. | ○ | - |
| | Volume Settings | The user can set the volume. | ○ | ○ |
| | | Initializing the settings:<br>The user can initialize the settings. | ○ | ○ |
| | | Automatic volume settings for high speed:<br>When the vehicle speed is 80 km/h (50 mph) or more, the volume automatically increases. The volume returns to the previous volume setting when the vehicle speed drops to 70 km/h (43 mph) or less. | ○ | ○ |
| | Phonebook Settings | Transferring a phonebook data:<br>The user can transfer the phonebook data from the registered Bluetooth phone to the system. | ○ | ○ |
| | | Automatically transferring a telephone number:<br>When a PBAP compatible phone is connected, the phonebook data of the phone can be automatically transferred. | - | ○ |
| | | Registering phone numbers<br>The user can register phone numbers in the phonebook.*5 | ○ | ○ |
| | | Adding data to the phonebook:<br>The user can add data to the phonebook.*5 | ○ | ○ |
| | | Editing a name:<br>The user can edit a name that has been entered. If no name has been entered, the number is displayed.*5 | ○ | ○ |
| | | Editing a phone number:<br>The user can register a phone number to "Phone#1", "Phone#2" or "Phone#3".*5 | ○ | ○ |
| | | Editing data:<br>The user can edit the registered data.*5 | ○ | ○ |
| | | Deleting data:<br>The user can delete the data.*5 | - | ○ |
| | | Deleting all the phone data:<br>The user can delete all the phone data.*5 | ○ | ○ |
| | | Deleting the call history data:<br>The user can delete the call history data individually or all at once.*5 | ○ | ○ |
| | | Selecting a group icon:<br>The user can select the desired icon. | ○ | - |
| | Screen Settings | Receiving call display:<br>The user can select the method of the receiving call display. | - | ○ |
| | | Checking the Bluetooth connection during startup:<br>When the ignition switch is turned to ON or ACC and the Bluetooth is automatically connected, the connection check | - | ○ |

| | | | | |
|---|---|---|---|---|
| | | will be displayed. | | |
| | | Initializing the settings:<br>The user can initialize the settings. | - | ○ |
| | Security Settings | Setting a passcode:<br>A passcode can be set up on every Bluetooth phone to be registered. | ○ | - |
| Set Bluetooth Phone | Enter Bluetooth Phone | In order to use the hands-free function of a Bluetooth phone, it is necessary to register the phone in the audio head unit. Once a phone is registered, the hands-free function becomes available automatically.*6 | ○ | - |
| | Selecting Bluetooth Phone | When 2 or more registered Bluetooth phones are in the cabin, it is necessary to select which phone to use to prevent the lines from being crossed. Only the selected phone is available for use as a hands-free phone. | ○ | - |
| | Displaying and Change Bluetooth Information | The user can set, change and initialize the information of the Bluetooth phone displayed on the screen. | ○ | - |
| | Deleting Bluetooth Phone | The user can delete a registered Bluetooth phone from the audio head unit. | ○ | - |
| Registering and Selecting a Bluetooth Phone | Bluetooth Phone Registration | In order to use the hands-free function of a Bluetooth phone, it is necessary to register the phone in the audio head unit. Once a phone is registered, the hands-free function becomes available automatically.*6 | - | ○ |
| | Bluetooth Phone Selection*3 | When 2 or more registered Bluetooth phones are in the cabin, it is necessary to select which phone to use to prevent the lines from being crossed. Only the selected phone is available for use as a hands-free phone. The phone registered last is automatically selected. | - | ○ |
| | Bluetooth Information Confirmation and Editing | The user can set, change and initialize the information of the Bluetooth phone displayed on the screen. | - | ○ |
| | Deleting a Bluetooth Phone | The user can delete a registered Bluetooth phone from the audio head unit. | - | ○ |
| Bluetooth Phone Message | Checking Message | The user can transmit the messages (Short Message Service (SMS)/ Multimedia Messaging Service (MMS)/email) received on the Bluetooth phone to the audio head unit.<br>• Displaying the message text.<br>• Reading out of the message.<br>• Calling a Short Message Service (SMS)/Multimedia Messaging Service (MMS) message sender's phone number. | - | ○ |
| | Reply Message | The user can reply to a message (Short Message Service (SMS)/Multimedia Messaging Service (MMS)/e-mail) received on the Bluetooth phone. | - | ○ |

| | | | | |
|---|---|---|---|---|
| | Editing Reply Message | The user can edit the reply. | - | ○ |

**HINT:**

○ : Usable

- : Not Usable

*1: Models with radio receiver assembly

*2: Models with radio and display receiver assembly

*3: Can be operated while driving.

*4: Deluxe grade

*5: Excluding phone with PBAP

*6: Automatic connection cannot be performed with some Bluetooth phone.