

F RELAY LOCATIONS

○ : Center J/B No.2

Near the Steering Column (See Page 21)

