


E ELECTRICAL WIRING ROUTING

Position of Parts in Instrument Panel

[LHD]



A12 A/C Amplifier
 A13 A/C Amplifier
 A14 A/C Amplifier
 A15 A/C Evaporator Temp. Sensor
 A16 Accelerator Pedal Position Sensor
 A17 Air Inlet Control Servo Motor
 A18 Air Mix Control Servo Motor
 A19 Air Vent Mode Control Servo Motor
 A20 Airbag Sensor Assembly
 A21 Airbag Sensor Assembly
 A22 Airbag Sensor Assembly
 A23 Airbag Squib (Front Passenger Airbag Assembly)
 A24 Airbag Squib (Steering Wheel Pad)
 A25 Ashtray Illumination
 A28 A/C Control Assembly
 A29 A/C Control Assembly
 A30 A/C Room Temp. Sensor
 A32 A/C Solar Sensor
 A33 Antenna Amplifier

B 5 Blower Motor
 B 6 Blower Relay (H1)
 B 7 Blower Relay (M1)
 B 8 Blower Relay (M2)
 B 9 Blower Resistor
 B10 Body ECU
 B16 Blower Motor Controller

C 6 Cigarette Lighter
 C 7 Circuit Opening Relay
 C 8 Combination Meter
 C 9 Combination Meter
 C10 Combination SW
 C11 Combination SW
 C12 Combination SW