


## E ELECTRICAL WIRING ROUTING

### Position of Parts in Instrument Panel

[LHD]



J 1 Junction Connector  
J 2 Junction Connector  
J 3 Junction Connector  
J 4 Junction Connector  
J 5 Junction Connector  
J 6 Junction Connector  
J 7 Junction Connector  
J 8 Junction Connector  
J 9 Junction Connector  
J 10 Junction Connector  
J 11 Junction Connector  
J 12 Junction Connector  
J 13 Junction Connector  
J 14 Junction Connector  
J 15 Junction Connector  
J 16 Junction Connector  
J 17 Junction Connector  
J 18 Junction Connector  
J 19 Junction Connector  
J 20 Junction Connector  
J 21 Junction Connector  
J 22 Junction Connector  
J 23 Junction Connector  
J 24 Junction Connector  
J 31 Junction Connector  
J 40 Junction Connector

K 2 Kick Down SW

O 2 O/D Main SW

P 3 Parking Brake SW

P 4 Power Point Relay

P 5 PTC Heater

P 6 PTC Heater Amplifier

R 3 Radar Sensor

R 4 Radio and Player with Display

R 5 Radio and Player with Display

R 6 Radio and Player

Radio and Player with Display

R 7 Radio and Player

Radio and Player with Display

R 8 Rear Heater Blower Motor

R 9 Rear Heater Relay

R 10 Rear Heater Relay (HI)

R 11 Rear Heater SW

R 12 Remote Control Mirror SW

R 28 Radio and Player with Display

R 29 Radio and Player with Display

R 30 Radio and Player with Display

R 31 Radio and Player with Display

R 32 Radio and Player with Display

R 33 Radio and Player with Display