

Storage Space


Storage space designed with this thought in mind: "Wouldn't be nice if there was ...?"

Anything, small or large, can be stored in the various storage spaces provided. This ease of use is an attractive feature.

MO

Front


- (1) Auxiliary Box
- (2) Glove Box
- (3) Cup Holder
- (4) Grocery Bag Hook (RHD Models Only, Passenger Side)



206MO45

Side

- (1) Bottle Holder
- (2) Pocket
- (3) Deck Box (LH & RH)




206MO46

INTERIOR

Spare Tire & Luggage Space

Optimum placement under the floor of the spare tire, fuel tank, and muffler results, not in a high floor, but in a spacious cabin and large luggage compartment.

The spare tire carrier, located under the left front seat, has been designed exclusively for a compact spare tire.




206MO47

Opening Width (Back Door)


	Europe	Australia & General Countries	Previous
Luggage Capacity VDA (ℓ)	212+70*	169 +132*	182
Rear Opening Width at Floor (mm)	1185	1185	1075

*: Luggage Box



206MO77

Luggage Box



206MO48

	Europe	Australia & General Countries
Width (mm)	1225	1230
Distance (mm)	380	400
Depth (mm)	225	345
Capacity VDA (ℓ)	70	132