

SFI SYSTEM (2AZ-FE)

05KF4-01

PRECAUTION

NOTICE:

Perform the RESET MEMORY (AT initialization) operation after replacing the automatic transaxle assembly, engine assembly or ECM.

HINT:

Initialization cannot be completed by only removing the battery cable.