

DTC	P0606	ECM/PCM PROCESSOR
------------	--------------	--------------------------

DTC	P0607	CONTROL MODULE PERFORMANCE
------------	--------------	-----------------------------------

DTC	P1611	IC CIRCUIT MALFUNCTION
------------	--------------	-------------------------------

CIRCUIT DESCRIPTION

DTC No.	DTC Detection Condition	Trouble Area
P0606 P0607 P1611	ECM internal error (1 trip detection logic)	• ECM

INSPECTION PROCEDURE

HINT:

Read freeze frame data using the Intelligent Tester II. Freeze frame data record the engine condition when malfunctions are detected. When troubleshooting, freeze frame data can help determine if the vehicle was moving or stationary, if the engine was warmed up or not, and other data from the time the malfunction occurred.

REPLACE ECM (See page 10-30)
