

CASSETTE TAPE CANNOT BE EJECTED

INSPECTION PROCEDURE

1 PRESS "EJECT" AND CHECK OPERATION

- (a) Press "EJECT" and check the operation.
- (1) Press the cassette tape EJECT switch of the radio receiver assembly for 2 seconds or more and check that the cassette tape is ejected.

OK: The cassette tape is ejected.

NG

**REPLACE RADIO RECEIVER ASSY
(SEE PUB. NO. RM864E, PAGE 67-2)**

OK

2 CHECK CASSETTE TAPE

- (a) Check the cassette tape.
- (1) Check that the ejected cassette tape does not have a peeled label, a cassette body deformation or any other defects.

OK: No fault on the cassette tape.

NG

CASSETTE TAPE IS FAULTY

OK

3 REPLACE CASSETTE TAPE WITH ANOTHER AND RECHECK

- (a) Replace the cassette tape with another and recheck.
- (1) Replace the cassette tape with another normal one to see if the same trouble occurs again.

OK: Malfunction disappears.

NG

**REPLACE RADIO RECEIVER ASSY
(SEE PUB. NO. RM864E, PAGE 67-2)**

OK

CASSETTE TAPE IS FAULTY