

PROBLEM SYMPTOMS TABLE

Chart No.	Symptom	See page
1	Entire combination meter does not operate	05-1237
2	Malfunction in speedometer	05-1240
3	Malfunction in tachometer	05-1244
4	Malfunction in fuel receiver gauge	05-1248
5	Malfunction in water temperature receiver gauge	05-1251