

DTC	P0500/21	VEHICLE SPEED SENSOR CIRCUIT MALFUNCTION
------------	-----------------	---

DTC	P0503/23	VEHICLE SPEED SENSOR CIRCUIT MALFUNCTION
------------	-----------------	---

CIRCUIT DESCRIPTION

See page 05-146.

DTC No.	DTC Detection Condition	Trouble Area
P0500/21	This trouble code is output when the vehicle speed signal from the vehicle speed sensor is cut for 0.14 sec. or more while the cruise control is in operation.	<ul style="list-style-type: none"> • Vehicle speed sensor • Vehicle speed sensor signal circuit • ECM
P0503/23	Momentary interruption and noise are detected when a rapid change of vehicle speed occurs while the cruise control is in operation.	<ul style="list-style-type: none"> • Vehicle speed sensor • Vehicle speed sensor signal circuit • ECM

WIRING DIAGRAM

See page 05-146.

INSPECTION PROCEDURE

See page 05-146.