



# FUEL SUCTION W/ PUMP & GAUGE TUBE ASSY (1AZ-FE/2AZ-FE) COMPONENTS

1113A-01


## 60/40 Split and Folding Seat Type:



## Captain Seat Type:



## 3 Tumble and Detachable Seats Type:



N·m (kgf·cm, ft·lbf) : Specified torque

A91581


Diagram illustrating the installation of the No. 3 Seat Assy LH and RH. The diagram shows the seat assembly with various components labeled:

- No. 3 Seat Assy RH
- No. 3 Seat Front Bracket Cover RH
- No. 3 Seat Front Bracket Cover LH
- No. 3 Seat Front Bracket Cover LH
- No. 3 Seat Front Bracket Cover RH
- No. 3 Seat Assy LH


Fasteners are labeled 39 (400, 29) and x2.

## A line drawing of two car seats, labeled "No. 3 Seat Assy". The seats are shown from a side-rear perspective, facing each other. Each seat has a headrest, a backrest with a central vertical seam, and a seat cushion. A small, dark rectangular component is visible on the side of the seat base, near the bottom.


A91582




Rear Door Scuff Plate RH



Floor Carpet Assy Front




Rear Door Scuff Plate LH



N·m (kgf·cm, ft·lbf) : Specified torque


A91583




N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A90076



 Non-reusable part

A90077