


# AUTOMATIC TRANSMISSION / TRANSAXLE (U241E) COMPONENTS

4006X-01




N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

N

D25839




N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

★ Precoated part

N

D25826




N-m (kgf-cm, ft-lbf) : Specified torque

◆ Non-reusable part

★ Precoated part

N


D25825



N ◆ Non-reusable part


N·m (kgf·cm, ft·lbf) : Specified torque


D09171




N

D09161










◆ Non-reusable part


N

D25838






D08097




◆ Non-reusable part

D08122




D08110



N·m (kgf·cm, ft·lbf) : Specified torque

P

D25769



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

D09218

N

D25840