

POWER WINDOW CONTROL SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

054TW-01

1 VEHICLE BROUGHT IN



2 CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK
(See page 05-612)



3 PROBLEM SYMPTOMS TABLE (See page 05-615)

(a) Without applicable symptoms, proceed to A

(b) With applicable symptoms, proceed to B

B

GO TO STEP 5

A

4 PERFORM TROUBLESHOOTING IN THE FOLLOWING METHOD, DEPENDING ON MALFUNCTION SYMPTOM

(a) Terminals of ECU (See page 05-614)



5 ADJUSTMENT, REPAIR OR REPLACEMENT



END