

CODE 3-1 IS OUTPUT**NOTICE:**

The DTC is 1CD-FTV engine only.

CIRCUIT DESCRIPTION

The transponder key ECU outputs DTC31 when a wrong or registered key code is identified.

HINT:

DTC31 is an abnormal code.

| DTC No. | DTC detecting condition | Trouble area |
|---------|-------------------------|--------------|
| 31 | Code 3-1 is output | • Key |

INSPECTION PROCEDURE**1 KEY REGISTRATION IN AUTOMATIC REGISTRATION**

- (a) Register the key that does not start the engine.

NG**REPAIR NORMAL****OK****CHECK DTC OUTPUT**