

THEFT/DETERRENT SYSTEM (Europe RHD only)

HOW TO PROCEED WITH TROUBLESHOOTING

054DT-01

1 VEHICLE BROUGHT TO WORKSHOP



2 CUSTOMER PROBLEM ANALYSIS/CHECK AND PROBLEM SYMPTOM CONFIRMATION



3 PROBLEM SYMPTOM TABLE (See page 05-719)

- (a) Without an applicable problem symptom table, proceed to "A".
 (b) With an applicable problem symptom table, proceed to "B".

B

Go to step 5


A

4 ACCORDING TO PROBLEM SYMPTOM, PERFORM TROUBLESHOOTING

- (a) PRE-CHECK (See page 73-24)
 (1) Inspection with hand-held tester (ECU data monitor)
 (2) Inspection with hand-held tester (Active test)
 (b) TERMINAL OF ECU (See page 05-718)



5 ADJUSTMENT, REPAIR OR REPLACE



END