


COOLER CONTROL SWITCH ASSY OVERHAUL


55085-01

1. REMOVE AIR OUTLET REGISTER ASSY RH
(See page 76-23)



2. REMOVE CONTROL KNOB SUB-ASSY

- (a) Remove the control knob sub-assy.



3. REMOVE COOLER CONTROL SWITCH ASSY

- (a) Remove the 2 screws and cooler control switch assy.