






# HEAD LIGHT COMPONENTS

65091-01





\* : When only the installation part of the headlight unit assy LH is damaged, it can be repaired inexpensively by using a bracket provided for repair. In this case, however, the headlight unit assy LH itself should not be damaged.