


INNER REAR VIEW MIRROR ASSY REPLACEMENT

7007X-01

HINT:

Installation is in the reverse order of removal. But the installation is indicated only when it has a point.

**1. REMOVE INNER REAR VIEW MIRROR STAY HOLDER COVER**

- (a) Using a moulding remover, disengage the claws and remove the inner rear view mirror stay holder cover.

2. REMOVE INNER REAR VIEW MIRROR ASSY

- (a) Remove the 2 screws and the inner rear view mirror assembly.