


REMOVAL

1. REMOVE PARKING BRAKE HOLE COVER
2. REMOVE UPPER CONSOLE PANEL
3. REMOVE CENTER CLUSTER FINISH PANEL
(See page [BO-69](#))



4. REMOVE A/C CONTROL ASSEMBLY
 - (a) Remove the A/C control name plate.
 - (b) Remove the 3 screws and A/C control assembly, then disconnect the connector.