

RECEIVER

ON-VEHICLE INSPECTION

AC005-01

INSPECT FITTINGS FOR LEAKAGE

Using a gas leak detector, check for leakage.

If there is leakage, check the tightening torque at the joints.