



ADJUSTMENT

ADJUST FOG LIGHT AIM

Adjust screw: Vertical direction