


Rear Wiper Switch Circuit

CIRCUIT DESCRIPTION

Body ECU judges the switch position with the terminal voltage of the rear wiper switch and runs the wiper motor.

WIRING DIAGRAM



INSPECTION PROCEDURE

1	Check rear wiper and washer switch (See page BE-34).
---	---

NG

Replace rear wiper and washer switch.

OK

2	Check harness and connector between rear wiper and washer switch and body ECU (See page IN-28).
---	--

NG

Repair or replace harness or connector.

OK

Proceed to next circuit inspection shown on problem symptoms table (See page [DI-517](#)).