

# ENGINE IMMOBILISER SYSTEM

## HOW TO PROCEED WITH TROUBLESHOOTING

DI1KE-05

Troubleshooting in accordance with the procedure on the following pages.

