



# CYLINDER HEAD COMPONENTS

EM1MO-01




Y


A14647



A14645



S02360




N·m (kgf·cm, ft·lbf) :Specified torque

- ◆ Non-reusable part

Y \* Replace only if damaged

A15275



A06828