

## **INSPECTION**

### **INSPECT OIL COOLER**

Check the oil cooler for damage or clogging.

If necessary, replace the oil cooler.