


# ENGINE INSPECTION

MA004-15

## HINT:

Inspect these items when the engine is cold.

1. **REPLACE TIMING BELT**  
(See page [EM-11](#))
2. **INSPECT DRIVE BELTS**  
(See page [CH-1](#))
3. **REPLACE SPARK PLUGS**  
(See page [IG-1](#))



## 4. INSPECT AIR FILTER

- (a) Visually check that the air cleaner element is not excessively dirty, damaged or oily.

## HINT:

Oiliness may indicate a stuck PCV valve.

If necessary, replace the air cleaner element.

- (b) Clean the element with compressed air.  
First blow from back side thoroughly, then blow off the front side of the element.

## 5. REPLACE AIR FILTER

Replace the used air cleaner element with a new one.

6. **REPLACE ENGINE OIL AND OIL FILTER**  
(See page [LU-3](#))
7. **REPLACE ENGINE COOLANT**  
(See page [CO-2](#))
8. **REPLACE GASKET IN FUEL TANK CAP**  
(See page [EC-6](#))
9. **INSPECT FUEL LINES AND CONNECTIONS**  
(See page [SF-26](#))
10. **INSPECT EXHAUST PIPES AND MOUNTINGS**  
(See page [EM-105](#))
11. **INSPECT VALVE CLEARANCE**  
(See page [EM-4](#))