










AUTOMATIC TRANSMISSION SST (Special Service Tools)

PP0DX-02

	09032-00100 Oil Pan Seal Cutter	
	09308-10010 Oil Seal Puller	
	09325-40010 Transmission Oil Plug	
	09350-30020 TOYOTA Automatic Transmission Tool Set	
	(09351-32010) One-way Clutch Test Tool	
	(09351-32020) Stator Stopper	
	09992-00095 Automatic Transmission Oil Pressure Gauge Set	
	(09992-00151) Adaptor B	
	(09992-00271) Gauge Assy	