


























# SUSPENSION AND AXLE














## SST (Special Service Tools)

PP3GO-02














	09214-7601 1	Crankshaft Pulley Replacer	Rear differential
	09223-00010	Cover & Seal Replacer	Front suspension
	09223-15020	Oil Seal & Bearing Replacer	Front differential Rear differential
	09223-15030	Oil Seal & Bearing Replacer	Front axle
	09223-56010	Crankshaft Rear Oil Seal Replacer	Rear axle
	09226-10010	Crankshaft Front & Rear Bearing Replacer	Front differential
	09240-00020	Wire Gauge Set	Front drive shaft
	09308-00010	Oil Seal Puller	Front differential Rear axle Rear differential
	09308-10010	Oil Seal Puller	Front differential Rear differential
	09309-37010	Transmission Bearing Replacer	Front differential Front suspension
	09316-2001 1	Transfer Bearing Replacer	Front suspension
	09316-6001 1	Transmission & Transfer Bearing Replacer	














## PREPARATION - SUSPENSION AND AXLE

	(09316-0001 1) Replacer Pipe	Rear differential
	(09316-00021) Replacer "A"	Rear differential
	(09316-00051) Replacer "D"	Rear axle Rear differential
	09330-00021 Companion Flange Holding Tool	Front differential Rear differential
	09350-20015 TOYOTA Automatic Transmission Tool Set	
	(09369-20040) Piston Spring Compressor Set	Front differential
	09502-12010 Differential Bearing Replacer	Front differential
	09504-0001 1 Differential Side Bearing Adjusting Nut Wrench	Rear differential
	09506-30012 Differential Drive Pinion Rear Bearing Cone Replacer	Front differential
	09506-35010 Differential Drive Pinion Rear Bearing Replacer	Front suspension Rear suspension
	09515-30010 Rear Wheel Bearing Replacer	Rear axle
	09521-24010 Drive Shaft Boot Clamping Tool	Front drive shaft
	09521-2501 1 Rear Axle Shaft Puller	Rear axle














	09527-1701 1	Rear Axle Shaft Bearing Remover	Front axle
	09554-22010	Differential Oil Seal Replacer	Front differential
	09556-22010	Drive Pinion Front Bearing Remover	Front differential Rear differential
	09564-3201 1	Differential Preload Adaptor	Front differential
	09570-2201 1	Differential Mounting Cushion Remover & Replacer	Front differential
	09608-32010	Steering Knuckle Oil Seal Replacer	Front differential
	09610-20012	Pitman Arm Puller	Front suspension
	09612-65014	Steering Worm Bearing Puller	Front differential
	(09612-01020)	Claw "B"	
	(09612-01050)	Hanger Pin with Nut	
	09613-26010	Steering Worm Bearing Cone Remover	Front suspension
	09628-6201 1	Ball Joint Puller	Front drive shaft Front suspension
	09631-10030	Oil Seal Remover	Front drive shaft














## PREPARATION - SUSPENSION AND AXLE

	09631-20060	Bearing Guide Nut Wrench	Front suspension
	09632-36010	Steering Vane Pump Bearing Replacer	Front suspension
	09636-20010	Upper Ball Joint Dust Cover Replacer	Front differential
	09649-17010	Steering Knuckle Tool	Front axle
	09650-1701 1	Hub Bolt Remover	Front axle Rear axle
	09710-14013	Rear Suspension Bushing Tool Set	Rear suspension
	(09710-00021)	Pipe	
	(09710-00061)	Replacer	
	09710-30021	Suspension Bushing Tool Set	
	(09710-03051)	Bushing Replacer	Front axle
	(09710-03121)	Bushing Remover Base	Front suspension
	09726-40010	Lower Control Shaft Bearing Replacer	Rear differential
	09727-00060	Arm Set "C"	Front suspension


	09727-00060 Arm Set "C"	Front suspension
	09727-30021 Coil Spring Compressor	Front suspension
	09922-10010 Variable Open Wrench	Front suspension
	09950-00020 Bearing Remover	Front suspension Front differential Rear differential
	09950-30012 Puller A Set	
	(09951-03010) Upper Plate	Front differential Rear differential
	(09953-03010) Center Bolt	Front differential Rear differential
	(09954-03010) Arm	Front differential Rear differential
	(09955-03030) Lower Plate 130	Front differential Rear differential
	(09956-03020) Adapter 18	Front differential
	(09956-03030) Adaptor 20	Rear differential
	09950-4001 1 Puller B Set	
	(09951-04010) Hanger 150	Front axle Front suspension Front differential Rear differential

## PREPARATION - SUSPENSION AND AXLE

	(09951-04020) Hanger 200	Front axle
	(09952-04010) Slide Arm	Front axle Front suspension Front differential Rear differential
	(09953-04020) Center Bolt 150	Front axle Front suspension Front differential Rear differential
	(09954-04010) Arm 25	Front axle Front suspension Front differential Rear differential
	(09955-0401 1) Claw No.1	Front differential
	(09955-04031) Claw No.3	Front axle Front suspension
	(09955-04061) Claw No.6	Front differential Rear differential
	(09957-04010) Attachment	Front axle Front suspension Front differential Rear differential
	(09958-0401 1) Holder	Front axle Front suspension Front differential Rear differential
	09950-60010 Replacer Set	
	(09951-00380) Replacer 38	Front differential
	(09951-00480) Replacer 48	Front differential Rear differential
	(09951-00540) Replacer 54	Front differential

	(09951-00550) Replacer 55	Rear differential
	(09951-00560) Replacer 56	Rear axle
	(09951-00610) Replacer 61	Rear axle
	(09951-00650) Replacer 65	Front axle Front differential
	09950-60020 Replacer Set No.2	
	(09951-00710) Replacer 71	Rear axle
	(09951-00730) Replacer 73	Rear differential
	(09951-00790) Replacer 79	Front differential
	(09951-00810) Replacer 81	Front axle
	(09951-00890) Replacer 89	Rear axle
	(09951-00910) Replacer 91	Front axle
	09950-70010 Handle Set	Front axle Front differential Rear axle Rear suspension
	(09951-07150) Handle 150	

## PREPARATION - SUSPENSION AND AXLE

	09960-10010 Variable Pin Wrench Set	Rear differential
---	-------------------------------------	-------------------