


## REPLACEMENT

### REPLACE LOWER CONTROL ARM BUSHING

- (a) Using SST and a press, remove the bushing.

SST 09710-14013 (09710-00021, 09710-00061),  
09950-70010 (09951-07150)



- (b) Using SST and a press, install the bushing.

SST 09506-35010, 09710-14013 (09710-00021)