



SERVICE HINTS

B16 (A) BODY ECU

7-GROUND : Always approx. 12 volts
(A)1-GROUND : Continuity with horn SW on

: PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page
B16	A	30	H5	28				
C14		30	H6	28				

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	24	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)