

# 2007 PRIUS ELECTRICAL WIRING DIAGRAM SYSTEM CIRCUITS

	Page
ABS .....	282
Air Conditioning .....	352
Audio System (Built-in Amplifier) .....	334
Audio System (Separate Amplifier) .....	324
Automatic Glare-Resistant EC Mirror .....	320
Automatic Light Control .....	156
Back-Up Light .....	184
Clock .....	310
Combination Meter .....	342
Cruise Control .....	262
Door Lock Control .....	202
Engine Control .....	128
EPS .....	276
Front Fog Light .....	158
Front Wiper and Washer .....	194
Garage Door Opener .....	322
Headlight .....	144
Headlight Beam Level Control .....	152
Horn .....	308
Hybrid Vehicle Immobiliser System .....	80
Ignition .....	124
Illumination .....	176
Interior Light .....	168
Key Reminder .....	188
Light Auto Turn Off System .....	160
Luggage Compartment Door Opener .....	234
Mirror Heater .....	316
Multi-Display (Built-in Amplifier) .....	334
Multi-Display (Separate Amplifier) .....	324
Multiplex Communication System (AVC-LAN Bus) .....	76
Multiplex Communication System (BEAN Bus) .....	68
Multiplex Communication System (CAN Bus) .....	72
Power Outlet .....	312
Power Source .....	64
Power Window .....	198
Push Button Start System .....	80
Radiator Fan and Condenser Fan .....	348
Rear Window Defogger .....	316
Rear Wiper and Washer .....	196
Remote Control Mirror .....	314
Seat Belt Waning .....	192
Shift Control System .....	248
Smart Key System .....	208
SRS .....	301
Stop Light .....	182
Taillight .....	176
Theft Deterrent .....	238

	Page
Tire Pressure Warning System .....	296
TOYOTA Hybrid System .....	92
TRAC .....	282
Turn Signal and Hazard Warning Light .....	164
VSC .....	282
Wireless Door Lock Control (w/ Smart Key System) .....	208
Wireless Door Lock Control (w/o Smart Key System) .....	226