

HOW TO PROCEED WITH TROUBLESHOOTING

The hand-held tester can be used at step 3, 6, 9, 12.

1 Vehicle Brought to Workshop




2 Customer Problem Analysis (SEE PAGE 05-952)




3 Check and Clear DTCs and Freeze Frame Data (SEE PAGE 05-973)



4 Problem Symptom Confirmation



Symptom does not occur: Go to step 5




Symptom occur: Go to step 6


5 Symptom Simulation (SEE PAGE 01-47)



6 DTC Check (SEE PAGE 05-973)




There is no output: Go to step 7



There is output: Go to step 8

7 Problem Symptoms Table (SEE PAGE 05-964)



Check for fluid leakage and Go to step 10

8 DTC Chart (SEE PAGE 05-985)



9 Circuit Inspection (SEE PAGE 05-989 to 05-1 135)



10 Identification of Problem



11	Repair
----	--------



12	Confirmation Test
----	-------------------



End
